


LAND CRUISER **PRADO**



TABLE OF CONTENTS



For vehicles with a navigation system, refer to the "Navigation System Owner's Manual" for information regarding the equipment listed below.

- Navigation system
- Air conditioning
- Hands-free system (for cellular phone)
- Toyota parking assist monitor

Before driving

- 1-1. Key information Keys...... 24
- 1-2. Opening, closing and locking the doors

Smart entry & start	
system	27
Wireless remote control	42
Side doors	48
Back door	52
Glass hatch	57

1-3. Adjustable components (seats, mirrors, steering wheel)

Steering Wilcel)	
Front seats	62
Rear seats	66
Driving position memory	
(driver's seat)	
Head restraints	
Seat belts	90
Steering wheel	96
Inside rear view mirror	98
Outside rear view mirrors 1	00

- Rear view monitor system
- · Rear seat entertainment system
- · Audio/video system
- Toyota parking assist-sensor
- Wide view front & side monitor

1-4.	Opening and closing the windows and moon roof	
	Power windows	103
	Moon roof	106
1-5.	Refueling	
	Opening the fuel tank	
C	Cap	111
6.	Theft deterrent system	
	Engine immobilizer	
	system	115
	Alarm	116

1-7. Safety information

Correct driving posture	118
SRS airbags	120
Child restraint systems	132
Installing child restraints	143

When driving 2

2-1. Driving procedures

Driving the vehicle	160
Engine (ignition) switch	
(vehicles without a smart	
entry & start system)	173
Engine (ignition) switch	
(vehicles with a smart	
entry & start system)	177
Automatic transmission	185
Manual Transmission	191
Turn signal lever	193
Parking brake	194
Horn	195

2-2. Instrument cluster

	1
Instrument cluster	2
Gauges and meters	
Indicators and warning lights	
Multi-information display (Non-Optitron type	
meters) 204 Multi-information display (Optitron type meters) 209	2-
Multi-information display (Accessory meters) 217	£

2-3. Operating the lights and wipers

	Headlight switch	224
	Fog light switch	230
	Windshield wipers and washer	231
	Rear window wiper and washer	
	Headlight cleaner switch 2	238
2-4.	Using other driving system	S
	Cruise control	240
	Dynamic radar cruise control	244
	Toyota parking assist-sensor	256
s'c	Rear view monitor system (vehicles with an accessory meter)	
	Wide view front & side monito (vehicles with an accessory	or
	meter)	270
	Driving assist systems 2 PCS (Pre-Crash Safety	278
	system)	284

2-5. Driving information

Cargo and luggage	291
Winter driving tips	294
Trailer towing	297

TABLE OF CONTENTS Index

3 Interior features

3-1.	Using the air conditioning
	system and defogger

Front manual air conditioning system 310
Front automatic air conditioning system 316
Rear manual air conditioning system 326
Rear automatic air conditioning system
Heater idle up switch 332
Rear window defogger switch

3-2. Using the audio system

-
Audio system types
Using the radio
Using the CD player 340
Playing MP3 and
WMA discs 349
Operating an iPod 357
Operating a USB
memory
Optimal use of the audio
system 374
Using the AUX port 377
Using the steering wheel
audio switches 379

3-3. Using the hands-free system (for mobile phone)

Hands-free system	
(for mobile phone)	382
Using the hands-free system	
(for mobile phone)	386
Making a phone call	392
Setting a mobile phone	395
Security and system	
setup	398
Using the phone book	401

3-4. Using the interior lights

Interior lights list	405
 Rersonal/interior light 	
main switch	406
Personal/interior lights	407
 Lounge illumination control 	
switches	408

3-5. Using the storage features

List of storage features	410
• Glove box	411
Card holder	412
Console box	413
 Bottle holders/door 	
pockets	415
Cup holders	416
Auxiliary boxes	420

3-6. Other interior features

Cool box	423
Sun visors	426
Vanity mirror	427
Clock	428
Outside temperature	
display	429
Ashtray	431
Conversation mirror	432
Power outlet	433
Seat heaters	437
Armrest	440
Coat hooks	441
Floor mat	442
Luggage compartment	
features	444

Ó
, e.
401
OL
7

Maintenance and care 4-1. Maintenance and care Cleaning and protecting the vehicle exterior 452 Cleaning and protecting the vehicle interior 456 4-2. Maintenance Maintenance requirements 4-3. Do-it-vourself maintenance -vourself service)0precautions 462 Hood...... 466 Engine compartment 467 Tires 485 Tire inflation pressure...... 488 Wheels 490 Air conditioning filter...... 492 Wireless remote control/ . . . C

electronic key battery	495	
Checking and replacing		
fuses	499	
Light bulbs	511	

2

3

5 When trouble arises

5-1. Essential information

Emergency flashers	526
If your vehicle needs	
to be towed	528
If you think something is	
wrong	535
Fuel pump shut off system	
(gasoline engine only)	536

5-2. Steps to take in an emergency

If a warning light turns	
on or a warning buzzer	
sounds	537
If a warning message is	
displayed	547
If you have a flat tire	567
If the engine will	
not start	586
If the shift lever cannot be	
shifted from P	588
If you lose your keys	589
If the electronic key does	
not operate properly	590
If the vehicle battery is	
discharged	594
If your vehicle overheats	599
If you run out of fuel and	
the engine stalls	
(diesel engine only)	602
If the vehicle becomes	
stuck	603
If your vehicle has to be stop	ped
in an emergency	605

6 Vehicle specifications

6-1. Specifications

Maintenance data	
(fuel, oil level, etc.)	608
Fuel information	624


6-2. Customization


Customizable features 626


Index


- Abbreviation list 638
 - Alphabetical index 639
 - What to do if 648


NotforReproduction























Pictorial index









For your information

Main Owners Manual

Please note that this manual applies to all models and all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Toyota policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustrations may differ from your vehicle in terms of equipment.

Accessories, spare parts and modification of your Toyota

A wide variety of non-genuine spare parts and accessories for Toyota vehicles are currently available in the market. Using these spare parts and accessories which are not genuine Toyota produces may adversely affect the safety of your vehicle, even though these parts may be approved by certain authorities in your county. Toyota therefore cannot accept any liability or guarantee spare parts and accessories which are not genuine Toyota products, nor for replacement or installation involving such parts.

This vehicle should not be modified with non-genuine Toyota products. Modification with non-genuine Toyota products could affect its performance, safety or durability and may even violate governmental regulations. In addition, damage or performance problems resulting from the modification may not be covered under warranty.

Installation of a mobile two-way radio system

As the installation of a mobile two-way radio system in your vehicle may affect electronic systems such as the multi-port fuel injection system/sequential multi-port fuel injection system, cruise control system, anti-lock brake system, SRS airbag system and seat belt pretensioner system, be sure to check with your Toyota dealer for precautionary measures or special instructions regarding installation.

Scrapping of your Toyota

The SRS airbag and seat belt pretensioner devices in your Toyota contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by your Toyota dealer before you scrap your vehicle.

General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give you full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.

General precaution regarding children's safety


Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, the moon roof, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

Symbols used throughout this manual

Cautions & Notices

This is a warning against something which, if ignored, may cause death or serious injury to people. You are informed about what you must or must not do in order to reduce the risk of death or serious injury to yourself and others.



ITNPM075

Indicates the outcome of an operation (e.g. a lid opens).

Before driving


1-1.	Key information	
	Keys	24
1-2.	Opening, closing and locking the doors	
	Smart entry & start system	. 27
	Wireless remote control	
	Side doors Back door	
	Glass hatch	
1-3.	Adjustable components (seats, mirrors, steering wheel) Front seats	5
	Front seats	62
	Rear seats	66
	(driver's seat)	83
	Head restraints	87
	Seat belts	90
	Steering wheel	96
	Inside rear view mirror	98
	Outside rear view mirrors	100

1-4.	I-4. Opening and closing the windows and moon roo		
	Power windows	103	
	Moon roof.	106	
1-5.	Refueling		
	Opening the fuel tank		
	сар	111	
.0			
1-6.	Theft deterrent system		
2	Engine immobilizer		
Ť	system		
	Alarm	116	
1-7.	Safety information		
	Correct driving posture	118	
	SRS airbags	120	
	Child restraint systems	132	
	Installing child		
	restraints	143	


1-1. Key information Keys

The following keys are provided with the vehicle.

Vehicles without a smart entry & start system



Using the mechanical key



To take out the mechanical key, push the release button and take the key out.

After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery depleted or the entry function does not operate properly, you will need the mechanical key. $(\rightarrow P. 590)$

When required to leave the vehicle's key to the vehicle with a parking attendant

Lock the glove box as circumstances demand. (\rightarrow P. 411)

Vehicles without a smart entry & start system

Carry the master key for your own use and provide the attendant with the valet key.

Vehicles with a smart entry & start system

Remove the mechanical key for your own use and provide the attendant with the electronic key only.

Key number plate

Keep the plate in a safe place such as your wallet, not in the vehicle. In the event that a mechanical key is lost, a new key can be made by your Toyota dealer using the key number plate. (\rightarrow P. 589)

When riding in an aircraft

When bringing a key with wireless remote control function onto an aircraft, make sure you do not press any buttons on the key while inside the aircraft cabin. If you are carrying the key in your bag etc., ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the key to emit radio waves that could interfere with the operation of the aircraft.

NOTICE

To prevent key damage

Observe the following:

- Do not drop the keys, subject them to strong shocks or bend them.
- Do not expose the keys to high temperatures for a long period of time.
- Do not get the keys wet or wash them in an ultrasonic washer etc.
- Do not attach metallic or magnetic materials to the keys or place the keys close to such materials.
- Do not disassemble the keys.
- Do not attach a sticker or anything else to the surface of the electronic key.
- Do not place the keys near objects that produce magnetic fields, such as TVs, audio systems, glass top ranges, or medical electrical equipment, such as low-frequency therapy equipment.

Carrying the electronic key on your person

Carry the electronic key 10 cm (3.9 m) or more away from electric appliances that are turned on. Radio waves emitted from electric appliances within 10 cm (3.9 in.) of the electronic key may interfere with the key, causing the key to not function properly.

In case of a smart entry & start system malfunction or other key-related problems


Take your vehicle with all the electronic keys provided with your vehicle to your Toyota dealer.

When a vehicle key is lost


If the key remains lost, the risk of vehicle theft increases significantly. Visit your Toyota dealer immediately with all remaining electronic keys that was provided with your vehicle.

1-2. Opening, closing and locking the doors Smart entry & start system^{*}


The following operations can be performed simply by carrying the electronic key on your person, for example in your pocket. (The driver should always carry the electronic key.)



*: If equipped




Unlocking and locking the doors (front door handles only)



Grip the handle to unlock the doors.

Make sure to touch the sensor on the back of the handle.


The doors cannot be unlocked for 3 seconds after the doors are locked.



Touch the lock sensor (the indentation on the upper or lower part of the door handle) to lock the doors.

Unlocking and locking the back door

Vehicles with back door mounted spare tire




- 1 Locks the all doors
- 2 Unlocks the all doors

The doors cannot be unlocked for 3 seconds after the doors are locked.



Vehicles without back door mounted spare the




1 Locks the all doors


2 Unlocks the all doors

The doors cannot be unlocked for 3 seconds after the doors are locked.

Opening the glass hatch



Effective range (areas within which the electronic key is detected)



NotforRep

When locking or unlocking the doors

The system can be operated when the electronic key is within about 0.7 m (2.3 ft.) of either of the outside front door handle.

When starting the engine or changing "ENGINE START STOP" switch modes

> The system can be operated when the electronic key is inside the vehicle.


When opening the glass hatch (if equipped) and locking or unlocking the back door.

This system can be operated when the electronic key is within about 0.7 m (2.3 ft.) of the back door handle.

Operation signals

A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: once; Unlocked: twice)

When the door cannot be locked by the lock sensor on the upper part of the door handle



Touch both lock sensors on the upper and lower part of the door handle simultaneously.



Alarms and warning indicators

A combination of exterior and interior alarms as well as warning lights and warning messages shown on the multi-information display is used to prevent theft of the vehicle and accidents resulting from erroneous operation.

• When any warning lights come on

Take appropriate measures depending on which warning light comes on. $(\rightarrow P. 543)$

 When a warning message is shown on the multi-information display Take appropriate measures in response to the warning message on the multi-information display. (→P. 557)

Alarm	Situation	Correction procedure
Interior alarm pings once and exterior alarm	An attempt was made to lock the doors using the entry function while the electronic key was still inside the passenger com- partment	Retrieve the elec- tronic key from the passenger compart- ment and lock the doors again
sounds once for 10 seconds ^{*1}	An attempt was made to exit the vehicle and lock the doors without first turn- ing the "ENGINE START STOP" switch OFF	Turn the "ENGINE START STOP" switch OFF and lock the doors again
Exterior alarm	An attempt was made to lock the vehicle while door is open	Close all of the doors and lock the doors again
sounds once for 10 seconds	An attempt was made to close the glass hatch while the electronic key was still inside the passenger com- partment	Open the glass hatch again and retrieve the electronic key from the passenger com- partment
Interior alarm pings continu ously	The "ENGINE START STOP" switch was turned to ACCESSORY mode while the driver's door was open (or the driver's door was opened while the "ENGINE START STOP" switch was in ACCES- SORY mode)	Turn the "ENGINE START STOP" switch OFF and close the driver's door

Alarm	Situation	Correction procedure
Interior alarm sounds continu- ously ^{*1}	When the "ENGINE START STOP" switch is in IGNITION ON or ACCES- SORY mode, an attempt was made to open the door and exit the vehicle, and the shift lever was not in P	Shift the shift lever to "P" and turn the "ENGINE START STOP" switch OFF
Interior and exte- rior alarms sound continuously ^{*1}	When the "ENGINE START STOP" switch is in IGNITION ON or ACCES- SORY mode, the driver's door was closed after the key was carried outside the vehicle, and the shift lever not in P	Shit he shift lever to P's turn the "ENGINE START STOP" switch OFF and close the driver's door again
	The electronic key has a low battery	Replace the electronic key battery
Interior alarm pings once ^{*1}	An attempt was made to start the engine without the electronic key being present, or the electronic key was not functioning normally	Start the engine with the electronic key present ^{*2}

Alarm	Situation	Correction procedure
Interior alarm pings once and exterior alarm sounds 3 times ^{*1}	The driver's door was closed after the key was carried outside the vehicle, and the "ENGINE START STOP" switch was not turned OFF	Turn the "ENGINE START STOP" switch OFF and close the driver's door again
	An occupant carried the electronic key outside the vehicle and closed the door while the "ENGINE START STOP" switch was not OFF	Bring the electronic key back into the vehi- cle

*1: A message will be shown on the multi-information display in the instrument cluster.

*2: If the engine does not start when the electronic key is inside the vehicle, the electronic key battery may be depleted or there may be difficulties receiving signal from the key. (PP. 591)

Security feature

If a door is not opened within approximately 30 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again.



Switching the door unlock function

It is possible to set which doors the entry function unlocks.

STEP 1 Turn the "ENGINE START STOP" switch OFF.

STEP 2 When the indicator on the key surface is turned off, press and hold

a or (if equipped) for approximately 5 seconds while press-

ing 🔒 on the key.

The setting changes each time an operation is preformed, as shown below. (When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat STEP 2.)

Multi-information display	Unlocking function	Веер
R/R	Hold the driver's door handle to unlock only the driver's door.	Exterior: Beeps three times
	Hold the front passenger's door handle for unlock all doors.	Interior: Pings once
	Hold either door handle to unlock all doors.	Exterior: Beeps twice Interior: Pings once

STEP 3 Vehicles with alarm system: Unlock the doors using the wireless remote control and open one of the doors.

If a door is not opened within 30 seconds after \therefore is pressed, the doors will be locked again and the alarm will automatically be set. In case that the alarm is triggered, immediately stop the alarm. (\rightarrow P. 116)

Battery-saving function

In the following circumstances, the entry function is disabled in order to prevent the vehicle battery from discharging and the electronic key battery from depleting.

- When the entry function has not been used for 5 days or more
- When the electronic key has been left within approximately 2 m (6 ft.) of the vehicle for 10 minutes or more
- If the entry function has not been used for 14 days or more, the vehicle cannot be unlocked by a door other than the driver's door. To unlock the vehicle, grip the driver's door handle or use the wireless remote control or the mechanical key.

The system will resume operation when:

- The vehicle is locked using the lock sensor when carrying the electronic key on your person.
- The vehicle is locked/unlocked using the vehicless remote control. $(\rightarrow P. 44)$
- The vehicle is locked/unlocked using the mechanical key. (→P. 590)

Conditions affecting operation

The smart entry & start system uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart entry & start system, wireless remote control and immobilizer system from operating properly.

(Ways of coping: \rightarrow P. 590)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone, cordless phone or other wireless communication devices
- When the electronic key is in contact with, or is covered by the following metallic objects
 - Cards to which aluminum foil is attached
 - Cigarette boxes that have aluminum full nside
 - Metallic wallets or bags
 - Coins
 - Hand warmers made of metal
 - Media such as CDs and DVDs
- When multiple electronic keys are in the vicinity
- When another wireless key (that emits radio waves) is being used nearby
- When carrying the electronic key together with the following devices that emit radio waves
 - Another vehicle's electronic key or a wireless key that emits radio waves
 - Personal computers or personal digital assistants (PDAs)
 - Digital audio players
 - Portable game systems
- If window tint with a metallic content or metallic objects are attached to the rear window

Note for the entry function

- Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases:
 - The electronic key is too close to the window or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
 - The electronic key is near the ground or in a high place, or too close to the rear bumper center when the glass hatch is opened.
 - The electronic key is on the instrument panel, luggage cover or floor, or in the glove box.
- Do not leave the electronic key on top of the instrument panel or near the door pockets when exiting the vehicle. Depending on the radio wave reception conditions, it may be detected by the antenna outside the cabin and the door will become lockable from the outside possibly trapping the electronic key inside the vehicle.
- As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone. However, only the doors detecting the electronic key can be used to unlock the vehicle.
- The doors may lock or unlock if the electronic key is within the effective range and a large amount of water splashes on the door handle, such as in the rain or in a car wast. The doors will automatically be locked after approximately 30 seconds if a door is not opened and closed.
- If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)

Note for locking the doors

- Touching the door lock sensor while wearing gloves may delay or prevent lock operation. Remove the gloves and touch the lock sensor again.
- When the lock operation is performed using the lock sensor, recognition signals will be shown up to two consecutive times. After this, no recognition signals will be given.
- If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. Place the key in a position 2 m (6 ft.) or more separate from the vehicle while the vehicle is being washed. (Take care to ensure that the key is not stolen.)
- If the electronic key is inside the vehicle and a door handle becomes wet during a car wash, a message may be shown on the multi-information display and a buzzer will sound outside the vehicle. To turn off the alarm, lock all the doors.
- The lock sensor may not work properly if thomes into contact with ice, snow, mud, etc. Clean the lock sensor and attempt to operate it again, or use the lock sensor on the lower part of the door handle.
- Fingernails may scrape against the door during operation of the door handle.

Be careful not to injure fingernails or damage the surface of the door.

Note for the unlocking function

- Gripping the door handle when wearing a glove may not unlock the door.
- A sudden approach to the effective range or door handle may prevent the doors from being unlocked. In this case, return the door handle to the original position and check that the doors unlock before pulling the door handle again.
- If there is another electronic key in the detection area, it may take slightly longer to unlock the doors after the door handle is gripped.

When the vehicle is not driven for extended periods

- To prevent theft of the vehicle, do not leave the electronic key within 2 m (6 ft.) of the vehicle.
- The smart entry & start system can be deactivated in advance. (\rightarrow P. 626)

To operate the system properly

Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off accidentally, or the door lock prevention may not function.)

If the smart entry & start system does not operate properly

- Locking and unlocking the doors: Use the mechanical key (\rightarrow P. 590) ctilo
- Starting the engine: \rightarrow P. 591

Electronic key battery depletion

- The standard battery life is 1 to 2 years.
- If the battery becomes low, an alarm will sound in the cabin when the engine stops. (\rightarrow P. 33)
- •As the electronic key always receives radio waves, the battery will become depleted even if the electronic key is not used. The following symptoms indicate that the dectronic key battery may be depleted. Replace the battery when necessary. (\rightarrow P. 495)
 - The smart entry & start system or the wireless remote control does not operate.
 - The detection area becomes smaller.
 - The LED indicator on the key surface does not turn on.
- To avoid serious deterioration, do not leave the electronic key within 1 m (3 ft.) of the following electrical appliances that produce a magnetic field:
 - TVs
 - Personal computers
 - Cellular phones, cordless phones and battery chargers
 - Recharging cellular phones or cordless phones
 - Glass top ranges
 - Table lamps

When the electronic key battery is fully depleted

→P. 495

Customization

Settings (e.g. smart entry & start system) can be changed. (Customizable features \rightarrow P. 626)

CAUTION

Caution regarding interference with electronic devices

 People with implanted pacemakers or cardiac defibrillators should maintain a reasonable distance between themselves and he smart entry & start system antennas. (→P. 32)

The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask your forota dealer for details, such as the frequency of radio waves and timing of emitting the radio waves. Then, consult your doctor to see if your should disable the entry function.

• User of any electrical medical device other than implanted pacemakers and implanted cardiac defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves.


Radio waves could have unexpected effects on the operation of such medical devices.

Ask your Toyota dealer for details on disabling the entry function.

1-2. Opening, closing and locking the doors Wireless remote control


The wireless remote control can be used to lock and unlock the vehicle.

Vehicles without a smart entry & start system (type A)



- Locks all the doors
 Closes the windows and moon roof (press and hold)*
- 3 Unlocks all the doors
- Opens the windows and moon roof (press and hold)*

Vehicles without a smart entry & start system (type B)




- Locks all the doors
 Closes the windows and
 - moon roof (press and hold)*
- 3 Unlocks all the doors
- Opens the windows and moon roof (press and hold)*
- Opens the glass hatch (press and hold)

The glass hatch can be opened only when the back door is closed.

*: This setting must be customized at your Toyota dealer.

Vehicles with a smart entry & start system



- 1 Locks all the doors
- Closes the windows and moon roof (press and hold)*
- 3 Unlocks all the doors
- Opens the windows and moon roof (press and hold)*
- Opens the glass hatch (press and hold) (vehicles with a glass hatch)

The glass hatch can be opened only when the back door is closed.

*Dis setting must be customized at your Toyota dealer.

Operation signals

Doors: A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once: Unlocked: Twice) Windows and moon roof: A buzzer sounds to indicate that the windows and moon roof are operating.

Glass hatch: A buzzer sounds once to indicate that the glass hatch have been opened.

Door lock buzzer

If an attempt to lock the doors is made when a door is not fully closed, a buzzer sounds continuously for 10 seconds. Fully close the door to stop the ducti buzzer, and lock the vehicle once more.

Security feature

 $\rightarrow P.36$

Alarm (if equipped)

Using the wireless remote control to lock the doors will set the alarm system. (→P. 116)

Conditions affecting operation

Vehicles without a smart entry & start system

The wireless remote control function may not operate normally in the following situations:

- •Near a TV tower, adio station, electric power plant, airport or other facility that generates strong radio waves
- When carrying a portable radio, cellular phone or other wireless communication device
- When multiple wireless keys are in the vicinity
- •When the wireless key is in contact with, or is covered by a metallic object
- When a wireless key (that emits radio waves) is being used nearby
- When the wireless key has been left near an electrical appliance such as a personal computer

Vehicles with a smart entry & start system

→P. 39

If the wireless remote control does not operate properly

Locking and unlocking the doors: Use the mechanical key. (\rightarrow P. 590)

Kev battery depletion

Vehicles without a smart entry & start system

If the wireless remote control function does not operate, the battery may be depleted. Replace the battery when necessary. (\rightarrow P. 495)

Vehicles with a smart entry & start system

 $\rightarrow P 42$

When the electronic key battery is fully depleted

→P. 495

Customization

Settings (e.g. wireless remote control system) can be changed. (Customizable features (Castomizable features)) rodu (Customizable features \rightarrow P. 626)

A CAUTION

When closing the windows or moon roof using wireless remote control

Observe the following precautions. Failing to do so may result in death or serious injury.

• Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window or moon roof is being operated.

To prevent inadvertent power windows and moon roof operation, never let a small child have and use the wireless remote control.

Jam protection function

• Never try jamming any part of your body to activate the jam protection function intentionally.

The jam protection function may not work if something gets caught just before the window or moon roof fully closes.

1-2. Opening, closing and locking the doors **Side doors**

The vehicle can be locked and unlocked using the entry function, wireless remote control or door lock switch.

Entry function

→P. 29


Wireless remote control

→P. 44

Key

Turning the key operates the doors as follows:


Vehicles without a smart entry & start system



- Locks all the doors
 Closes the windows and moon roof (turn and hold)*
 Unlocks all the doors
 Open the windows and moon roof (turn and hold)*
 - *: This setting must be customized at your Toyota dealer.

Vehicles with a smart entry & start system

The doors can also be locked and unlocked with the mechanical key. $(\rightarrow P. 590)$



Locking the driver's door from the outside without a key

STEP 1 Move the inside lock button to the lock position.

STEP 2 Close the door while pulling the door handle.

Vehicles without a smart entry & start system


The door cannot be locked if the key is in the engine switch.

Vehicles with a smart entry & start system

The door cannot be locked if the "ENGINE START STOP" switch is in ACCESSORY or IGNITION ON mode, or the electronic key is left inside the vehicle.

The key may not be detected correctly and the door may be locked.

Rear door child-protector lock



The door cannot be opened from inside the vehicle when the lock is set.

These locks can be set to prevent children from opening the rear doors. Push down on each rear door switch to lock both rear doors.

Using the mechanical key (vehicles with a smart entry & start system)

The doors can also be locked and unlocked with the mechanical key. $(\rightarrow P. 590)$

Customization

Settings (e.g. unlocking function using a key) can be changed. (Customizable features \rightarrow P. 626)

CAUTION

To prevent an accident

Observe the following precautions while driving the vehicle. Failing to do so may result in a door opening and an occupant falling out, resulting in death or serious injury.

- Always use a seat belt.
- Always lock all the doors.

• Ensure that all the doors are properly closed.

Do not pull the inside handle of the doors while driving.
 The doors may be opened and the passengers are thrown out of the vehicle and it may result in death or serious injury.

Be especially careful for the driver's door, as the door may be opened even if the inside look button is in locked position.

• Set the rear door child-protector locks when children are seated in the second seat.

1-2. Opening, closing and locking the doors **Back door**

The back door can be locked/unlocked and opened the following procedures.

Locking and unlocking the back door

Entry function (if equipped)

→P. 30


Wireless remote control

→P. 44

Door lock switch

→P. 49

Inside lock button (5-door models with back door mounted spare tire)




Opening the back door from outside the vehicle

Vehicles with back door mounted spare tire


1 Pull the handle

2 Open the back door


The back door can be kept open at a desired position.



Vehicles without back door mounted spare tire



Keeping the back door open



Pull the handle

2 Open the back door

The back door can be kept open at a desired position.

1 Unlocks back door stop-


per

the back door stopper

The back door stopper can only be operated when the back door is fully open.

When closing the back door, check that the back door stopper is unlocked.


Back door child-protector lock (5-door models)



The door cannot be opened from inside the vehicle when the lock is set.

This lock can be set to prevent children from opening the back door. Push down on back door switch to lock back door.

Rear step bumper



The rear step bumper is for rear end protection and easier stepup loading.

A CAUTION

While driving

- duction Keep the back door closed while driving If the back door is left open, it may hit near-by objects while driving or luggage may be unexpectedly thrown out, causing an accident. In addition, exhaust gases may other the vehicle, causing death or a serious health hazard. Make sure to close the back door before driving.
- Before driving the vehicle make sure that the back door is fully closed. If the back door is not fully closed, it may open unexpectedly while driving, causing an accident.
- Never let anyone sit in the luggage compartment. In the event of sudden braking, sudden swerving or a collision, they are susceptible to death or serious injury.

When children are in the vehicle

Observe the following precautions. Failure to do so may result in death or serious injury.

Do not leave children alone in the luggage compartment. If a child is accidentally locked in the luggage compartment, they could have heat exhaustion.

Do not allow a child to open or close the back door. Doing so may cause the back door to operate unexpectedly, or cause the child's hands, head, or neck to be caught by the closing back door.


CAUTION

Operating the back door

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in serious injury.


- When opening or closing the back door, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the back door is about to open or close.
- Use caution when opening or closing the back door in windy weather as it may move abruptly in strong wind.



- The back door may close if the back door stopper is not locked (specifically, when using the luggage compartment with the back door kept open at your desired position). It is more difficult to open or close the back door on an incline than on a level surface, so beware of the back door unexpectedly opening or closing by itself. Make sure that the back door stopper is locked and secure when using the luggage compartment.
- When closing the back door, take extra care to prevent your fingers etc. from being caught.
- When closing the back door, make sure to press it lightly on its outer surface. If the back door handle is used to fully close the back door, it may result in hands or arms being caught.

CAUTION

- Do not pull on the back door damper stay to close the back door, and do not hang on the back door damper stay.
 Doing so may cause hands to be caught or the back door damper stay to break, causing an accident.
- Do not attach any accessories other than genuine Toyota parts to the back door. Such additional weight on the back door may cause the back door to fall closed again after it is opened.




1-2. Opening, closing and locking the doors **Glass hatch**^{*}

The glass hatch can be opened using the glass hatch opener or wireless remote control.

- Entry function (vehicles with a smart entry & start system) \rightarrow P. 31
- Wireless remote control

→P. 44

Glass hatch opener



Press the button to pop up the glass that n.

2 Raise

The class hatch can be opened only when the back door is closed.

The glass hatch cannot be opened when the back door is locked. Unlock the back door to open the glass hatch. $(\rightarrow P. 52)$

Before driving

When opening the glass hatch

- Open the glass hatch slowly and carefully.
- Use the glass hatch opener when the back door is closed.
- Opening the glass hatch while the rear window wiper is in operation

Rear window wiper operation will stop moving. Operation will recommence after the glass hatch has been closed.

Function to prevent the glass hatch being locked with the electronic key inside (vehicles with a smart entry & start system)

• When all doors are being locked, closing the glass hatch with the electronic key left inside the luggage compartment will so ind an alarm. In this case, the glass hatch can be opened using the entry function.

- Even when the spare electronic key is put in the luggage compartment with all the doors locked, the key confinement prevention function can be activated so the glass hatch can be opened. In order to prevent theft, take all electronic keys with you when leaving the vehicle.
- Even when the electronic key is put in the luggage compartment with all the doors are locked, the key may not be detected depending on the places and the surrounding radio wave conditions. In this case, the key confinement prevention function cannot be activated, causing the doors to lock when the glass hatch is closed. Make sure to check where the key is before closing the glass hatch.

After closing the glass hatch

Check that the glass hatch is firmly closed. If it is not firmly closed, the rear window wiper and washer will not operate correctly.

While driving

• Keep the glass hatch closed while driving.

If the glass hatch is left open, it may hit near-by objects while driving or luggage may be unexpectedly thrown out, causing an accident.

In addition, exhaust gases may enter the vehicle, causing death or a serious health hazard. Make sure to close the glass hatch before driving.

 Before driving the vehicle, make sure that the glass hatch is fully closed. If the glass hatch is not fully closed, it may open unexpectedly while driving, causing an accident.

When children are in the vehicle

Do not allow a child to open or close the glass hat ch

Doing so may cause the glass hatch to operate unexpectedly, or cause the child's hands, head, or neck to be caught by the closing glass hatch.

Operating the glass hatch

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in serious injury.

- Remove any heavy loads, such as snow and ice, from the glass hatch before opening it. Failure to do so may cause the glass hatch fall closed again after it is opened.
- When opening or closing the glass hatch, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the glass hatch is about to open or close.

CAUTION

Operating the glass hatch

 Use caution when opening or closing the glass hatch in windy weather as it may move abruptly in strong wind.





- The glass hatch may fall if it is not opened fully. It is more difficult to open or close the glass hatch on an incline than on a level surface, so beware of the glass hatch unexpectedly opening or closing by itself. Make sure that the glass hatch is fully open and secure when using the loggage compartment.
- When closing the glass hatch, take extra care to prevent your fingers etc. from being caught.
- When closing the glass hatch, make oure to press it lightly on its outer surface.

 Do not pull on the glass batch damper stay to close the glass hatch, and do not hang on the glass hatch damper stay.

Doing so may cause hands to be caught or the glass hatch damper stay to break, causing an accident.


• Do not attach any accessories other than genuine Toyota parts to the glass hatch. Such additional weight on the glass hatch may cause the glass hatch to fall closed again after it is opened.

Glass hatch damper stays

The glass hatch is equipped with damper stays that hold the glass hatch in place.

Observe the following precautions.


Failure to do so may cause damage to the glass hatch damper stay, resulting in malfunction.



- Do not attach any foreign objects, such as stickers, plastic sheets, or adhesives to the damper stay rod.
- Do not touch the damper stay rod with gloves or other fabric items.
- Do not attach any accessories other than genuine Toyota parts to the glass hatch.
- Denot place your hand or foot on the Camper stay or apply lateral forces to it.

1-3. Adjustable components (seats, mirrors, steering wheel) Front seats

Manual seat




Power seat 1 Seat position adjustment switch 2 Seatback angle adjustment switch 3 Seat cushion (front) angle adjustment switch (driver's side only) 4 Vertical height adjustment 00 switch (driver's side only) 5 Lumber support adjustment 2 switch (driver's side only) 5 TINI 3 Mode Active head restraints When the occupant's lower back presses against the seatback during a rear-end collision, the head restraint moves slightly forward and upward to help reduce the risk of whiplash on the seat occupant.


ITN13M162

Moving a front passenger's seat for second seat access (3-door models)

Getting in the vehicle



Getting out of the vehicle



Pull the seatback angle adjustment lever and fold down the seatback. The seat will slide forward.

Move the seat to the front-most position

Depress the release pedal and fold down the seatback. The seat will slide forward.

Move the seat to the front-most position


Make sure that no passenger is seated on the front passenger seat before depressing the release pedal.

After passengers have entered/exited the vehicle

Lift up the seatback and slide the seat backward until it locks.


Active head restraints


Even small forces applied to the seatback may cause the head restraint to move. Pushing up a locked head restraint forcibly may appear the head restraint inner structure. These do not indicate problems.



Before driving

1-3. Adjustable components (seats, mirrors, steering wheel) **Rear seats**







Before driving

Moving a second seat for third seat access (5-door models with third seats)

Getting in the vehicle (left side only)



Getting out of the vehicle



Pull the seatback angle adjustment lever and fold down the seatback. The seat will slide forward.

Move the seat to the front-most position

Pull the release lever and fold down the seatback. The seat will slide forward.

Move the seat to the front-most position


Make sure that no passenger is seated on the second seat before pulling the release lever.

After passengers have entered/exited the vehicle

Lift up the seatback and slide the seat backward until it locks.

Tumbling the second seats (3-door models)

Before tumbling the second seats



Notro


ITN13M070

Æ


Lower the head restraints to the lowest position.




Use the seat belt hangers to prevent the belts from being tangled Tumbling the second seats



Pull the seatback angle lever and fold them down.




Pull the seat lock release lever on the back and swing the whole



Push the knob to unlock the seat, swing the whole seat down and swing the seatback up.

Folding down the second seatbacks (5-door models without third seats)


Before folding down the second seatbacks



Stow the center seat belt buckle with the hook-and-loop fastener and lower the head restraints to the lowest position.



Folding down second seatbacks



ITN13M115


STEP 2

Swing the bottom cushion up by guiling the lock release strap.

Push the seatback lock release button and fold them down.

To return the second seatbacks to their original positions, lift them up until they lock. Folding down the second seatbacks (5-door models with third seats)

Before folding down the second seatbacks



Lower the head restraints to the lowest position.




Folding down second seatbacks



Pull the seatback lock release lever and fold them down.

To return the second seatbacks to their original positions, lift them up until they lock.

Folding down second center seatback only (5-door models)




To return the center seatback to its original position, lift it up until it locks.

If you cannot raise the second seatback

ITN13M084


00

จ




Folding down the third seats (manual seat)


Before folding down the third seats




Folding down the third seats

From back door side





Before folding down the third seats



Returning the third seats Press and hold STEP 1 Two beeps sound and seatback and seat cushion begin to move. When operating is completed, two beeps sound again. ITN13M137 Lift the head restraints up until .iea Jck. the product STEP 2

The third power seats can be operated when

- The "ENGINE START STOP" switch is off.
- The shift lever is in P position (vehicles with an automatic transmission) or the parking brake is applied (vehicles with a manual transmission) with the "ENGINE START STOP" switch in IGNITION ON mode.

During third power seat stowing operation

Do not remove your hand from the switch until the operation stops automatically. If you remove your hand from the switch, the operation will stop and the buzzer will sound continuously. The buzzer will stop when the switch is pressed again.

Enlarging the luggage compartment (vehicles with third power seats)

The third seat can be used for sitting when it is in the position shown in [STEP 2] of the folding down the third seats. (P. 6)

This can be convenient for enlarging the luggage compartment, for instance when the luggage is against the back of the seatback.



If the warning buzzer sounds continuously (vehicles with third power seats)


If there is an abnormality in the system, the warning buzzer will sound continuously while the "ENGINE START STOP" switch is in IGNITION ON mode. In this case, perform the following operations:





For each step, wait until the seat movement stops automatically and the two beeps sound twice before removing your hand from the switch.

If the warning buzzer does not stop even after performing the above procedure correctly, perform the following operations:



CAUTION

When folding the seatbacks down

Observe the following precautions. Failure to do so may result in death or serious injury.

- Do not fold the seatbacks down while driving.
- Stop the vehicle on level ground, set the parking brake and shift the shift lever to P (automatic transmission) or 1 (manual transmission).
- Do not allow anyone to sit on a folded seatback or in the luggage compartment while driving.
- Do not allow children to enter the luggage compartment

Seat adjustment

• To reduce the risk of sliding under the lap beli during a collision, do not recline the seat more than necessary.

If the seat is too reclined, the lap belt variable past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.

Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.

• Be careful not to get hands or feet pinched between the rear console box and the rear second seat when folding down the seatback.

A CAUTION When stowing the third seats Observe the following precautions. Failure to do so may result in death or serious iniurv. • Check that there is no luggage and that there are no other people around the seat before stowing operation. • Conduct the procedure slowly and carefully (vehicles with manual third seats). Do not insert hands or feet into the moving parts of the set Do not allow children to operate the seat. Do not use the seat if only the seat cushion had een stowed (vehicles with manual third seats). After returning the seatbacks to the upright position Observe the following precautions. Failure do so may result in death or serious injury. • Make sure the seatback is secure locked by pushing it forward and rearward on the top. Check that the seat belts are not twisted or caught in the seatback. NOTICE When returning the third seat (vehicles with a luggage cover) If the luggage cover is installed in the luggage compartment, make sure you


remove it before returning the third seat. (\rightarrow P. 448) The luggage cover may be damaged by the seat.

Your preferred driving position (the position of the driver's seat and steering wheel) can be memorized and recalled with the touch of a button. It is also possible to set this function to activate automatically when the driver's door is unlocked.

Two different driving positions can be entered into memory.

Entering a position to memory

- STEP 1 Check that the shift lever is in P.
- STEP 2 Turn the "ENGINE START STOP" switch to IGNITION ON mode.
- STEP 3 Adjust the driver's seat and steering when the desired positions.




While pressing the "SET" button, or within 3 seconds after the "SET" button is pressed, press button 1 or 2 until the signal beeps.

If the selected button has already been preset, the previously recorded position will be overwritten. Before driving

Recalling the memorized position

STEP 1 Check that the shift lever is in P.

STEP 2 Turn the "ENGINE START STOP" switch to IGNITION ON mode.




Linking driving position memory with door unlock operation

Record your driving position to button 1 or 2 before performing the following:

Carry only the key to which you want to link the driving position. If 2 or more keys are in the vehicle, the driving position cannot be linked properly.

STEP 1 Turn the "ENGINE START STOP" switch IGNITION ON mode and close the driver's door.

Check that the shift lever is in P.



While pressing the desired button (1 of 2), press the driver's door lock switches (either lock or unlock) until the signal beeps.

The driving position is recalled when the driver's door is unlocked using the entry function or wireless remote control and the driver's door is opened.

Operating the driving position memory after turning the engine off

Memorized positions (except the steering wheel position) can be activated up to 180 seconds after the driver's door is opened and another 60 seconds after it is closed again, even after turning the "ENGINE START STOP" switch off.

Canceling the linked door unlock operation

- STEP 1 Turn the "ENGINE START STOP" switch IGNITION ON mode and close the driver's door.
- STEP 2 While pressing "SET" button, press driver's door lock switches (either lock or unlock) until the signal beeps.


Stopping seat position operation part-way through

-g operations:
 g operat


Seat adjustment caution

Take care during seat adjustment so that the seat does not strike the rear passenger or squeeze your body against the steering wheel.

1-3. Adjustable components (seats, mirrors, steering wheel) Head restraints



Removing the head restraints (front, second and third manual seats)




Pull the head restraint up while pressing the lock release button.

Adjusting the height of the head restraints



Make sure that the head restraints are adjusted so that the center of the head restraint is closest to the top of your ears.

Using the second center, second outer (5-door models without third seats) and third manual seat head restraints.



Always raise the head restraint one level from the stowed position when using.

Using the third power seats

Always lift the head restraints up until they lock when using.

Installing the head restraints

- STEP 1 Align the head restraint with the installation holes.
- STEP 2 Push down the head restraint to the lock position.

Head restraint precautions

Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.


- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- After adjusting the head restraints, push down on them and make sure they are locked in position.

• Do not drive with the head restraints removed.

1-3. Adjustable components (seats, mirrors, steering wheel) Seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle.

Correct use of the seat belts




Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.

Position the Lap belt as low as possible over the hips.

Adjust the position of the seaback. Sit up straight
 and well back in the seat.

4 Do not twist the seat belt.

Fastening and releasing the seat belt



- To fasten the seat belt, push the plate into the buckle until a click sound is heard.
- **2** To release the seat belt, press the release button.


Adjusting the seat belt shoulder anchor height (front and outer second [5-door models] seats)



- Push the seat belt shoulder anchor down while pressing the release button.
- 2 Push the seat belt shoulder anchor up.

Move the height adjuster up and down as needed until you hear a click.

Seat belt pretensioners (front seats)



The pretensioner helps the seat belt to quickly restrain the occupant by retracting the seat belt when the vehicle is subjected to certain types of severe frontal collision or side collision (vehicles with SRS side airbags and curtain shield airbags).

The pretensioner may not activate in the event of a minor frontal or side impact, or a rear impact.

1

Pre-crash seat belts (front seats of vehicles with pre-crash safety system)

If the pre-crash sensor detects that a collision is unavoidable, the precrash safety system will retract the seat belt, thus enhancing the effectiveness of the seat belt pretensioner in a crash.

The same will happen if the driver makes an emergency braking or loses control of the vehicle. (\rightarrow P. 284)

Emergency locking retractor (ELR)


The retractor will lock the belt during a sudden stop trop impact. It may also lock if you lean forward too quickly. A slow, easy notion will allow the belt to extend so that you can move around fully.

Automatic locking retractor (ALR) (if equipped)

When a second seat passenger's shoulder belt is completely extended and then retracted even slightly, the belt is locked in that position and cannot be extended. This feature is used to hold the child restraint system (CRS) firmly. To free the belt again, fully retract the belt and then pull the belt out once more. (\rightarrow P. 143)

Notfor

Pregnant women



Obtain medical advice and wear the seat belt in the proper way. $(\rightarrow P. 90)$

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants. Extend the shoulder belt completely over the shoulder and position the belt across the chest. Avoid belt contact over the rounding of the abdominal area.

If the seat belt is not worn properly, not only the pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking, sudden swerving of a collision.

People suffering illness

Obtain medical advice and wear the seat belt in the proper way. $(\rightarrow P. 90)$

Child seat belt usage

The seat belts of your vehicle were principally designed for persons of adult size.

- Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt. (→P. 132)
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions on P. 90 regarding seat belt usage.

Replacing the belt after the pretensioner has been activated

If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.

Seat belt regulations

If seat belt regulations exist in the country where you reside, please contact your Toyota dealer for seat belt replacement or installation.

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident. Failure to do so may cause death or serious injury.

-allure to do so may cause death of senou

Wearing a seat belt

- Ensure that all passengers wear a seat belt.
- Always wear a seat belt properly.
- Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- Toyota recommends that children be seated in the real seat and always use a seat belt and/or an appropriate child restraint system.
- To achieve a proper seating position, do not recline the seat more than necessary. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- Do not wear the shoulder belt under your arm.
- Always wear your seat belt low and soug across your hips.

Seat belt pretensioners

If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at your Toyota dealer.

CAUTION

Child restraint lock function belt precaution

Do not allow children to play with the child restraint lock function belt. If the belt becomes twisted around a child's neck, it will not be possible to pull the belt out leading to choking or other serious injuries that could result in death. If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

Seat belt damage and wear

- Do not damage the seat belts by allowing the belt, plate or buckle to be jammed in the door.
- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do not use a damaged seat belt until it is replaced. Damaged seat belt cannot protect an occupant from death or serious injury.
- Ensure that the belt and plate are locked and the belt is not twisted. If the seat belt does not function correctly mmediately contact your Toyota dealer.
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident even if there is no obvious damage.
- Do not attempt to install remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by your Toyota dealer. Inappropriate handling of the pretensioner may prevent it from operating properly, resulting to death or serious injury.


Precaution for pre-crash seat belts

Do not rely on the pre-crash safety to avoid accidents. Always pay attention to the surrounding conditions, and drive safely and responsibly.

1-3. Adjustable components (seats, mirrors, steering wheel) **Steering wheel**

The steering wheel can be adjusted to a comfortable position.

Manual adjustment




Hold the steering wheel and pull the lever down.



Adjust to the ideal position by moving the steering wheel horizontally and vertically.


After adjustment, pull the lever up to secure the steering wheel.



Power adjustment


STEP 2

Operating the switch moves the steering wheel in the following directions:



- 1 Up
- 2 Down
- 3 Away from the driver
- 4 Toward the driver

Auto tilt away (power adjustment type)



When the "ENGINE START STOP" switch is turned off, the steering wheel returns to its stowed position by moving up and away to enable easier driver entry and exit.

Turning the "ENGINE START STOP" switch to ACCESSORY or IGNITION ON mode will return the steering wheel to the original position

The power adjustment type steering wheel can be adjusted when

The "ENGINE START STOP" switch is in ACCESSORY or IGNITION ON mode*.

*: If the driver's seat belt is fastened, the steering wheel can be adjusted regardless of "ENGINE START STOP" switch mode.

Automatic adjustment of the steering position

A desired steering position can be entered to memory and recalled automatically by the driving position memory system. (\rightarrow P. 83)

Caution while driving

Do not adjust the steering wheel while driving.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.

After adjusting the steering wheel (manual adjustment type)


Make sure that the steering wheel is securely locked.

Otherwise, the steering wheel may move suddenly, possibly causing an accident, and resulting in death or serious injury.

1-3. Adjustable components (seats, mirrors, steering wheel) Inside rear view mirror

Glare from the headlights of vehicles behind can be reduced by using the following functions.


Manual anti-glare inside rear view mirror



- Normal position
- Anti-glare position

Auto anti-glare inside rear view mirror

In automatic mode, sensors are used to detect the headlights of vehicles behind and the reflected light is automatically reduced.




Turns automatic mode on/off

ction

The indicator comes on when automatic mode is turned on.


The mirror will revert to the automatic mode each time the "ENGINE START STOP" switch is turned to IGNITION ON mode.

Adjusting the height of rear view mirror



death or serious injury.


1-3. Adjustable components (seats, mirrors, steering wheel) Outside rear view mirrors



Mirror angle can be adjusted using the switch.

Folding the mirrors

Manual type



Mirror angle can be adjusted when

The "ENGINE START STOP" switch is in ACCESSORY or IGNITION ON mode.

When the mirrors are fogged up (vehicles with mirror defoggers)

Turn on the mirror defoggers to defog the mirrors. (\rightarrow P. 333)

CAUTION

When driving the vehicle

Observe the following precautions while driving. Failing to do so may result in loss of control of the vehicle and cause an accident, resulting in death or serious injury.

• Do not adjust the mirrors while driving.

- Do not drive with the mirrors folded.
- Both the driver and passenger side mirrors must be extended and properly adjusted before driving.

When a mirror is moving

To avoid personal injury and mirror malfunction, be careful not to get your hand caught by the moving mirror.

When the mirror defoggers are operating vehicles with mirror defoggers)

Do not touch the rear view mirror surfaces, as they can become very hot and burn you.

NOTICE


If ice should jam the mirror

Do not operate the control or scrape the mirror face. Use a spray de-icer to free the mirror

1-4. Opening and closing the windows and moon roof **Power windows**

The power windows can be opened and closed using the switches.

Operating the switch moves the windows as follows:




- Closing
 One-touch closing*
- 3 Opening

duc

- 4 One-touch opening*
- *: Pushing the switch in the opposite direction will stop window travel partway.

Window lock switch



Press the switch down to lock the passenger window switches.

Use this switch to prevent children from accidentally opening or closing a passenger window. Before driving

The power windows can be operated when

The "ENGINE START STOP" switch is in IGNITION ON mode.

Operating the power windows after turning the engine off

The power windows can be operated for approximately 45 seconds even after the "ENGINE START STOP" switch is turned to ACCESSORY mode or turned off. They cannot, however, be operated once either front door is opened.

Jam protection function

If an object becomes caught between the window and the window frame, window travel is stopped and the window is opened slightly.

When the power window does not close normally

If the jam protection function is operating abnormally and a window cannot be closed, perform the following operations using the power window switch on the relevant door.

- After stopping the vehicle, the window can be closed by holding the power window switch in the operouch closing position while the "ENGINE START STOP" switch is turned to IGNITION ON mode.
- If the window still cannot be closed even by carrying out the operation explained above, initialize the function by performing the following procedure.
- STEP 1 Hold the power window switch in the one-touch closing position. Continue holding the switch for a further 6 seconds after the window has closed.
- STEP 2 Hold the power window switch in the one-touch opening position. Continue holding the switch for a further 2 seconds after the window has opened completely.
- STEP 3 Hold the power window switch in the one-touch closing position once again. Continue holding the switch for a further 2 seconds after the window has closed.

If you release the switch while the window is moving, start again from the beginning. If the window continues to close but then re-open slightly even after performing the above procedure correctly, have the vehicle inspected by your Toyota dealer.

Door lock linked window operation

The power windows can be opened and closed using the wireless remote control or mechanical key if customized at your Toyota dealer. (\rightarrow P. 44, 48)

Customization

Settings (e.g. linked door lock operation) can be changed. duction (Customizable features \rightarrow P. 626)

CAUTION

Closing the windows

Observe the following precautions. Failing to do so may result in death or serious injury.

- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.
- Do not allow children to operate the power windows. Closing a power window on someone can cause serious injury, and in some instances, even death.

Jam protection function

• Never use any part of your body to intentionally activate the jam protection function.

The jam protection function may not work if something gets caught just before the window fully closes.

1-4. Opening and closing the windows and moon roof ${\rm Moon}\ {\rm roof}^*$

Use the overhead switches to open and close the moon roof and tilt it up and down.

Opening and closing • Opens the moon roof* The moon roof stops slightly before the fully open position to reduce wind noise. Press the switch again to fully 1 open the moon roof. 2 2 Closes the moon roof* ITN14M008 *:Lightly press either of the moon roof switches to stop the moon roof partway. Tilting up and down Tilts the moon roof up* 2 Tilts the moon roof down* *: Lightly press either of the moon roof switches to stop the moon roof partway. TN14M010

The moon roof can be operated when

The "ENGINE START STOP" switch is in IGNITION ON mode.

Operating the moon roof after turning the engine off

The moon roof can be operated for approximately 45 seconds after the "ENGINE START STOP" switch is turned to ACCESSORY mode or turned off. It cannot, however, be operated once either front door is opened.

Jam protection function

If an object is detected between the moon roof and the frame while the moon roof is closing or tilting down, travel is stopped and the moon roof opens slightly.

Sunshade

The sunshade can be opened and closed manually. However, the sunshade will open automatically when the moon roof is opened.

Door lock linked moon roof operation.

The moon roof can be opened and closed using the wireless remote control or mechanical key if customized at your Toyota dealer. (\rightarrow P. 44, 48)

Moon roof open reminder function

An alarm will sound when the driver's door is opened with the moon roof not fully closed and the "ENGINE START STOP" switch off.



When the moon roof does not close normally

Perform the following procedure:

- If the moon roof closes but then re-opens slightly
- STEP 1 Stop the vehicle.

	^	
STEP 2 Press and hold " \lor " on the	ය	. ^ I
	\sim	

The moon roof will close, re-open and pause for approximately 10 seconds.^{*2} Then it will close again, tilt up and pause for approximately 1 second. Finally, it will tilt down, open and close.

STEP 3 Check to make sure that the moon roof is completely closed and then release the switch.

If the moon roof tilts down but then tilts back up

- STEP 1 Stop the vehicle.
- STEP 2 Press and hold "∧" on the state and the tilt up position and tops.
- STEP 3 Release " \land " on the \bigcirc once and then press and hold " \land " on the \bigcirc again.*1

The moon roof will pause for approximately 10 seconds in the tilt up position. *2 Then it will adjust slightly and pause for approximately 1 second.

Finally, it will tilt down, open and close.

- STEP 4 Check to make sure that the moon roof is completely closed and then release the switch.
 - *1: If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.
 - *²: If the switch is released after the above mentioned 10 second pause, automatic operation will be disabled. In that case, press


and hold "v" on the

will tilt up and pause for approximately 1 second. Then it will tilt down, open and close. Check to make sure that the moon roof is completely closed and then release the switch.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by your loyota dealer.

Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable features →P. 626)




Perform the following steps to open the fuel tank cap.


Before refueling the vehicle

Turn the "ENGINE START STOP" switch off and ensure that all the doors and windows are closed.

Opening the fuel tank cap



Closing the fuel tank cap



After refueling, turn the fuel tank cap until you hear a click. Once the cap is released, it will turn slightly in the opposite direction.

Fuel types

Use of ethanol blended gasoline in a gasoline engine

 1GR-FE engine

 Unleaded gasoline, Research octane number 95 or higher

 1KD-FTV engine

 Diesel fuel, Cetane number 48 or higher

 Use of ethanol blended gasoline

 Toyota allows the use of ethanol blended gasoline where the ethanol content is up to 10 %. Make sure that the ethanol blended gasoline to be used has a Research octane number that follows the above.

Fuel tank capacity

Vehicles without sub fuel tank system Approximately 87 L (23.0 gal., 19.1 Imp.gal.)

Vehicles with sub fuel tank system Approximately 150 L (39.6 gal., 33.0 Imp.gal)

When refueling the vehicle

Observe the following precautions while refueling the vehicle. Failure to do so may result in death or serious injury.

- After exiting the vehicle and before opening the fuel door, touch an unpainted metal surface to discharge any static electricity. It is important to discharge static electricity before refueling because sparks resulting from static electricity can cause fuel vapors to ignite while refueling.
- Always hold the grips on the fuel tank cap and turn it slowly to remove it.
 A whooshing sound may be heard when the fuel tank cap is loosened.
 Wait until the sound cannot be heard before fully removing the cap. In hot weather, pressurized fuel may spray out of the filler peck and cause injury.
- Do not allow anyone that has not discharged static electricity from their body to come close to an open fuel tank.
- Do not inhale vaporized fuel. Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle.
 Doing so may cause the fuel to ignite and cause a fire.
- Do not return to the vehicle or touch any person or object that is statically charged.

This may cause static electricity to build up, resulting in a possible ignition hazard.

1

A CAUTION

When refueling

Securely insert the fuel nozzle into the fuel filler neck. If fuel is added with the nozzle slightly lifted away from the fuel filler neck, the automatic shut off function may not operate, resulting in fuel overflowing from the tank.

When replacing the fuel cap

Do not use anything but a genuine Toyota fuel tank cap designed for your vehicle. Doing so may cause a fire or other incident which may result in .ilc. death or serious injury.

NOTICE

Refueling

Do not spill fuel during refueling.


Doing so may damage the vehicle, such as causing the emission control systems to operate abnormally or damaging fuel system components or the vehicle's painted surface **\$** vehicle's painted surface. Notfor

114

1-6. Theft deterrent system **Engine immobilizer system**

The vehicle's keys have built-in transponder chips that prevent the engine from starting if a key has not been previously registered in the vehicle's on-board computer.

Never leave the keys inside the vehicle when you leave the vehicle.



The indicator light flashes after the "ENGINE START STOP" switch has been turned off to indicate that the system is operating.

The indicator light stops flashing after the ENGINE START System maintenance The vehicle has a maintenance Condition STOP^{*} switch has been turned to ACCESSORY or IGNITION mode to indicate that the

- If the key is in contact with a metallic object
- If the key is in close proximity to or touching a key to the security system (key with a built-in transponder chip) of another vehicle

NOTICE

To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.


The system sounds the alarm and flashes lights when forcible entry is detected.

Triggering of the alarm

The alarm is triggered in the following situations when the alarm is set:

- A locked door or glass hatch is unlocked or opened in any way other than using the entry function or the wireless remote control. (The doors will lock again automatically.)_
- The hood is opened.

Setting the alarm system



Close the doors, glass hatch and bood, and lock all the doors using the entry function or wireless remote control. The system will be set automatically after 30 seconds.

The indicator light changes from being on to flashing when the system is set.

Deactivating or stopping the alarm

Do one of the following to deactivate or stop the alarm.

- Unlock the doors using the entry function or the wireless remote control.
- Start the engine. (The alarm will be deactivated or stopped after a few seconds.)

System maintenance

The vehicle has a maintenance-free type alarm system.

Items to check before locking the vehicle

To prevent unexpected triggering of the alarm and vehicle theft, make sure of the following.

- Nobody is in the vehicle.
- The windows and moon roof are closed before the alarm is set.
- No valuables or other personal items are left in the vehicle.

Triggering of the alarm

The alarm may be triggered in the following situations. (Stopping the alarm deactivates the alarm system)

- The doors are unlocked using the mechanical key
- A person inside the vehicle opens a door or hood.
- The battery is recharged or replaced when the vehicle is locked.

Alarm-operated door lock

- When the alarm is operating, the doors are locked automatically to prevent intruders.
- Do not leave the key inside the vehicle when the alarm is operating, and make sure the key is not inside the vehicle when recharging or replacing the battery.


🔨 NOTICE

To ensure the system operates correctly


Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

1-7. Safety information Correct driving posture


Drive with a good posture as follows:



- **1** Sit upright and well back in the seat. (\rightarrow P. 62)
- 2 Adjust the position of the seat forward or backward to ensure the pedals can be reached and easilv depressed to the extent required. (\rightarrow P.62)
- 3 Adjust the seatback so that the controls are easily operable.
- 4 Adjust the tilt and telescopic positions of the steering wheel downward so the airbag is facing your chest. (→P. 96)
- **5** Lock the head restraint in place with the center of the head restraint closest to the top of your ears. (\rightarrow P. 87)
- NotForRer 6 Wear the seat belt correctly. (→P. 90)



The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.




SRS side and curtain shield airbags

SRS side airbags (if equipped)
 Can help protect the torso of the front seat occupants

SRS curtain shield airbags (if equipped)
 Can help protect primarily the head of occupants in the outer seats



Airbag system components



The main SRS airbag system components are shown above. The SRS airbag system is controlled by the airbag sensor assembly. The airbag sensor assembly consists of a safing sensor and a main sensor.

In certain types of severe frontal or side impacts, the SRS airbag system triggers the airbag inflators. A chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.

If the SRS airbags deploy (inflate)

- Bruising and slight abrasions may result from contact with a deploying (inflating) SRS airbag.
- A loud noise and white powder will be emitted.

Vehicles with SRS curtain shield airbags

Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the front seats, second seats, and parts of the front, center and rear pillars and roof side rail, may be hot for several minutes. The airbag itself may also be hot.

Vehicles without SRS curtain shield airbags

Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the front seats may be hot for several minutes. The airbag itself may also be hot.

The windshield may crack.

SRS airbag deployment conditions (SRS ront airbags)

• The SRS front airbag will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to an approximately 20 - 30 km/h [12 - 18 mph] frontal collision with a fixed wall that does not move or deform).

However, this threshold velocity will be considerably higher if the vehicle strikes an object, such as a parked vehicle or sign pole, which can move or deform on impact or if the vehicle is involved in an underride collision (e.g. a collision in which the front of the vehicle "underrides", or goes under, the bed of a truck, etc.).


It is possible that in some collisions where the forward deceleration of the vehicle is very close to the designed threshold level, the SRS front airbags and the seat belt pretensioners may not activate together.

SRS airbag deployment conditions (SRS side airbags and curtain shield airbags)

The SRS side and curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by an approximately 1500 kg [3307 lb.] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at an approximate speed of 20 - 30 km/h [12 -18 mph]).

Conditions under which the SRS airbags may deploy (inflate), other than a collision

The SRS front airbags may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.




Hitting a curb, edge of pavement or hard surface

Falling into or jumping over a deep holeLanding hard or falling

Types of collisions that may not deploy the SRS airbags (SRS front airbags)


The SRS front airbags are generally not designed to inflate if the vehicle is involved in a side drivear collision, if it rolls over, or if it is involved in a lowspeed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags may occur.



- Collision from the side
- Collision from the rear
- Vehicle rollover

Types of collisions that may not deploy the SRS airbags (SRS side airbags and curtain shield airbags)


The SRS side airbag and curtain shield airbag system may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.



- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle



The SRS side airbags and curtain shield airbags are not generally designed to inflate if the vehicle is involved in a frontal or rear collision, if it rolls over, or if it is involved in a low-speed side collision.




Collision from the front Collision from the rear Vehicle rollover


When to contact your Toyota dealer


In the following cases, contact your Toyota dealer, as soon as possible.


• Any of the SRS airbags have been inflated.



• The front of the vehicle is damaged or deformed, or was involved in an accident that was not severe enough to cause the SRS airbags to inflate.







- A portion of a door is damaged or deformed, or the vehicle was involved in an accident that was not severe enough to cause the SRS side airbags and curtain shield airbags to inflate.
- Vehicles without an SRS knee airbag The pad section of the steering wheel or dashboard near the front passenger airbag is scratched, cacked, or otherwise damaged.

Vehicles with an SRS knee airbag

The pad section of the steering wheel, dashboard near the front passenger airbag cover or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.

- the surface of the seats with the side airbag is scratched, cracked or otherwise damaged.
- The portion of the front pillars, center pillars, rear pillars or roof side rail garnishes (padding) containing the curtain shield airbags inside is scratched, cracked or otherwise damaged.

SRS airbag precautions

Observe the following precautions regarding the SRS airbags. Failure to do so may cause death or serious injury.

• The driver and all passengers in the vehicle must wear their seat belts properly.

The SRS airbags are supplemental devices to be used with the seat belts.

• The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag.

Since the risk zone for the driver's airbag is the first 50, 75 mm (2 - 3 in.) of inflation, placing yourself 250 mm (10 in.) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 250 mm (10 in.) away now, you can change your driving position in several ways:


- Move your seat to the rear as far as you can while still reaching the pedals comfortably.
- Slightly recline the back of the seat. Although vehicle designs vary, many drivers can achieve the 250 mm (10 in.) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm, non-slippery cushion, or raise the seat if your vehicle has that feature.
- If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended above, while still maintaining control of the foot pedals, steering wheel, and your view of the instrument panel controls.

CAUTION

SRS airbag precautions

- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Toyota strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are safer for infants and children than the front passenger seat. (→P. 132)




CAUTION

SRS airbag precautions









Vehicles without SRS curtain shield airbags

Do not lean against the front door.

Vehicles with SRS curtain shield airbags

Do not lean against the door, the roof side rail or the front, center and rear pillars.

• Do not allow anyone to kneel on the passenger seats toward the door or put their head or hands outside the vehicle.


< C'

Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad and lower portion of the instrument panel.

These items can become projectiles when the SRS driver, front passenger and knee airbags deploy.

 Do not attach anything to areas such as the door, windshield glass, side door glass, front, center or rear pillars, roof side rail and assist grip.

SRS airbag precautions



Vehicles without a smart entry & start system


Do not attach any heavy, sharp or hard objects such as keys or accessories to the key. The objects may restrict the SRS knee airbag inflation or be thrust into the driver's seat area by the force of the deploying airbag, hus causing a danger.

- Do not hang coat hangers or other hard objects on the coat hooks. All of these items could become projectiles and may cause death or serious injury, should the SRS curtain shield airbag deploy.
- If the vinyl cover is put on the area where he SRS knee airbag will deploy, be sure to remove it.
- Do not use seat accessories which over the parts where the SRS side airbags inflate as they may interfere with inflation of the airbags. Such accessories may prevent the side airbags from activating correctly, disable the system or cause the side airbags to inflate accidentally, resulting in death or serious injury.

 Do not strike or apply significant levels of force to the area of the SRS airbag components

Doing so can cause the SRS airbags to malfunction.

- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.
- If breathing becomes difficult after the SRS airbags have deployed, open a door or window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.
- If the areas where the SRS airbags are stored, such as the steering wheel pad and front, center and rear pillar garnishes, are damaged or cracked, have them replaced by your Toyota dealer.



1

Toyota strongly urges the use of child restraint systems.

Points to remember

Studies have shown that installing a child restraint on a rear seat is much safer than installing one to the front passenger seat.

- Choose a child restraint system that suits your vehicle and is appropriate to the age and size of the child.
- For installation details, follow the instructions provided with the child restraint system.

General installation instructions are provided in this manual. $(\rightarrow P. 143)$

- If child restraint system regulations exist in the country where you reside, please contact your Toyota dealer for the child restraint system installation.
- Toyota recommends that you use a child restraint system which conforms to the regulation ECE No.44.

Types of child restraints

Child restraint systems are classified into the following 5 groups according to the regulation ECE No.44.

Group 0: Up to 10 kg (22 lb.) (0 - 9 months)

Group 0⁺: Up to 13 kg (28 lb.) (0 - 2 years)

Group I: 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)


Group II: 15 to 25 kg (34 to 55 lb.) (4 years - 7 years)

Group III: 22 to 36 kg (49 to 79 lb.) (6 years - 12 years)

In this owner's manual, the following 3 types of popular child restraint systems that can be secured with the seat belts are explained:

Before driving

Baby seat (infant seat)



Child restraint system suitability for various seating positions

Information provided in the table shows your child restraint system suitability for various seating positions.

3-door models

Seating	Front passenger seat					
position	Standard	Airbag manual on-off switch		Second seat		
Mass groups		ON	OFF	Outside	Center	
0 Up to 10 kg (22 lb.) (0 - 9 months)	X Never put	X Never put			U	
0 ⁺ Up to 13 kg (28 lb.) (0 - 2 years)	X Never put	X Never	U	U	U	
I 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)	Rear- facino X Never put Forward- facing — UF*	Rear- facing — X Never put Forward- facing — UF*	U	U	U	
II, III 15 to 36 kg (34 to 79 lb.) (4 - 12 years)	UF*	UF*	U	U	U	

Key of letters inserted in the above table:


- U: Suitable for "universal" category child restraint system approved for the use in this mass group.
- UF: Suitable for forward-facing "universal" category child restraint system approved for the use in this mass group.
- X: Not suitable seat position for children in this mass group.

NOTE:

*: Move the seatback to the most upright position.

The child restraint system mentioned in the table may not be available outside of the EU area.

Other child restraint system which is different from the system mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer concerned and the seller of those sears.



5-door models

Seating						Third seat (if equipp	
position	Stan- dard		Second seat				
Mass groups	uaru	ON	OFF	Outside	Center	ed)	
0 Up to 10 kg (22 lb.) (0 - 9 months)	X Never put	X Never put	U	U	L1	L1	
0 ⁺ Up to 13 kg (28 lb.) (0 - 2 years)	X Never put	X Never put	U	Jeri	L1	L1	
I 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)	Rear- facing — X Never put For- ward- facing - UF ^{*1}	Rear- facing — X Never For- ward- facing — UF ^{*1}	P	U	L2*2	L2 ^{*3}	
II, III 15 to 36 kg (34 to 79 lb.) (4 - 12 years)	UF ^{*1}	UF ^{*1}	U	U	L3 ^{*2}	L3 ^{*4}	

Key of letters inserted in the above table:

- U: Suitable for "universal" category child restraint system approved for the use in this mass group.
- UF: Suitable for forward-facing "universal" category child restraint system approved for the use in this mass group.
- L1: Suitable for "TOYOTA BABY SAFE (0 to 13 kg [0 to 28 lb.])" approved for the use in this mass group
- L2: Suitable for "TOYOTA DUO+ (without ISOFIX, 9 to 18 kg [20 to 39 lb.])" approved for the use in this mass group
- L3: Suitable for "TOYOTA KID (15 to 36 kg [34 to 73.b.])" approved for the use in this mass group
- X: Not suitable seat position for children in this mass group.

NOTE:

- *1: When you use a child restraint system in this position, move the seatback to the most upright position.
- *²: When you use a child restraint system in this position, move the head restraint to the lowest position.
- *3: When you use a chirclestraint system in this position, move the head restraint to the upmost position. (vehicles with third manual seats)
- *4: When you use a child restraint system in this position, remove the head restraint. (vehicles with third manual seats)

The child restraint system mentioned in the table may not be available outside of the EU area.

Other child restraint system which is different from the system mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer concerned and the seller of those seats.

Child restraint system suitability for various seating positions (with ISOFIX rigid anchors)

Information provided in the table shows your child restraint system suitability for various seating positions.

Mass groups			Vehicle ISOFIX positions	
	Size class	Fixture	Second seat	
			Outside	
Carrycot	F	ISO/L1	O x	
	G	ISO/L2	Х	
		X	Х	
0	E	150/R1	Х	
Up to 10 kg (22 lb.) (0 - 9 months)		(1)	Х	
0 ⁺ Up to 13 kg (28 lb.) (0 - 2 years)	₽-	ISO/R1	Х	
	D	ISO/R2	Х	
	С	ISO/R3	Х	
	•	(1)	Х	
40	D	ISO/R2	Х	
	С	ISO/R3	Х	
9 to 18 kg	В	ISO/F2	IUF	
(20 to 39 lb.) (9 months - 4 years)	B1	ISO/F2X	IUF	
	А	ISO/F3	IUF	
		(1)	Х	
II, III 15 to 36 kg (34 to 79 lb.) (4 - 12 years)		(1)	х	

(1) For the child restraint system which do not carry the ISO/XX size class identification (A to G), for the applicable mass group, the car manufacturer shall indicate the vehicle specific ISOFIX child restraint system(s) recommended for each position

Key of letters inserted in the above table:

- IUF: Suitable for ISOFIX forward-facing child restraint systems of universal category approved for use in this mass group
- X٠ ISOFIX position not suitable for ISOFIX child restraint systems in this mass group and/or this size class.

The child restraint system mentioned in the table may not be available outside of the EU area.

Other child restraint systems different from the systems mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer and retailer.

NotforReq

When installing a child restraint system on the front passenger seat or second seat (5-door models with third seats)



When you have to use a child restraint system, adjust the seat cushion to the fully rearward.

Selecting an appropriate child restraint system

- Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.
- If the child is too large for a child restraint system, sit the child on a rear seat and use the vehicle's seat belt. (→P. 90)



Using a child restraint system

The use of a child restraint system not suitable for the vehicle may not properly secure the infant or child. It may result in death or serious injury (in the event of sudden braking, sudden swerving or an accident).

Child restraint precautions

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system depending on the age and size of the child. Holding a child in your arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield, or between you and the vehicle's interior.
- Toyota strongly urges the use of a proper child estraint system that conforms to the size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.
- Never install a rear-facing child restraint system on the front passenger seat. In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child.
- A forward-facing child restraint system may be installed on the front passenger seat only when its unavoidable. Always move the seat as far back as possible, because the front passenger airbag could inflate with considerable speed and force. Otherwise, the child may be killed or seriously injured.

CAUTION

Child restraint precautions

- Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front, center and rear pillars or roof side rail from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the SRS side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.
- Make sure you have complied with all installation instructions provided by the child restraint manufacturer and that the system is properly secured. If it is not secured properly, it may cause death or serie injury to the child in the event of a sudden stop, sudden swerve or at accident.

Child restraint lock function belt precaution

Do not allow children to play with the child restraint lock function belt. If the belt becomes twisted around a child's neck, it will not be possible to pull the belt out leading to choking or other serious injuries that could result in death. If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.


When the child restraint system is not in use

- Keep the child restraint system properly secured on the seat even if it is not in use. Do not store the child restraint system unsecured in the passenger compartment.
- If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the luggage compartment. This will prevent it from injuring passengers in the event of a sudden stop, sudden swerve or an accident.

1-7. Safety information Installing child restraints

Follow the child restraint system manufacturer's instructions. Firmly secure child restraints to the seats using a seat belt or ISOFIX rigid anchors. Attach the top strap when installing a child restraint.





TIN17M053

Seat belts equipped with a child restraint locking mechanism (ALR/ELR belts on the second seats)

ISOFIX rigid anchors (ISOFIX child restraint system)

Lower anchors are provided for the outer second seats. (Tags displaying the location of the anchors are attached to the seats.)


Child restraint anchor fitting

An anchor fitting is provided for each second seat.

Before driving

Installing child restraints using a seat belt (child restraint lock function belt)

- Rear-facing Baby seat (infant seat)/child seat (convertible seat)
- 3-door models




- 5-door models
- STEP 1


- 1 1st lock position
- 2 5th lock position

Fold the seatback forward and then back to the 1st lock position (most upright position) until it locks into place. Adjust the seatback to the 5th lock position.

Fold the seatback forward. Then return the seatback and secure it at the first lock position (most upright position). (\rightarrow P. 66)



Place the child restraint system on the second seat facing the rear of the vehicle.



ITN17M094

STEP 4


STEP 5

Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.

Fully extend the shoulder belt and allow it to retract to put it in lock mode, the belt cannot be extended.

While pushing the child restraint system down into the second seats, allow the shoulder belt to retract until the child restraint system is securely in place.

> After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.




Latch the hook of the top strap onto the anchor bracket. $(\rightarrow P. 152)$

Make sure the seat belt is tightly secured, and that there is no slack in the belt.

■ Forward-facing — Child seat (convertible seat)

3-door models







Fito the seatback forward and then back to the 1st lock position (most upright position) until it locks into place. Adjust the seatback to the 5th lock position.

Fold the seatback forward. Then return the seatback and secure it at the first lock position (most upright position). (\rightarrow P. 66)

Before driving



STEP 6



While pushing the child restraint system down into the second seats, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.

Latch the hook of the top strap onto the ancher bracket. (→P. 152)

Make sure the seat belt is tightly secured, and that there is no slack in the belt.

Junior seat (booster seat) 40⁴ 3-door models STEP 1 1 0000 TN17M155


1 1st lock position

2 5th lock position

Fold the seatback forward and then back to the 1st lock position (most upright position) until it locks into place. Adjust the seatback to the 5th lock position.

5-door models

STEP 2



Fold the seatback forward. Then return the seatback and secure it at the first lock position (most upright position).


Place the child testraint system on the seat facing the front of the vehicle.



Sit the child in the child restraint system. Fit the seat belt to the child restraint system according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.

Check that the shoulder belt is correctly positioned over the child's shoulder, and that the lap belt is as low as possible. $(\rightarrow P. 90)$


Removing a child restraint installed with a seat belt



Push the buckle release button and fully retract the seat belt.

Installation with ISOFIX rigid anchors (ISOFIX child restraint system)


3-door models



1 1st lock position 2 5th lock position

Fold the seatback forward and then back to the 1st lock position (most upright position) until it locks into place. Adjust the seatback to the 5th lock position.

5-door models



Fold the seatback forward. Then return the seatback and secure it at the first lock position (most upright position).




Flip the cover (3-door models and 5-door models with third seats), and latch the buckles onto the anchors.

strap, the top strap should be latched onto the anchors.

Child restraint systems with a top strap

STEP 1 Secure the child restraint using a seat belt or ISOFIX rigid anchors, and do the following.



STEP 2 Front of vehicle 3 TIN17M077

Move the head restraint in place at the upmost position.



Attaching clip
 Hoper anchor strap
 Anchor fitting

Open the anchor bracket cover, latch the hook onto the anchor bracket and tighten the top strap.

Make sure the top strap is securely latched.

When installing a child restraint system in the seat with ELR belt $(\rightarrow P. 143)$

You need a locking clip to install the child restraint system. Follow the instructions provided by the manufacturer of the system. If your child restraint system does not provide a locking clip, you can purchase the following item from your Toyota dealer:

Locking clip for child restraint system (Part No. 73119-22010)

When installing a junior (booster) seat

To prevent the belt from going into ALR lock mode, do not fully extend the shoulder belt. ALR mode causes the belt to tighten only. This could cause injury or discomfort to the child. (\rightarrow P. 92)

When installing a child restraint system

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If the child restraint system is not correctly fixed in place, the child or other passengers may be seriously injured or even killed in the event of sudden braking, sudden swerving or an accident.





- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the left-hand second seat.
 - Adjust the front passenger seat so that it does not interfere with the child restraint system.
- Child restraint system installed on the third seat should not contact the second seatbacks.
- Only put a forward facing child restraint system on the front seat when unavoidable. When installing a forward-facing child restraint system on the front passenger seat, move the seat as far back as possible.

Failing to do so may result in death or serious injury if the airbags deploy (inflate).



When installing a child restraint system





• Extreme Hazard! Do not use a rearward facing child restraint on a seat protected by an airbag in front of it! This is because the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child.

There is a sticker of the passenger side of the instrument panel and a label on the driver side sun visor, indicating it is forbidden to attach a rearward facing child restrain to the front passenger seat.

Details of the label on the driver side sup visor are shown in the illustration

A WARNING	AVERTISSEMENT WARNUNG AVVISO ADVERTENCIA WAARSCHUWING
	GDO NOT place a rear facing child seat on the front seat unless the passenger
	Bairbag is deactivated. DEATH OR SERIOUS INJURY can occur. See owner's manual.
	NE JAMAIS placer un siège enfant positionné dos à la route sur le siège avant,
	F saut si l'airbag passager est désactivé. Risque de MORT OU BLESSURE GRAVE.
	Voir de manuel du propriétaire.
	KEINEN rückwärtsgerichteten Kindersitz auf dem Vordersitz verwenden, außer der
	Beitahrer-Airbag ist deaktiviert. TOD ODER SCHWERE VERLETZUNGEN können
	die Folge sein. Siehe Betriebsanleitung.
	NON posizionare il seggiolino per bambini rivolto in senso opposto a quello di marcia
	I sul sedile anteriore se l'airbag del passeggero non e'stato disattivato. Rischio di
	MORTE O LESIONI GRAVI. Consultare il manuale di uso e manutenzione.
	NO coloque una silla para niños en sentido contrario al de la marcha del vehiculo
	e en el asiento del acompañante, excepto si el airbag del pasajero estuviera desactivado
	Riesgo de MUERTE O HERIDAS GRAVES. Consulte el manual del propietario.
	GEEN tegen de rijrichting in geplaatst kinderzitje op de voorstoel plaatsen,
	tenzij de passagiersairbag gedeactiveerd is. DOOD OF ZWARE VERWONDINGEN
	Skunnen het gevolg zijn. Zie instruktieboekje

When installing a child restraint system

- If child restraint system regulations exist in the country where you reside, please contact your Toyota dealer for the child restraint system installation.
- When installing a child restraint system on the second center seat, adjust both seat cushions to the same position (vehicles with third manual/power seats) and align both seatbacks at the same angle. The seatbacks must be adjusted to the same angle. Otherwise, the child restraint system cannot be securely restrained and this may cause death or serious injuries in a collision.
- When a junior (booster) seat is installed, always ensure that the shoulder belt is positioned across the center of the child's choulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder. Failing to do so may result in death or serious injury in the event of sudden braking, sudden swerving or an accident.
- Ensure that the belt and plate are securely locked and the seat belt is not twisted.
- Push and pull the child restraint system from side to side and forward to be sure it is secure.
- After securing a child restraint system, never adjust the seat.
- Follow all installation instructions provided by the child restraint system manufacturer.

CAUTION

To correctly attach a child restraint system to the anchors

• When using the lower anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint system. Make sure the child restraint system is securely attached, or it may cause death or serious injury to the child or other passengers in the event of sudden braking, sudden swerving or an accident.



• When using the right side lower anchors for the child restraint system, do not sit in the center seat.

Seat belt function may be impaired, such as being positioned overly high or loose-fitting, which may result in death or serious injury in the event of sudden braking, sudden swerving or an accident.

Using child restraint anchorages

WARNING: child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seatbelts, harnesses, or for attaching other items or equipment to the vehicle.

NotforReproduction

2-1. Driving procedures

Driving the vehicle	160
Engine (ignition) switch	
Engine (ignition) switch	
(vehicles with a smart	
Horn	195
	(vehicles wit out a smart entry & stan system) Engine (conition) switch

When driving

2

2-2. Instrument cluster

Gauges and meters	196
Indicators and warning lights	200
Multi-information display	
(Non-Optitron type meters)	204
Multi-information display (Optitron type meters)	209
Multi-information display	
(Accessory meters)	217
Operating the lights and	

2-3. Operating the lights and winers

Headlight switch	224
Fog light switch	230
Windshield wipers and	
washer	231
Rear window wiper and	
washer	236
Headlight cleaner switch	238

2-5. Driving information

Cargo and luggage	291
Winter driving tips	294
Trailer towing	297

For details of equipment related to off-road driving, such as the four-wheel drive system, refer to the "Off-road Driving Owner's Manual".

The following procedures should be observed to ensure safe driving:

Starting the engine

→P. 177

Driving

Automatic transmission

STEP 1 With the brake pedal depressed, shift the shift lever to D. $(\rightarrow P. 185)$

STEP 2 Release the parking brake. (\rightarrow P. 194)

STEP 3 Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

Manual transmission

- STEP 1 While depressing the clutch pedal, shift the shift lever to 1. $(\rightarrow P. 191)$
- STEP 2 Release the parking brake. (\rightarrow P. 194)
- STEP 3 Gradually release the clutch pedal. At the same time, gently depress the accelerator pedal to accelerate the vehicle.

Stopping

Automatic transmission

- STEP 1 With the shift lever in D, depress the brake pedal.
- STEP 2 If necessary, set the parking brake.

If the vehicle is to be stopped for an extended period of time, shift the shift lever to P or N. (\rightarrow P. 185)

Manual transmission

STEP 1 While depressing the clutch pedal, depress the brake pedal.

STEP 2 If necessary, set the parking brake.

If the vehicle is to be stopped for an extended period of time, shift the shift lever to N. (\rightarrow P. 191)

Parking the vehicle

Automatic transmission

STEP 1 With the shift lever in D, depress the brake pedal.

STEP 2 Set the parking brake. (\rightarrow P. 194)

- STEP 3 Shift the shift lever to P. $(\rightarrow P. 185)$ If parking on a hill, block the wheels as needed.
- STEP 4 Press the "ENGINE START STOP" switch to stop the engine.
- STEP 5 Lock the door, making sure that you have the key on your person.

Manual transmission

- STEP 1 While depressing the clutch pedal, depress the brake pedal.
- STEP 2 Set the parking brake. (\rightarrow P. 194)
- STEP 3 Shift the shift lever to N. (\rightarrow P. 191)

If parking on a hill, shift the shift lever to 1 or R and block the wheels as needed.

- STEP 4 Press the "ENGINE START STOP" switch to stop the engine.
- STEP 5 Lock the door, making sure that you have the key on your person.

When driving

Starting off on a steep uphill

Automatic transmission

- STEP 1 Make sure that the parking brake is set and shift the shift lever to D.
- STEP 2 Gently depress the accelerator pedal.
- STEP 3 Release the parking brake.

Manual transmission

- STEP 1 With the parking brake firmly set and the clutch pedal fully depressed, shift the shift lever to 1.
- STEP 2 Lightly depress the accelerator pedal at the same time as gradually releasing the clutch pedal.

t C

STEP 3 Release the parking brake.

Driving in the rain

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged up, and the road will be slippery.
- Drive carefully when it starts to rain, because the road surface will be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

Breaking in your new Toyota

To extend the life of the vehicle, observing the following precautions is recommended:

- For the first 300 km (200 miles): Avoid sudden stops.
- For the first 800 km (500 miles): Do not tow a trailer.
- For the first 1000 km (600 miles):
 - Do not drive at extremely high speeds.
 - Avoid sudden acceleration.
 - Do not drive continuously in the low gears.
 - · Do not drive at a constant speed for extended periods
 - Do not drive slowly with the manual transmission in a high gear.

Drum-in-disc type parking brake system

Your vehicle has a drum-in-disc type parking brake system. This type of brake system needs bedding-down of the brake shoes periodically or whenever the parking brake shoes and/or drum are replaced. Have your Toyota dealer perform the bedding-down operation.

Idling time before stopping the engine (diesel engine)

To prevent damage to the turbocharger, allow the engine to idle immediately after high-speed driving or driving up a hill.

Driving condition		Idling time
Normal city driving		Not necessary
High-speed	Constant speed of approx. 80 km/h (50 mph)	Approximately 20 seconds
driving	Constant speed of approx. 100 km/h (63 mph)	Approximately 1 minute
Steep hill driving or continuous driving at 100 km/h (63 mph) or more (race track driving etc.)		Approximately 2 minutes


When driving

Operating your vehicle in a foreign country

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel. (\rightarrow P. 612)

Eco-friendly driving (vehicles with an automatic transmission)

Vehicles with a non-optitron type meters



Vehicles with an optitron type meters

If Eco Driving Indicator Light turns on, it indicates that you are driving at Ecofriendly driving. In case of over-use of the accelerator that cause the vehicle to exceed Zone of Eco driving, Eco Driving Indicator Light will turn off

Eco Driving Indicator Light will not operate in the following conditions:

• The shift lever in anything other than D.

The vehicle is set to second start mode.
 (→P. 186)

The vehicle speed is approximately 130 km/h (81 mph) or higher.



CAUTION

When starting the vehicle


On vehicles with an automatic transmission, always keep your foot on the brake pedal while stopped with the engine running. This prevents the vehicle from creeping.

When driving the vehicle

- Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
 - Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident that could result in death or serious injury.
 - When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
 - Make sure to keep a correct driving posture even when moving the vehicle only slightly. This allows you to epress the brake and accelerator pedals properly.
 - Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- Do not drive the vehicle over or stop the vehicle near flammable materials. The exhaust system and exhaust gases can be extremely hot. These hot parts may cause a fire if there is any flammable material nearby.
- On vehicles with an automatic transmission, do not let the vehicle roll backwards while the shift lever is in a driving position, or roll forward while the shift lever is in R.

Doing so may cause the engine to stall or lead to poor brake and steering performance, resulting in an accident or damage to the vehicle.

If the smell of exhaust is noticed inside the vehicle, open the windows and check that the back door is closed. Large amounts of exhaust in the vehicle can cause driver drowsiness and an accident, resulting in death or a serious health hazard. Have the vehicle inspected by your Toyota dealer immediately.



When driving on slippery road surfaces

- Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle, resulting in an accident.
- Sudden changes in engine speed, such as engine braking caused by upshifting and down-shifting, may cause the vehicle to skid, resulting in an accident.
- After driving through a puddle, lightly depress the brake pedal to make sure that the brakes are functioning properly. Wet brake pads may prevent the brakes from functioning properly. If the brakes on only one side are wet and not functioning properly, steering control may be affected, resulting in an accident.

When shifting the shift lever


On vehicles with an automatic transmission be careful not to shift the shift lever with the accelerator pedal depressed. Shifting the shift lever to a gear other than P or N may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result to death or serious injury.

If you hear a squealing or scraping noise (brake pad wear indicators)

Have the brake pads checked and replaced by your Toyota dealer as soon as possible.

Rotor damage may result if the pads are not replaced when needed.

It is dangerous to grive the vehicle when the wear limits of the brake pads and/or those of the brake discs are exceeded.



When the vehicle is parked

- Do not attach adhesive discs to the windshield or windows. Do not place containers such as air fresheners on the instrument panel or dashboard. Adhesive discs or containers may act as lenses, causing a fire in the vehicle.
- Do not leave a door or window open if the curved glass is coated with a metallized film such as a silver-colored one. Reflected sunlight may cause the glass to act as a lens, causing a fire.
- Always apply the parking brake, shift the shift lever to P (vehicles with an automatic transmission only), stop the engine and lock the vehicle.
 Do not leave the vehicle unattended while the engine is running.
- Do not touch the exhaust pipes while the engine is running or immediately after turning the engine off.
 Doing so may cause burns.
- Do not leave the engine running in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the engine is running, exhaust gases may collect and enter the vehicle. This may lead to death or a serious health hazard.

Exhaust gases

Exhaust gases include harmful carbon monoxide (CO), which is colorless and odorless. Inhaling exhaust gases may lead to death or a serious health hazard.

- If the vehicle is in a poorly ventilated area, stop the engine. In a closed area, such as a garage, exhaust gases may collect and enter the vehicle. This may lead to death or a serious health hazard.
- The exhaust system should be checked occasionally. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by your Toyota dealer. Failure to do so may allow exhaust gases to enter the vehicle, resulting in death or a serious health hazard.

CAUTION

When taking a nap in the vehicle

Always turn the engine off. Otherwise, if you accidentally move the shift lever or depress the accelerator pedal, this could cause an accident or fire due to engine overheating. Additionally, if the vehicle is parked in a poorly ventilated area, exhaust gases may collect and enter the vehicle, leading to death or a serious health hazard.

When braking

 When the brakes are wet, drive more cautiously.
 Braking distance increases when the brakes are wet, and this may cause one side of the vehicle to brake differently than the other side. Also, the parking brake may not securely hold the vehicle.

 If the power brake assist function does not operate, do not follow other vehicles closely and avoid hills or sharp turns that require braking. In this case, braking is still possible, but the trake pedal should be depressed more firmly than usual. Also, the braking distance will increase.

Do not pump the brake pedal if the engine stalls.
 Each push on the brake pedal uses up the reserve for the power-assisted brakes.

• The brake system consists of 2 individual hydraulic systems: If one of the systems fails, the other will still operate. In this case, the brake pedal should be depressed more firmly than usual and the braking distance will increase.

If this happens, do not continue to drive the vehicle. Have your brakes fixed immediately.

When driving the vehicle

Automatic transmission

- Do not depress the accelerator and brake pedals at the same time during driving. If the brake pedal is depressed while driving with the accelerator pedal depressed, driving torque may be restrained.
- Do not use the accelerator pedal or depress the accelerator and brake pedals at the same time to hold the vehicle on a hill.

Manual transmission

- Do not depress the accelerator and brake pedals at the same time during driving. If the brake pedal is depressed while driving with the accelerator pedal depressed, driving torque may be restrained.
- Do not shift gears unless the clutch pedal is fully depressed. After shifting, do not release the clutch abruptly. Doing so may damage the clutch, transmission and gears.
- Observe the following to prevent the outch from being damaged.
 - Do not rest your foot on the clutch pedal while driving.
 - Do not use any gears other than the 1st gear when starting off and moving forward.
 - Do not use the clutch to hold the vehicle when stopping on an uphill grade.
- Do not shift the shift lever to R when the vehicle is still moving. Doing so may damage the clutch, transmission and gears.

When parking the vehicle

On vehicles with an automatic transmission, always shift the shift lever to P. Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if the accelerator pedal is accidentally depressed.

NOTICE

Avoiding damage to vehicle parts

 Do not turn the steering wheel fully in either direction and hold it there for an extended period of time.

Doing so may damage the power steering pump.

- When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.
- Diesel engine only: Make sure to idle the engine immediately after highspeed driving or hill climbing. Stop the engine only after the turbocharger has cooled down.

Failure to do so may cause damage to the turbocharge

If you get a flat tire while driving

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually depress the brake pedal to slow down the vehicle.

- It may be difficult to control your vehicle
- The vehicle will make abnormal sounds or vibrations.

The vehicle will lean abnormally.

Information on what to do in case of a flat tire. (\rightarrow P. 567)

When encountering flooded roads

Do not drive on a road that has flooded after heavy rain etc. Doing so may cause the following serious damage to the vehicle:

- Engine stalling
- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have your Toyota dealer check the following:

- Brake function
- Changes in quantity and quality of oil and fluid used for the engine, transmission, transfer, differentials, etc.
- Lubricant condition for the propeller shaft, bearings and suspension joints (where possible), and the function of all joints, bearings, etc.

2-1. Driving procedures

Engine (ignition) switch (vehicles without a smart entry & start system)

Starting the engine

Automatic transmission

- STEP 1 Check that the parking brake is set.
- STEP 2 Check that the shift lever is set in P.
- STEP 3 Firmly depress the brake pedal.
- STEP 4 Turn the engine switch to the "START" position to start the engine.

Manual transmission (gasoline engine)


- STEP 1 Check that the parking brake is set.
- STEP 2 Check that the shift lever is set in N.
- STEP 3 Firmly depress the clutch pedal.
- STEP 4 Turn the engine switch to the "SCART" position to start the engine.

ction

Manual transmission (diesel engine)


- STEP 1 Check that the parking brake is set.
- STEP 2 Check that the shift lever is set in N.
- STEP 3 Firmly depress the clutch pedal.
- STEP 4 Turn the engine switch to the "ON" position.
 - The **O** indicator turns on.
- STEP 5 After the ∞ indicator light goes out, turn the engine switch to the "START" position to start the engine.

Changing the engine switch positions



Turning the key from "ACC" to "LOCK"

STEP 1 Shift the shift lever to P (automatic transmission) or N (manual transmission). (→P. 185, 191)




Push in the key and turn to the "LOCK" position.

tion

If the engine does not start

The engine immobilizer system may not have been deactivated. (\rightarrow P. 115)

When the steering lock cannot be released



When starting the engine, the engine switch may seem stuck in the "LOCK" position. To free it, turn the key while turning the steering wheel slightly left and right.

Key reminder function

A buzzer sounds if the driver's door is opened while the engine switch is in the "LOCK" or "ACC" position to remind you to remove the key.

CAUTION

When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances. Doing so may cause an accident resulting in death or serious injury.

Caution when driving

Do not turn the engine switch to the "LOCK" position while driving. If in an emergency, you must turn the engine off while the vehicle is moving, turn the engine switch only to the "ACC" position to stop the engine. An accident may result if the engine is stopped while driving.

NOTICE

To prevent battery discharge

Do not leave the engine switch in the "ACC" or "ON" position for long periods of time without the engine running.

duc

When starting the engine

- Do not crank the engine or more than 30 seconds at a time. This may overheat the starter and wring system.
- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have the engine checked immediately.

2-1. Driving procedures Engine (ignition) switch (vehicles with a smart entry & start system)

Performing the following operations when carrying the electronic key on your person starts the engine or changes "ENGINE START STOP" switch modes.

Starting the engine

Automatic transmission

- STEP 1 Check that the parking brake is set.
- STEP 2 Check that the shift lever is set in P.
- STEP 3 Firmly depress the brake pedal.

The "ENGINE START STOP" switch indicator will turn green. If the indicator does not turn green, the engine cannot be started.



Press the "ENGINE START STOP" switch.

The engine will crank until it starts or for up to 30 seconds, whichever is less.

Continue depressing the brake pedal until the engine is completely started.

Diesel engine only: the **OO** indicator turns on. The engine will start after the indicator light goes out.

The engine can be started from any "ENGINE START STOP" switch mode.


Manual transmission

STEP 1 Check that the parking brake is set.

STEP 2 Check that the shift lever is set in N.

STEP 3 Firmly depress the clutch pedal.

The "ENGINE START STOP" switch indicator will turn green. If the indicator does not turn green, the engine cannot be started.



Stopping the engine

Automatic transmission

STEP 1 Stop the vehicle.


- STEP 2 Shift the shift lever to P.
- STEP 3 Set the parking brake. (\rightarrow P. 194)
- STEP 4 Press the "ENGINE START STOP" switch.
- STEP 5 Release the brake pedal and check that the indicator on the "ENGINE START STOP" switch is off.

- STEP 3 Set the parking brake. (→P. 194) STEP 4 Press the "ENGINE START of the brack STEP 5 Release the brack STEP 5 Release the brake pedal and check that the indicator on the "ENGINE START STOP" switch is off. NotFor

When driving

Changing "ENGINE START STOP" switch modes

Modes can be changed by pressing the "ENGINE START STOP" switch with brake pedal (vehicles with an automatic transmission) or clutch pedal (vehicles with a manual transmission) released. (The mode changes each time the switch is pressed.)



When stopping the engine with the shift lever in a position other than P (Vehicles with an automatic transmission)

If the engine is stopped with the shift lever in a position other than P, the "ENGINE START STOP" switch will not be turned off but instead be turned to ACCESSORY mode. Perform the following procedure to turn the switch off:

STEP 1 Check that the parking brake is set.

STEP 2 Shift the shift lever to P.

- STEP 3 Check that the indicator on the "ENGINE START STOP" switch is illuminated in amber and there press the "ENGINE START STOP" switch once.
- STEP 4 Check that the indicator on the CONGINE START STOP" nor switch is off.

Auto power off function

Vehicles with an automatic transmission

If the vehicle is left in ACCESSORY or IGNITION ON mode (the engine is not running) for more than an hour with the shift lever in P, the "ENGINE START STOP" switch will automatically turn off. However, this function cannot entirely prevent battery discharge. Do not leave the vehicle with the "ENGINE START STOP" switch in ACCESSORY or IGNITION ON mode for long periods of time when the engine is not running.

Vehicles with a manual transmission

If the vehicle is left in ACCESSORY or IGNITION ON mode (the engine is not running) for more than an hour, the "ENGINE START STOP" switch will automatically turn off. However, this function cannot entirely prevent battery discharge. Do not leave the vehicle with the "ENGINE START STOP" switch in ACCESSORY or IGNITION ON mode for long periods of time when the engine is not running.

Operation of the "ENGINE START STOP" switch

When operating the "ENGINE START STOP" switch, one short, firm press is enough. If the switch is pressed improperly, the engine may not start or the "ENGINE START STOP" switch mode may not change. It is not necessary to press and hold the switch.

Electronic key battery depletion

→P. 42

Conditions affecting operation

→P. 39

Note for the entry function

→P. 40


If the engine does not start

The engine immobilizer system may not have been deactivated. (\rightarrow P. 115)

Steering lock

After turning the "ENGINE START STOP" switch off and opening and closing the doors, the steering wheel will be locked due to the steering lock function. Operating the "ENGINE START STOP" switch again automatically cancels the steering lock.

When the steering lock cannot be released



The green indicator light on the "ENGINE START STOP" switch will flash and a message will be shown on the multi-information display. Press the "ENGINE START STOP" switch again while turning the steering wheel left and right.

tion

Steering lock motor overheating prevention

To prevent the steering lock motor from overheating, the motor may be suspended if the engine is turned on and off repeatedly in a short period of time. In this case, refrain from operating the engine. After about 10 seconds, the steering lock motor will resume functioning.

When the "ENGINE START STOP" switch indicator flashes in amber

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer immediately.

If the electronic key battery is depleted

 $\rightarrow P.495$

CAUTION

When starting the engine

duction Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances. Doing so may cause an accident resulting in death or serious injury.

Caution while driving

If the vehicle begins to slide due to engine failure or other circumstances, do not lock or open the doors until the vehicle reaches a safe and complete stop. Activation of the steering lock in this circumstance may lead to an accident, resulting in death or serious injury.

Stopping the engine in an emergency

If you want to stop the engine in an emergency while driving the vehicle, press and hold the "ENGINE START STOP" switch for more than 3 seconds. However, do not touch the "ENGINE START STOP" switch while driving except in an emergency. Turning the engine off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.

When driving

NOTICE

To prevent battery discharge

- Do not leave the "ENGINE START STOP" switch in ACCESSORY or IGNI-TION ON mode for long periods of time without the engine running.
- If the indicator on the "ENGINE START STOP" switch is illuminated, the "ENGINE START STOP" switch is not off. When exiting the vehicle, always check that the "ENGINE START STOP" switch is off.
- On vehicles with an automatic transmission, do not stop the engine when the shift lever is in a position other than P. If the engine is stopped in another shift lever position, the "ENGINE START STOP" switch will not be turned off but instead be turned to ACCESSORY mode. If the vehicle is left in ACCESSORY mode, battery discharge may occur.

When starting the engine


- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have the engine checked immediately.
- Symptoms indicating a malfunction with the "ENGINE START STOP" switch

If the "ENGINE START STOR" seems to be operating somewhat differently than usual, such as the switch sticking slightly, there may be a malfunction. Contact your Toyota dealer immediately.

2-1. Driving procedures Automatic transmission^{*}

Select a shift position appropriate for the driving conditions.

Shifting the shift lever



While the "ENGINE START STOP" switch is in IGNITION ON mode, move the shift lever with the brake pedal depressed.

When shifting the shift lever between P and D, make sure that the vehicle is completely stopped.

Shift position purpose				
Shift position	Function			
Р	Parking the vehicle/starting the engine			
R	Reversing			
N	Neutral			
D	Normal driving ^{*1}			
S	S mode driving ^{*2} (\rightarrow P. 188)			


*1: Shifting to the D position allows the system to select a year suitable for the driving conditions. Setting the shift lever to the D position is recommended for normal driving.

*2: Selecting shift ranges using S mode restricts the upper limit of the possible gear ranges, controls engine braking forces, and prevents unnecessary upshifting.

Selecting the second start mode

Use second start mode for accelerating and driving on slippery road surfaces such as snow.


Non-Optitron type meters



Turn the "2nd STRT" button on.

Press the button again to cancel second start mode.

Optitron type meters



STEP 2 2nd STRT 2nd STRT Cont

1 Press the menu switch.

The multi-information display will change modes to electronic features control mode.

Press the "ENTER" switch upwards or downwards until "2ND START" appears.

Press the "ENDER" switch to change to 'ON".

The "2nd STRT" indicator will be displayed.


Each pressing of the switch turns second start mode on and off.

Press the menu switch to change to the normal display.

When driving

Changing shift ranges in S mode

When the shift lever is in the S position, the shift lever can be operated as follows:



The initial shift range in S mode is set automatically to 4 according to vehicle speed. However, the initial shift range may be set to 3 if Al-SHIFT has operated while the shift lever was in the D position. $(\rightarrow P. 189)$

Shift ranges and their functions

- You can choose from 5 level of engine braking force.
- A lower shift range will provide greater engine braking force than a higher shift range, and the engine speed will also increase.

Driving on a downhill

On declines, there may be case where the vehicle shifts down automatically to obtain engine braking. As a result of the downshifting, the engine speed may increase.

Second start mode automatic deactivation

Second start mode is automatically deactivated if the engine is turned off after driving in second start mode.

S mode

When the shift range is 4 or lower, holding the shift lever toward "+" sets the shift range to 5.

AI-SHIFT

AI-SHIFT automatically selects a suitable gear according to driver performance and driving conditions.

AI-SHIFT automatically operates when the shift lever is in the D position. (Shifting the shift lever to the S position cancels the function.)

When driving with the cruise control or dynamic radar cruise control

Engine braking will not occur in S mode, even when downshifting to 4. $(\rightarrow P. 240, 244)$

If the shift lever cannot be shifted from P

→P. 588

If the "S" indicator does not come on even after shifting the shift lever to S

This may indicate a malfunction in the automatic transmission system. Have the vehicle inspected by your Toyota dealer immediately.

(In this situation, the transmission will operate in the same manner as when the shift lever is in D.)

Downshift restriction warning buzzer (S mode)

To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some circumstances, downshifting may not be possible even when the shift lever is operated. (A buzzer will sound twice.)

CAUTION

When driving on slippery road surfaces

Do not accelerate or shift gears suddenly.

Sudden changes in engine braking may cause the vehicle to spin or skid, resulting in an accident.



2-1. Driving procedures Manual Transmission^{*}

Fully depress the clutch pedal before operating the shift lever, and then release it slowly. 6 Noiton

Shifting the shift lever

Maximum downshifting speeds

Observe the downshifting speeds in the following table to prevent over-revving the engine.


	Shift	Maximum speed (km/h [mph])	
	position		Transfer position L4
	1	50 (31)	20 (12)
	2	103 (64)	40 (25)
Gasoline engine	3	141 (88)	55 (34)
	4	176 (109)	69 (43)
	5	180 (112)	82 (51)
	1	38 (24)	15 (9)
	2	77 (48)	30 (19)
Diesel engine	20	105 (65)	41 (25)
	4	131 (81)	51 (32)
C	0 ⁵	157 (98)	61 (38)

Reverse warning buzzer

A buzzer will source o alert the driver if the shift lever is shifted to the R position.

2-1. Driving procedures Turn signal lever

The turn signal lever can be used to show the following intentions of the driver:



Turn signals can be operated when

Vehicles without a smart entry & start system

The engine switch is in the "ON" position.


Vehicles with a smart entry & start system

The "ENGINE START STOP" switch is in IGNITION ON mode.


If the indicator flashes faster than usual

Check that a light bulb in the front or rear turn signal lights has not burned out.

2-1. Driving procedures **Parking brake**



2-1. Driving procedures **Horn**



To sound the horn, press on or close to the mark.

After adjusting the steering wheel (vehicles with manual adjustment


type steering wheel)


Make sure that the steering wheel is securely locked. The horn may not sound if the steering wheel is not securely locked. $(\rightarrow P. 96)$



2-2. Instrument cluster Gauges and meters

Non-Optitron type meters






When driving

Changing the display

Non-Optitron type meter (\rightarrow P. 204)

Optitron type meter



The meters and display illuminate when

Vehicles without a smart entry & start system

The engine switch is in the "ON" position.

Vehicles with a smart entry & start system

The "ENGINE START STOP" switch is in IGNITION ON mode.

The brightness of the instrument cluster lights

Vehicles with a non-optitron type meter

When the headlight switch is turned to on, the brightness will be reduced slightly.

Vehicles with an optitron type meter

When the headlight switch is turned to on, the brightness will be reduced slightly unless the control dial is turned fully clockwise.

When disconnecting and reconnecting battery terminals

The trip meter data will be reset.

If the trip meter was displayed last, the ODO screen will be displayed after resetting.

NOTICE


To prevent damage to the engine and its components

- Do not let the indicator needle of the tachometer enter the red zone, which indicates the maximum engine speed.
- The engine may be overheating if the engine coolant temperature gauge is in the red zone (H). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (→P. 599)

2-2. Instrument cluster Indicators and warning lights

The indicators and warning lights on the instrument cluster and center panel inform the driver of the status of the vehicle's various systems.

Instrument cluster (non-optitron type meters)



ITN22M024 Indicators The indicators inform the driver of the operating state of the vehicle's various systems. 'SET" indicator Turn signal indicator <u>5</u> <u>c</u> (→P. 193) (→P. 240, 244) Dynamic radar cruise Headlight high beam control indicator \wedge indicator (→P. 224 (→P. 244) (if equipped) Slip indicator*2 Tail light indic 305 ج کے (→P. 279) (→P. 224 *1 Front log light indicator VSC OFF indicator*2 **≇**0 5 OFF (→P. 230) (→P. 279) (if equipped) *1 *1



Center panel

PASSENGER

Eco Driving Indicator Light (\rightarrow P. 207, 215)

(automatic transmission)



Cruise control indicator $(\rightarrow P. 240, 244)$

"TRC OFF" indicator^{*2} (\rightarrow P. 279)

(diesel engine)

TRC

OFF

(if equipped)

Engine preheating indicator (\rightarrow P. 177)



Multi-terrain Select indicator*2



Crawl Control indicator*2



Downhill assist control system indicator*2




transmission)

Automatic transmission second start indicator (→P. 186)



Low speed four-wheel drive indicator light*2



Rear differential lock

Center differential lock


indicator*2

(if equipped)

- *1: These lights turn on when the engine switch is turned to the "ON" position (vehicles without a smart entry & start system) or the "ENGINE START STOP" switch is turned to IGNITION ON mode (vehicles with a smart entry & start system) to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if a light does not turn on, or the lights do not turn off. Have the vehicle inspected by your Toyota dealer.
- *2: Refer to the "Off-road Driving Owner's Manual"
- *3: The light turns on when pre-crash braking is disabled. The light flashes quickly to indicate that the system is operating.

Warning lights

Warning lights inform the driver of malfunctions in any of the vehicle's systems. (\rightarrow P. 537)



- *1: These lights turn on when the engine switch is turned to the "ON" position (vehicles without a smart entry & start system) or the "ENGINE START STOP" switch is turned to IGNITION ON mode (vehicles with a smart entry & start system) to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if a light does not turn on, or if the lights do not turn off. Have the vehicle inspected by your Toyota deater.
- *2: The light flashes to indicate a malfunction.


CAUTION

If a safety system warning light does not come on


Should a safety system light such as ABS/Multi Terrain ABS and the SRS warning light not come on when you start the engine, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Toyota dealer immediately if this occurs.

2-2. Instrument cluster Multi-information display (Non-Optitron type meters)*

The multi-information display presents the driver with a variety of driving-related data including the current outside air temperature.



Switching the display



Items displayed can be switched by pressing the "ODO/TRIP" button.

Display items

Odometer



Displays the total **dis**tance the vehicle has been driven.

Trip meters A and B



Displays the distance the vehicle has been driven since the meter was last reset. Trip meters A and B can be used to record and display different distances independently.

Press the hold the button to reset.

Driving range



Displays the estimated maximum distance that can be driven with the quantity of fuel remaining


- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated.

Current fuel consumption



Displays the current rate of fuel consumption

Eco Driving Indicator Zone Display* (\rightarrow P. 207) and average fuel consumption



Displays the average fuel consumption since the function was reset

- The function can be reset by pressing the "ODO/ TRIP" button for longer than 4 second when the average fuel consumption is displayed.
- Use the displayed average fuel consumption as a reference.

Average vehicle speed



Displays the average vehicle speed since the engine was started or the function was reset

The function can be reset by pressing the "ODO/ TRIP" button for longer than 1 second when the average vehicle speed is displayed.

Eco Driving indicator Light setting screen*




Eco Driving Indicator Light can be set to on or off.

The function can be activated or deactivated by pressing the "ODO/TRIP" button for longer than 1 second when the Eco Driving Indicator Light setting screen is displayed.

*: Displayed on vehicles with an automatic transmission only

Eco Driving Indicator



Notfor

- Eco Driving Indicator Light During Eco-friendly acceleration (Eco driving), Eco Driving Indicator Light will turn on.
- Eco Driving Indicator Zone Display Suggests Zone of Eco driving with current Eco driving ratio based on acceleration.
- 3 Zone of Eco driving
- Eco driving ratio based on acceleration
 - If the vehicle exceeds Zone of Eco driving, the right side of Eco Driving Indicator Zone Display will blink and Eco Driving Indicator Light will turn off.
 - Priving Indicator Light will not operte in the following conditions:
- The shift lever in anything other than D.
- The vehicle is set to second start mode.
 (→P. 186)
- The vehicle speed is approximately 130 km/h (81 mph) or higher.

When disconnecting and reconnecting battery terminals

The following information data will be reset:

- Trip meter
- Average fuel consumption
- Average vehicle speed

If the trip meter was displayed last, the ODO screen will be displayed after resetting.

The information display at low temperatures (vehicles with an automatic transmission)

Allow the interior of the vehicle to warm up before using the information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or serious injury.


A NOTICE

The multi-information display at low temperatures

Allow the interior of the vehicle to warm up before using the information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.


2-2. Instrument cluster Multi-information display (Optitron type meters)*

The multi-information display presents the driver with a variety of driving-related data including the current outside air temperature.



*: If equipped

Switching the display



Menu switch

Changes modes to electronic features control mode, customization mode or back to normal display mode

2 "ENTER" switch

Changes trip information items. This switch is also used to turn on/off electronic features controls and to change customization settings.

Display items

Trip information contents

Trip information items displayed can be switched by pressing the "ENTER" switch upwards or downwards.


,¢

Front tire angle



The direction of the front tires is displayed

The tire direction is displayed in 3 stages for both left and right, in accordance with the angle of the tire.







Displays the average fuel consumption since the function was reset

- The function can be reset by pressing the "ENTER" switch for longer than 1 second when the average fuel consumption is displayed.
- Use the displayed average fuel consumption as a reference.

When driving

• Average vehicle speed





Electronic features control can be turned on/off when

"ENGINE START STOP" switch is in IGNITION ON mode.

System check display


After turning the "ENGINE START STOP" switch to IGNITION ON mode, "TOYOTA" is displayed while system operation is checked. When the system check is complete, the normal screen will return.

Conditions for ending electronic features control

In the following situations, the electronic features control will end automatically:

- assist-sensor starts operating
 ane Crawl Control is operated
 The dynamic radar cruise control is operated
 A warning message appears after the sis displayed A warning message appears after the electronic features control screen is displayed

Eco Driving Indicator



- Eco Driving Indicator Light During Eco-friendly acceleration (Eco driving), Eco Driving Indicator Light will turn on.
- Eco Driving Indicator Zone Display Suggests Zone of Eco driving with current Eco driving ratio based on acceleration.
- 3 Zone of Eco driving
- 4 Eco driving ratio based on acceleration.

If the vehicle exceeds Zone of Eco driving, the right side of Eco Driving Indicator Zone Display will blink and Eco Driving Indicator Light will turn off.

Eco Driving Indicator Light will not oper-

The shift lever in anything other than D.

The vehicle is set to second start mode. $(\rightarrow P. 186)$

 The vehicle speed is approximately 130 km/h (81 mph) or higher.

Outside temperature display

n'FO

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change:

- When the vehicle is stopped, or moving at low speeds (less than 20 km/h [12 mph])
- When the outside temperature has changed suddenly (at the entrance/ exit of a garage, tunnel, etc.)

When "--" or "E" is displayed

The system may be malfunctioning. Take your vehicle to your Toyota dealer.

When disconnecting and reconnecting battery terminals

The following information data will be reset:

- Average fuel consumption after refueling
- Average fuel consumption
- Average vehicle speed
- Elapsed time

The information display at low temperatures whicles with an automatic transmission)

Allow the interior of the vehicle to warm up before using the information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.


For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or serious injury.

The multi-information display at low temperatures


Allow the interior of the vehicle to warm up before using the information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

2-2. Instrument cluster Multi-information display (Accessory meters)*


The multi-information display presents the driver with a variety of driving-related data including the current outside air temperature.



*: If equipped



Driving range




Displays the estimated maximum distance that can be driven with the quantity of fuel remaining

This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.

When only a small amount of fuel is added to the tank, the display may not be updated.


Average fuel consumption after repelling and current fuel consumption



Displays the average fuel consumption since the vehicle was last refueled and the current rate of fuel consumption

Use the displayed average fuel consumption as a reference.

Average fuel consumption



Average vehicle speed

OUTSIDE 20 °C AVERAGE SPEED 40 km/h TO22M037E Elapsed time 0UTSIDE 20 °C ELAPSED TIME 12:00

Displays the average fuel consumption since the function was reset


- The function can be reset by pressing and holding the "RESET" switch when the average fuel consumption is displayed.
- Use the displayed average fuel consumption as a reference.

Displays the average vehicle speed since the function was


The function can be reset by pressing and holding the "RESET" switch when the average vehicle speed is displayed.


Displays the elapsed time since the function was last reset

The function can be reset by pressing and holding the "RESET" switch when the elapsed time is displayed.



When driving







Press the " \land " or " \checkmark " switch to select ON or OFF.

Setting up the display of the monitors

To set up the display, press the "DISP" switch when the camera image is being displayed until the desired item appears.

If left idle for approximately 10 seconds, the display will revert to the previous screen.





Press the " \land " or " \checkmark " switch to adjust the contrast.

- +: Strengthen
- -: Weaken

Setting the brightness



Press the " \land " or " \lor " switch to adjust the brightness.

- +: Brighter
- -: Darker

Liquid crystal display

Small spots or light spots may appear on the display. This phenomenon is characteristic of liquid crystal displays, and there is no problem continuing to use the display.

Outside temperature display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.

- When stopped, or driving at low speeds (less than 20 km/h [12 mph])
- When the outside temperature has changed suddenly (at the entrance/ exit of a garage, tunnel, etc.)
- When "--" or "E" is displayed on the outside temperature display

The system may be malfunctioning. Take your vehicle to your Toyota dealer.

When disconnecting and reconnecting battery terminals

The following information data and setting will be reset:

- Average fuel consumption after refueling
- Average fuel consumption
- Average vehicle speed
- Elapsed time
- Customization

Setting of available anguages can be changed. (Customizable features \rightarrow P. 626)

NOTICE


The multi-information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

2-3. Operating the lights and wipers **Headlight switch**

The headlights can be operated manually or automatically.

Turning the end of the lever turns on the lights as follows:



- The front position, tail, license plate and instrument panel lights turn on.
- The headlights and all lights listed above turn on.

AUTO Vehicles without a (if equipped) smart entry & start sys-


em: The headlights, and so on turn on and off automatically (when the engine switch is in the "ON" position.) Vehicles with a smart

entry & start system: The headlights front position lights and so on turn on and off automatically (when the "ENGINE START STOP" switch is in IGNITION ON mode.)

Turning on the high beam headlights

≣(

2



Pull the lever toward you to the center position to turn the high beams off.

Pull the lever toward you and release it to thash the high beams once


You can flash the high beams with the headlights on or off.

Manual headlight leveling dial (if equipped)


The level of the headlights can be adjusted according to the number of passengers and the loading condition of the vehicle.

TN23M032

TN23M031



2 Lowers the level of the headlights



Guide to dial settings

Vehicles with third seats

Occupancy and luggage load conditions		Dial position	
Occupants	Luggage load	With rear height control air suspension	Without rear height control air suspension
Driver only, or driver and one passenger in the front seat	None	0	0
Driver, front passen- ger and all passen- gers in the rear seats farthest to the rear	None	uctio,	1
All seats occupied	None	0	2
All seats occupied	Full luggage loading	0.5	2.5
Driver	Full luggage loading	0.5	3

Vehicles without third seats


Occupancy and luggage load conditions		Dial position	
Occupants	Luggage load	3-door models	5-door models
Driver only, or driver and one passenger in the front seat	None	0	0
Driver, front passen- ger and all passen- gers in the rear seats farthest to the rear	None	1.5	1
All seats occupied	None	1.5	1
All seats occupied	Full luggage loading	3	3.5
Driver	Full luggage loading	4	4

AFS (Adaptive Front-lighting System) (if equipped)

AFS (Adaptive Front-lighting System) secures excellent visibility at intersections and on curves by automatically adjusting the direction of the light axis of the headlights according to vehicle speed and the degree of the tire's angle as controlled by steering input.

AFS operates at speeds of 10 km/h (6 mph) or higher.

Deactivating AFS



1 Press the menu switch.

The multi-information display will change modes to electronic features control mode.

Press the "ENTER" switch
 Opwards or downwards until
 "AFS" appears.

Press the "ENTER" switch to change to "OFF".

The "AFS OFF" indicator will be displayed.

Each pressing of the switch turns "AFS" on and off.

Press the menu switch to change to the normal display.

Headlight control sensor (if equipped)



The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield.

Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.

Automatic light off system

Type A

Vehicles without a smart entry & start system

The headlights, front position, tail, license plate, front and rear fog (if equipped), and instrument panel lights turn off automatically if the engine switch is turned to the "ACC" or "LOCK" position and the driver's door is opened.

To turn the lights on again, turn the engine switch to the "ON" position, or turn the light switch off once and then back to \bullet or $\equiv 0$.

Vehicles with a smart entry & start system

The headlights, front position, license plate, front fog, and instrument panel lights turn off automatically if the "ENGINE START STOP" switch is turned to ACCESSORY mode or turned off and the driver's door is opened.

To turn the lights on again, turn the "ENGINE START STOP" switch to IGNI-TION ON mode, or turn the light switch off once and then back to \bullet or $\equiv O$.



Туре В

- When only the tail lights come on: The front position, tail, license plate, front, and instrument panel lights turn off if the "ENGINE START STOP" switch is turned to ACCESSORY mode or turned off and the driver's door opened.
- When the headlights come on: The headlights, front position, tail, license plate, front, and instrument panel lights turn off 30 seconds after a door or the glass hatch (if equipped) is opened and closed.

To turn the lights on again, turn the "ENGINE START STOP" switch to IGNI-TION ON mode, or turn the light switch off once and then back to \bullet or $\equiv O$.

Automatic headlight leveling system (if equipped)

The level of the headlights is automatically adjusted according to the number of passengers and the loading condition of the vehicle to ensure that the headlights do not interfere with other road users.

■ If the "AFS OFF" indicator flashes

It may indicate a malfunction in the system. Contact your Toyota dealer.

Customization

Settings (e.g. light sensor sensitivity) can be changed. (Customizable features \rightarrow P 626)


NOTICE

To prevent battery discharge

Do not leave the lights on longer than necessary when the engine is not running.

2-3. Operating the lights and wipers Fog light switch*

The fog lights secure excellent visibility in difficult driving conditions, such as in rain and fog.





The headlights or front position lights are turned on.

2-3. Operating the lights and wipers Windshield wipers and washer

Intermittent windshield wipers with interval adjuster

The wiper operation is selected by moving the lever as follows. When intermittent windshield wiper operation is selected, the wiper interval can be also adjusted.





 Washer/wiper dual operation


The wipers will automatically operate a couple of times after the washer squirts.

Vehicles with the headlight cleaners: If the headlights are on, the headlight cleaners will operate once.


Rain-sensing windshield wipers (if equipped)

When **AUTO** is selected, the wipers will operate automatically when the sensor detects falling rain. The system automatically adjusts wiper timing in accordance with rain volume and vehicle speed.

When **AUTO** is selected, the sensor sensitivity can be adjusted as follows by turning the switching:



- Rain-sensing wiper operation ("AUTO")
- 2 Low speed wiper operation
- 3 High speed wiper operation
- 4 Temporary operation



5 Decreases the sensitivity 6 Increases the sensitivity

Washer/wiper dual operation 7 The wipers operate automatically After operating several times, the wipers operate one more time after a short delay to Notrot

prevent dripping.)

Vehicles with the headlight cleaners: If the headlights are on, the headlight cleaners will operate once.

The windshield wiper and washer can be operated when

Vehicles without a smart entry & start system The engine switch is in the "ON" position.

Vehicles with a smart entry & start system The "ENGINE START STOP" switch is in IGNITION ON mode.

Raindrop sensor (vehicles with rain-sensing windshield wipers)



 The raindrop sensor judges the amount of raindrops.

An optical sensor is adopted. It may not operate properly when sunlight from the rising or setting of the sun intermittently strikes the windshield, or if bugs etc. are present or the windshield.

- If the wiper switch is turned to the "AUTO" position while the "ENGINE START STOP" switch is in IGNITION ON mode, the wipers will operate once to show that "AUTO" mode is activated.
- When the sensor sensitivity ting is turned toward high while in "AUTO" mode, the wipers will operate once to indicate that the sensor sensitivity is enhanced.
- If the temperature of the raindrop sensor is 90 °C (194 °F) or higher, or -15 °C (5 °F) or tower, automatic operation may not occur. In this case, operate the wipers in any mode other than "AUTO".
- Effects of vehicle speed on wiper operation (vehicles equipped with rain-sensing windshield wipers)

With the settings other than "AUTO" also, the time until drip prevention wiper sweep occurs is changed depending on vehicle speed.

With "LO" selected, wiper operation will be switched from low speed to intermittent wiper operation only when the vehicle is stationary. (However, when the sensor sensitivity is adjusted to the highest level, the mode cannot be switched.)

If no windshield washer fluid sprays

Check that the washer nozzles are not blocked if there is washer fluid in the windshield washer fluid reservoir.

Caution regarding the use of windshield wipers in "AUTO" mode

The windshield wipers may operate unexpectedly if the sensor is touched or the windshield is subject to vibration in "AUTO" mode. Take care that your fingers or anything else does not become caught in the windshield wipers.

▲ NOTICE

When the windshield is dry

Do not use the wipers, as they may damage the windshed.

When the washer fluid tank is empty

Do not operate the switch continually as the washer fluid pump may overheat.

When there is no washer fluid spray from the nozzle


Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually

When a nozzle becomes blocked

Do not try to clear it with a pin or other object. The nozzle will be damaged.

2-3. Operating the lights and wipers Rear window wiper and washer

The wiper operation is selected by moving the lever as follows:



The rear window wiper and washer can be operated when

Vehicles without a smart entry & start system The engine switch is in the "ON" position.

Vehicles with a smart entry & start system The "ENGINE START STOP" switch is in IGNITION ON mode.

• The glass hatch (if equipped) is closed.

If no washer fluid sprays

Check that the washer nozzles are not blocked if there is washer fluid in the Inction washer fluid reservoir.

NOTICE

When the rear window is dry


Do not use the wiper, as it may damage the ear window.

When the washer fluid tank is empty

Do not operate the switch continuaty as the washer fluid pump may over-Notfor heat.

2-3. Operating the lights and wipers Headlight cleaner switch^{*}

Washer fluid can be sprayed on the headlights.



Press the switch to clean the headlights.

The headlight cleaners can be operated when

Vehicles without a smart entry & start system. The engine switch is in the "ON" position and the headlight switch is turned on.

If equipped, the headlight switch is in the "AUTO" position and the headlight is on.

Vehicles with a smart entry & start system: The "ENGINE START STOP" switch is in IGNITION ON mode and the headlight switch is turned on.

If equipped, the headlight switch is in the "AUTO" position and the headlight is on.

Windshield was he linked operation

Vehicles without a smart entry & start system: When the windshield washer is operated with the engine switch is in the "ON" position and the headlight on, the headlight cleaners will operate once. (\rightarrow P. 231)

Vehicles with a smart entry & start system: When the windshield washer is operated with the "ENGINE START STOP" switch is in IGNITION ON mode and the headlight on, the headlight cleaners will operate once. (\rightarrow P. 231)


When the washer fluid tank is empty

Do not press the switch continually as the washer fluid pump may overheat.




2-4. Using other driving systems **Cruise control***

Use the cruise control to maintain a set speed without depressing the accelerator pedal.



Adjusting the set speed




- Increases the speed
- 2 Decreases the speed

Hold the lever until the desired speed setting is obtained.

Fine adjustment of the set speed can be made by lightly pushing the lever up or down and releasing it

Canceling and resuming the constant speed control



Pulling the lever toward you cancels the constant speed control.

The speed setting is also canceled when the brakes are applied or the clutch pedal (manual transmission only) is depressed.

Pushing the lever up resumes the constant speed control.

Cruise control can be set when

- The shift lever is in D, or 4 or 5 range of S has been selected (vehicles with an automatic transmission).
- Vehicle speed is above approximately 40 km/h (25 mph).

Accelerating

The vehicle can be accelerated normally. After acceleration, the set speed resumes.

Automatic cruise control cancelation

Cruise control will stop maintaining the vehicle speed in a vof the following situations:

• Actual vehicle speed falls more than approximately 16 km/h (10 mph) below the preset vehicle speed.


At this time, the memorized set speed is not retained.

- Actual vehicle speed is below approximately 40 km/h (25 mph).
- VSC is activated.

If the cruise control indicator light flashes


Press the "ON-OFF" button once to deactivate the system, and then press the button again to reactivate the system.

If the cruise control speed cannot be set or if the cruise control cancels immediately after being activated, there may be a malfunction in the cruise control system. Have the vehicle inspected by your Toyota dealer.





2-4. Using other driving systems Dynamic radar cruise control*

Dynamic radar cruise control supplements conventional cruise control with a vehicle-to-vehicle distance control. In vehicle-to-vehicle distance control mode, the vehicle automatically accelerates or decelerates in order to maintain a set following distance from vehicles ahead.



Selecting cruise mode





Selecting vehicle-to-vehicle distance control mode:

Press the "ON-OFF" button to activate the cruise control.

Press the button again to deactivate the cruise control.

Selecting conventional constant speed control mode:

Press the "ON-OFF" button to activate the cruise control.

Press the button again to deactivate the cruise control.


Vehicle-to-vehicle distance control mode is always reset when the "ENGINE START STOP" switch is turned to IGNITION ON mode.

2 Switch to constant speed control mode.

(Push the lever forward and hold for approximately one second.)

Cruise control indicator will come on.

Driving in the selected cruise control mode



Accelerate or decelerate to the desired speed, and push the lever down to set the speed.

"SET" indicator will come on.






Hold the lever until the desired speed setting is displayed.

Fine adjustment of the set speed can be made by lightly pushing the lever up or down and releasing it.

Canceling and resuming the constant speed control




Pulling the lever toward you cancels the constant speed control.

The speed setting is also canceled when the brakes are applied.

Pushing the lever up resumes the constant speed control

Changing the vehicle-to-vehicle distance



Pressing the button changes the Ovehicle-to-vehicle distance as follows:

- 1 Long
- 2 Medium
- 3 Short


The vehicle-to-vehicle distance is set automatically to long mode when the "ENGINE START STOP" switch is turned to IGNITION ON mode.

If a vehicle is running ahead of you, the preceding vehicle mark will be also displayed.

Driving in vehicle-to-vehicle distance control mode

This mode employs a sensor to detect the presence of vehicles up to approximately 120 m (400 ft.) ahead and to judge the distance between your vehicle and the vehicle ahead of you.

Note that vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



Example of constant speed cruising When there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control.

2 Example of deceleration cruising

When the vehicle ahead is driving slower than the set speed

When a vehicle is detected running ahead of you in the same lane, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.

3 Example of follow-up cruising

When following a vehicle driving slower than the set speed

The system continues follow-up cruising while adjusting for changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver.

4 Example of acceleration

When there no longer are vehicles driving slower than the set speed in the lane ahead

When the vehicle ahead of you executes a lane change, the system slowly accelerates until the set speed is reached. The system then returns to constant speed cruising.

Approach warning

When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Apply the brakes to ensure an appropriate vehicle-to-vehicle distance.

Dynamic radar cruise can be set when

- The shift level is in D. (Recommended) Dynamic radar cruise control can also be set when the shift lever is in the S position and range 4 or 5 has been selected.
- Vehicle speed is above approximately 50 km/h (30 mph).

Switching modes

The mode cannot be switched to constant speed control mode if vehicle-tovehicle distance control mode has been used. The mode also cannot be switched from constant speed control to vehicle-to-vehicle distance control mode. Turn the system off by pressing the "ON-OFF" button, and turn it on again.

Accelerating

The vehicle can be accelerated normally. After acceleration, the set speed resumes. However, during vehicle-to-vehicle distance control mode, the vehicle speed may decrease below the set speed in order to maintain the distance to the vehicle ahead.

Automatic cancelation of vehicle-to-vehicle distance control

Vehicle-to-vehicle distance control driving is automatically canceled in the following situations:

- Actual vehicle speed falls below approximately 40 km/h (25 mph).
- VSC is activated.
- The sensor cannot operate correctly because it is covered in some way.
- The windshield wipers are operating at high speed
- The driving mode is set to second start mode.
- Bad weather causes the detection function to become extremely unstable.

If vehicle-to-vehicle distance control driving is automatically canceled for any other reason, there may be a malfunction in the system. Contact your Toyota dealer.

Automatic cancelation of constant speed control

The cruise control will stop maintaining the vehicle speed in the following situations:

• Actual vehicle speed is more than approximately 16 km/h (10 mph) below the set vehicle speed.

At this time, the memorized set speed is not retained.

- Actual vehicle speed falls below approximately 40 km/h (25 mph).
- VSC is activated.


Vehicle-to-vehicle distance settings

Select a distance from the table below. Note that the distances shown correspond to a vehicle speed of 80 km/h (50 mph). Vehicle-to-vehicle distance increases/decreases in accordance with vehicle speed.

Distance options	Vehicle-to-vehicle distance	
Long	Approximately 50 m (160 ft.)	
Medium	Approximately 40 m (130 ft.)	
Short	Approximately 30 m (100 ft.)	

Radar sensor and grille cover

Always keep the sensor and grille cover clean to ensure that the vehicle-tovehicle distance control operates properly. (Some obstructions, such as snow, ice and plastic objects, cannot be detected by the obstruction sensor.) Dynamic radar cruise control is canceled if an obstruction is detected.



Warning lights and messages for dynamic radar cruise control

Warning lights and messages are used to indicate a system malfunction or to inform the driver of the need for caution while driving. (\rightarrow P. 547)

Approach warning

In the following instances, there is a possibility that the warnings will not occur:

- When the speed of the vehicle ahead matches or exceeds your vehicle speed
- When the vehicle ahead is traveling at an extremely slow speed
- Immediately after the cruise control speed was set
- •When the accelerator pedal is depressed, and immediately after it is released

CAUTION

Before using dynamic radar cruise control

Do not overly rely on vehicle-to-vehicle distance control.

Be aware of the set speed. If automatic deceleration/acceleration is not appropriate, adjust the vehicle speed, as well as the distance between your vehicle and vehicles ahead by applying the brakes etc.

Cautions regarding the driving assist systems

Observe the following precautions.

Failure to do so may cause an accident resulting in death or serious injury.

Assisting the driver to measure following distance

The dynamic radar cruise control is only intended to help the driver in determining the following distance between the driver's own vehicle and a designated vehicle traveling ahead. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for driver to pay close attention to the vehicle's surroundings.

• Assisting the driver to judge propertolowing distance

The dynamic radar cruise control determines whether the following distance between the driver's own vehicle and a designated vehicle traveling ahead is appropriate or not. It is not capable of making any other type of judgement. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger in any given situation.

• Assisting the driver to operate the vehicle

The dynamic radar cruise control has no capability to prevent or avoid a collision with a vehicle traveling ahead. Therefore, if there is ever any danger, the driver must take immediate and direct control of the vehicle and act appropriately in order to ensure the safety of all involved.

To avoid inadvertent cruise control activation

Switch the cruise control off using the "ON-OFF" button when not in use.

Situations unsuitable for dynamic radar cruise control

Do not use dynamic radar cruise control in any of the following situations.

Doing so may result in inappropriate speed control and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice and snow
- On steep downhills, or where there are success changes between sharp up and down gradients
- At entrances to expressways
- When weather conditions are bac enough that they may prevent the sensors from functioning correct of fog, snow, sandstorm, heavy rain, etc.)
- When a buzzer is heard often
- When towing a trailer or emergency towing
- In traffic conditions where the vehicle is repeatedly sped up and slowed down at frequent intervals

CAUTION

When the sensor may not be correctly detecting the vehicle ahead

Apply the brakes as necessary when any of the following types of vehicles are in front of you.

As the sensor may not be able to correctly detect these types of vehicles, the approach warning (\rightarrow P. 251) will not be activated, and a fatal or serious accident may result.

- Vehicles that cut in suddenly
- Vehicles traveling at low speeds
- Vehicles that are not moving
- Vehicles with small rear ends (trailers with no load on board etc.)
- Motorcycles traveling in the same lane

Conditions under which the vehicle-to-vehicle distance control may not function correctly

Apply the brakes as necessary in the tolowing conditions as the radar sensor may not be able to correctly detect vehicles ahead, and a fatal or serious accident may result:

- When water or snow thrown up by the surrounding vehicles hinders the functioning of the sense
- When your vehicle is pointing upwards (caused by a heavy load in the luggage compartment etc.)
- When the road curves or when the lanes are narrow
- When steering wheel operation or your position in the lane is unstable
- When the vehicle ahead of you decelerates suddenly
- Excessive exhaust gas (black smoke) is coming from the vehicle ahead or other vehicles around you, obscuring your front view
- The rear section of the vehicle ahead is extremely dirty
- The vehicle ahead has higher ground clearance

CAUTION

To ensure the sensor functions correctly

Do not do the following to the sensor or grille as doing so may cause the sensor not to function correctly and could result in an accident:

- Sticking or attaching anything to them
- Leaving them dirty
- Disassembling or subjecting them to strong shocks
- Modifying or painting them
- Replacing them with non-genuine parts

Handling the radar sensor

Observe the following to ensure the cruise control system can function effectively.

Otherwise, the system may not function correctly and could result in an accident.


- Keep the sensor and front grille cover clean at all times. Clean the sensor and front grille cover with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact.
 If the sensor moves even slightly off position, the system may malfunction.
 If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by your Toyota dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille cover or surrounding area.
- Do not modify or paint the sensor and grille cover.
- Do not replace them with non-genuine parts.

The distance from your vehicle to nearby obstacles when parallel parking or maneuvering into a garage is measured by the sensors and communicated via the indicator (non-optitron type meters), the multi-information display (optitron type meters), the accessory meter (if equipped), and a buzzer. Always check the surrounding area when using this system.

Vehicles with a navigation system

Refer to the "Navigation System Owner's Manual".


Vehicles without a navigation system Types of sensors 1 Front corner sensors (if sed) center sensors (if 2 Front equipped) 3 Rear corner sensors 4 Rear center sensors 2 1 4 1 TN24M058a Toyota parking assist-sensor switch 4 sensor type



Turns Toyota parking assistsensor on/off

When on, the indicator light come on and the buzzer sounds to inform the driver that the system is operational.

8 sensor type



1 Press the menu switch.

The multi-information display will change modes to electronic features control mode.

Press the "ENTER" switch upwards or downwards until the Toyota parking assistsensor mark appears in the multi-information display.

Press the ENTER" switch to change to "ON".

The Toyota parking assistsensor indicator will be displayed.

Each pressing of the switch turns the Toyota parking assistsensor on and off.

When on, the buzzer sounds to inform the driver that the system is operational.

Press the menu switch to change to the normal display.


Display

When the sensors detect an obstacle, the Toyota parking assist-sensor indicator is illuminated by an LED (non-optitron type meters), or a graphic is shown on the multi-information display (optitron type meters and accessory meter) depending on the position and distance to the obstacle.

2


4 sensor type

8 sensor type (vehicles with an optitron type meters)



- Front corner sensor operation
- 2 Front center sensor operation
- 3 Front tire angle
- 4 Rear corner sensor operation
- 5 Rear center sensor operation

8 sensor type (vehicles with an accessory meter)



The distance display and buzzer

When a sensor detects an obstacle, the direction of and the approximate distance to the obstacle are displayed and the buzzer sounds.


Distance display

Corner sensor

Approximate	4 sensor type	8 sensor type	
distance to obstacle*		Optitron type meter	Accessory neter (insert display)
Front: 60 cm (2.0 ft.) to 47.5 cm (1.6 ft.) Rear: 55 cm (1.8 ft.) to 37.5 cm (1.2 ft.)	(blinking)	(continuous)	(blinking)
Front: 47.5 cm (1.6 ft.) to 35 cm (1.1 ft.) Rear: 37.5 cm (1.2 ft.) to 25 cm (0.8 ft.)	(blinking rapidly)	(continuous)	(blinking rapidly)
Front: Less than 35 cm (1.1 ft.) Rear: Less than 25 cm (0.8 ft.)	(continuous)	(blinking)	(continuous)

*: 4 sensor type contains only rear sensors

Center sensors



*: 4 sensor type contains only rear sensors


Buzzer operation and distance to an obstacle

A beep sounds when the corner sensors and center sensors are operating.


- The buzzer beeps faster as the vehicle approaches an obstacle. When the vehicle comes within the following distance of the obstacle, the buzzer sounds continuously.
 - Front corner sensors: Approximately 35 cm (1.1 ft.)
 - Front center sensors: Approximately 30 cm (1.0 ft.)
 - Rear corner sensors: Approximately 25 cm (0.8 ft.)
 - Rear center sensors: Approximately 40 cm (1.3 ft.)
- When 2 or more obstacles are detected simultaneously, the

Sensors that operate


4 sensor type



8 sensor type



Detection range of the sensors



Approximately 100 cm (3.3 ft.) Approximately 150 cm (4.9 ft.)

Approximately 60 cm (2.0 ft.)

Approximately 55 cm (1.8 ft.)

The diagram shows the detection range of the sensors. Note that the sensors may not be able to detect obstacles that are extremely close to the vehicle.

The range of the sensors may change depending on the shape of the object etc.

*: If equipped

When driving

Sensor detection information

- Certain vehicle conditions and the surrounding environment may affect the ability of a sensor to correctly detect an obstacle. Particular instances where this may occur are listed below.
 - There is dirt, snow or ice on a sensor.
 - A sensor is frozen.
 - A sensor is covered in any way.
 - The vehicle is leaning considerably to one side.
 - On an extremely bumpy road, on an incline, on gravel, or on grass.
 - The vicinity of the vehicle is noisy due to vehicle homs, motorcycle engines, air brakes of large vehicles, or other lour noises producing ultrasonic waves.
 - There is another vehicle equipped with parking assist sensors in the vicinity.
 - A sensor is coated with a sheet of spray or heavy rain.
 - The vehicle is equipped with a fender pole or radio antenna.
 - Towing eyelets are installed.
 - A bumper or sensor receives a strong impact.
 - The vehicle is approaching a tail or right-angled curb.
 - In harsh sunlight or intense cold weather.
 - A non-genuine Toyota suspension (lowered suspension etc.) is installed.

In addition to the examples above, there are instances in which, because of their shape, signs and other objects may be judged by a sensor to be closer than they are

- The shape of the obstacle may prevent a sensor from detecting it. Pay particular attention to the following obstacles:
 - Wires, fences, ropes, etc.
 - · Cotton, snow and other materials that absorb sound waves
 - Sharply-angled objects
 - Low obstacles
 - Tall obstacles with upper sections projecting outwards in the direction of your vehicle

If the vehicle indicator remains on while the rear corner and rear center indicators flash and the malfunction beep sounds for approximately 8 seconds. (vehicles with a non-optitron type meter)

Have the vehicle inspected by your Toyota dealer.

If the vehicle indicator and the rear corner and rear center indicators flash and the malfunction beep sounds for approximately 8 seconds. (vehicles with a non- optitron type meter)

Clean the sensors with soft cloth.

If a message is displayed (vehicles with an optitron type meter)

→P. 547

Customization that can be configured at Toyota dealer roducti

Setting of buzzer volume can be changed. (Customizable features \rightarrow P. 626)

CAUTION

Caution when using the Toyota parking assist-sensor

Observe the following precautions.

Failing to do so may result in the vehicle being unable to be driven safely and possibly cause an accident.

Do not use the sensor at speeds in excess of 10 km/h (6 mph).

• Do not attach any accessories within the sensor range.

NOTICE

Notes when washing the vehicle


Do not apply intensive bursts of water or steam to the sensor area. Doing so may result in the sensor malfunctioning.

2-4. Using other driving systems Rear view monitor system (vehicles with an accessory meter)*

The rear view monitor assists the driver by displaying an image of the area behind the vehicle while reversing. The image is displayed in reverse on the screen. This reversed image is a similar image to the one on the inside rear view mirror.

Vehicles with a navigation system

For the advanced parking guidance system, refer to the "Navigation System Owner's Manual".



Vehicles without a navigation system

The rear view image is displayed when the shift lever is in the R position.


Vanicles with an automatic transmission

Vehicles with a manual transmission

If the shift lever is shifted out of R, the screen returns to the previous one.

Displayed area

Vehicles with back door mounted spare tire




Corners of bumper

The area covered by the camera is limited. Objects which that are close to either corner of the bumper or under the spare wheel cover cannot be seen on the screen.


The area displayed on the screen may vary depending on vehicle orientation or road conditions.

Vehicles without back door mounted spare tire




The area covered by the camera is limited. Objects which that are close to either corner of the bumper or under the bumper cannot be seen on the screen.

The area displayed on the screen may vary depending on vehicle orientation or road conditions.




Rear view monitor camera

Vehicles with back door mounted spare tire



Vehicles without back door mounted spare tire




In the following cases, it may be difficult to see images on the screen even when the system is functioning correctly:

- The vehicle is in a dark area, such as at niaht.
- The temperature near the lens is extremely high or low.
- Water droplets are on the camera lens or humidity is high, such as when it rains.
- Foreign matter, such as snow and mud. adheres to the camera lens.
- The sup headlights are shining nto the camera lens. directla

When the back door is open

The screen cannot be used because a message is displayed. When backing up the vehicle, make sure the back door is securely closed.

Smear effect



If a bright light, such as sunlight reflected off the vehicle body, is picked up by the camera, a smear effect* characteristic to the camera may occur.

*: Smear effect — A phenomenon that occurs when a bright light is picked up by the camera; when transmitted by the camera, the light source appears to have a vertical streak above and below it.

When using the rear view monitor system

Observe the following precautions to avoid an accident that could result in death or serious injuries:

- Never depend solely on the monitor system when reversing.
- Always check visually and with the mirrors to confirm your intended path is clear.
- Depicted distances between objects and flat surfaces differ from actual distances.

Conditions which may affect the rear view monitor system

- If the back of the vehicle has been hit, the camera's position and mounting angle may have changed. Have the vehicle inspected by your Toyota dealer.
- Rapid temperature changes, such as when hot water is poured on the vehicle in cold weather, may cause the system to function abnormally.
- If the camera lens is extremely city, it cannot transmit a clear image. Rinse with water and wipe with a soft cloth. If the camera lens is extremely dirty, wash with a mild cleanser and rinse.
- The displayed image may be darker and moving images may be slightly distorted when the system is cold.

2-4. Using other driving systems

Wide view front & side monitor (vehicles with an accessory meter)*

This system can display the wide view front monitor and the side monitor.


The wide view front monitor uses a super-wide angle lens to display on screen the areas to the left and right of the vehicle and the blind spots to the front of the vehicle. This system helps the driver check for approaching cars, bicycles and pedestrians when at intersections with poor visibility.

The side monitor uses a camera installed in the passenger's side outside rear view mirror to display on screen the area to the left of the vehicle, helping the driver check this area.

Vehicles with a navigation system

Refer to the "Navigation System Owner's Manual".

Vehicles without a navigation system



The camera image is displayed when the wide view front & side monitor switch is pressed.


Changing the display The screen changes as follows with each press of the wide view front & side monitor switch. Wide view front monitor (Side monitor) -The wide view front monitor display and trip information are not accessible when the shift lever is in R.

On vehicles with Multi-terrain Select, the Multi-terrain Monitor can be switched to by pressing the wide view front & side monitor switch roduci while the system is operating.

Display


Wide view front monitor

The image from the front carrier is displayed. Use this monitor to help check the area in front of the vehicle for safety, for example in intersections with poor visibility.




Side monitor


The image from the side camera is displayed. Use this monitor to help check the area to the left of the vehicle, for example when taking off and stopping, when turning left, etc. (\rightarrow P. 272)



Using the vehicle width line



Use the vehicle width line to check the vehicle's distance from objects such as curbstones etc. As shown in the illustration, be sure that the vehicle width line does not overlap the object. If you also move the vehicle so that the vehicle width line and the object are parallel, you can park parallel to the object.



- The wide view front a side monitor can be operated when
 - The "ENGINE START STOP" switch is in IGNITION ON mode.
 - The vehicle speed is less than approximately 10 km/h (6 mph).

Automatic system cancelation

- In the following situations, the system is canceled automatically.
- When the vehicle speed exceeds approximately 12 km/h (7 mph).
- When the shift lever is in R.
- When the shift lever is in P. (vehicles with an automatic transmission)

When the outside rear view mirrors have been folded

The side monitor screen can be displayed even if the outside rear view mirrors have been folded. In this case, there will be a slight difference between the image displayed when the outside rear view mirrors are extended and when the outside rear view mirrors have been folded.


If the side monitor is displayed while the outside rear view mirrors are folded, you cannot check the area near the front edge of the vehicle as the base of the outside rear view mirrors will be in the way.

Displayed area

The area covered by the camera is limited. Objects which are close to either corner of the bumper or under the bumper cannot be seen on the screen.

The area displayed on the screen may vary according to vehicle orientation or road conditions.

Front camera




This section is masked to prevent the oriver from moving the vehicle while only watching the wide view front monitor screen. The driver must visually confirm this area directly.


2 Camera's field of view

3 Objects visible to the camera

- 4 Objects not visible to the camera
- 5 Parts of the vehicle (bumper, grill, etc.)




Side camera



In the following cases, it may be difficult to see images on the screen even when the system is functioning correctly:

- The vehicle is in a dark area, such as at night.
- The temperature near the lens is extremely high or low.
- Water droplets are on the camera lens or humidity is high, such as when it rains.
- Foreign matter, such as snow and mud, adheres to the camera lens.
- The sun or headlights are shining directly into the camera lens.
- The camera lens is damaged by flying stones.

Smear effect



If a bright light, such as sunlight reflected off the vehicle body, is picked up by the camera, a smear effect^{*} characteristic to the camera may occur.

*: Smear effect — A phenomenon that occurs when a bright light is picked up by the camera; when transmitted by the camera, the light source appears to have a vertical streak above and below it. The vertical streak also appears in the masked areas.

CAUTION

When using the wide view front & side monitor system

Observe the following precautions to avoid an accident that could result in death or serious injuries.

- Never depend solely on the monitor system.
- Always check visually and with the mirrors to confirm your intended path is clear.
- Depicted distances between objects and flat surfaces differ from actual distances.
- Do not use the system if the hood or doors are open.

CAUTION

Conditions which may affect the wide view front & side monitor system

- If the front of the vehicle or the passenger side outside rear view mirror has been hit, the camera's position and mounting angle may have changed. Have the vehicle inspected by your Toyota dealer.
- Rapid temperature changes, such as when hot water is poured on the vehicle in cold weather, may cause the system to function abnormally.
- If the camera lens is extremely dirty, it cannot transmit a clear image. Rinse with water and wipe with a soft cloth. If the camera lens is extremely dirty, wash with a mild cleanser and rinse.
- The displayed image may be darker and moving images may be slightly distorted when the system is cold.
- Situations unsuitable for wide view front & side monitor
 - On icy or slick road surfaces, or in snow
 - When using tire chains or emergency tires.
 - On roads that are not flat or straight such as curves or slopes.
- If the tires are changed, the position of the guide lines displayed on the screen may be incorrect. When changing the tires, consult your Toyota dealer.
- Depending on the orcumstances of the vehicle (number of passengers, amount of luggage, etc.), the position of the guide lines displayed on the screen may change. Be sure to check visually behind and all around the vehicle before proceeding.

When using the wide view front & side monitor

Even if an obstacle is no longer visible on the side monitor, do not turn the steering wheel further in the direction the vehicle is turning until the vehicle has moved completely past the obstacle. If the steering wheel is turned to full lock, the vehicle will turn in the smallest possible turning circle, and may collide with the obstacle.

To help enhance driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface

Multi Terrain ABS (Anti-lock Brake System) (vehicles with a Multi-terrain Select system)

→Refer to the "Off-road Driving Owner's Manual" •

Brake assist

Generates an increased level of braking force after the brake pedal is depressed when the system detects a parts stop situation

VSC (Vehicle Stability Control)

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces

TRC (Traction Control) for H4 mode

Helps to maintain drive power and prevent the 4 wheels from spinning when starting the vehicle or accelerating on slippery roads

Active TRC (Traction Control) for L4 mode*

→Refer to the "Off-road Driving Owner's Manual"

Hill-start assist control (if equipped)

→Refer to the "Off-road Driving Owner's Manual"

KDSS (Kinetic Dynamic Suspension System) (if equipped)


→Refer to the "Off-road Driving Owner's Manual"

PCS (Pre-Crash Safety system) (if equipped)

→P. 284

*: The function only works in vehicles with Multi-terrain Select when Multi terrain Select is switched on

When the VSC/TRC systems are operating




If the vehicle is in danger of slipping or if any of the drive wheels spins, the slip indicator flashes to indicate that the VSC/TRC systems are operating.

A buzzer (intermittent) sounds to indicate that VSC is operating.

Disabling the TRC/VSC systems

If the vehicle gets stuck in fresh snow or muc, the TRC/VSC systems may reduce power from the engine to the wheels. You may need to turn the system off to enable you to tock the vehicle in order to free it.






To turn the TRC system off, quickly press and release the button.

The "TRC OFF" indicator light will come on or the TRC OFF will be shown on the multi-information display.

Press the button again to turn the system back on.

- *1: Vehicles with an optitron type meters
- *2: Vehicles with a non-optitron type meters

Turning off both TRC and VSC systems



To turn the TRC and VSC systems off, press and hold the button for 3 seconds and more while the vehicle is stopped.

The VSC OFF indicator light will come on and the "TRC OFF" indicator light will come on or TRC OFF will be shown on the multiinformation display.

Press the button again to turn the system back on.

¹: Vehicles with an optitron type meters

Vehicles with a non-optitron type meters

Sounds and vibrations caused by the ABS, brake assist, VSC and TRC systems

- A sound may be heard from the engine compartment when the engine is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has occurred in any of these systems.
- Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.
 - Vibrations may be felt through the vehicle body and steering.
 - A motor sound may be heard after the vehicle comes to a stop.
 - The brake pedal may pulsate slightly after the ABS is activated.
 - The brake pedal may move down slightly after the ABS is activated.

Reactivation of the TRC/VSC systems after turping off the engine

Turning off the engine after turning off the **TREASE** systems will automatically reactivate them.

Reactivation of the TRC system linked wehicle speed


When only the TRC system is turned of, the TRC system will turn on when vehicle speed increases. However, when both TRC and VSC systems are turned off, the systems will not turn on even when vehicle speed increases.

When the brake system operates continuously

The brake actuator may overheat. In this case, the TRC and VSC will stop operating, a buzzer will sound and the "TRC OFF" indicator will come on (non-optitron type meters) or the TRC OFF will be shown on the multi-information display (optitron type meters). Refrain from using the system until the "TRC OFF" indicator turns off (non-optitron type meters) or the message goes off (optitron type meters). (There is no problem with continuing normal driving.)

If the slip indicator comes on...

It may indicate a malfunction in the VSC or TRC system. Consult your Toyota dealer.



CAUTION

When the TRC/VSC systems are turned off

Be especially careful and drive at a speed appropriate to the road conditions. As these are the systems to help enhance vehicle stability and driving force, do not turn the TRC/VSC systems off unless necessary.

Replacing tires

Make sure that all tires are of the same size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the recommended tire inflation pressure level.

The ABS and VSC will not function correctly if different tites are installed on the vehicle.

Contact your Toyota dealer for further information when replacing tires or wheels.

Handling of tires and the suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause the system to malfunction.

When the radar sensor detects the possibility of a frontal collision, the pre-crash safety systems such as the brakes and seat belts are automatically engaged in an attempt to lessen impact and injuries to occupants as well as vehicle damage.

Pre-crash seat belts

If the pre-crash sensor detects that a collision is unavoidable, the pre-crash safety system will retract the seat belt before the collision occurs.

The same will happen if the driver makes an emergency braking or loses control of the vehicle. $(\rightarrow P. 92)$

However, when the VSC system is disabled, the system will not operate in the event of skidding.

Pre-crash brake assist

When there is a high possibility of a frontal collision, the system applies greater braking force in relation to how strongly the brake pedal is depressed


Pre-crash braking

When there is a high possibility of a frontal collision, the system warns the driver using a warning light, warning display and buzzer. If the System determines that a collision is unavoidable, the brakes are automatically applied to reduce the collision speed. Pre-crash braking can be disabled using the pre-crash braking off switch.

AVS (Adaptive Variable Suspension System) control (if equipped)

When the system determines that there is a high possibility of a frontal collision, the AVS optimizes the damping effect \rightarrow Refer to the "Off-road Driving Owner's Manual"


Disabling pre-crash braking



- 1 Pre-crash braking disabled
- 2 Pre-crash braking enabled

The "PCS" warning light turns on when pre-crash braking is disabled.

Radar sensor



The radar sensor detects vehicles or other obstacles on or near the road ahead and determines whether a collision is imminent based on the position, speed, and heading of the obstacles.

When driving

The pre-crash safety system is operational when

- Pre-crash seat belts (situation 1):
 - Vehicle speed is greater than about 5 km/h (4 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle ahead is greater than about 30 km/h (19 mph).
 - The front occupants are wearing a seat belt.
- Pre-crash seat belts (situation 2):
 - Vehicle speed greater than about 30 km/h (19 mph).
 - The system detects sudden braking or skidding.
 - The front occupants are wearing a seat belt.
- Pre-crash brake assist:
 - Vehicle speed is greater than about 30 km/h (19 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle ahead is greater than about 30 km/h (19 mph).
 - The brake pedal is depressed.
- Pre-crash braking:
 - The pre-crash braking off switch is not pressed.
 - Vehicle speed is greater than about 15 km/h (10 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle ahead is greater than about 15 km/h (10 mph).
- AVS (Adaptive Variable Suspension System) control (if equipped):
 - Vehicle speed is greater than about 5 km/h (4 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle ahead is greater than about 30 km/h (19 mph).

Conditions that may trigger the system even if there is no possibility of a collision

- •When there is an object by the roadside at the entrance to a curve
- When passing an oncoming vehicle on a curve
- When driving over a narrow iron bridge
- When there is a metal object on the road surface
- When driving on an uneven road surface
- When passing an oncoming vehicle on a right-turn
- When your vehicle rapidly closes on the vehicle in front
- When a grade separation/interchange, sign, billboard, or other structure appears to be directly in the vehicle's line of travel
- When a billboard or other metallic structure appears to be in the direct line of travel due to driving on a hill.
- When an extreme change in vehicle height occurs
- When the axis of the radar is out of adjustment
- When passing through certain toll gates
- When driving on a bridge

When the system is activated in the situations described above, there is also a possibility that the sear belts will retract quickly and the brakes will be applied with a force greater than normal. When the seat belt is locked in the restricted position, stop the vehicle in a safe place, release the seat belt and refasten it.

Situations in which the pre-crash safety system does not function properly

The system may not function effectively in situations such as the following:

- On roads with sharp bends or uneven surfaces
- If a vehicle suddenly moves in front of your vehicle, such as at an intersection
- If a vehicle suddenly cuts in front of your vehicle, such as when overtaking
- In inclement weather such as heavy rain, fog, snow or sand storms
- When your vehicle is skidding with the VSC system off
- When an extreme change in vehicle height occurs
- When the axis of the radar is out of adjustment

Automatic cancelation of Pre-crash safety system

When a malfunction occurs due to sensor contaminations, etc. that results in the sensors being unable to detect obstacles, the pre-crash safety system will be automatically disabled. In this case, the system will not activate even if there is a collision possibility.

Obstacles not detected

The sensor cannot detect plastic obstacles such as traffic cones. There may also be occasions when the radar sensor cannot detect pedestrians, animals, bicycles, motorcycles, trees, or snowdrifts.

When there is a malfunction in the system

Warning lights and/or warning messages will turn on or flash. (\rightarrow P. 547)

CAUTION

Limitations of the pre-crash safety system

Do not overly rely on the pre-crash safety system. Always drive safely, taking care to observe your surroundings and checking for any obstacles or other road hazards.

Failure to do so may cause an accident resulting in death or serious injury.

Cautions regarding the assist contents of the system

By means of alarms and brake control, the pre-crash safety system is intended to assist the driver in avoiding collisions through the process of LOOK-JUDGE-ACT. There are limits to the degree of assistance the system can provide, so please keep in mind the following important points.

• Assisting the driver in watching the road


The pre-crash safety system is only able to detect obstacles directly in front of the vehicle, and only within a limited range. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for the driver to pay close attention to the vehicle surroundings.

Assisting the driver in making correct judgment

When attempting to estimate the possibility of a collision, the only data available to the pre-crash safety system is that from obstacles it has detected directly in tront of the vehicle. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of collision in any given situation.

Assisting the driver in taking action

The pre-crash safety system's braking assist feature is designed to help reduce the severity of a collision, and so only acts when the system has judged that a collision is unavoidable. This system by itself is not capable of automatically avoiding a collision or bringing the vehicle to a stop safety. For this reason, when encountering a dangerous situation the driver must take direct and immediate action in order to ensure the safety of all involved.




Take notice of the following information about storage precautions, cargo capacity and load:

- Stow cargo and luggage in the luggage compartment whenever possible.
- Be sure all items are secured in place.
- To maintain vehicle balance while driving, position luggage evenly within the luggage compartment.

ductio • For better fuel economy, do not carry unnecessary weight.

Roof luggage carrier (if equipped) Roof luggage carrier components



CAUTION

Things that must not be carried in the luggage compartment

The following things may cause a fire if loaded in the luggage compartment:

- Receptacles containing gasoline
- Aerosol cans

CAUTION

Storage precautions

Observe the following precautions.

Failure to do so may result in death or serious injury.

- Stow cargo and luggage in the luggage compartment whenever possible.
- Do not stack anything in the luggage compartment higher than the seatbacks.

Such items may be thrown about and possibly injure people in the vehicle in the event of a sudden braking, sudden swerving or an accident.

 Do not place cargo or luggage in or on the following locations as the item may get under the clutch, brake or accelerator pedat and prevent the pedals from being depressed properly, block the driver's vision, or hit the driver or passengers, causing an accident:

- · At the feet of the driver
- On the front passenger or rear seats (when stacking items)
- On the luggage cover
- On the instrument panel
- On the dashboard
- Secure all items in the occupant compartment, as they may shift and injure someone in the event of sudden braking, sudden swerving or an accident.
- When you fold down the rear seats, long items should not be place directly behind the from seats.

• Never allow anyone to ride in the luggage compartment. It is not designed for passengers. They should ride in their seats with their seat belts properly fastened. Otherwise, they are much more likely to suffer death or serious bodily injury, in the event of a sudden braking, sudden swerving or an accident.

Roof luggage carrier precautions

To use the roof rails as a roof luggage carrier, you must fit the roof rails with two or more genuine Toyota cross rails or their equivalent.

Follow the manufacturer's instructions and precautions when installing the cross rails or their equivalent.

A CAUTION Load and distribution Do not overload vour vehicle. Do not apply loads unevenly. Improper loading may cause deterioration of steering or braking control which may cause death or serious injury. When loading cargo Observe the following precautions: Place the cargo so that its weight is distributed evenly between the front and rear axles If loading long or wide cargo, never exceed the vehicle overall length or width. (\rightarrow P. 608) Before driving, make sure the cargo is securely fastened on the roof luggage carrier. Loading cargo on the roof luggage carrier will make the center of gravity of the vehicle higher. Avoid high speeds, sudden starts, sharp turns, sudden braking or abrupt maneuvers, otherwise it may result in loss of control or vehicle rollover due to failure to operate this vehicle correctly and result in death or serious injury. • If driving for a long distance, on rough roads, or at high speeds, stop the vehicle now and then during the trip to make sure the cargo remains in its place. Do not exceed 80 kg (176 lb.) cargo weight on the roof luggage carrier.

When loading cargo (vehicles with a moon roof)

Be careful not to scratch the surface of the moon roof.

When driving

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

Pre-winter preparations

- Use fluids that are appropriate to the prevailing outside temperatures.
 - Engine oil
 - Engine coolant
 - Washer fluid
- Have a service technician inspect the level and specific gravity of battery electrolyte.
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the rear tires.

Ensure that all tires are the same size and brand, and that chains match the size of the tires.

Before driving the vehicle

Perform the following according to the driving conditions:

- Do not try to forcibly open a window or move a wiper that is frozen. Pour warm water over the frozen area to melt the ice.
 Wipe away the water immediately to prevent it from freezing.
- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Remove any ice that has accumulated on the vehicle chassis.
- Periodically check for and remove any excess ice or snow that may have accumulated in the wheel well or on the brakes.

When driving the vehicle


Accelerate the vehicle slowly and drive at a reduced speed suitable to road conditions.

When parking the vehicle (in the winter time or in the cold latitudes)

Park the vehicle and move the shift lever to P (automatic transmission) or 1 or R (manual transmission) without setting the parking brake. The parking brake may freeze up, preventing it from being released. If necessary, block the wheels to prevent inadvertent sliding or creeping.

Selecting tire chains

Use the correct tire chain size when mounting the snow chains. Chain size is regulated for each the size.



1 Side chain

ang

(5 mm [0.20 in.] in diameter)

2 Cross chain

(6.3 mm [0.25 in.] in diameter)

Regulations on the use of tire chains

Regulations regarding the use of tire chains vary depending on location and type of road. Always check local regulations before installing chains.

Tire chain installation

Observe the following precautions when installing and removing chains:

- Install and remove tire chains in a safe location.
- Install tire chains on the rear tires. Do not install tire chains on the front tires.
- Install tire chains on rear tires as tightly as possible. Retighten chains after driving 0.5 - 1.0 km (1/4 - 1/2 mile).
- Install tire chains following the instructions provided with the tire chains.

CAUTION

Driving with snow tires

Observe the following precautions to reduce the risk of accidents. Failing to do so may result in a loss of vehicle control and cause death or serious injury.

Use tires of the specified size.

- Maintain the recommended level of air pressure.
- Do not drive at speeds in excess of the speed limit or the speed limit specified for the snow tires being used.
- Use snow tires on all, not just some wheels.

Driving with tire chains

Observe the following precautions to reduce the risk of accidents. Failing to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used, or 50 km/h (30 mph), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden turns and braking, as use of chains may adversely affect vehicle handling.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.

Your vehicle is designed primarily as a passenger-and-load carrying vehicle. Towing a trailer will have an adverse effect on handling, performance, braking, durability, and fuel consumption. For your safety and the safety of others, do not overload the vehicle or trailer.

Toyota warranties do not apply to damage or malfunction caused by towing a trailer for commercial purposes.

For towing purposes, Toyota recommend use of the following parts:

- When towing a caravan trailer etc., use a distributing hitch.
- When the total trailer weight is greater than the chicle weight, use a sway control device.

Weight limits

Confirm that the total trailer weight, goes vehicle weight, gross axle weight and trailer tongue load are all within the limits.

Gross vehicle weight

The gross vehicle weight must not exceed the following:

2900 kg (6393 lb.): 1 CR engine 2990 kg (6592 b): 1 KD engine (5-door models) 2600 kg (5732 lb.): 1 KD engine (3-door models)

The gross vehicle weight is the sum weight of the unloaded vehicle, driver, passengers, luggage, hitch and trailer tongue load. Also included is the weight of any special equipment installed on your vehicle.

Gross axle weight

The load on either the front or rear axle resulting from distribution of the gross vehicle weight on both axles must not exceed the following:

Front: 1450 kg (3197 lb.) Rear: 1800 kg (3968 lb.)


Trailer tongue load

The trailer cargo load should be distributed so that the tongue load is 9 to 11 % of the total trailer weight, not exceeding the following:

250 kg (551 lb.): 1GR and 1KD engines (5-door models) 300 kg (661 lb.): 1KD engine (3-door models)

(Tongue load/Total trailer weight x100 = 9 to 11 %)

The total trailer weight and tongue load can be measured with platform scales found at a highway weighing stations, building supply companies, trucking companies, junk yards, etc.



Hitch

Trailer hitch assemblies have different weight capacities established by the hitch manufacturer. Even though the vehicle may be rated for towing a higher weight, the operator must never exceed the maximum weight rating specified for the trailer hitch.

Connecting trailer lights

Use the wire harness stored in the rear end under the jack.

When connecting and disconnecting a trailer (vehicles with rear height control air suspension)

Connecting

- STEP 1 Set the rear height control air suspension to LO mode.
- STEP 2 Turn off the "ENGINE STAR STOP" switch or the rear height control air suspension.
- STEP 3 Connect the trailer.
- STEP 4 Turn on the switch that was turned off on step 2.
- STEP 5 Set the rear height control air suspension to N mode.

Disconnecting

- STEP 1 Set the rear height control air suspension to LO mode.
- STEP 2 Turn off the rear height control air suspension.
- STEP 3 Turn off the "ENGINE START STOP" switch.
- STEP 4 Set the supporting leg of a trailer on the ground and raise the hitch by 100 mm (4 in.).
- STEP 5 Turn on the "ENGINE START STOP" switch.
- STEP 6 Turn on the rear height control air suspension.
- STEP 7 Wait until vehicle height is stabilized.

Make sure the hitch is disconnected. If the hitch does not disconnect, raise the hitch higher and repeat steps 2 through 7.

Before towing

Check that the following conditions are met:

- The vehicle's tires are properly inflated. (\rightarrow P. 622)
- Trailer tires are inflated according to the trailer manufacturer's recommendation.
- All trailer lights work.
- All lights work each time you connect them.
- The trailer ball is set up at the proper height for the coupler on the trailer.
- The vehicle remains level when a loaded or unloaded trailer is hitched. Do not drive if the vehicle is not level, and check for improper tongue load, overloading, worn suspension, or other possible causes.
- The trailer cargo is securely loaded.
- The rear view mirrors conform to all applicable federal, state/provincial or local regulations. If they do not, install reactive mirrors appropriate for towing purposes.

Break-in schedule

Toyota recommends that you do not use a new vehicle or a vehicle with any new power train components (engine, transmission, differential, wheel bearings, etc.) to tow a trailer for the first 800 km (500 miles) of driving.

Maintenance

- If you tow a trailer, your vehicle will require more frequent maintenance due to the additional load. (See "Warranty and Service Booklet".)
- Retighten the fixing bolts of the towing ball and bracket after approximately 1000 km (600 miles) of trailer towing.

When using a weight carrying hitch

The gross vehicle weight value will differ when the weight carrying hitch is in use (only on models listed below).

When using the weight carrying hitch, an amount up to the total trailer weight can be towed by reducing the number of passengers.

Refer to the table below for the passenger numbers of each model.

5-door 7-seat models

Model	Sub fuel	Maximum seating capacity			Gross vehicle	
code ^{*1}	tank	Front seats	Second seats	Third seats	weight (kg, lb.)	
	With	2	3	<u>.</u> .0	2880 (6350) ^{*2}	
	Without	2	3		2910 (6417) ^{*3}	
KDJ150R -GKAEYQ	With	2	3	0	2970 (6549) ^{*3}	
GIVIETQ	Without	2	.70	0	2920 (6439) ^{*4}	
	With	2	3	0	2980 (6571) ^{*4}	
KDJ150R -GKFEYQ	With	8-°	3	0	2870 (6328) ^{*2}	
GRJ150R -GKAEKQ	With	2	3	0	2800 (6174) ^{*2}	
	Without	2	3	0	2835 (6251) ^{*3}	
	With	2	3	0	2890 (6372) ^{*3}	
	Without	2	3	0	2845 (6273) ^{*4}	
	With	2	3	0	2900 (6395) ^{*4}	
GRJ150R -GKFEKQ	With	2	3	0	2790 (6152) ^{*2}	


3-door models

Model code ^{*1}	Maximum sea	Gross vehicle	
Model code	Front seats	Second seats	weight (kg, lb.)
KDJ155R-GJAEYW	2	1	2575 (5678) ^{*5}
KDJ155K-GJAETW	2	1	2590 (5711) ^{*6}

*1: Model code is indicated on the Certification Label. (\rightarrow P. 609)

- *2: Vehicles standard with 265/65R17 tires
- *3: Vehicles standard with 265/60R18 tires without electronically modulated air suspension system
- *4: Vehicles with electronically modulated air suspension system
- *5: Vehicles with intermittent wind shield wipers with interval adjuster





A CAUTION

When towing a trailer

- If the total trailer weight exceeds 750 kg (1653 lb.), trailer brakes are required.
- Never tap into your vehicle's hydraulic system, as this will lower the vehicle's braking effectiveness.
- Never tow a trailer without using a safety chain securely attached to both the trailer and the vehicle. If damage occurs to the coupling unit or hitch ball, there is a risk of the trailer wandering into another lane.

▲ NOTICE

When installing a trailer hitch

- ductic Use only the position recommended by your Toyota dealer. Do not install the trailer hitch on the bumper; this may cause body damage.
- Do not use axle-mounted hitches as they can cause damage to the axle housing, wheel bearings, wheels or tires.

Brakes

Toyota recommends trailers with brakes that conform to all applicable federal and state/provincial regulations.

Do not directly splice trailer lights

Directly splicing trailer lights may damage your vehicle's electrical system and cause a malfunction.

Trailer towing tips

Your vehicle will handle differently when towing a trailer. The 3 main causes of vehicle-trailer accidents are driver error, excessive speed and improper trailer loading. Keep the following in mind when towing:

- Before starting out, check the trailer lights and the vehicle-trailer connections. Recheck after driving a short distance.
- Practice turning, stopping and reversing with the trailer attached in an area away from traffic until you become accustomed to the feel of the vehicle.
- Reversing with a trailer attached is difficult and requires practice. Grip the bottom of the steering wheel and move your hand to the left to move the trailer to the left. Move your hand to the right to move the trailer to right. (This is generally opposite to reversing without a trailer attached.) Avoid sharp or prolonged turning. Have someone guide you when reversing to reduce the risk of an accident.
- As stopping distance is increased when towing a trailer, vehicle-tovehicle distance should be increased. For each 10 km/h (6 mph) of speed, allow at least one vehicle and trailer length.
- Avoid sudden braking as you may skid, resulting in jackknifing and loss of control. This is especially true on wet or slippery surfaces.
- Avoid jerky starts or sudden acceleration.
- Avoid jerky steering and sharp turns, and slow down before making turns.
- Note that when making a turn, the trailer wheels will be closer than the vehicle wheels to the inside of the turn. Compensate by making a larger than normal turning radius.

- Crosswinds and rough roads will adversely affect handling of your vehicle and trailer, causing sway. Periodically check the rear to prepare for being passed by large trucks or buses, which may cause your vehicle and trailer to sway. If swaying occurs, firmly grip the steering wheel, reduce speed immediately but gradually, and steer straight ahead. Never increase speed. If you make no extreme correction with the steering or brakes, your vehicle and trailer will stabilize.
- Take care when passing other vehicles. Passing requires considerable distance. After passing a vehicle, do not forget the length of your trailer, and be sure you have plenty of room before changing lanes.
- In order to maintain efficient engine braking and electrical charging performance, do not use 6th gear (manual) or overdrive (automatic). On vehicles with an automatic transmission: Transmission shift range position must be in 4, in S mode.
- Due to the added load of the trailer, your vehicle's engine may overheat on hot days (at temperatures over 30 °C [85 °F]) when driving up a long or steep grade. If the engine coolant temperature gauge indicates overheating, immediately turn off the air conditioning (if in use), pull your vehicle off the road and stop in a safe spot. (→P. 599)
- Always place wheel blocks under both the vehicle and the trailer wheels when parking. Apply the parking brake firmly, and put the transmission in P (automatic transmission) or in the 1st or R (manual transmission). Avoid parking on a slope, but if unavoidable, do so only after performing the following:

- STEP 1 Apply the brakes and keep them applied.
- STEP 2 Have someone place wheel blocks under both the vehicle and trailer wheels.
- STEP 3 When the wheel blocks are in place, release the brakes slowly until the blocks absorb the load.
- STEP 4 Apply the parking brake firmly.
- STEP 5 Shift into the 1st or R (manual transmission) or P (automatic transmission) and turn off the engine.

• When restarting after parking on a slope:



- STEP 1 With the transmission in the P position (automatic transmission) or the clutch pedal (manual transmission) depressed, start the engine. On vehicles with an automatic transmission, be sure to keep the brake pedar pepressed.
- STEP 2 Shift into 3, 2, 1, or the R position (if reversing).
- STEP 3 Release the parking brace (also brake pedal on vehicles with an automatic transmission), and slowly pull or back away from the wheel blocks. Stop and apply the brakes.
- STEP 4 Have someone retrieve the blocks.

To avoid an accident

- Observe the legal maximum speeds for trailer towing.
- Slow down and downshift before descending steep or long downhill grades. Do not make sudden downshifts.
- Avoid holding the brake pedal down too long or applying the brakes too frequently. This could cause the brakes to overheat and result in reduced braking efficiency.

When driving

3-1.	Using the air conditioning system and defogger
	Front manual air conditioning system 310
	Front autor and air conditioning system
	Rear vielnual air conditioning
A.	system 329
act.	Heater idle up switch 332 Rear window defogger
d'r	switch 333
3-2.	Using the audio system
	Audio system types 335
	Using the radio 337
4	Using the CD player 340 Playing MP3 and

Operating a USB

Optimal use of the audio

Interior features

3

3-3. Using the hands-free system (for mobile phone)

	Hands-free system	202	
	(for mobile phone)		
	Using the hands-free syste		
	(for mobile phone)	386	ł
	Making a phone call	392	
	Setting a mobile phone	395	6
	Security and system		
	setup	398	1
	Using the phone book	401	(
3-4.	Using the interior lights	~	
	Interior lights list	405	
	Personal/interior light		ł
	main switch	406	ľ

Interior lights list	405
Personal/interior light	
main switch	406
Personal/interovlights	407

3-5. Using the storage features

List of storage features	41	0
• Glove box	41	1
Card holder	41	2

- Console t 0 413
- Bottle itolders/door

pockets	11	5
pockets	41	J


Cup holde	rs	416
-----------	----	-----

P	yuxi	iliary	boxes		420
---	------	--------	-------	--	-----


Other interior features	
Cool box 4	23
Sun visors 4	26
Vanity mirror 4	27
Clock 4	28
Outside temperature	
display 4	29
Ashtray 4	31
Conversation mirror 4	32
Power outlet 4	33
Seat heaters 4	37
Armrest 4	40
Coat hooks 4	41
Floor mat 4	42
Luggage compartment	

lyyaye compariment	
eatures	444

3-1. Using the air conditioning system and defogger **Front manual air conditioning system**^{*}




If the "A/C" button is not pressed, the system will blow ambient temperature air or heated air.



Some models


311

Interior features




The mode switches between outside air mode (introduces air from outside the vehicle) (indicator off) and recirculated air mode (recycles air inside the vehicle) (indicator on) each time the button is pressed.

Defogging the windshield




Front side outlets



- Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

Rear outlets (vehicles without a rear manual ar conditioning system)



Using the system in recirculated air mode

The windows will fog up more easily if recirculated air mode is used for an extended period of time.

When driving on dusty roads


Close all windows. If dust thrown up by the vehicle is still drawn into the vehicle after closing the windows, it is recommended that the air intake mode be set to outside air mode and the fan speed to any setting except off.

When the indicator light on the "A/C" button flashes

Press the "A/C" button to turn off the cooling and dehumidification function and turn it on again. There may be a problem in the air conditioning system if the indicator light continues to flash. Turn the air conditioning system off and have it inspected by your Toyota dealer.


When outside air temperature is below 0 °C (32 °F)

The cooling and dehumidification function may not operate even when the "A/C" button is pressed.



3-1. Using the air conditioning system and defogger **Front automatic air conditioning system***

Air outlets and fan speed are automatically adjusted according to the temperature setting.



Using the automatic air conditioning system

STEP 1 Press the "AUTO" button.

The air conditioning system begins to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.

STEP 2 Turn the "TEMP" knob (driver's side) clockwise to increases the temperature and turn the "TEMP" knob (driver's side) counterclockwise to decreases the temperature.

When the "DUAL" button is pressed (the indicator on the "DUAL" button is on) or the passenger's side temperature control knob is turned, the temperature for the driver and passenger seats can be adjusted separately.

Adjusting the settings manually

speed, press

Basic setting

STEP 1 To turn on the air conditioning system and adjust the fan

to increase the fan speed and " \checkmark "

to decrease the fan speed.


Pres**s** 🗮 to turn the fan off.

STEP 2 To adjust the temperature setting, turn the "TEMP" knob (driver's side) clockwise to increases the temperature and turn the "TEMP" knob (driver's side) counterclockwise to decreases the temperature.


> When the "DUAL" button is pressed (the indicator on the "DUAL" button is on) or the passenger's side temperature control knob is turned, the temperature for the driver and passenger seats can be adjusted separately.

STEP 3 To change the air outlets, press the air outlet selector button.

The air outlets used are switched each time the button is pressed. The air flow shown on the display indicates the following:




*1: Only in the automatic mode (Air may not always flow.)




: Some models


Air flows to the upper body and feet.





The mode switches between outside air mode (introduces air from outside the vehicle) (indicator off) and recirculated air mode (recycles air inside the vehicle) (indicator on) each time the button is pressed.



Defogging the windshield








Operates pollen removal mode on/off.

Outside air mode switches to recirculated air mode. Pollen is removed from the air and the air flows to the upper part of the body.


Usually the system will turn off automatically after approximately 3 minutes.

Adjusting the position and opening and closing the air outlets

Front center outlets



Rear outlets (vehicles without a rear automatic air conditioning system)



- Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

Using automatic mode

Fan speed is adjusted automatically according to the temperature setting and ambient conditions. As a result, the following may occur.

- Immediately after the switch is pressed, the fan may stop for a while until warm or cool air is ready to flow.
- Cool air may flow to the area around the upper body when the heater is on.

Switching between outside air and recirculated air modes

Recirculated air mode or outside air mode may be automatically switched to in accordance with the temperature setting, inside temperature, outside temperature, etc.

Using the system in recirculated air mode

The windows will fog up more easily if the regirculated air mode is used.

Window defogger feature

Recirculated air mode may automatically switch to outside air mode in situations where the windows need to be delogged.

Pollen removal mode

- In order to prevent the windows from fogging up when the outside air is cold, the following may occur.
 - Outside air mode does not switch to recirculated air mode.
 - The air conditioning system operates automatically.
 - The operation cancels after 1 minute.

When driving on dusty roads

Close all windows. If dust thrown up by the vehicle is still drawn into the vehicle after closing the windows, it is recommended that the air intake mode be set to outside air mode and the fan speed to any setting except off.

When the indicator light on the "A/C" button flashes

Press the "A/C" button to turn off the cooling and dehumidification function and turn it on again. There may be a problem in the air conditioning control system if the indicator light continues to flash. Turn the air conditioning system off and have it inspected by your Toyota dealer.

When outside air temperature is below 0 °C (32 °F)

The cooling and dehumidification function may not operate even when the "A/C" button is pressed.

Using the rear automatic air conditioning system

- When the rear automatic air conditioning system is on, the indicator light on the "REAR" button is turned on.
- If the system is left untouched for approximately 10 seconds after changing to the rear automatic air conditioning system, the control mode in the front control panel returns to the front.

Air conditioning odors

- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring:
 - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
 - The start timing of the blower may be delayed for a short period of time immediately after the air conditioning system is started in automatic mode.

Customization


Settings (e.g. A/C automatic mode button operation) can be changed. (Customizable features \rightarrow P. 626)

CAUTION


To prevent the windshield from fogging up

Do not use Je during cool air operation in extremely humid weather. The


difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.



3-1. Using the air conditioning system and defogger **Rear manual air conditioning system**^{*}



Air flows as shown below according to the mode selected.




Adjusting the fan speed

Turn the air volume control knob clockwise (increase) or counterclockwise (decrease).

Adjusting the position of and opening and closing the air outlets

Roof side outlets



- Direct air flow to the left or right, up or down.
- 2 Turn the knob fully to the back of the vehicle to close the vent.


NOTICE

To prevent battery discharge

duction Do not leave the air conditioning system on longer than necessary when the engine is stopped.

3-1. Using the air conditioning system and defogger **Rear automatic air conditioning system***

Air outlets and fan speed are automatically adjusted according to the temperature setting.



The air conditioning system will operate, and air outlets and fan speed will be adjusted automatically.


STEP 2 Press *** on the "TEMP" button to increase the temperature and ** to decrease the temperature.


Adjusting the settings manually

Adjusting the temperature setting

Press " \land " on the "TEMP" button to increase the temperature and " \lor " to decrease the temperature.

Changing the air outlets






To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is stopped.

Interior features

3-1. Using the air conditioning system and defogger Heater idle up switch^{*}

This feature is used to boost heating effect in extremely cold conditions when the vehicle is not moving.




Press the switch to increase engine speed.

Press the switch again to return the engine to the normal idle speed. If you do not turn the switch to off, the engine speed is increased whenever the engine is started.

- The engine is running.
 The engine coolant temperature from.

Defoggers are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors (if equipped).


Vehicles with a front manual air conditioning system



- ▲ Vehicles without the outside rear view mirror defoggers
- Vehicles with the outside rear view mirror defoggers
- Turns the defoggers on/off

The deforgers will automatically turn of after their operation time. The operation time is between 15 minutes and 270 minutes depending on the ambient temperature and vehicle speed.

Vehicles with a front automatic air conditioning system



- Vehicles without the outside rear view mirror defoggers
- Vehicles with the outside rear view mirror defoggers

Turns the defoggers on/off

The defoggers will automatically turn off after their operation time. The operation time is between 15 minutes and 270 minutes depending on the ambient temperature and vehicle speed.

The defoggers can be operated when

Vehicles without a smart entry & start system The engine switch is in the "ON" position.

Vehicles with a smart entry & start system The "ENGINE START STOP" switch is in IGNITION ON mode.

The outside rear view mirror defoggers (vehicles with the outside rear view mirror defoggers)

Turning the rear window defogger on will turn the outside rear view mirror defoggers on.

CAUTION

When the outside rear view mirror defoggers are on (vehicles with the outside rear view mirror defoggers)

Do not touch the outside surface of the rear view mirrors, as they can become very hot and burn you.

334

3-2. Using the audio system Audio system types^{*}

Vehicles with a navigation system


Refer to the "Navigation System Owner's Manual".

Vehicles without a navigation system

Type A: CD player with AM/FM radio

Type B: CD player with a changer and AM/FM radio

Туре А





Interior features



Title	Page
Using the radio	P. 337
Using the CD player	P. 340
Playing MP3 and WMA discs	P. 349
Operating an iPod	P. 357
Operating a USB memory	P. 365
Optimal use of the audio system	P. 374
Using the AUX port	8 .877
Using the steering switches	P. 379

Using mobile phones

Interference may be heard through the audio system's speakers if a mobile phone is being used inside or close to the vehicle while the audio system is operating.

To prevent battery discharge


Do not leave the audio system on longer than necessary with the engine off.

To avoid damaging the audio system

Take care not to spill drinks or other fluids over the audio system.

3-2. Using the audio system Using the radio





Setting station presets

Manually operation

- STEP 1 Search for the desired stations by turning the "TUNE•SEL" knob or pressing "∧" or "∨" on the "SEEK/TRACK" button.
- STEP 2 Press and hold the button (from the 1 button to the 6 button) the station is to be set to until you hear a beep.

Automatically operation (type B)

Press and hold the "AUTO•P" button until you hear a beep.

Up to 6 stations are set in order of reception quality. When the setting is complete, 2 beeps will be heard.

Press the "AUTO•P" button again to return to the previously set stations. This temporary memory function is useful if you move out of the reception area while driving.

To preset the stations, press and hold each of the 1 button to the 6 button in turn until you hear a beep

Scanning radio stations

- Scanning the preset radio stations
- STEP 1 Press and hold the "SCAN" button until you hear a beep. Preset stations will be played for 5 seconds each.

STEP 2 When the desired station is reached, press the button again.

Scanning all the radio stations within range

STEP 1 Press the "SCAN" button.

All the stations with reception will be played for 5 seconds each.

STEP 2 When the desired station is reached, press the button again.

Silencing the sound (type A)

Press the "MUTE" button.

Press the button again to turn the system back on.

When the battery is disconnected


All preset stations are erased.

Reception sensitivity

- It is difficult to maintain perfect radio reception at all times due to the continually changing position of the antenna, difference in signal strength and surrounding objects, such as trains and transmitters.
- When the "AUTO-P" button is used, automatic station selection and automatic registering of the stations may not be possible. (type B)
- The radio antenna is mounted inside the ear quarter window. To maintain clear radio reception, do not attach metallic window tinting or other metallic objects to the antenna wire mounted inside the rear quarter window.

3-2. Using the audio system Using the CD player





Loading a CD

Loading a CD

Туре А

Insert a CD.

Туре В

STEP 1 Press the "LOAD" button.

"WAIT" is shown on the display.

STEP 2 When the indicator on the slot turns from amber to green, insert a CD.

The display changes from "WAIT" to "LOAP

Loading multiple CDs (type B)

STEP 1 Press and hold the "LOAD" button until you hear a beep.

"WAIT" is shown on the display

STEP 2 When the indicator on the slot turns from amber to green, insert a CD.

The display changes from "WAIT" to "LOAD".

The indicator on the slot turns to amber when the CD is being inserted.

STEP 3 When the indicator on the slot turns from amber to green, insent the next CD.

Repeat the procedure for the remaining CDs.

To cancel the operation, press the "LOAD" button. If you do not insert a disc within 15 seconds, loading will be canceled automatically.


Ejecting CDs

Ejecting a CD

Type A

Press ____ and remove the CD.

Туре В



Selecting, fast-forwarding, reversing and scanning tracks

Selecting a track

Press " \land " to move up or " \lor " to move down using the "SEEK/ TRACK" button until the desired track number is displayed.

Fast-forwarding and reversing tracks

To fast-forward or reverse, press and hold " \land " or " \lor " on the "SEEK/TRACK" button until you hear a beep.

Scanning tracks

STEP 1 Press the "SCAN" button.

The first ten seconds of each track will be playe

To cancel, press the "SCAN" button again

STEP 2 Press the button again when the desired track is reached.

Selecting a CD (type B)

Selecting a CD to play

To select the desired CD, press " \land " or " \lor " on the "CH/DISC" button.

Scanning loaded CDs

STEP 1 Press and hold the "SCAN" button until you hear a beep.

The first ten seconds of the first track on each CD will be played.

To cancel, press the "SCAN" button again.

STEP 2 Press the button again when the desired CD is reached.

Playing and pausing tracks (type B)

To play or pause a track, press the 3 (►■) button.

Random playback

Current CD

Press the 1 (RAND) button.

Songs are played in random order.

To cancel, press the 1 (RAND) button again.

All CDs (type B)

Press and hold the 1 (RAND) button until you hear a beep.

Rep

Tracks on all loaded CDs are played in random order.

To cancel, press the 1 (RAND) button again.

Repeat play

Repeating a track

Press the 2 (RPT) button

To cancel, press the 2 (RPT) button again.

Repeating alof the tracks on a CD (type B)

Press and hold the 2 (RPT) button until you hear a beep.

To cancel, press the 2 (RPT) button again.

Switching the display

Press the "TEXT" button.

Each time the button is pressed, the display changes in the following order: Elapsed time \rightarrow CD title \rightarrow Track title.

Silencing the sound (type A)

Press the "MUTE" button.

Press the button again to turn the system back on.

CD player protection feature

To protect the internal components, playback is automatically stopped when a problem is detected.

Display

Up to 12 characters can be displayed at a time.

If there are 13 or more characters, pressing and holding the "TEXT" button for 1 second or more enables to display the remaining characters.

A maximum of 24 characters can be displayed.

If the "TEXT" button is pressed for more than 1 second again or has not been operated for more than 6 seconds, the display will return to the first 12 characters.

Depending on the contents recorded, the characters may not be displayed properly or may not be displayed at all.

■ When "ERROR" or "WAIT" is shown on the display

- "ERROR": This indicates a trouble either in the CD or inside the player. The CD may be dirty, damaged, or inserted up-side down.
- "WAIT": This indicates that operation is stopped due to a high temperature inside the player. Wait for a while and then press the "CD" or "CD•AUX" button. If the CD still cannot be played back, contact your Toyota dealer.

Discs that can be used

Discs with the marks shown below can be used.

Playback may not be possible depending on recording format or disc feauctio tures, or due to scratches, dirt or deterioration.



Joi


CDs with copy-protect features may not be use

Lens cleaners

Do not use lens cleaners. Doing so may damage the CD player.

If discs are left inside the CD player or in the ejected position for extended periods of time

The discs may be damaged and may not play properly.






 CDs that have tape, stickers or CD-R labels attached to them, or that have had the label peeled off

CD player precautions

Failure to follow the precautions below may result in serious damage to the CDs or the player itself.


- Do not insert anything other than CDs into the Slot
- Do not apply oil to the CD player.
- Store CDs away from direct sunlight.
- Never try to disassemble any part of the CD player.





3-2. Using the audio system Playing MP3 and WMA discs





Interior features

Loading and ejecting MP3 and WMA discs

→P. 341, 342

Selecting MP3 and WMA discs

→P. 343

Selecting and scanning a folder

Selecting a folder one at a time

Press " \land " or " \lor " on the "FOLDER" button or the (\checkmark) or 5 (\lor) button to select the desired folder.

Returning to the first folder

Press and hold " \checkmark " on the "FOLDER" button or the 5 (\lor) button until you hear a beep.

Scanning the first file of all the folders

STEP 1 Press and hold the "SCAN" button until you hear a beep.

The first ten seconds of the first file in each folder will be played.

STEP 2 When the desired folder is reached, press the "SCAN" button again.

Fast-forwarding and reversing files

To fast-forward or reverse, press and hold " \land " or " \lor " on the "SEEK/ TRACK" button until you hear a beep.

Selecting and scanning files Selecting a file

Turn the "TUNE•SEL" knob or press " \wedge " or " \vee " on the "SEEK/ TRACK" button to select the desired file.

Scanning the files in a folder (type B)

Press the "SCAN" button.

The first ten seconds of each file will be played.

To cancel, press the "SCAN" button again.

When the desired file is reached, press the "SCAN" button again.

Playing and pausing files (type B)

To play or pause a file, press the 3 () button.

Random playback

Playing files from a folder in random order Press the 1 (RAND) botton.

To cancel, press the 1 (RAND) button again.

Playing all the files from a disc in random order

Press and hold the 1 (RAND) button until you hear a beep.

To cancel, press the 1 (RAND) button again.

Repeat play

Repeating a file

Press the 2 (RPT) button.

To cancel, press the 2 (RPT) button again.

Repeating all the files in a folder

Press and hold the 2 (RPT) button until you hear a beep.

To cancel, press the 2 (RPT) button again.

Switching the display

Press the "TEXT" button.

Each time the button is pressed, the display changes in the following order: Folder no./File no./Elapsed time \rightarrow Folder name \rightarrow File name \rightarrow Album title (MP3 only) \rightarrow Track title \rightarrow Artist name

Silencing the sound (type A)

Press the "MUTE" button

Press the button again to turn the system back on.

CD player protection feature

 $\rightarrow P 345$

Display

→P. 345

When "ERROR", "WAIT" or "NO MUSIC" is shown on the display

- "ERROR": This indicates a problem either in the CD or inside the player. The CD may be dirty, damaged, or inserted up-side down.
- "WAIT": This indicates that operation is stopped due to a high temperature inside the player. Wait for a while and then press the "CD" or "CD•AUX" button. If the CD•stillcannot be played back, contact your Toyota dealer.

"NO MUSIC": This indicates that an MP3/WMA file is not included in the CD.

Discs that can be used

→P 346

Lens cleaners

→P 346

Reprod If discs are left inside the player or in the ejected position for extended periods of time

→P. 346

MP3 and WMA files

MP3 (MPEG Audio LAYER3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size by using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

There is a limit to the MP3 and WMA file standards that can be used and to the media/formats on which the files are recorded.

- MP3 file compatibility
 - Compatible standards MP3 (MPEG1 LAYER3, MPEG2 LSF LAYER3)
 - Compatible sampling frequencies MPEG1 LAYER3: 32, 44.1, 48 (kHz) MPEG2 LSF LAYER3: 16, 22.05, 24 (kHz)
 - Compatible bit rates (compatible with VBR) MPEG1 LAYER3: 64, 80, 96, 112, 128, 160, 192, 224, 256, 320 (kbps) MPEG2 LSF LAYER3: 64, 80, 96, 112, 128, 144, 160 (kbps)
 - · Compatible channel modes: stereo, joint stereo, dual channel and duction monaural
- WMA file compatibility
 - Compatible standards WMA Ver. 7, 8, 9
 - Compatible sampling frequencies 32, 44.1, 48 (kHz)
 - Compatible bit rates (only compatible with 2-channel playback) Ver. 7, 8: CBR 48, 64, 80, 96, 128, 160, 192 (kbps) Ver. 9: CBR 48, 64, 80, 96, 128, 160, 192, 256, 320 (kbps)

Compatible media

Media that can be used for MP3 and WMA playback are CD-Rs and CD-RWs.

Playback in some instances may not be possible if the CD-R or CD-RW is not finalized. Playback may not be possible or the audio may jump if the disc is scratched or marked with fingerprints.

Compatible disc formats

The following disc formats can be used:

• Disc formats: CD-ROM Mode 1 and Mode 2

CD-ROM XA Mode 2, Form 1 and Form 2

 File formats: ISO9660 Level 1, Level 2, (Romeo, Joliet) MP3 and WMA files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows:

- · Maximum directory hierarchy: 8 levels (including the root)
- Maximum length of folder names/file names: 32 characters
- Maximum number of folders: 192 (including the roof)
- Maximum number of files per disc: 255

File names

The only files that can be recognized as MP3 WMA and played are those with the extension .mp3 or .wma.

Discs containing multi-session recording

As the audio system is compatible with multi-sessions, it is possible to play discs that contain MP3 and WMA files. However, only the first session can be played.

ID3 and WMA tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

MP3 and WMA playback

When a disc containing MP3 or WMA files is inserted, all files on the disc are first checked. Once the file check is finished, the first MP3 or WMA file is played. To make the file check finish more quickly, we recommend you do not write in any files other than MP3 or WMA files or create any unnecessary folders.

Discs that contain a mixture of music data and MP3 or WMA format data cannot be played.

Extensions

If the file extensions .mp3 and .wma are used for files other than MP3 and WMA files, they will be mistakenly recognized and played as MP3 and WMA files. This may result in large amounts of interference and damage to the speakers.

Playback

- To play MP3 file with steady sound quality we recommend a fixed bit rate of least 128 kbps and a sampling frequency of 44.1 kHz.
- CD-R or CD-RW playback may not be possible in some instances, depending on the characteristics of the disc.
- There is a wide variety of freeware and other encoding software for MP3 and WMA files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result: In some cases, playback may not be possible at all.
- When files other than MP3 or WMA files are recorded on a disc, it may take more time to recognize the disc and in some cases, playback may not be possible at all.
- Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S.A. and other countries.

CDs and adapters that cannot be used

→P. 347

CD player precautions

→P. 348

3-2. Using the audio system **Operating an iPod**^{*}


Connecting an iPod enables you to enjoy music from the vehicle speakers.

Connecting an iPod

STEP 1 Open the cover and connect an iPod using an iPod cable.


Turn on the power of the iPod if it is not turned on.

Vehicles with an automatic transmission




Control panel

Туре А



Type B



"PODCASTS" → "GENRES" → "COMPOSERS" → "AUDIOBOOKS"

STEP 3 Press the "TUNE•SEL" knob to select the desired play mode.

Play mode list

Play mode	First selection	Second selection	Third selection	Fourth selection
"PLAYLISTS"	Playlists select	Songs select	-	-
"ARTISTS"	Artists select	Albums select	Songs select	-
"ALBUMS"	Albums select	Songs select	-	-
"SONGS"	Songs select	-	-	-
"PODCASTS"	Albums select	Songs select	- ~	-
"GENRES"	Genre select	Artists select	Albums select	Songs select
"COMPOS- ERS"	Composers select	Albums select	Songs select	-
"AUDIO- BOOKS"	Songs select		-	-

Selecting a list

STEP 1 Turn the "TUNE•SEL" knob to display the first selection list.

- STEP 2 Press the "TUNESEL" knob to select the desired item. Pressing the knob changes to the second selection list.
- STEP 3 Repeat the same procedure to select the desired song name. To return to the previous selection list, select "GO BACK" or press the 4 (**5**) button.

Selecting songs

Turn the "TUNE•SEL" knob or press " \land " or " \lor " on the "SEEK/TRACK" button to select the desired song.

Playing and pausing songs

To play or pause a song, press the $3 (\mathbf{PII})$ button.

Fast-forwarding and rewinding songs

To fast-forward or rewind, press and hold " \land " or S on the "SEEK/ TRACK" button until you hear a beep.

Shuffle playback

Playing songs from one playlist or album in random order Press the 1 (RAND) button.

To cancel, press the 1 (RAND) button again.

Playing songs from all the playlists or albums in random order Press and hold the 1 (RAND) button until you hear a beep.

To cancel, press the 1 (RAND) button again.

Repeat play

Press the 2 (RPT) button.

To cancel, press the 2 (RPT) button again.

Switching the display

Press the "TEXT" button.

Each time the button is pressed, the display changes in the following order: Elapsed time \rightarrow Album title \rightarrow Track title \rightarrow Artist name

Silencing the sound (type A)

Press the "MUTE" button.

Press the button again to turn the system back on.

Adjusting sound quality and volume balance

STEP 1 Press the "TUNE•SEL" knob to enter Pod menu mode.

STEP 2 Pressing the "TUNE•SEL" know hanges sound modes.

(→P. 374)

About iPod

- Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.
- iPod is a trade mark of Apple inc., registered in the U.S. and other countries.

iPod functions

- When an iPod is connected and the audio source is changed to iPod mode, the iPod will resume play from the same point in which it was last used.
- Depending on the iPod that is connected to the system, certain functions may not be available. Disconnecting the device and reconnecting it once again may resolve some malfunctions.

iPod problems

To resolve most problems encountered when using your iPod, disconnect your iPod from the vehicle iPod connection and reset it.

For instructions on how to reset your iPod, refer to your iPod Owner's Manual.

Display

→P. 345

Error messages

"ERROR": This indicates a problem in the iPod or its connection.

"NO MUSIC": This indicates that there is no music data in the iPod.

"EMPTY": This indicates that an empty playlist is selected

"UPDATE": This indicates that the version of the iPod is not compatible. Upgrade your iPod software to the latest version.

Compatible models

Model	Generation	Software version		
iPod	5th generation	Ver. 1.2.0 or higher		
iPod nano	1st generation	Ver. 1.3.0 or higher		
	2nd generation	Ver. 1.1.2 or higher		
×	3rd generation	Ver. 1.0.0 or higher		
iPod touch	1st generation	Ver. 1.1.0 or higher		
iPod classic	1st generation	Ver. 1.0.0 or higher		

Depending on differences between models or software version etc., some models listed above might be incompatible with this system.

iPod 4th generation and earlier models are not compatible with this system. iPhone, iPod mini, iPod shuffle and iPod photo are not compatible with this system.

Items related to standards and limitations are as follows:

- Maximum number of lists in device: 9999
- Maximum number of songs in device: 65535
- Maximum number of songs per list: 65535

CAUTION

Caution while driving

Do not connect iPod or operate the controls.

NOTICE

To prevent damage to iPod

- Do not leave iPod in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the player.
- Do not push down on or apply unnecessary pressure to the iPod while it is connected as this may damage the iPod or its terminal



3-2. Using the audio system Operating a USB memory^{*}


Connecting a USB memory enables you to enjoy music from the vehicle speakers.

Connecting a USB memory

STEP 1 Open the cover and connect a USB memory.


Turn on the power of the USB memory if it is not turned on.

Vehicles with an automatic transmission




Control panel

Туре А







Selecting folders one at a time

Press " \land " or " \checkmark " on the "FOLDER" button or the 6 (\land) or 5 (\lor) button to select the desired folder.

Returning to the first folder

Press and hold " \lor " on the "FOLDER" or the 5 (\lor) button until you hear a beep.

Scanning the first file of all the folders

STEP 1 Press and hold the "SCAN" button until you hear a beep.

The first ten seconds of the first file in each folder will be played.

STEP 2 When the desired folder is reached, press the "SCAN" button again.

Selecting and scanning files

Selecting files

Turn the "TUNE•SEL" knob or press "^" or on the "SEEK/ **J**ctio TRACK" button to select the desired file.

Scanning the files in a folder

Press the "SCAN" button.

The first ten seconds of each file will be

To cancel, press the "SCAN" button again.

When the desired file is reached, press the "SCAN" button again.

Plaving and pausing files

To play or pause a file, press the $3 (\ge 1)$ button.

Fast-forwarding and rewinding files

To fast-forward or rewind, press and hold "^" or "V" on the "SEEK/ TRACK" button until you hear a beep.

Random playback

Playing files from a folder in random order

Press the 1 (RAND) button.

To cancel, press the 1 (RAND) button again.

Playing all the files from a USB memory in random order

Press and hold the 1 (RAND) button until you hear a beep.

To cancel, press the 1 (RAND) button again.

Repeat play

Repeating a file

Press the 2 (RPT) button.

ductio To cancel, press the 2 (RPT) button and

Repeating all the files in a folde

Press and hold the 2 (RPT) button until you hear a beep.

To cancel, press the 2 (RPT) button again.

Switching the display

Press the "TEXT" button.

Each time the button is pressed, the display changes in the following order: Elapsed time \rightarrow Folder name \rightarrow File name \rightarrow Album title (MP3 only) \rightarrow Track title \rightarrow Artist name

Silencing the sound (type A)

Press the "MUTE" button.

Press the button again to turn the system back on.

USB memory functions

Depending on the USB memory that is connected to the system, certain functions may not be available. Disconnecting the device and reconnecting it once again may resolve some malfunctions.

Display

→P. 345

Error messages

"ERROR": This indicates a problem in the USB memory or its connection.

"NO MUSIC": This indicates that no MP3/WMA files are included in the USB memory.

USB memory

Compatible devices

USB memory that can be used for MP3 an WMA playback

Compatible device formats

The following device formats can be used:

- USB communication formate USB2.0 FS (12mbps)
- File formats: FAT16/32 (Windows)
- Correspondence class: Mass storage class

MP3 and WMA files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows:

- Maximum directory hierarchy: 8 levels
- Maximum number of folders in a device: 999 (including the root)
- Maximum number of files in a device: 65025
- Maximum number of files per folder: 255

MP3 and WMA files

MP3 (MPEG Audio LAYER 3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

There is a limit to the MP3 and WMA file standards that can be used and to the media/formats on which the files are recorded.

MP3 file compatibility

- Compatible standards MP3 (MPEG1 AUDIO LAYERII, III, MPEG2 ADDIO LAYERII, III, MPEG2.5)
- Compatible sampling frequencies
 MPEG1 AUDIO LAYERII, III: 32, 44.1 48 (kHz)
 MPEG2 AUDIO LAYERII, III: 16, 2205, 24 (kHz)
 MPEG2.5: 8, 11.025, 12 (kHz)
- Compatible bit rates (compatible with VBR) MPEG1 AUDIO LAYERII, Nr. 32-320 (kbps) MPEG2 AUDIO LAYERIK III: 32-160 (kbps) MPEG2.5: 32-160 (kbps)
- Compatible channel modes: stereo, joint stereo, dual channel and monaural
- WMA file compatibility
 - Compatible standards
 WMA Ver. 9
 - Compatible sampling frequencies HIGH PROFILE 32, 44.1, 48 (kHz)
 - Compatible bit rates HIGH PROFILE 32-320 (kbps, VBR)
- File names

The only files that can be recognized as MP3/WMA and played are those with the extension .mp3 or .wma.

ID3 and WMA tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3, 2.4 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

MP3 and WMA playback

- When a device containing MP3 or WMA files is connected, all files in the USB memory device are checked. Once the file check is finished, the first MP3 or WMA file is played. To make the file check finish more quickly, we recommend that you do not include any files other than MP3 or WMA files or create any unnecessary folders.
- When the USB device is connected and the audio source is changed to USB memory mode, the USB device will start playing the first file in the first folder. If the same device is removed and reinserted (and the contents have not been changed), the USB device will resume play from the same point in which it was last used.

Extensions

If the file extensions .mp3 and .wma are used for files other than MP3 and WMA files, they will be mistakenly recognized and played as MP3 and WMA files. This may result in large amounts of interference and damage to the speakers.

- Playback
 - To play MR3 files with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
 - There is a wide variety of freeware and other encoding software for MP3 and WMA files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
 - Microsoft, Windows, and Windows Media are registered trademarks of Microsoft Corporation in the U.S.A. and other countries.

Caution while driving


Do not connect USB memory or operate the controls.

To prevent damage to USB memory

- Do not leave USB memory in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the player
- Do not push down on or apply unnecessary pressure to the USB memory while it is connected as this may damage the USB memory or its terminal.
- Do not insert foreign objects into the port as this may damage the USB memory or its terminal.

Interior features

3-2. Using the audio system Optimal use of the audio system



- **1** Displays the current mode
- 2 Changes the following settings
 - Sound quality and volume balance →P. 374

The sound quality and balance setting can be changed to produce the best sound.

 Automatic Sound Levelizer on/off
 375

Adjusting sound quality and volume balance

Changing sound quality modes

Pressing the "TUNE SEL" knob.

Pressing the button changes sound modes in the following order:

 $\texttt{`BAS''} \rightarrow \texttt{`MID''}(\texttt{type B}) \rightarrow \texttt{`TRE''} \rightarrow \texttt{`FAD''} \rightarrow \texttt{`BAL''} \rightarrow \texttt{`ASL''}$

Adjusting sound quality

Turning the "TUNE•SEL" knob adjusts the level.

Mode displayed	Sound quality mode	Level	Turn coun- terclockwise	Turn clockwise
"BAS"	Bass ^{*2}	-5 to 5		
"MID"*1	Mid-range*2	-5 to 5	Low	High
"TRE"	Treble*2	-5 to 5		
"FAD"	Front/rear volume balance	F7 to R7	Shifts to rear	Shifts to front
"BAL"	Left/right volume balance	L7 to R7	Shifts to left	Shifts to right

*1: If equipped

*2: The sound quality level is adjusted individually in each audio mode.

Turning the Automatic Sound Levelizer (ASL) on/off

Туре А

When "ASL" is selected, turning the "TUNE•SEL" knob to the right changes the ASL" level in the order of "LOW", "MID" and "HIGH".

Turning the "TUNE•SEL" knob to the left turns "ASL" off.

ASL automatically adjusts the volume and tone quality according to the vehicle speed.

Туре В

Turning the "TUNE•SEL" knob clockwise turns on the ASL, and turning the "TUNE•SEL" knob counterclockwise turns off the ASL.

ASL automatically adjusts the volume and tone quality according to the noise level as you drive your vehicle.

Trademark owned by SRS Labs, Inc. (Type A)



The audio systems utilize SRS FOCUS® and SRS TruBass® audio enhancement technologies, under license from SRS Labs, Inc., in all mode except AM radio mode.

FOCUS, TruBass, SRS and **()** symbols are trademarks of SRS Labs, Inc.


Inc. FOCUS and TruBass technologies are incorporated under license from SRS Labs, Inc.

3-2. Using the audio system Using the AUX port^{*}

This port can be used to connect a portable audio device and listen to it through the vehicle's speakers.

STEP 1 Open the cover and connect the portable audio device.

Vehicles with an automatic transmission



Operating portable audio devices connected to the audio system

The volume can be adjusted using the vehicle's audio controls. All the other adjustments must be made on the portable audio device itself.


When using a portable audio device connected to the power outlet

Noise may occur during playback. Use the power source of the portable audio device.

NotforReproduction

3-2. Using the audio system Using the steering wheel audio switches^{*}

Some audio features can be controlled using the switches on the steering wheel.



Turning the power on

Press the "MODE" button when the audio system is turned off.

The audio system can be turned off by holding the switch down for 1 second or more.

Changing the audio source

Press the "MODE" button when the audio system is turned on. The audio source changes as follows each time the button is pressed. If no discs are inserted in the player, that mode will be skipped.

 $\mathsf{FM1} \to \mathsf{FM2} \to \mathsf{CD} \ \mathsf{player} \to \mathsf{AUX} \to \mathsf{iPod} \ \mathsf{or} \ \mathsf{USB} \ \mathsf{memory} \to \mathsf{AM} \to \mathsf{FM1}$

Adjusting the volume

Press "+" on \bigcirc to increase the volume and "-" to decrease the volume.

Hold down the button to continue increasing or decreasing the volume.

Selecting a radio station

STEP 1 Press the MODE" button to select the radio mode.

STEP 2 Press n or " \checkmark " on \odot to select a radio station.

To scan for receivable stations, press and hold " \wedge " or " \vee " the button until you hear a beep.

Selecting a track/file or song

- STEP 1 Press the "MODE" button to select CD, iPod or USB memory mode.
- STEP 2 Press "∧" or "∨" on e e to select the desired track/file or song.

Selecting a folder

STEP 1 Press the "MODE" button to select USB memory mode.

STEP 2 Press and hold " \wedge " or " \vee " on \odot until you hear a beep.

Selecting a disc in the CD player

STEP 1 Press the "MODE" button to select CD mode.

STEP 2 Press and hold " \wedge " or " \vee " or \otimes \otimes until you hear a beep.

Canceling automatic selection of a radio station

Press 💿 💿 again.

To reduce the risk of an accident

Exercise care when operating the audio switches on the steering wheel.

3-3. Using the hands-free system (for mobile phone) Hands-free system (for mobile phone)*

The hands-free system is a function that allows you to use your mobile phone without touching it.

This system supports Bluetooth[®] mobile phones. Bluetooth[®] is a wireless data system that allows the mobile phone to wirelessly connect to the hands-free system and make/receive calls.

Vehicles with a navigation system

Refer to the "Navigation System Owner's Manual".

Vehicles without a navigation system

Hands-free system quick guide

STEP 1 Setting a mobile phone. (\rightarrow P. 388)


STEP 2 Adding an entry to the phonebook (Up to 20 names can be stored.) (\rightarrow P. 401)

tion

STEP 3 Dialing by inputting a name (P. 392)

Hands-free function list

Title	Page
Using the hands-free system ■Using the hands-hee phone system for the first time	P. 386
40	I



Conditions under which the system will not operate

- If using a mobile phone that does not support Bluetooth[®].
- If the mobile phone is switched off.
- If you are outside service range.
- If the mobile phone is not connected.
- If the mobile phone's battery is low.
- The mobile phone is behind the seat or in the glove box or console box
- Metal is covering or touching the phone

Signal status

This display may not correspond exactly with the mobile phone itself.

When using the hands-free system

- The audio system and voice guidance are muted when making a call.
- If both parties speak at the same time ritmay be difficult to hear.
- If the incoming call volume is overly loud, an echo may be heard.
- Try to face toward the microphone as much as possible when speaking.
- In the following circumstances, it may be difficult to hear the other party:
 - · When driving on uppaved roads
 - When driving at high speeds
 - When a window is open
 - When the air conditioning is blowing directly on the microphone
 - · When the air conditioning is set to high

When transferring ownership of the vehicle

Be sure to initialize the system to prevent personal data from being improperly accessed. (\rightarrow P. 400)

About Bluetooth[®]



Bluetooth is a registered trademark of Bluetooth SIG. Inc.

Compatible models

Compatible with HFP (Hands Free Profile) Ver 5 and OPP (Object Push Profile) Ver. 1.1.

If your mobile phone does not support HFR you cannot enter the Bluetooth[®] phone. If your mobile phone support OPP alone, you cannot use the Bluetooth[®] phone.

CAUTION

Caution while driving

Do not use a mobile phone or connect the Bluetooth[®] phone.

or


🔨 NOTICE

To prevent damage to mobile phones

Do not leave mobile phones in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the phone.

3-3. Using the hands-free system (for mobile phone) Using the hands-free system (for mobile phone)

Audio unit



1 Display

A message, name, phone number, etc. is displayed.

Lower-case characters and special characters cannot be displayed.

2 Selects speed dials

3 Displays information that is too long to be displayed at one time on the display (press and hold)

4 Selects items such as menu and number

Turn: Selects an item

Press: Inputs the selected item


NotForRep 5 Bluetooth[®] connection condition

If "BT" is not displayed, the hands-free system cannot be used.


6 Reception level


Steering wheel switches

Туре А









1 Volume

The voice guidance volume cannot be adjusted using this button.

2 Off-hook switch

Turns the hands-free system on/starts a call

3 On-hook switch

Turns the hands-free system off/ends a call/refuses a

Talk switch

Turns the voice command system on (press)/turns the voice command system off (press and hold)

Using the hands-free phone system for the first time

Before using the hands-free phone system, it is necessary to register a mobile phone in the system. The system will enter phone registration mode automatically when starting the system with no mobile phone registered. Follow the procedure below to register (pair) a mobile phone:

- STEP 1 Press the off-hook switch and select "Pair phone" using the "TUNE•SEL" knob.
- STEP 2 Select "Record Name" using the "TUNE•SEL knob, and say the name to be registered after the beep.
- The name to be registered will be repeated aloud
- STEP 3 Select "Confirm" using the "TUNE SEL" knob.
- A passkey will be displayed.
- STEP 4 Input the passkey into the mobile phone.
 - Refer to the manual that comes with the mobile phone for the operation of the phone.

388

First menu	Second menu	Third menu	Operation detail
"Callback"	-	-	Dialing a number stored in the incoming call history memory
"Redial"	-	-	Dialing a number stored in the outgoing call history memory
"Phone- book"	"Add Entry"	-	Adding a new phone num- ber
	"Change Name"	-	Changing the registered name in the phone book
	"Delete Entry"	oro	Deleting the registered data
	"Del Spd Dial"	Rei	Deleting speed dials
	"List Names"	0 -	Listing the registered data
	"Speed Dial"	-	Setting speed dials

First menu	Second menu	Third menu	Operation detail
"Setup"	"Security"	"Set PIN"	Setting a PIN code
		"Phbk Lock"	Locking the phone book
		"Phbk Unlock"	Unlocking the phone book
	"Phone Setup"	"Pair Phone"	Registering a mobile phone
		"Select Phone"	Selecting a mobile phone to be used
		"Change Name"	Changing the negistered name of mobile phone
		"List Phones"	Listing the registered mobile phones
		"Set Passkey"	hanging the passkey
		"Delete Phone"	Deleting a registered mobile phone
	"System Setup"	"Guidance Vol"	Setting voice guidance vol- ume
		Bevice Name"	Displaying the Bluetooth [®] device address and name
		"Initialize"	Initializing the system
	4		

Automatic volume adjustment

When vehicle speed reaches 80 km/h (50 mph) or more, the volume automatically increases. The volume returns to the previous volume setting when vehicle speed drops to 70 km/h (43 mph) or less.

Operations that cannot be performed while driving


- Operating the system with the "TUNE•SEL" knob
- Registering a mobile phone to the system

Changing the passkey

→P. 397

NotForReproduction

3-3. Using the hands-free system (for mobile phone) Making a phone call



STEP 1 Press the talk switch and say a registered name.

The desired name or number is displayed.

STEP 2 Dial by one of the following methods:

- a. Press the off-hook switch.
- b. Select "Dial" using the "TUNE•SEL" knob.

In <u>STEP 1</u>, if the pronounced name cannot be recognized, select the desired name using the "TUNE•SEL" knob.

Speed dialing

- STEP 1 Press the off-hook switch.
- STEP 2 Press the preset button in which the desired number is registered
- STEP 3 Press the off-hook switch.

When receiving a phone call

Answering the phone

Press the off-hook switch

Refusing the call

Press the on-hook switch.

Transferring a call

+oduction A call can be transferred between the mobile phone and system while dialing, receiving a call, or during a call. Use one of the following methods:

Operate the mobile phone. a.

> Refer to the manual that comes with the mobile phone for the operation of the phone.

- b. Press the off-hook switch*.
- *: This operation can be performed only when transferring a call from the mobile phone to the system during a call.

Using a call history memory

Follow the procedure below to use number stored in call history memory:

STEP 1 Press the off-hook switch and select "Redial" (when using a number stored in the outgoing call history memory) or "Call back" (when using a number stored in the incoming call history memory) using the "TUNE•SEL" knob.

STEP 2 Select the desired number using the "TUNE•SEL" knob.

STEP 3 The following operations can be performed:

Dialing: Press the off-hook switch or select Dial" using the "TUNE•SEL" knob.

Storing the number in the phone book. Select "Store" and then "Confirm" using the "TUNE•SEL" knob.

Deleting: Select "Delete" and then "Confirm" using the "TUNE•SEL" knob.

Call history

Up to 5 numbers can be stored in each of the outgoing and incoming call history memories.

When talking on the phone

- Do not talk simultaneously with the other party.
- Keep the volume of the receiving voice down. Otherwise, voice echo will increase.

Registering a mobile phone in the hands-free phone system allows the system to function. The following function can be used for registered mobile phones:

Functions and operation procedures

To enter menu for each function, follow the steps below.

- STEP 1 Press the off-hook switch and select "Setup" using the "TUNE•SEL" knob.
- STEP 2 Select "Phone Setup" using the "TUNE•SEL" knob.
- STEP 3 Select one of the following items using the "TUNE•SEL" ducti knob:
 - Registering a mobile phone "Pair Phone"
 - Selecting a mobile phone to be use "Select Phone"
 - Changing the registered has of a mobile phone "Change Name"
 - Listing the registered mobile phones "List Phones
 - Changing the passkey "Set Passkey"
 - Deleting a registered mobile phone "Delete Phone"

Registering a mobile phone

Select "Pair Phone" using the "TUNE•SEL" knob, and perform the procedure for registering a mobile phone. (\rightarrow P. 388)

Selecting a mobile phone to be used

STEP 1 Select "Select Phone" using the "TUNE•SEL" knob.

STEP 2 Select the mobile phone to be used using the "TUNE•SEL" knob.

Changing the registered name of a mobile phone

STEP 1 Select "Change Name" using the "TUNE SEL" knob.

- STEP 2 Select the desired mobile phone have to be changed using the "TUNE•SEL" knob.
- STEP 3 Select "Record Name" using the "TUNE•SEL" knob, and say the new name after the been.

The name to be registered will be repeated aloud.

STEP 4 Select "Confirm" using the "TUNE•SEL" knob.

Listing the registered mobile phones

Select "List Phones" using the "TUNE•SEL" knob. The list of registered mobile phones will be read aloud.

When listing is complete, the system returns to "Phone Setup".

Changing the passkey

- STEP 1 Select "Set Passkey" using the "TUNE•SEL" knob.
- STEP 2 Select a 4 to 8-digit number using the "TUNE•SEL" knob.

The number should be input 1 digit at a time.

STEP 3 When the entire number to be registered as a passkey has been input, press the "TUNE•SEL" knob again.

If the number to be registered has 8 digits, pressing of the knob is not necessary.

Deleting a registered mobile phone

STEP 1 Select "Delete Phone" using the "TUNE SPL" knob.

STEP 2 Select the desired mobile phone to be deleted using the "TUNE•SEL" knob.

The number of mobile phones that can be registered

Up to 6 mobile phones can be registered in the system.

3-3. Using the hands-free system (for mobile phone) Security and system setup

To enter the menu of each setting, follow the steps below.
Security setting items and operation procedures STEP 1 Press the off-hook switch and select "Setup" using the "TUNE•SEL" knob.
STEP 2 Select "Security" using the "TUNE•SEL" knob.
STEP 3 Select one of the following items using the "TUNE•SEL" knob:
 Setting or changing the PIN (Personal Identification Number) "Set PIN"
 Locking the phone book "Phbk Lock"
 Setting or changing the PIN (Personal Identification Number) "Set PIN" Locking the phone book "Phbk Lock" Unlocking the phone book "Phbk Unlock" System setup items and operation procedures
STEP 1 Press the off-hook switch and select "Setup" using the "TUNE•SEL" knobe
STEP 2 Select "System Setup" using the "TUNE•SEL" knob.
STEP 3 Select one of the following items using the "TUNE•SEL" knob:
 Setting voice guidance volume "Guidance Vol"
 Displaying the Bluetooth[®] device address and name "Device Name"
 Initializing the system "Initialize"

Setting or changing the PIN

Setting a PIN

STEP 1 Select "Set PIN" using the "TUNE•SEL" knob.

STEP 2 Enter a PIN using the "TUNE•SEL" knob.

Input the code 1 digit at a time.

Changing the PIN

STEP 1 Select "Set PIN" using the "TUNE•SEL" knob.

STEP 2 Enter the registered PIN using the "TUNE•SEL" knob.

STEP 3 Enter a new PIN using the "TUNE•SEL" know Input the code 1 digit at a time.

Locking or unlocking the phone book

- STEP 1 Select "Phbk Lock" or "Phbk phock" using the "TUNE•SEL" knob.
- STEP 2 Input a new PIN by using the "TUNE•SEL" knob and select "Confirm" using the "TUNE•SEL" knob.

Input the code 1 digit at a time.

Setting voice guidance volume

STEP 1 Select "Guidance Vol" using the "TUNE•SEL" knob.

STEP 2 Change the voice guidance volume.

To decrease the volume: Turn the "TUNE•SEL" knob counterclockwise.

To increase the volume: Turn the "TUNE•SEL" knob clockwise.

Displaying the Bluetooth[®] device address and name

- STEP 1 Select "Device Name" using the "TUNE•SEL" knob.
- STEP 2 Turn the "TUNE•SEL" knob to display the Bluetooth[®] device address and name.
- STEP 3 Select "Go Back" using the "TUNE•SEL" knob to return to "System Setup".

Initializing the system

STEP 1 Select "Initialize" and then "Confirm" using the "TUNE-SEL" knob.

STEP 2 Select "Confirm" again using the "TUNE SEL" knob.

Initialization

• The following data in the system can be initialized:


- Phone book
- · Outgoing and incoming call history
- Speed dials
- · Registered mobile phone data
- Security code
- Passkeys for the mobile phones
- Guidance volume
- Receiver volume
- Ring tone volume
- Once the initialization has been completed, the data cannot be restored to its original state.

When the phone book is locked

The following functions cannot be used:

- Dialing by inputting a name
- Speed dialing
- Dialing a number stored in the call history memory
- Using the phone book

3-3. Using the hands-free system (for mobile phone) Using the phone book



Interior features

Adding a new phone number

The following methods can be used to add a new phone number:

- Transferring data from the mobile phone
- Inputting a phone number using the "TUNE•SEL" knob
- Selecting a phone number from outgoing or incoming call history

Adding procedure

STEP 1 Select "Add Entry" using the "TUNE•SEL" knob.

STEP 2 Use one of the following methods to input telephone number:

Transferring data from the mobile phone:

- STEP2-1 Select "By Phone" and then "Confirm" using the "TUNE•SEL" knob.
- STEP2-2 When "Transfer" appears in the display, transfer the data from the mobile phone.

Refer to the manual that comes with the mobile phone for the details of transferring data.

STEP2-3 Select the desired data using the "TUNE•SEL" knob.

Inputting a phone number using the "TUNE•SEL" knob:

STER2-1 Select "Manual Input" using the "TUNE•SEL" knob.

STEP2-2 Input a phone number using the "TUNE•SEL" knob, and press the "TUNE•SEL" knob again. Input the phone number 1 digit at a time.

Selecting a phone number from outgoing or incoming call history:

- STEP2-1 Select "Call History" using the "TUNE•SEL" knob.
- STEP2-2 Select "Outgoing" or "Incoming" using the "TUNE•SEL" knob.
- STEP2-3 Select the desired data using the "TUNE•SEL" knob.

STEP 3 Select "Record Name" using the "TUNE•SEL" knob, and say the desired name after the beep.

The name to be registered will be repeated aloud.

STEP 4 Select "Confirm" using the "TUNE•SEL" knob.

STEP 5 Select "Confirm" again using the "TUNE•SEL" knob.

In <u>STEP 5</u>, selecting "Speed Dial" instead of "Confirm" registers the newly added phone number as a speed dial.

Changing the registered name in the phone book

STEP 1 Select "Change Name" using the "TUNE SEL" knob.

- STEP 2 Select the desired name to be changed using the "TUNE•SEL" knob.
- STEP 3 Select "Record Name" using the UNE•SEL" knob, and say the new name after the beep.

The name to be registered will be repeated aloud.

STEP 4 Select "Confirm" using the "TUNE•SEL" knob.

Listing the registered deta

Selecting "List Names" using the "TUNE•SEL" knob. The list of the registered data withbe read aloud.

When listing is complete, the system returns to "Phonebook".

Pressing the off-hook switch while an entry is being read aloud selects the entry, and calls the registered phone number.

Setting speed dials

STEP 1	Select	"Speed	Dial"	using the	"TUNE•SEL" I	knob.

- STEP 2 Select the desired data using the "TUNE•SEL" knob.
- STEP 3 Select the desired preset button, and register the data into speed dial by either of the following methods:
 - a. Press the desired preset button, and select "Confirm" using the "TUNE•SEL" knob.
 - b. Press and hold the desired preset button.

Deleting the registered data

STEP 1 Select "Delete Entry" using the "TUNE SEL" knob.

STEP 2 Select the desired data to be detected using the "TUNE•SEL" knob.

Deleting speed dials

- STEP 1 Select "Del Spd Dial" Using the "TUNE•SEL" knob.
- STEP 2 Press the preset botton to which the desired speed dial is registered after the beep.


The name to be deleted will be heard.

STEP 3 Select "Confirm" using the "TUNE•SEL" knob.


Limitation of number of digits

A phone number that exceeds 24 digits cannot be registered.

3-4. Using the interior lights Interior lights list




Personal/interior light main switch




Personal/interior lights

Personal/interior lights

Front



Rear (without personal lights)



TN35M008

1 Turns the lights on

Turns the lights on/off


Turns the door position on

Door position: When the personal/interior light main switch is in the "OFF" position, the lights will not turn on.

Lounge illumination control switches (if equipped)

The brightness of the following the lights can be adjusted:

- Inside door handle lights
- Ornament illumination
- Door pocket lights
- Footwell lights



Illuminated entry system

Vehicles without a smart entry & start system

The lights automatically turn on/off according to the engine switch position, whether the doors are locked/unlocked, and whether the doors are open/ closed.

Vehicles with a smart entry & start system

The lights automatically turn on/off according to "ENGINE START STOP" switch mode, the presence of the electronic key, whether the doors are locked/unlocked, and whether the doors are open/closed.

To prevent battery discharge


If the following lights remain on when the door is not fully closed and the personal/interior light main switch is in the door position, the lights will go off Inside door handle lights (if equipped)
Ornament illumination (if equipped) automatically after 20 minutes:

- Door pocket lights (if equipped)
- Footwell lights (if equipped
- Running board lights (if equipped)

Customization

Settings (e.g. time elapsed before the interior lights turn off) can be changed. (Customizable features \rightarrow P. 626)

3-5. Using the storage features List of storage features



Glove box

CAUTION


Items that should not be left in the storage spaces

Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:

- Glasses may be deformed by heat or cracked if they come into contact with other stored items.
- Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.

Glove box

The glove box can be opened by pulling the lever and can be locked and unlocked by using the mechanical key.




Glove box light

The glove box light turns on when the tail lights are on.

CAUTION

Caution while driving


Keep the glove box closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by the open glove box or the items stored inside.




Console box (if equipped)

Your vehicle is equipped with either a console box or cool box. For vehicles with the cool box, refer to P. 423.

Console box



Using the console box vent



Air from the air conditioner can be distributed into the console box by opening and closing the vent.

- 1 Open
- 2 Close

Items unsuitable for the console box

- Drinks in unsealed containers
- Fragile items, perishables or anything with strong odor
- Owner's manual, electronic devices, CDs, etc. (when using the console box vent)

When using the console box lid as an armrest



Slide the console box lid forward or backward as needed. Slide the lid while pulling up the lever to release the lock.

A CAUTION

Caution while driving

Reptoduction Reptoduction Keep the console box closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by the open console box or the items stored inside.

NOTICE


Trav

Do not insert items exceeding the height of the tray. Doing so may prevent opening and closing of the lid.

Bottle holders/door pockets

Bottle holders/door pockets

Front



When using the holder as a bottle holder

- When storing a bottle, close the cap.
- The bottle may not be stored depending on its size or shape.


NOTICE

Items that should not be stowed in the bottle holders

Do not place open bottles in the bottle holders, or glasses and paper cups containing liquid. The contents may spill and glasses may break.

Cup holders


Front (vehicles with an automatic transmission)



Press down and release the cup holder lid.


You can remove the holder inside.





Press down and release the cup holder lid.


ou can remove the separate tray inside.




Pull the armrest down.

Cup holders

Rear (type B) (if equipped)




Pull the armrest down and press in and release the button.



Removing the holder, separate tray and adapter Front (vehicles with an automatic transmission)



Pull up the holder.



Cup holders

A CAUTION

Items unsuitable for the cup holder

Do not place anything other than cups, mugs or beverage cans in the cup holders.

Other items may be thrown out of the holders in the event of sudden braking, sudden swerving or an accident, cause injury. If possible, cover hot drinks to prevent burns.

When not in use

Keep the cup holders closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by the open cup holders or the items stored inside. duct

NOTICE


To prevent damage to the rear cup holders (rear [type B])

Stow the cup holders before stowing the armrest. Notfor

Interior features


Auxiliary boxes


Туре А



Auxiliary boxes

Type D (vehicles with an automatic transmission)





CAUTION


Caution while driving

- Keep the auxiliary boxes closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by an open auxiliary box or the items stored inside.
- Do not place cups, beverage cans or bottles in the box. They may be thrown out of the box in the event of sudden braking, sudden swerving or an accident, resulting in injury. (type D)

Items unsuitable for storing (type A)

- Do not store items heavier than 0.2 kg (0.4 lb.).
 Doing so may cause the auxiliary box to open and the items inside may fall out, resulting in an accident.
- Do not put large items in the overhead console The overhead console may not be able to be shut from the conversation mirror state.

3-6. Other interior features **Cool box**^{*}



Items unsuitable for the cool box

- Drinks in unsealed containers
- Fragile items, perishables or anything with strong odor
- Owner's manual, electronic devices, CDs, etc.

When the indicator light flashes

The cool box is not operated when any of the following conditions occurs.

When the air conditioning system is off

Turn the air conditioning system on also turns on the cool box.

- When outside air temperature is about 0 °C (32 °F) or below
- When the indicator light on the "A/C" button (\rightarrow P. 310 (316) also flashes

Press the "A/C" button to turn off the cooling and debumidification function and turn it on again.

If the indicator light continues to flash, there hav be a malfunction in the system. Turn the air conditioning system of and have it inspected by your Toyota dealer.

When using the cool box lid as an armrest



Slide the cool box lid forward or backward as needed. Slide the lid while pulling up the lever to release the lock.

CAUTION

Caution while driving

Keep the cool box closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by the open cool box or the items stored inside.


NOTICE

To prevent battery discharge


To prevent battery discharge Do not leave the cool box on longer than necessary when the engine is stopped.

3-6. Other interior features **Sun visors**

Type A



- To set the visor in the forward position, flip it down.
- To set the visor in the side position, flip down, unhook, and swing it to the side.




*.*0

To set the visor in the forward position, flip it down.
 To set the visor in the side position, flip down, unhook, and swing it to the side.

To use the side extender, place the visor in the side position, then slide it backward.

3-6. Other interior features Vanity mirror




Slide the cover to open.

The light turns on when the cover is opened.

To prevent battery discharge


3-6. Other interior features **Clock**

Vehicles with a front manual air conditioning system



- Adjusts the hours
- 2 Adjusts the minutes

Vehicles with a front automatic air conditioning system



The clock is displayed when

Vehicles without a smart entry & start system

The engine switch is in the "ACC" or "ON" position.

Vehicles with a smart entry & start system

The "ENGINE START STOP" switch is in ACCESSORY or IGNITION ON mode.


When disconnecting and reconnecting battery terminals

The clock data will be reset.

3-6. Other interior features Outside temperature display

The temperature display shows temperatures within the range of -40 $^{\circ}$ C (-40 $^{\circ}$ F) and 50 $^{\circ}$ C (122 $^{\circ}$ F).

Non-Optitron type meter (vehicles with an automatic transmission)



The outside temperature is displayed when

Vehicles without a smart entry & start system The engine switch is in the "ON" position.

Vehicles with a smart entry & start system The "ENGINE START STOP" switch is in IGNITION ON mode.

Display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change:


- When the vehicle is stopped, or moving at low speeds (less than 20 km/h [12 mph])
- •When the outside temperature has changed successive (at the entrance/ exit of a garage, tunnel, etc.)

When "--"or "E" is displayed

The system may be malfunctioning. Take four vehicle to your Toyota dealer.



3-6. Other interior features Ashtray



Not

The ashtray can be installed in the auxiliary box (type D) $(\rightarrow P. 420)$ or cup holder (→P. 416).

CAUTION

When not in use


uction Keep the ashtray closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by the open ashtray or ash flying out.

To prevent fire

- Fully extinguish matches and agarettes before putting them in the ashtray, then make sure the ashtrax is fully closed.
- Do not place paper of any other type of flammable object in the ashtray.

3-6. Other interior features **Conversation mirror**

The conversation mirror can provide the driver and the front passenger with a view of the rear seat area without the need to turn around.




The power outlet can be used for the following components:


12 V: Accessories that run on less than 10 A. Accessories that run on less than 10 A should be used when using several power outlets at the same time.

220 VAC: Accessories that use less than 100 W.

Center of console (12 V)


Vehicles with an automatic transmission





Luggage compartment (220 VAC) (if equipped)

3 door models



The power outlet can be used when

Vehicles without a smart entry & start system

12 V: The engine switch is in the "ACC" or "ON" position.

220 VAC: The engine switch is in the "ON" position.

Vehicles with a smart entry & start system

12 V: The "ENGINE START STOP" switch is in ACCESSORY or IGNITION ON mode.

220 VAC: The "ENGINE START STOP" switch is in IGNITION ON mode.

NOTICE

To avoid damaging the power outlet

Close the power outlet lid when the power outlet is not in use. Foreign objects or liquids that enter the power outlet may cause a short circuit.

To prevent blown fuse

12 V

Do not use an accessory that uses more than 12 V 10 A.

220 VAC

Do not use a 220 VAC appliance that requires more than 100 W.

If a 220 VAC appliance that consumes more than 100 is used, the protection circuit will cut the power supply.

To prevent battery discharge

Do not use the power outlet longer than necessary when the engine is not running.

Appliances that may not operate properly (220 VAC)

The following 220 VAC appliances may not operate properly even if their power consumption is under 100 W:

Appliances with high initial peak wattage

Measuring devices that process precise data

• Other appliances that require an extremely stable power supply

3-6. Other interior features **Seat heaters***

Vehicles with an automatic transmission

Turns the seat heater on The indicator light comes on. 2 Adjusts the seat tempera-2 2 ture The further you turn the dial Not For Motor Not 1 1 upward, the warmer the seat

Vehicles with a manual transmission

The seat heaters can be used when

Vehicles without a smart entry & start system


The engine switch is in the "ON" position.

Vehicles with a smart entry & start system

The "ENGINE START STOP" switch is in IGNITION ON mode.

When not in use

Turn the dial fully backward. The indicator light goes off.




Do not put heavy objects that have an uneven surface on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.


To prevent battery discharge

Turn the seat heaters off when the engine is not running.

3-6. Other interior features **Armrest***



3-6. Other interior features Coat hooks




CAUTION CAUTION Items that cannot be hung on the coat hook (venicles with SRS curtain shield airbags)

Do not hang coat hangers or other hard of sharp objects on the hook. If the Not For Peter SRS curtain shield airbags deploy, these items may become projectiles, causing death or serious injury.

3-6. Other interior features **Floor mat**

Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.



Fix the floor mat in place using the retaining hooks (clips) provided.

The shape of the retaining hooks (clips) and the fixing procedure of the floor mat for your vehicle may differ from those shown in the illustration. For details, refer to the floor mat retention clip installation instructions supplied with the Clips.

CAUTION

Observe the following precautions.


Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle, leading to a serious accident.

When installing the driver's floor mat

- Do not use floor mats designed for other models or different model year vehicles, even if they are Toyota Genuine floor mats.
- Only use floor mats designed for the driver's seat.
- Always install the floor mat securely using the retaining hooks (clips) provided.
- Do not use two or more floor mats on top of each other.
- Do not place the floor mat bottom-side up or upside-down.

CAUTION


Before driving



- Check that the floor mat is securely fixed in the correct place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.
- With the engine stopped and the shift lever in P (automatic transmission) or N (manual transmission) fully depress each pedal to the floor to make sure it does not interfere with the floor mat.

3-6. Other interior features Luggage compartment features

Deck rail (if equipped)




Cargo hooks (if equipped)


To attach the deck hooks, use the deck rails.

The deck hook itself is not included as an original equipment.

Vehicles with the third seats (power seat): When using the deck rail, the third seat must be fold down. (->








Raise the hook to use.


The cargo hooks are provided for securing loose items.

Vehicles with the third seats (manual seat): When using the deck hooks, the third seat must be fold down. (\rightarrow P. 74)

Turn the knob clockwise.


2 Open the lid.





Luggage cover (if equipped)

3-doors models




Attach the hooks to the head restraints.



5-doors models

STEP 2



ITN37M066c


Attach the hooks to the head restraints.

Vehicles with the third seats: When using the luggage cover, the third seat must be fold down. (\rightarrow P. 74, 76)

Pull out the luggage cover and hook it on the anchors.


Removing the luggage cover

The luggage cover can be removed by following the procedure below.



Retract the cover and release both ends, then lift it out.

After removing the luggage cover, place it somewhere other than the passenger compartment.



Faster the button when the second seats in the rear-most position.

Unfasten the buttons before sliding the second seats forward.

CAUTION

When the cargo hooks are not in use

To avoid injury, always return the cargo hooks to their stowed positions.

Caution while driving

Keep the auxiliary box closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by an open auxiliary box or the items stored inside.

Caution for the luggage cover

Do not allow children to climb on the luggage cover. Climbing on the luggage cover, possibly causing death or serious injury to the child.

NotforReproduction

Maintenance and care

4

	4-1.	Maintenance and care	
		Cleaning and protecting the vehicle exterior	452
		Cleaning and protecting	
		the vehicle terior	456
	4-2.	Maintenance	
		Maintenance	
	3 C	requirements	459
NotForRer	0.3.	Do-it-yourself maintenan	ce
00		Do-it-yourself service	400
2 × 1		precautions	
		Hood	
~~~		Engine compartment	
		Tires	
$\mathbf{v}$		Tire inflation pressure	488
6		Wheels	490
•		Air conditioning filter	492
		Wireless remote control/	
		electronic key battery	495
		Checking and replacing	
		fuses	499
		Light bulbs	511

# 4-1. Maintenance and care Cleaning and protecting the vehicle exterior

Perform the following to protect the vehicle and maintain it in prime condition:

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois.
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.

If water does not bead on a clean surface, apply wax when the vehicle r Repr body is cool.

### Automatic car washes

- Fold the mirrors backbefore washing the vehicle. Start washing from the front of the vehicle. Make sure to extend the mirrors before driving.
- Brushes used in automatic car washes may scratch the vehicle surface and harm your vehicle's paint.

### High pressure car washes

- Do not allow the nozzles of the car wash to come within close proximity of the windows and the air suspension unit.
- Before using the car wash, check that the fuel filler door on your vehicle is closed properly.

### Touch-up paint (if equipped)

Touch-up paint may be used to cover small chips or scratches.

Apply the paint soon after the damage occurs or corrosion may set in. To apply the touch-up paint so it is hardly noticeable, the trick is to apply it only to the bare spots. Apply only the smallest amount possible and do not paint the surface around the scratch or chip.

### Aluminum wheels

- Remove any dirt immediately by using a neutral detergent. Do not use hard brushes or abrasive cleaners. Do not use strong or harsh chemical cleaners. Use the same mild detergent and wax as used on the paint.
- Do not use detergent on the wheels when they are hot, for example after driving for long distance in the hot weather.
- Wash detergent from the wheels immediately after use.

### Bumpers and side moldings

Do not scrub with abrasive cleaners.

### Notes for vehicles with a smart entry & start system (if equipped)


- If the door handle becomes we while the electronic key is within the effective range, the door may lock and unlock repeatedly. Place the key in a position 2 m (6 ft.) or more separate from the vehicle while the vehicle is being washed. (Take care to ensure that the key is not stolen.)
- If the electronic key is inside the vehicle and a door handle becomes wet during a car wash, a message may be shown on the multi-information display and a buzzer will sound outside the vehicle. To turn off the alarm, lock all the doors.

# **CAUTION**

### When washing the vehicle

Do not apply water to the inside of the engine compartment. Doing so may cause the electrical components etc. to catch fire.

# When cleaning the windshield (vehicles with rain-sensing windshield wipers)



Set the wiper switch to off.

If the wiper switch is in "AUTO", the wipers may operate unexpectedly in the following situations, and may result in hands being caught or other serious injuries and cause damage to the wiper blades.

•When the upper part of the windshield where the raindrop sensor is located is touched by hand

• When a wet rag or similar is held close to the raindrop sensor

- If something bumps against the windshield
- If you directly touch the sensor body or if something bumps into the raindrop sensor

### Precautions regarding the exhaust pipe

Exhaust gasses cause the exhaust pipe to become quite hot.

When washing the vehicle, be careful not to touch the pipe until it has cooled sufficiently, as touching a hot exhaust pipe can cause burns.

# **NOTICE**

# To prevent paint deterioration and corrosion on the body and components (aluminum wheels etc.)

• Wash the vehicle immediately in the following cases:

- · After driving near the sea coast
- · After driving on salted roads
- · If coal tar or tree sap is present on the paint surface
- If you see dead insects, insect droppings or bird droppings on the paint
- After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
- If the vehicle becomes heavily soiled in dust or much
- If liquids such as benzene and gasoline are spilled on the paint surface

# To prevent paint deterioration and corrosion on the body and components (aluminum wheels etc.)

- If the paint is chipped or scratched, have prepaired immediately.
- To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing wheels.

# Cleaning the exterior lights

- Wash carefully. Do not use organic substances or scrub with a hard brush. This may damage the surfaces of the lights.
- Do not apply wax on the surfaces of the lights.
   Wax may cause damage to the lenses.

### To prevent damage to the windshield wiper arms

When lifting the wiper arms away from the windshield, pull the driver side wiper arm upward first, and repeat for the passenger side. When returning the wipers to their original position, do so from the passenger side first.

# When using an automatic car wash (vehicles with rain sensing windshield wipers)

Set the wiper switch to the off position.

If the wiper switch is in "AUTO", the wipers may operate and the wiper blades may be damaged.

# 4-1. Maintenance and care Cleaning and protecting the vehicle interior

The following procedures will help protect your vehicle's interior and keep it in top condition:

# Protecting the vehicle interior

Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.

# Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe any excess dirt and dust with a soft cloth dampened with diluted detergent.

Use a diluted water solution of approximately 5 wheutral wool detergent.

- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detorgent.
- Wipe the surface with a dry soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded ventilated area.

Cleaning the synthetic leather areas

- Remove loose dirt using a vacuum cleaner.
- Apply a note soap solution to the synthetic leather using a sponge or soft cloth.
- Allow the solution to soak in for a few minutes. Remove the dirt and wipe off the solution with a clean, damp cloth.

### Caring for leather areas

Toyota recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

### Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not use water. The excellent results are obtained when keeping the carpet as dry as possible.

### Seat belts

Clean with mild soap and lukewarm water using a clott r sponge. Also roduc check the belts periodically for excessive wear, fraying or cuts.

# **A** CAUTION

### Water in the vehicle

- Do not splash or spill liquid in the vehicle. Doing so may cause electrical components etc. to malfunction or catch fire.
- omponents or wiring in the vehicle interior wet. Do not get any of the SRS (→P. 122)

An electrical maltunction may cause the airbags to deploy or not function properly, resulting in death or serious injury.

# Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.

# **NOTICE**

#### Cleaning detergents

- Do not use the following types of detergent, as they may discolor the vehicle interior or cause streaks or damage to painted surfaces:
  - Non-seat portions: Organic substances such as benzene or gasoline, alkaline or acidic solutions, dye, and bleach
  - Seats: Alkaline or acidic solutions, such as thinner, benzene, and alcohol

 Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.

#### Preventing damage to leather surfaces

Observe the following precautions to avoid damage to and deterioration of leather surfaces:

- Remove any dust or dirt from leather surfaces immediately.
- Do not expose the vehicle to direct studight for extended periods of time. Park the vehicle in the shade, especially during summer.
- Do not place items made of virva, plastic, or containing wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

### Water on the floor

Do not wash the vehicle floor with water.

Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components such as the audio system above or under the floor of the vehicle. Water may also cause the body to rust.

#### Cleaning the inside of the rear window

Do not use glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires or antenna. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires or antenna.

Be careful not to scratch or damage the heater wires or antenna.

# 4-2. Maintenance Maintenance requirements

To ensure safe and economical driving, day-to-day care and regular maintenance is essential. Toyota recommends performing the following maintenance:

### Scheduled maintenance

Scheduled maintenance should be performed at specified intervals according to the maintenance schedule.

For full details of your maintenance schedule, read the "Warranty and Service Booklet".

### Do-it-yourself maintenance

What about do-it-yourself maintenance?



Many maintenance items are easy to do yourself if you have a little mechanical ability and a few basic automotive tools.

Note, however, that some maintenance tasks require special tools and skills. These are best performed by qualified technicians. Even if you are an experienced do-it-yourself mechanic, we recommend that repairs and maintenance be conducted by your Toyota dealer who will keep a record of maintenance on your vehicle. This record could be helpful should you ever fequire Warranty Service.

#### Where to go for service?

It makes good sense to take your vehicle to your local Toyota dealer for service.

Toyota technicians are well-trained specialists receiving the latest service information through technical bulletins, service tips, and in-dealership training programs. They learn to work on Toyota before they work on your vehicle, rather than while they are working on it. Doesn't that seem like the best way?

Your Toyota dealer has invested a lot of money in special Toyota tools and service equipment. It helps them to do the job better and at less cost.

Your Toyota dealer's service department will perform all of the scheduled maintenance on your vehicle reliably and economically.

#### Does your vehicle need repair?

Be on the alert for changes in performance and sounds, and visual tip-offs that indicate service is needed. Some important clues are:

- Engine missing, stumbling, or pinging
- Appreciable loss of power
- Strange engine noises
- A fluid leak under the vehicle (However, water dripping from the air conditioning after use is normal.)
- Change in exhaust sound (This may indicate a dangerous carbon monoxide leak, Drive with the windows open and have the exhaust system checked immediately.)
- Flat-looking tires, excessive tire squeal when cornering, uneven tire wear
- Vehicle pulls to one side when driving straight on a level road
- Strange noises related to suspension movement
- Loss of brake effectiveness, spongy feeling brake pedal, pedal almost touches the floor, vehicle pulls to one side when braking
- Engine coolant temperature continually higher than normal

If you notice any of these clues, take your vehicle to your Toyota dealer as soon as possible. Your vehicle may need adjustment or repair.

# **CAUTION**

# If your vehicle is not properly maintained

Improper maintenance could result in serious damage to the vehicle and possible serious injury or death.

### Handling of the battery

Battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. ( $\rightarrow$ P. 477)

NotforReproduction

# 4-3. Do-it-yourself maintenance **Do-it-yourself service** precautions

If you perform maintenance yourself, be sure to follow the correct procedures as given in these sections.

Items	Parts and tools
Battery condition $(\rightarrow P. 477)$	<ul> <li>Warm water</li> <li>Baking soda</li> <li>Grease</li> <li>Conventional wrench (for terminal clamp bolts)</li> </ul>
Engine coolant level (→P. 474)	<ul> <li>"Toyota Super Long Life Coolant" or similar high quality ethylene glycol based non-silicate, non- amine, non-mitrite and non-borate coolant with long-life hybrid organic acid technology. "Toyota Super Long Life Coolant" is pre- mixed with 50 % coolant and 50 % deionized water.</li> <li>Funnel (used only for adding cool- ant)</li> </ul>
Engine oil level (→P. 470)	<ul> <li>"Toyota Genuine Motor Oil" or equivalent</li> <li>Rag or paper towel</li> <li>Funnel (used only for adding engine oil)</li> </ul>

Items		Parts and tools
Fuses	(→P. 499)	<ul> <li>Fuse with same amperage rating as original</li> </ul>
Light bulbs	(→P. 511)	<ul> <li>Bulb with same number and wattage rating as original</li> <li>Phillips-head screwdriver</li> <li>Flathead screwdriver</li> <li>Wrench</li> </ul>
Radiator, condenser ar cooler	nd inter- (→P. 476)	70.
Tire inflation pressure	(→P. 488)	Tire pressure gauge     Compressed air source
Washer fluid	(→P. 481)	<ul> <li>Water or washer fluid containing antipeeze (for winter use)</li> <li>Funnel (used only for adding water or washer fluid)</li> </ul>
	6	
	.0	
	orke	
40		

# 

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury, observe the following precautions:

### When working on the engine compartment:

- Keep hands, clothing, and tools away from the moving fan and engine drive belt.
- Be careful not to touch the engine, radiator, exhaust manifold, etc. right after driving as they may be hot. Oil and other fluids may also be hot.
- Do not leave anything that may burn easily, such as paper or rags, in the engine compartment.
- Do not smoke, cause sparks or expose an operation that tery. Fuel and battery fumes are flammable
- Be extremely cautious when working on the battery. It contains poisonous and corrosive sulfuric acid.
- Take care because brake fluid can harm your hands or eyes and damage painted surfaces.

If fluid gets on your hands on in your eyes, flush the affected area with clean water immediately

If you still experience discomfort, consult a doctor.

### When working near the electric cooling fans or radiator grille:

Vehicles with a smart entry & start system: Be sure the "ENGINE START STOP" switch is off. With the "ENGINE START STOP" switch in IGNITION ON mode, the electric cooling fans may automatically start to run if the air conditioning is on and/or the coolant temperature is high. ( $\rightarrow$ P. 476)

Vehicles without a smart entry & start system: Be sure the "ENGINE START STOP" switch is off.

With the "ENGINE START STOP" switch in IGNITION ON mode, the electric cooling fan may automatically start to run if the air conditioning is on and/or the coolant temperature is high. ( $\rightarrow$ P. 476)

# 

# When working on or under the vehicle

Do not get under the vehicle with just the jack supporting it. Always use automotive jack stands or other solid supports.

# Safety glasses

Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in your eyes.

# 

# If you remove the air cleaner filter

Driving with the air cleaner filter removed may cause excessive engine wear due to dirt in the air. Also a backfire could cause a fire in the engine compartment.

# If the fluid level is low or high

Notf

It is normal for the brake fluid lever to go down slightly as the brake pads wear or when the fluid level in the accumulator is high.


If the reservoir needs frequent refilling, it may indicate a serious problem.

# Pull the hood release lever. STEP 1 The hood will pop up slightly. ✓ / ITN43M054 Move the auxiliary catch lever STEP 2 to side direction and lift the hood HOT RASMOSS **CAUTION** Pre-driving che Check that the hood is fully closed and locked. If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.


# Release the lock from the inside of the vehicle to open the hood.

# 4-3. Do-it-yourself maintenance Engine compartment

# **1GR-FE engine**








#### Engine compartment cover

#### Removing the engine compartment cover




Maintenance and care

#### **Engine oil**

With the engine at operating temperature and turned off, check the oil level on the dipstick.


#### Checking the engine oil

STEP 1 Park the vehicle on level ground. After turning off the engine, wait more than five minutes for the oil to drain back into the bottom of the engine.



TY43C009

#### **Diesel engine**



Make sure to check the **oi** type and prepare the items needed before adding oil.

Engine oil select		→P. 613
Oil quantity (Low → Full)	1GR-FE engine	1.7 L (1.8 qt., 1.5 lmp.qt.)
	1KD-FTV engine	1.3 L (1.4 qt., 1.1 Imp.qt.)
Items		Clean funnel

STEP 1 Remove the oil filler cap by turning it counterclockwise.

STEP 2 Add engine oil slowly, checking the dipstick.

STEP 3 Install the oil filler cap by turning it clockwise.

#### Engine oil consumption

- The amount of engine oil consumed depends on the oil viscosity, the quality of the oil and the way the vehicle is driven.
- More oil is consumed under driving conditions such as high speeds and frequent acceleration and deceleration.
- A new engine consumes more oil.
- •When judging the amount of oil consumption, keep in mind that the oil may have become diluted, making it difficult to judge the true level accuratelv.
- Oil consumption: Max. 1.0 L per 1000 km (1.1 gt./600m) iles. 0.9 Imp. at./ 600 miles)
- If you consume more than 1.0 L (1.1 qt., 0.9 Imp ct.) every 1000 km (600 Reprodi miles), contact your Toyota dealer.

#### **A** CAUTION

#### Used engine oil

- Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation or skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.
- Dispose of use Dil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the ground. Call your Toyota dealer, service station or auto parts store for information concerning recycling or disposal.

Do not leave used engine oil within the reach of children.

#### NOTICE

#### To prevent serious engine damage

Check the oil level on regular basis.


#### When replacing the engine oil

- Be careful not to spill engine oil on the vehicle components.
- Avoid overfilling, or the engine could be damaged.
- Check the oil level on the dipstick every time you refill the vehicle.
- Be sure the engine oil filler cap is properly tightened.

#### Engine coolant

The coolant level is satisfactory if it is between the "F" and "L" lines on the reservoir when the engine is cold.

#### **Gasoline engine**



#### Coolant selection

Only use "Toyota Super Long Life Coolant" or a similar high guality ethylene glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

"Toyota Super Long Life Coolant" is a mixture of 50 % coolant and 50 % deionized water. (Enabled: -35 °C [-31 °F])

For more details about engine coolant, contact your Toyota dealer.

#### If the coolant level drops within a short time of replenishing

Visually check the radiator, hoses, engine coolant reservoir aps, drain cock and water pump.

produc If you cannot find a leak, have your Toyota dealer test the cap and check for leaks in the cooling system.

#### **CAUTION**

#### When the engine is hot

Do not remove the radiator cap, or the coolant reservoir cap.

The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.

#### NOTICE

#### When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

#### If you spill coolant

Be sure to wash it off with water to prevent it from damage to parts or paint.

#### Radiator, condenser and intercooler

Check the radiator, condenser and intercooler and clear any foreign obiects.

If any of the above parts are extremely dirty or you are not sure of their condition, have your vehicle inspected by your Toyota dealer.

#### **CAUTION**

#### When the engine is hot

When the engine is hot Do not touch the radiator, condenser or intercooler as the may be hot and cause serious injuries, such as burns.


476

#### Battery


Check the battery as follows:

#### Battery exterior

Make sure that the battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.



- Terminals
   Hold-down clamp
- Checking battery fluid (vehicles with the battery indicator) Check the battery condition using the indicator color.



- 1 Blue: Good condition
- White: Charging is necessary. Have the vehicle inspected by your Toyota dealer.
- Red: Not working properly.
   Have the battery checked by your Toyota dealer.

#### Before recharging

When recharging, the battery produces hydrogen gas which is flammable and explosive. Therefore, observe the following before recharging:

- If recharging with the battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the battery.
- After recharging/reconnecting the battery (vehicles with a smart entry & start system)

The engine may not start. Follow the procedure below mitialize the system.

- STEP 1 Shift the shift lever to P (automatic transmission) or depress the brake pedal with the shift lever in N transmission).
- STEP 2 Open and close any of the doors

STEP 3 Restart the engine.

- Unlocking the doors using the smart entry & start system may not be possible immediately after reconnecting the battery. If this happens, use the wireless remote control or the mechanical key to lock/unlock the doors.
- Start the engine with the "ENGINE START STOP" switch in ACCES-SORY mode. The engine may not start with the "ENGINE START STOP" switch turned OFF. However, the engine will operate normally from the second attempt.
- The "ENGINE START STOP" switch mode is recorded by the vehicle. If the battery is reconnected, the vehicle will return the "ENGINE START STOP" switch mode to the status it was in before the battery was disconnected. Make sure to turn off the engine before disconnect the battery. Take extra care when connecting the battery if the "ENGINE START STOP" switch mode prior to discharge is unknown.

If the system will not start even after multiple attempts, contact your Toyota dealer.

#### 

#### Chemicals in the battery

Batteries contain poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near battery:

- Do not cause sparks by touching the battery terminals with tools.
- Do not smoke or light a match near the battery.
- Avoid contact with eyes, skin and clothes.
- Never inhale or swallow electrolyte.
- Wear protective safety glasses when working near the battery.
- Keep children away from the battery.

#### Where to safely charge the battery

Always charge the battery in an open area. Do not charge the battery in a garage or closed room where there is not sufficient ventilation.

#### Emergency measures regarding electrolyte

If electrolyte gets in your eyes
 Flush your eyes with clean water for at least 15 minutes and get immediate medical attention of possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility.

- If electrolyte gets on your skin
   Wash the affected area thoroughly. If you feel pain or burning, get medical attention immediately.
- If electrolyte gets on your clothes

It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.

 If you accidentally swallow electrolyte Drink a large quantity of water or milk. Get emergency medical attention immediately.

#### NOTICE

#### When recharging the battery


Never recharge the battery while the engine is running. Also, be sure all accessories are turned off.

#### When adding distilled water

Avoid overfilling. Water spilled during battery recharging may cause corrosion.




#### Washer fluid



If the washer fluid level is at "LOW", add washer fluid.

#### Using the gauge



The washer fluid level is checked by observing the position of the level on the liquid covered holes in the gauge.

from the bottom ("LOW" position), refill the washer fluid.

#### **CAUTION**

#### When adding washer fluid

Do not add washer fluid when the engine is hot or running as washer fluid contains alcohol and may catch fire if spilled on the engine etc.

#### **NOTICE**

#### Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid. Doing so may cause streaking on the vehicle's painted surfaces.

#### Diluting washer fluid

Dilute washer fluid with water as necessary. Refer to the freezing temperatures listed on the label of the washer fluid bottle.

#### Draining the fuel filter water (diesel engine only)

The water in the fuel filter must be drained immediately if the warning light and buzzer or warning message appears:


#### Vehicles with a non-optitron type meters

When the fuel system warning light flashes and buzzer sounds.

#### Vehicles with an optitron type meters

When the warning message "DRAIN WATER FROM FUEL FILTER" appears on the instrument cluster and buzzer sounds.

STEP 1 Remove the drain plug from the clamp and place a small tray to catch the water.




Turn the drain plug about 2-2-1/2 urns.

Loosening more than this will cause water oozing from around the drain plug.

Operate the priming pump until the fuel begins to run out.

STEP 3 After draining, retighten the drain plug. Do not use a tool.

#### **Discharging dust valve**



Squeeze the rubber cap to remove the dust if the discharging dust valve is dirty.

Shape of the valve differs slightly in accordance with the engine.

#### To prevent damaging the engine

NOTICE To prevent damaging the engine Do not drive with the discharging dust give removed. Doing so cause excessive engine wear Also backfiring row result in a firm in the Do not drive with the discharging dust valve removed. Doing so cause excessive engine wear. Also backfiring may result in a fire in the engine compartment.

# Maintenance and care

# 4-3. Do-it-yourself maintenance **Tires**


Replace or rotate tires in accordance with maintenance schedules and treadwear.

TY41C001

Checking tires

Tire rotation

Front



- 1 New tread
- 2 Treadwear indicator
- 3 Worn tread

The location of treadwear indicators is shown by the "TWI" or " $\triangle$ " marks, etc., molded on the sidewall of each tire.

Check spare tire condition and pressure if not rotated.

otate the tires in the order hown.

To equalize tire wear and help extend tire life, Toyota recommends that you rotate your tires approximately every 5000 km (3000 miles).



#### When to replace your vehicle's tires

Tires should be replaced if:

- •You have tire damage such as cuts, splits, cracks deep enough to expose the fabric, and bulges indicating internal damage
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage

If you are not sure, consult with your Toyota dealer.

#### Tire life

Any tire over 6 years old must be checked by a gualified technician even if it has seldom or never been used or damage is not obvious

#### If the tread on snow tires wears down below 4 mm (0.16 in.)

The effectiveness of the tires as snow tires is lost.

Observe the following precautions to prevent accidents.

When inspecting or replacing tires Observe the following precent Failure to do so Failure to do so may cause damage to parts of the drive train as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- Do not mix tires of different makes, models or tread patterns. Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Toyota.
- Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- Do not mix summer, all season and snow tires.
- Do not use tires that have been used on another vehicle. Do not use tires if you do not know how they were used previously.

#### NOTICE

#### Driving on rough roads

Take particular care when driving on roads with loose surfaces or potholes. These conditions may cause losses in tire inflation pressure, reducing the cushioning ability of the tires. In addition, driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.

#### If tire inflation pressures become low while driving

Do not continue driving, or your tires and/or wheels may be ruined.



## 4-3. Do-it-yourself maintenance Tire inflation pressure

Make sure to maintain the proper tire inflation pressure. Tire inflation pressure should be checked at least once per month. However, Toyota recommends that tire inflation pressure be checked once every two weeks. ( $\rightarrow$ P. 622)

#### Effects of incorrect tire inflation pressure

duction Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel efficiency
- Reduced driving comfort and tire life
- Reduced safety
- Damage to the drive train
- If a tire needs frequent inflating, have it checked by your Toyota dealer.

#### Instructions for checking tire inflation pressure

When checking tire inflation pressure observe the following:


• Check only when the tires are cold.

If your vehicle has been parked for at least 3 hours and has not been driven for more than the work of 1 mile, you will get an accurate cold tire inflation pressure reading.

• Always use a tire pressure gauge.

The appearance of the tire can be misleading. In addition, tire inflation pressure that is even just a few pounds off can affect ride quality and handling.

- Do not reduce tire inflation pressure after driving. It is normal for tire inflation pressure to be higher after driving.
- Never exceed the vehicle capacity weight. Passengers and luggage weight should be placed so that the vehicle is balanced.



#### NOTICE

#### When inspecting and adjusting the inflation pressure

Be sure to put the tire valve cape back on.

Without the valve caps, dirt or moisture could get into the valve and cause air leakage, which could result in an accident. If the caps are lost, replace them as soon as possible.

If a wheel is bent, cracked or heavily corroded, it should be replaced. Otherwise, the tire may separate from the wheel or cause loss of handling control.

#### Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width, and inset*.

Replacement wheels are available at your Toyota dealer.

ductio Toyota does not recommend using the following:

- *: Conventionally referred to as "offset".
- Wheels of different sizes or types
- Used wheels
- Bent wheels that have been straightened

#### Aluminum wheel precautions

- Use only Toyota wheel outs and wrenches designed for use with your aluminum wheels.
- When rotating, repairing or changing your tires, check that the wheel nuts are still tight after driving 1600 km (1000 miles).
- Be careful not to damage the aluminum wheels when using tire chains.


• When balancing your wheels, use only Toyota genuine balance weights or the equivalent. If clip-on balance weights are being used, use a plastic or rubber hammer to install the weight.

#### **CAUTION**

#### When replacing wheels

- Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in loss of handling control.
- Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing death or serious injury.

#### When installing the wheel nuts





- Be sure to install the wheel nuts with the tapered end facing inward. Installing the nuts with the tapered end facing outward can cause wheel to break and eventually cause a wheel to come off while driving, which could lead to an accident resulting in death or serious injury.
- Never use oil or grease on the wheel bolts or wheel nuts.

Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to bosen and the wheel may fall off, causing an accident and resulting in death or serious injury. Remove any oil or grease from the wheel bolts or wheel nuts. The air conditioning filter must be cleaned or changed regularly to maintain air conditioning efficiency.

#### Removal method

STEP 1 Turn the engine switch (vehicles without a smart entry & start system) or "ENGINE START STOP" switch (vehicles with a smart entry & start system) off.






If an air gun is not available, have the filter cleaned by your Toyota dealer.

#### Checking interval

Inspect, clean and replace the air conditioning filter according to the maintenance schedule. In dusty areas or areas with heavy traffic flow, more frequent cleaning or early replacement may be required. (For scheduled maintenance information, please refer to the "Warranty and Service Booklet".)

#### If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.



# 4-3. Do-it-yourself maintenance Wireless remote control/electronic key battery

Replace the battery with a new one if it is depleted.


#### You will need the following items:


- Flathead screwdriver
- Lithium battery


Vehicles without a smart entry & start system: CR2016

Vehicles with a smart entry & start system: CR1632

#### Replacing the battery







Remove the depleted battery.

HOR

Insert a new battery with the "+" terminal facing up.

#### Use the following types of lithium battery

Vehicles without a smart entry & start system OR2016 Vehicles with a smart entry & start system: OR1632

- Batteries can be purchased at your Toyota dealer, local electrical appliance shops or camera stores.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the local laws.

#### If the electronic key battery is depleted

The following symptoms may occur:

- The smart entry & start system (if equipped) and wireless remote control will not function properly.
- The operational range will be reduced.

Maintenance and care

#### **CAUTION**

#### Removed battery and other parts

Keep away from children. These parts are small and if swallowed by a child, they can cause choking. Failure to do so could result in death or serious injury.


#### NOTICE

#### For normal operation after replacing the battery

Observe the following precautions to prevent accidents


- Always work with dry hands. Moisture may cause the battery to rust.
- NotforRepro Do not touch or move any other components inside remote control.
- Do not bend the battery terminals.

## 4-3. Do-it-yourself maintenance Checking and replacing fuses



STEP 3 After a system failure, see "Fuse layout and amperage ratings" (→P. 502) for details about which fuse to check.


STEP 4 Remove the fuse with the pull-out tool.



STEP 5 Check if the fuse is blown.

#### Туре А

Туре В



Only type A fuse can be removed using the pullout tool.




Blown fuse

Replace the blown fuse with one of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.


- Normal fuse
- 2 Blown fuse

Contact your Toyota dealer.



#### Fuse layout and amperage ratings

#### **Engine compartment**



	Fuse	Ampere	Circuit
1	A/C RR	• 40 A	Rear air conditioning system
2	PTC HTR NOB	30 A	—
3	AIR SUS	50 A	Air suspension system, AIR SUS NO.2
4	INV	15 A	Inverter
5	DEF	30 A	Rear window defogger
6	FOG RR	7.5 A	Rear fog lights
7	DEICER	20 A	—

Fuse		Ampere	Circuit
8	FUEL HTR*2	25 A	Fuel heater
	AIR PMP HTR ^{*1}	10 A	Air pump heater
9	PTC HTR NO.2	30 A	PTC heater
10	PTC HTR NO.1	50 A	PTC heater
11	IG2	20 A	Injector, ignition, meter
12	HORN	10 A	Horn
13	EFI	25 A	EFI ECU, EDU, ECT ECU, fuel pump, A/F heater telay, FPC, EFI NO.2
14	A/F ^{*1}	20 A	A/F SSR
15	MIR HTR	15 A	Mirrorheater
16	VISCUS*2	10 A	0
17	FOLD SEAT LH	30 A	Folding seat (left)
18	FOLD SEAT RH	30 A	Folding seat (right)
19	A/C COMP	A OO	Air conditioning system
20	CDS FAN	20 A	Condenser fan
21	STOP HOL	10 A	Emergency stop light relay, stop lights, high mount stop light, stop light switch, VSC/ABS ECU, tow- ing, smart entry & start system, ECT ECU
22	AIR SUS NO.2	7.5 A	AIR SUS ECU
23	H-LP RH-HI	15 A	Headlight high beam (right)
24	H-LP LH-HI	15 A	Headlight high beam (left)


Fuse		Ampere	Circuit
25	25 HTR 50 A		Air conditioning system
26	WIP WSH RR	30 A	Rear window wipers and washer
27	H-LP CLN	30 A	Headlight cleaner
28	ST	30 A ^{*1} 40 A ^{*2}	STARTER MTR
29	H-LP HI	25 A	DIM relay, headlights
30	ALT-S	7.5 A	ALT
31	TURN & HAZ	15 A	Front turn signal light, rear turn sig- nal light, side turn signal light, meter turn signal light, trailer light
32	D/L NO.1	25 A	Door lockmotor, glass hatch opener
33	ETCS ^{*1}	10 A	EFLECU
34	FUEL PMP*3	15 A	Fuel pump
35	TOWING	30 A	Towing
36	ALT NOL	120 A	Air conditioning system, AIR SUS, headlight cleaner, PTC heater, tow- ing, folding seat, STOP, rear win- dow defogger, MIR HTR, CDS FAN, RR FOG, DEICER, MG-CLT, J/B, INV, RR WIP, RR WSH
37	P/I-B	80 A	Injector, ignition, meter, EFI, A/F heater, horn
38	GLOW ^{*2}	80 A	Glow plug
39	RAD NO.1	15 A	Audio system, navigation system, rear seat entertainment system

Fuse		Ampere	Circuit	
40	0 AM2 7.5 A		Starter system	
41	RAD NO.2	10 A	Navigation system	
42	MAYDAY ^{*1}	7.5 A	Multiport fuel injection system/ sequential multiport fuel injection system	
43	AMP	30 A	Audio system	
44	ABS NO.1	50 A	ABS, VSC	
45	ABS NO.2	30 A	ABS, VSC	
46	AIR PMP ^{*1}	50 A		
47	SECURITY	10 A	Multiport fue triection system/ sequential multiport fuel injection system	
48	SMART	7.5 A	Smart entry & start system	
49	STRG LOCK	20 A	Steering lock system	
50	TOWING BRK	30 A	Towing	
51	WIP RR LA R		Rear window wiper	
52	DOME NOT	10 A	Interior lights, personal lights, van- ity lights, door courtesy lights, foot- well lights, outer foot lights, overhead module	
53	53 ECU-B 10 A sensor, wireless remote control seat position memory, tilt and te scopic steering, multi display, sn entry & start system, folding sea cool box, DSS#2 ECU, steering		BODY ECU, meter, heater, steering sensor, wireless remote control, seat position memory, tilt and tele- scopic steering, multi display, smart entry & start system, folding seat, cool box, DSS#2 ECU, steering switch, D-module switch, overhead module	

Fuse		Ampere	Circuit
54	H-LP RH-LO	15 A	Headlight low beam (right), head- light leveling system
55	H-LP LH-LO	15 A	Headlight low beam (left)
56	INJ	10 A	Coil, injector, ignition, ECT ECU, noise filter
57	EFI NO.2	10 A	O2 SSR, AFM, ACIS VSV, AI COMB, EYP VSV, AI DRIVER, EGR VRV, SWIRL VSV, SWIRL VSV 2, E/G CUT VSV, EGR COOL BYPASS VSV, D-SLDT ROTARY SOL, AI VSV RLY
58	WIP FR NO.2	7.5 A	DSS#1 ECU
59	WSH RR	15 A	Rear window washer
60	SPARE		Spare fuse
61	SPARE		Spare fuse
62	SPARE	~~	Spare fuse

*1: 1GR -FE models only *2: 1KD-FTV models only *3: 1KD-FTV models with sub fuel tank only

#### Under the instrument panel



Fuse		Ampere	Circuit
1	P/OUTLET	15 A	Poweroutlet
2	ACC	75 A	Outside rear view mirror motor, BODY ECU, air conditioning sys- tem, audio system, navigation sys- tem, parking assist system, sequential switch, back up relay, DSS#2 ECU, AT indicator, EFI ECU, shift lock ECU
3	BKUP L	10 A	Back-up lights, audio system, multi information display, DSS#2 ECU, parking assist sensor
4	TOWING BKLP	10 A	Towing
5	AVS	20 A	Air suspension system
6	KDSS	10 A	KDSS ECU
7	4WD	20 A	4WD system, rear differential lock
8	P/SEAT FL	30 A	Front power seat (left)

Fuse		Ampere	Circuit
9	D/L NO.2	25 A	Door lock motor, glass hatch opener, BODY ECU
10	PSB	30 A	PSB ECU
11	TI & TE	15 A	Tilt and telescopic steering
12	FOG FR	15 A	Front fog lights
13	OBD	7.5 A	DLC 3
14	A/C	7.5 A	Air conditioning system
15	AM1	7.5 A	-
16	DOOR RL	25 A	Rear power window (left)
17	ECU-IG NO.1	10 A	Shift lock ECU, VSC ECU, steering sensor , aw rate sensor, sequential switch, auto wiper ECU, back up relay, outside rear view mirror heater, tilt & telescopic steering, PSB ECU, DSS#1 ECU, front radar sensor, power steering ECU
18	IG1	7.5 A	Front turn signal light, rear turn sig- nal light, side turn signal light, meter turn signal light, trailer light, ALT, VSC, C/C switch
19	ECU-IG NO.2	10 A	Rear window defogger, seat heater switch, inverter relay, air condition- ing system, EC mirror, BODY ECU, navigation system, DSS#2 ECU, moon roof ECU, meter switch, parking assist sensor, accessory meter, folding seat ECU, O/H IG, D- module, rain sensor, air suspen- sion, P/SEAT IND
20	S/HTR FR	20 A	Seat heater
21	P/SEAT FR	30 A	Front power seat (right)


	Fuse	Ampere	Circuit
22	DOOR P	30 A	Front power window (passenger's side)
23	DOOR	10 A	Power window
24	DOOR D	25 A	Front power window (driver's side)
25	DOOR RR	25 A	Rear power window (right)
26	S/ROOF	25 A	Moon roof
27	WIP	30 A	Windshield wipers and washer
28	WASHER	20 A	Windshield wipers and washer, rear window wipers and washer
29	COOLING	10 A	Cool box
30	IGN	10 A	EFI ECD, C/OPN RLY, VSC ECU, air bag ECU, smart entry & start system, steering lock ECU
31	GAUGE	7.5 A	Neter
32	PANEL	<b>0</b> .5 A	Switch illumination, glove box light, navigation system, audio system, air conditioning system, outside rear view mirror switch, folding seat switch, multi-information display, P/SEAT IND, SHIFT, COOL BOX
33	TAIL	10 A	Front position lights, tail lights, license plate lights, towing, front fog lights

#### After a fuse is replaced

- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement. (→P. 511)
- If the replaced fuse blows again, have the vehicle inspected by your Toyota dealer.

#### If there is an overload in a circuit

The fuses are designed to blow, ptorecting the wiring harness from damage.



#### Before replacing fuses

Have the cause of electrical overload determined and repaired by your Toyota dealer as soon as possible.


You may replace the following bulbs yourself. The difficulty level of replacement varies depending on the bulb. If necessary bulb replacement seems difficult to perform, contact your Toyota dealer.

For more information about replacing other light bulbs, contact your Toyota dealer.

# Preparing for light bulb replacement Check the wattage of the light bulb being replaced. (→P. 623) Removing the engine compartment covers →P. 469 Front bulb locations Headlight high beam Front position light Headlight high beam Front position light Front turn signal light Headlight how beam (halogen bulb)


#### Rear bulb locations


#### Vehicles with under floor mounted spare tire



#### Replacing light bulbs

#### Headlight low beams (vehicles with halogen bulbs)






## **1** Remove the fender liner bolt STEP 1 and partly remove the fender liner. 2 Unplug the connector while pushing the lock release. TINA 3M035 PIOQUICTION 1 Turn the light bulb counterclock-STEP 2 TN43M118


#### Front fog lights (if equipped)

#### Front position lights




Turn the bulb base counterclockwise.


The shape of the bulb base differs slightly on the let and right



#### Front turn signal lights


STEP 1 Remove the fender liner bolts.






#### Rear turn signal lights and back-up lights


STEP 1 Open the back door.






#### License plate lights

#### Vehicles with under floor mounted spare tire



#### Vehicles with back door mounted spare tire



#### Lights other than the above

If any of the lights listed below has burnt out, have it replaced by your Toyota dealer.

- Headlight low beams (high-intensity discharge bulbs)
- Side turn signal lights
- High mounted stoplight
- Stop/tail lights

#### High-intensity discharge (HID) headlights

If voltage to the high-intensity discharge bulbs is insufficient, the light may not come on, or may go out temporarily. The high-intensity discharge bulbs will come on when normal power is restored.


#### LED light bulbs


The side turn signal lights, tail/stop lights and high mounted stoplight consists of a number of LEDs. If any of the LEDs burn out, take your vehicle to your Toyota dealer to have the light replaced.

#### Condensation build-up on the inside of the lens

Contact your Toyota dealer for more information in the following situations. Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction.

Large drops of water are built up on the inside of the lens.





#### When trouble arises

### 5

#### 5-1. Essential information


Emergency flashers	526
If your vehicle needs	
to be towed	528
If you think something is	
wrong	535
Fuel pump shut off system	
(dasoline engine only)	536

### 5-2. Steps to take in an emergency If a warning light turns on or a warning byzzer sounds... message is NotForRepro ve a flat tire ...... 567 If you lose your keys ...... 589 If the electronic key does not If your vehicle If you run out of fuel and If your vehicle has to

## 5-1. Essential information **Emergency flashers**

Use the emergency flashers if the vehicle malfunctions or is involved in an accident.

#### Туре А




Press the switch to flash all the turn signal lights. To turn them off, push the switch once again.




#### Туре В

Type C



Press the switch to flash all the turn signal lights. To turn them off, push the switch once again.



TN51M022

#### 

#### To prevent battery discharge

Do not leave the emergency flashers on longer than necessary when the engine is not running.



When trouble arises

#### 5-1. Essential information If your vehicle needs to be towed

If towing is necessary, we recommend having your vehicle towed by your Toyota dealer or a commercial towing service, using a lift-type truck or a flat bed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws.

#### Before towing

The following may indicate a problem with your transmission. Contact your Toyota dealer before towing.

• The engine is running but the vehicle will not not

• The vehicle makes an abnormal sound in the vehicle makes an abnormal sound in the vehicle will not the vehicle w

#### **Emergency towing**


If a tow truck is not available in an emergency, your vehicle may be temporarily towed using a cable or chain secured to the emergency towing hooks. This should only attempted on hard surfaced roads for short distances at low speeds.

A driver must be in the vehicle to steer and operate the brakes. The vehicle's wheels, drive train, axles, steering and brakes must be in good condition.


For vehicles with an automatic transmission, only the front towing hooks may be used.

# productio Towing hook (front) ITN51M001 Towing hook (rea N TN51M002

#### Towing with a sling-type truck



#### Using a flat bed truck



If your Toyota is transported by a flat bed truck, it should be tied down at the locations shown in the illustration.



If you use chains or cables to tie down your vehicle, the angles shaded in black must be 45°.

Do not overly tighten the tie downs or the vehicle may be damaged.

#### Before emergency towing

#### Vehicles without a smart entry & start system

- STEP 1 Release the parking brake.
- STEP 2 Put the four-wheel drive control switch in H4F. (The center differential is unlocked.)
- STEP 3 Shift the shift lever in N (automatic transmission) or neutral (manual transmission).
- STEP 4 Put the engine switch in the "ACC" (engine off) or "ON" position (engine running).

#### Vehicles with a smart entry & start system

- STEP 1 The "ENGINE START STOP" switch must be in the ACCESSORY mode (engine off) or IGNITION ON mode (engine running).
- STEP 2 Put the four-wheel drive control switch in H4. (The center differential is unlocked.)
- STEP 3 Put the vehicle height in the Namede and press height control switch to turn off the rear height control air suspension. (if equipped)
- STEP 4 Shift the shift lever in N (automatic transmission) or neutral (manual transmission).
- STEP 5 Release the parking brake.

#### 

#### Caution while towing

 Use extreme caution when towing the vehicle. Avoid sudden starts or erratic driving maneuvers which place excessive stress on the emergency towing hook and the cables or chains. Always be cautious of the surroundings and other vehicles while towing.


 Vehicles with a smart entry & start system: Do not turn the "ENGINE START STOP" switch off. Doing so will lock the steering wheel and prevent operation, possibly causing an accident and resulting in death or serious injury.

- If the engine is not running, the power assist for the brakes and steering will not function, making steering and braking more difficult.
- Before emergency towing (vehicles with rear height control air suspension)

When your vehicle is towed, put the vehicle leight in the "N" mode and push the height control off button to turn of the rear height control suspension system.

Otherwise, the vehicle height may be changed in the automatic leveling function, resulting in an unexpected accident. For details, refer to the "Off-road driving Owner's manual"

Not



If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact your Toyota dealer as soon as possible.

#### Visible symptoms

- Fluid leaks under the vehicle (Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear
- Engine coolant temperature gauge needle continually points ductio higher than normal

#### Audible symptoms

- Changes in exhaust sound
- Excessive tire squeal when corneri
- Strange noises related to the suspension system
- Pinging or other noises related to the engine

#### Operational symptoms

- Engine missing, sturbling or running roughly
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking
- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

#### 5-1. Essential information Fuel pump shut off system (gasoline engine only)

To minimize the risk of fuel leakage when the engine stalls or when an airbag inflates upon collision, the fuel pump shut off system stops the supply of fuel to the engine.

Follow the procedure below to restart the engine after the system is activated

#### Vehicles without a smart entry & start system

STEP 1 Turn the engine switch to the "ACC" or "LOCK" position.

STEP 2 Restart the engine.

#### Vehicles with a smart entry & start system

STEP 1 Turn the "ENGINE START STOP" switch to ACCESSORY mode Reproc or turn it off.

STEP 2 Restart the engine.

#### NOTICE

#### Before starting the engine

Inspect the ground under the vehicle.

If you find that fuel has leaked on to the ground, the fuel system has been damaged and is in need of repair. Do not restart the engine.

Calmly perform the following actions if any of the warning lights comes on or flashes. If a light comes on or flashes, but then goes off, this does not necessarily indicate a malfunction in the system. However, if this continues to occur, have the vehicle inspected by your Toyota dealer.

Stop the vehicle immediately. Continuing to drive the vehicle may be dangerous.

The following warning indicates a possible problem in the brake system. Immediately stop the vehicle in a safe place and contact your Toyota dealer.

Warning light	Warning light/Details
	<ul> <li>Brake system warning light (warning buzzer)*</li> <li>Low brake fluid</li> <li>Malfunction in the brake system This light also comes on when the parking brake is not released. If the light turns off after the parking brake is fully released the system is operating normally.</li> </ul>

*: Parking brake engaged warning buzzer:

A buzzer will sound if the vehicle is driven at a speed of approximately 5 km/h (3 mph) or more.

#### Stop the vehicle immediately.

The following warnings indicate the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and contact your Toyota dealer.

Warning light	Warning light/Details
<b>-</b> +	Charging system warning light Indicates a malfunction in the vehicle's charging system.
عتي:	Low engine oil pressure warning light (vehicles with non-optitron type meters) Indicates that the engine oil pressure is too low
	NotForReproduc

#### Have the vehicle inspected immediately.

Failure to investigate the cause of the following warnings may lead to the system operating abnormally and possibly cause an accident. Have the vehicle inspected by your Toyota dealer immediately.

Warning light	Warning light/Details
ι ^ζ ι	<ul> <li>Malfunction indicator lamp</li> <li>Indicates a malfunction in:</li> <li>The emission control system;</li> <li>The electronic engine control system;</li> <li>The electronic throttle control system;</li> <li>The electronic automatic transmission control system.</li> </ul>
×	<ul> <li>SRS warning light</li> <li>Indicates a malfunction in:</li> <li>The SRS airbag system or</li> <li>The seat belt pretensioner system.</li> </ul>
(ABS)	ABS warning light Indicates a malfunction in: • The ABS; or • The brake assist system
<b>@!</b>	Power steering system warning light Indicates a malfunction in the power steering system
PCS (Flashes)	<ul> <li>Pre-crash safety system warning light (vehicles with optitron type meters)*1 Indicates a malfunction in the pre-crash safety system. The warning light will operate as follows, even when the system is not malfunctioning: <ul> <li>The light will flash quickly when the system is operating.</li> <li>(→P. 284)</li> </ul> The light will turn on when the pre-crash braking is disabled. (→P. 285) The light will turn on when the system cannot temporarily be used. (→P. 554)</li></ul>

Warning light	Warning light/Details
	<ul> <li>Slip indicator light Indicates a malfunction in: <ul> <li>Vehicle Stability Control;</li> <li>Traction Control*1;</li> <li>The indicator will blink when the system listed above or below is operational. (→P. 278)</li> <li>Active TRC*1,2;</li> <li>Down Hill assist Control*1,2;</li> <li>Hill-start Assist Control*1,2; or</li> <li>Crawl Control*1,2.</li> </ul></li></ul>
A/T OIL TEMP	<ul> <li>Automatic transmission fluid temperature warning light (vehicles with an automatic transmission) (vehicles with non-optitron type meters)</li> <li>Indicates that the automatic transmission fluid temperature is too high if the light comes on. Stop the vehicle in a safe place, shift the shift lever to P and wait until the light goes off. If the light goes off, you may start the vehicle again.</li> <li>Indicates a maliunction in the automatic transmission sys- tem if the light flashes.</li> </ul>
KDSS	KDSS warning light ^{*1} Indicates a malfunction in KDSS
T-BELT	Timing belt replacement warning light (vehicles with non-optitron type meters) ^{*3} Indicates that the timing belt should be replaced.
	<ul> <li>Fuel system warning light (vehicles with non-optitron type meters)^{*3} (warning buzzer)^{*4}</li> <li>Indicates:</li> <li>The amount of accumulated water in the fuel filter has reached the specified level if the light flashes.</li> <li>Malfunction in the fuel system if the light comes on.</li> </ul>

- *1: If equipped
- *2: Refer to the "Off-road Driving Owner's Manual"
- *3: 1KD-FTV models only
- *4: The buzzer will sound at the same time the warning light flashes.

## Follow the correction procedures.

After taking the specified steps to correct the suspected problem, check that the warning light goes off.

Warning light	Warning light/Details	Correction procedure
	Open door warning light (warning buzzer)*1 Indicates that a door or glass hatch is not fully closed.	Check that all doors or glass hatch are closed.
	Low fuel level warning light Vehicles without sub fuel tank: Indicates that remaining fuel is about 13.0 L (3.4 gal., 2.8 Imp.gal.) or less if the light comes on Vehicles with sub fuel tank ^{*2} : Indicates that remaining fuel is about 22.0 L (5.8 ca), 4.8 Imp.gal.) or less if the light comes on. 1KD-FTV models with sub fuel tank ^{*2} only: Indicates that remaining fuel is about 22.0 L (5.8 gal., 4.8 Imp.gal.) or less if the light flashes.	Refuel the vehicle.
X	Driver's seat belt reminder light (warning buzzer) ^{*3} Warns the driver to fasten his/her seat belt.	Fasten the seat belt.

Warning light	Warning light/Details	Correction procedure
(On the center panel)	Front passenger's seat belt reminder light (warning buzzer) ^{*3} Warns the front passen- ger to fasten his/her seat belt.	Fasten the seat belt.
	Master warning light (if equipped) A buzzer sounds and the warning light comes on or flashes to indicate that the master warning system has detected a malfunc- tion.	Take appropriate action in accordance with the mes- sage displayed on the multi- information display.
	Low engine oil level warroing light (vehicles with non-optitron type meters) Indicates that the engine oil level is too low.	Add oil.

*1:Open door warning buzzer

The open door warning buzzer sounds to alert one or more of the doors is not fully closed (with the vehicle having reached a speed of 5 km/h [3 mph]).

*2:If equipped

*3:Driver's and front passenger's seat belt reminders:

The driver's and front passenger's seat belts reminder sounds to alert the driver and front passenger that his/her seat belt is not fastened. The buzzer sounds for 30 seconds after the vehicle has reached a speed of at least 20 km/h (12 mph). Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 90 more seconds.

# Follow the correction procedures. (Smart entry & start system warning light and buzzer) (vehicles with non-optitron type meters)

After taking the specified steps to correct the suspected problem, check that the warning light turns off.

Interior buzzer	Exterior	Warning light	Details	Correction procedure
Contin- uous	Contin- uous	<b>-j-</b> 0	Indicates that the driver's door was opened and closed while the electronic key was not in the vehicle, the shift lever was not in R (auto- matic transmission) or N (manual transmis- sion) and the "ENGINE S MART STOP" switch was not turned off.	<ul> <li>Shift the shift lever to P.</li> <li>Bring the electronic key back into the vehicle.</li> </ul>
Sounds once	3 times		Indicates that the driver's door has been opened or closed with the "ENGINE START STOP" switch in any mode other than OFF, the shift lever was in P (automatic transmis- sion) or N (manual transmission) and the electronic key outside of the detection area.	<ul> <li>Turn the "ENGINE START STOP" switch off.</li> <li>Bring the electronic key back into the vehicle.</li> </ul>

Interior buzzer	Exterior	Warning light	Details	Correction procedure
Sounds once	Sounds once for 10 sec- onds	(Comes on for about 60 seconds.)	Indicates that the "ENGINE START STOP" switch in any mode other than OFF, the shift lever was in P (vehicles with an auto- matic transmission), the electronic key out- side of the detection area and attempt to lock the vehicle with smart entry & start sys- tem.	<ul> <li>Turn the "ENGINE START STOP" switch off.</li> <li>Bring the electronic key back into the vehicle.</li> </ul>
Sounds once	Sounds 3 times		Indicates that a door other than the driver's door has been opened or closed with the "ENGINE START STOP" switch in any mode other than OFF, the shift lever was in P (automatic transmis- sion) or N (manual transmission) and the electronic key outside of the detection area.	<ul> <li>Turn the "ENGINE START STOP" switch off.</li> <li>Bring the electronic key back into the vehicle.</li> </ul>
Sounds once		<b>~!-</b> 0	Indicates the elec- tronic key is not present when attempt- ing to start the engine.	Confirm the location of the elec- tronic key

#### If the malfunction indicator lamp comes on while driving

The malfunction indicator lamp will come on if the fuel tank becomes completely empty. If the fuel tank is empty, refuel the vehicle immediately. The malfunction indicator lamp will go off after several trips.

If the malfunction indicator lamp does not go off, contact your Toyota dealer as soon as possible.

#### If the low speed four-wheel drive indicator light or the center differential lock indicator light blinks

Take the specified steps. ( $\rightarrow$ Refer to the "Off-road Driving Qwner's Manual")

#### Front passenger detection sensor and passenger seat belt reminder

- If luggage is placed on the front passenger seat the front passenger detection sensor may cause the warning light to flash, even if a passenger is not sitting in the seat.
- If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.

#### Customization

The vehicle speed linked seat bet reminder buzzer can be disabled. (Customizable features  $\rightarrow$  P. 628)

(Customizable features →P, 628)

## **CAUTION**

#### If both the ABS and the brake system warning lights remain on

Stop your vehicle in a safe place immediately and contact your Toyota dealer. The vehicle will become extremely unstable during braking, and the ABS system may fail, which could cause an accident resulting in death or serious injury.

#### When the power steering system warning light comes on

The steering wheel may become extremely heavy.

If the steering wheel becomes heavier than usual when operating, hold ,ouctio firmly and operate using more force than usual.

# NOTICE

# If the fuel filter warning light comes on

Never drive the vehicle with the warning light on. Continued driving with water accumulated in the fuel filter with damage the fuel injection pump. Notfor

546

# 5-2. Steps to take in an emergency If a warning message is displayed^{*}

The multi-information display shows warnings of system malfunctions, incorrectly performed operations, or shows messages that indicate a need for maintenance.

If a warning is shown on the multi-information display, stay calm and perform the following actions:



1 Master warning light

The master warning light also comes on or flashes in order to indicate that a message is currently being displayed on the multi-information display.

2 Multi-information display

If any of the warning lights comes on again after the following actions have been performed, contact your Toyota dealer.

*: If equipped


## Stop the vehicle immediately

A buzzer sounds and a warning message is shown on the multi-information display. The following warning indicates the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and contact your Toyota dealer.


Warning message	Details
ENGINE OIL PRESSURE LOW	Indicates abnormal engine of pressure The warning light may come on if the engine oil pressure is too low.

## Have the vehicle inspected immediately.

A buzzer sounds and a warning message is shown on the multi-information display. Failure to investigate the cause of the following warnings may lead to the system operating abnormally and possibly cause an accident Have the vehicle inspected by your Toyota dealer immediately.



Warning message	Details
CHECK PCS SYSTEM	Indicates a malfunction in the pre-crash safety system
PCS (Flashes)	
(If equipped)	70;
CHECK SONAR SYSTEM	Indicates a malfunction in the parking assist- sensor The malfunctioning sensor is shown flashing on
(If equipped)	the display.
	0
40	



## Follow the correction procedures.

A buzzer sounds and a warning message is shown on the multi-information display. After taking the specified steps to correct the suspected problem, check that the warning message goes off.

Warning message	Details	Correction procedure
5-door / 3-door models models		
	611	ction
	Indicates that one or more of the doors is not fully closed The system also indi- cates which doors are not fully closed.	
P Not	h the vehicle reaches a speed of 5 km/h (3 mph), flashes and a buzzer sounds	Make sure that all the doors are closed.
	to indicate that the door(s) are not yet fully closed.	

Warning message	Details	Correction procedure
(If equipped)	Indicates that the glass hatch is not fully closed If the vehicle reaches a speed of 5 km/h (3 mph), flashes and a buzzer sounds to indicate that the glass hatch is not yet fully closed.	Close the glass hatch.
MOONROOF OPEN (Flashes) (If equipped)	Indicates that the moon roof is not fully closed (with the "ENGINE START STOP" switchoff, and the driver's door open)	Close the moon roof.
RELEASE PARKING BRAKE	Indicates that the parking brake is still engaged If the vehicle reaches a speed of 5 km/h (3 mph), flashes and a buzzer sounds to indicate that the parking brake is still engaged.	Release the parking brake.

Warning message	Details	Correction procedure
	Indicates that engine oil level is low	Check the level of engine oil, and add if necessary. This message may appear if the vehicle is stopped on a slope. Move the vehicle to a level surface and check to see if the message disappears.
DRAIN WATER FROM FUEL FILTER	Indicates that the amount of accumus lated water in the fuer filter has reached the specified level	Drain the water from the fuel filter. $(\rightarrow P. 483)$
T-BELT MAINTENANCE REQUIRED (Diesel engine)	Indicates that the tim- ing belt is scheduled to be changed.	Have the timing belt checked and/or changed by your Toyota dealer.
PCS TEMPORARILY NOT AVAILABLE PCS (If equipped)	Indicates that the pre- crash safety system is not currently func- tional	<ul> <li>Clean the grille and the sensor.</li> <li>In case of overheating, the system will become functional once the system cools down.</li> </ul>

Warning message	Details	Correction procedure
CLEAN SONAR	Indicates that parking assist-sensor is dirty or covered with ice A buzzer also sounds.	Clean the sensor.
CLEAN RADAR SENSOR	Indicates that the radar cruise control sensor is dirty or cov ered with ice A buzzer also sounds.	Clean the grill and the sensor if they are dirty.
CRUISE CONTROL NOT AVAILABLE (Flashes) (If equipped)	Indicates that the radar cruise control system is unable to judge vehicle-to-vehi- cle distance A buzzer also sounds.	If the windshield wipers are on, turn them off or set them to a mode other than "AUTO" or high speed wiper oper- ation.

Warning message	Details	Correction procedure
(If equipped)	Indicates that your vehicle is nearing the vehicle ahead (in radar cruise mode)	Slow the vehicle by applying the brakes.
BRAKE! PCS (Flashes) (If equipped)	Indicates that there is a high possibility of a frontal collision, or that collision, or that the pre-crash braking function is operating A buzzer also sounds.	Sow the vehicle by applying the brakes.
CHECK FUEL SYSTEM	Indicates that remain- ing fuel is approxi- mately 22.0 L (5.8 gal., 4.8 Imp.gal.) or less A buzzer also sounds.	Refuel the vehicle.

*: 1KD-FTV models with sub fuel tank only

# Have the malfunction repaired immediately.

After taking the specified steps to correct the suspected problem, check that the warning message and light go off.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Sounds once		KEY NOT DETECTED	The electronic key is not detected when an attempt is made to stan the engine.	Confirm the location of the elec- tronic key.
		(Flashes)		
		NotforRep	SOC	

When trouble arises

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Sounds	Sounds	KEY NOT DETECTED	The electronic key was carried out- side the vehicle and a door other than the driver's door was opened and closed while the "ENGINE START STOP" switch was in a mode other than off.	Bring the electronic key back into the vehicle.
once	3 times	(Flashes) Ref of Ref	The sliver's door was opened and closed while the electronic key was not in the vehicle, the shift lever was in P (automatic transmission) or N (manual transmis- sion) and the "ENGINE START STOP" switch was not turned off.	Turn the "ENGINE START STOP" switch off or bring the electronic key back into the vehicle.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Sounds once	Sounds once for 10 sec- onds	KEY NOT DETECTED	An attempt was made to exit the vehicle with the electronic key and lock the doors without first turn- ing the "ENGINE START STOP switch off.	Turn the "ENGINE START STOP" switch off and lock the doors again.
		TURN POWER OFF (Displayed alternately)		
Sounds	_	KEY NOT DETECTED (Flashes)	An attempt was made to start the engine without the electronic key being present, or the electronic key was not function- ing normally. An attempt was made to drive when the regular	Confirm that the electronic key is inside the vehicle.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Contin- uous		SHIFT TO P POSITION WHEN ALIGHTING (Flashes) (If equipped)	The driver's door was opened when the shift lever was not in P and the "ENGINE START STOP" switch was not turned off.	Shift the shift lever to P.
		SHIFT TO P POSITION WHEN ALIGHTING	The driver's door was opened and crosed while the	• Shift the shift lever
Contin- uous	Contin- uous	KEY NOT DETECTED (Displayed alternately) (Flashes) (If equipped)	cTED the shift lever was not in P and the "ENGINE START STOP" switch was not turned off. es)	to P. • Bring the electronic key back into the vehicle.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
			An attempt was made to lock the doors using the smart entry & start system while the electronic key was still inside the vehi- cle.	Retrieve
Sounds once	Contin- uous	KEY DETECTED IN VEHICLE	An attempt was made to lock either front door by open- ing a door and put-	the elec- tronic key from the vehicle and lock the
		(Flashes)	ting the inside lock butter into the lock position, then clos- ing the door by	doors again.
		Ret	pulling on the out- side door handle with the electronic	
		For	key still inside the vehicle.	
		Not		

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Sounds		DEPRESS BRAKE PEDAL, TOUCH ENGINE SWITCH WITH KEY (automatic transmission) or DEPRESS CLUTCH PEDAL, TOUCH ENGINE SWITCH WITH KEY (manual transmission)	<ul> <li>When the doors were unlocked with the mechanical key and then the "ENGINE START STOP" switch was pressed, the elec- tronic key could not be detected in the vehicle.</li> <li>The electronic key could not be detected in the vehicle even after the "ENGINE START STOP" switch was pressed two con- secutive times.</li> </ul>	Touch the electronic key to the "ENGINE START STOP" switch while depressing the brake pedal (automatic transmis- sion) or clutch pedal (manual transmis- sion).
Sounds once	_	SHIFT TO P POSITION TO START (Flashes)	An attempt was made to start the engine with the shift lever in an incorrect position.	Shift the shift lever to P and start the engine.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Sounds		SHIFT TO P POSITION AND PUSH ENGINE SWITCH TO TURN POWER OFF	An attempt was made to turn the "ENGINE START STOP" switch off when the shift lever was not in P	To turn off the engine, first shift the shift lever to P and then turn the "ENGINE START STOP" switch off.
	_	AUTO POWER OFF TO CONSERVE BATTERY	Power was turned off due to the auto- matic power off function.	Next time when start- ing the engine, increase the engine speed slightly and maintain that level for approxi- mately 5 minutes to recharge the battery.
Sounds once		KEY BATTERY LOW	The electronic key has a low battery. (The message will be shown for about 15 seconds.)	Replace the elec- tronic key battery. $(\rightarrow P. 495)$

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Sounds		DEPRESS BRAKE PEDAL AND PUSH ENGINE SWITCH TO START (automatic transmission) or DEPRESS CLUTCH PEDAL AND PUSH ENGINE SWITCH	The driver's door was opened and closed with the "ENGINE START STOP" switch turned off and then the "ENGINE START STOP" switch was put m ACCESSORY mode twice without the engine being started.	Press the "ENGINE START STOP" switch while depressing the brake pedal (automatic transmis- sion) or clutch pedal (manual transmis- sion).
		TO START (manual transmission) (Flashes)	During an engine starting procedure in the event that the electronic key was not function- ing properly $(\rightarrow P. 590)$ , the "ENGINE START STOP" switch was touched with the electronic key.	Press the "ENGINE START STOP" switch within 10 seconds of the buzzer sounding.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Sounds once		STEERING LOCK ACTIVE (Flashes)	The steering lock could not be released within 3 seconds of the "ENGINE START STOP" switch being pressed	Press the "ENGINE START STOP" switch while depressing the brake pedal and moving the steering wheel left and right.

#### Other messages

If the following message is displayed, take appropriate action and confirm that the message has disappeared.

(→Refer to the "Off-road Driving Owner's Manual")

Message	Correction procedure
CRAWL NOT AVAILABLE SELECT L4 AND SHIFT TO D OR R POSITION (If equipped)	Select the four-wheel driving position switch in L4 and shift the shift lever to D or R.

Message	Correction procedure
CRAWL NOT AVAILABLE CHECK SYSTEM OPERATION CONDITIONS (If equipped)	Confirm the operating conditions.

#### Warning light display in radar cruise mode (if equipped)

In the following cases, the warning light may not be displayed even if vehicle-to-vehicle distance decreases:

- When your vehicle and the vehicle ahead are traveling at the same speed or the vehicle ahead is traveling more quickly than your vehicle
- When the vehicle ahead is traveling at a very low speed
- Immediately after cruise control speed is set
- At the instant the accelerator pedal is depressed

## <u>∧</u> NOTICE

## While the engine of level warning is displayed

Continued engine operation with low engine oil will damage the engine.


# 5-2. Steps to take in an emergency **If you have a flat tire**


Remove the flat tire and replace it with the spare provided.

### Before jacking up the vehicle

- Stop the vehicle on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to P (automatic transmission) or R (manual transmission).
- Turn off the rear height control air suspension (if equipped). (→Refer to the "Off-road Driving Owner's Manual")
- Stop the engine.
- Turn on the emergency flashers. ( $\rightarrow P$ , §
- Location of the spare tire, jack and tools

# Vehicles with under floor mounted spare tire







#### Vehicles with back door mounted spare tire


## Taking out the jack

### 5-door models







# Taking out the tool box



## Taking out the spare tire


### Vehicles with back door mounted spare tire





Unlock the spare tire lock system.


- Insert the key into the cylinder.
- 2 Remove the key and the cylinder.




#### Vehicles with under floor mounted spare tire

STEP 1 Assembling the jack handle.

Remove the jack handle extension bar from the tool box and assemble by following these steps.






Loosen the bolt and the screw using either the jack handle end or a screwdriver.




Assemble the jack handle extension bar and the jack handle and tighten the bolt and the screw.

Check that the bolt and screw are firmly tightened.


Remove the cover.







When trouble arises

# Replacing a flat tire






Pry off the wheel ornament, using the beveled end of the wheel ornament remover as shown.




Slightly loosen the wheel nuts (one turn).

### STEP 4 Assembling the jack handle.

Remove the jack handle, jack handle extension bar and jack handle bar from the tool box and assemble by following these steps.





 Loosen the bolt and the screw using either the jack handle end or a screwdriver.




Assemble the jack handle extension bar and the jack handle bar and tighten the bolts.


Check that the bolts are firmly tightened.

Assemble the jack handle extension bar and the jack handle and tighten the screw.

Check that the screw is firmly tightened.




### Installing the spare tire



Remove any dirt or foreign matter from the wheel contact surface.


If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, and the tire to come off.



Install the spare tire and loosely tighten each nut by hand to appropriately the same amount.


orn the nut washers until they come into contact with the disc wheel.

Lower the vehicle.



Firmly tighten each nut two or three times in the order shown in the illustration

**Tightening torgue** 112 N•m (11.4 kgf•m, 83 ft•lbf)




ers.

Reinstall the wheel ornament.


Stowing the flat/spare tire, jack and tools


STEP 6 Stow the flat tire, tools and jack securely, and replace all cov-

# Vehicles with back door mounted spare tire



Install the tire and loosely tighten each nut by hand to approximately the same amount.





Firmly tighten each nut two or three times in the order shown in the illustration.

**Tightening torque:** 60 N•m (6.0 kgf•m, 44 ft•lbf)

Tighten the spare tire lock nut first.

Lock the spare tire lock system

1 Spare tire lock nut.

2 Insert the key and cylinder.

Remove the key while holding the cylinder in place.


Check that the cylinder is locked securely.

Install the spare wheel cover in the reverse order of removal.

**Tightening torque:** 14 N•m (1.4 kgf•m, 10 ft•lbf)

STEP 5 Stow the tools and jack securely, and replace all covers.

### Vehicles with under floor mounted spare tire



Lay down the tire with the outer side facing up, and install the holding bracket.

Insert the holding bracket tab into one of the holes in the wheel.

STEP 2 Raise the tire.

Vehicles with kinetic dynamic suspension: Pull the tire towards the rear of the vehicle when raising. After raising, visually check that the tire is not interfering with suspension components.

STEP 3 Stow the tools and jack secure and replace all covers.

Vehicles with spare tire lock system (vehicles with back door mounted spare tire)

Use the spare tire lock nut only for the spare tire carrier.

# 

### Using the tire jack

Improper use of the tire jack may cause the vehicle to suddenly fall off the jack, leading to death or serious injury.

- Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains.
- Only use the tire jack that comes with this vehicle for replacing a flat tire.
   Do not use it on other vehicles, and do not use other tire jacks for replacing tires on this vehicle.
- Always check that the tire jack is securely set to the jack point.
- Do not put any part of your body under the vehicle while it is supported by the jack.
- Do not start or run the engine while your vehicle is supported by the jack.
- Do not raise the vehicle while someone sinside.
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.
- Vehicles with rear height control air suspension: Be sure to turn off the height control and stop the engine.

Take particular care when lowering the vehicle to ensure that no one working on or near the vehicle will be injured.

### Using the jack handle

Tighten all the jack handle bolts securely using a Phillips-head screwdriver, to prevent the extension parts from coming apart unexpectedly.

# **CAUTION**

### Replacing a flat tire

Observe the following precautions to reduce the risk of death or serious injury:

• Do not touch the disc wheels or the area around the brakes immediately after the vehicle has been driven.

After the vehicle has been driven the disc wheels and the area around the brakes will be extremely hot. Touching these areas with hands, feet or other body parts while changing a tire, etc. may result in burns.

• Vehicles with under floor mounted spare tire: Lower the spare tire completely to the ground before removing it from under the vehicle.

 Do not try to remove the wheel ornament by hand. Take due care in handling the ornament to avoid unexpected personal injury.

• Have the wheel nuts tightened with a torque wrench to 112 N•m (11.4 kgf•m, 83 ft•lbf) as soon as possible after changing wheels.

Failure to follow these precautions could cause the nuts to loosen and the wheel may fall off, which could lead to an accident causing death or serious injury.

- Do not attach a heavily damaged wheel ornament, as it may fly off the wheel while the vehicle is noving.
- When installing a tire only use wheel nuts that have been specifically designed for that wheel.
- If there are any cracks or deformations in the bolt screws, nut threads or bolt holes of the wheel, have the vehicle inspected by your Toyota dealer.

Failure to follow these precautions could cause the wheel nuts to loosen and the tire to fall off, resulting in death or serious injury.

### When installing the wheel nuts

Be sure to install the wheel nuts with the tapered end facing inward.  $(\rightarrow P. 491)$ 

# **CAUTION**

### After using the tools and jack

Before driving, make sure all the tools and jack are securely in place in their storage location to reduce the possibility of personal injury during a collision or sudden braking.

# 

### Do not drive the vehicle with a flat tire.

Do not continue driving with a flat tire.

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair.

When stowing the flat tire (vehicles with under floor mounted spare tire)

Ensure that there is no object caught between the tire and the vehicle underbody.

### When assembling the jack handle extension

Tighten all the joints securely. Otherwise the extension may come off and it may damage the paint or Guide body.

If the engine will not start even though correct starting procedures are being followed ( $\rightarrow$ P. 173, 177), consider each of the following points:

The engine will not start even when the starter motor operates normally.

One of the following may be the cause of the problem:

- There may not be sufficient fuel in the vehicle's tank.
   Gasoline engine: Refuel the vehicle.
   Diesel engine: (→P. 602)
- The engine may be flooded. (gasoline engine)
   Try to restart the engine again following correct starting procedures. (→P. 177)
- There may be a malfunction in the engine immobilizer system. ( $\rightarrow$ P. 115)
- The starter motor turns over slowly, the interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.

One of the following may be the cause of the problem:

• The battery may be discharged. ( $\rightarrow$ P. 594)

• The battery terminal connections may be loose or corroded.

### The starter motor does not turn over.

The engine starting system may be malfunctioning due to an electrical problem such as an open circuit or a blown fuse. However, an interim measure is available to start the engine.  $(\rightarrow P. 587)$ 

The starter motor does not turn over, the interior lights and headlights do not turn on, or the horn does not sound.

One of the following may be the cause of the problem:

- One or both of the battery terminals may be disconnected.
- The battery may be discharged. ( $\rightarrow$ P. 594)
- There may be a malfunction in the steering lock system.

Contact your Toyota dealer if the problem cannot be repaired, or if repair procedures are unknown.

Emergency start function (vehicles with a smart entry & start system)

When the engine does not start, the following steps can be used as an interim measure to start the engine if the "ENGINE START STOP" switch is functioning normally

- STEP 1 Set the parking brake.
- STEP 2 Put the shift lever in P (automatic transmission) or N (manual transmission)
- STEP 3 Set the "ENGINE START STOP" switch to the ACCESSORY mode
- STEP 4 Push and hold the "ENGINE START STOP" switch for about 15 seconds while depressing the brake pedal (automatic transmission) or brake and clutch pedal (manual transmission) firmly.

Even if the engine can be started using the above steps, the system may be malfunctioning. Have the vehicle checked by your Toyota dealer. When trouble arises

# 5-2. Steps to take in an emergency If the shift lever cannot be shifted from **P**^{*}

If the shift lever cannot be shifted with your foot on the brake pedal, there may be a problem with the shift lock system (a system to prevent accidental operation of the shift lever). Have the vehicle inspected by your Toyota dealer immediately.


The following steps may be used as an emergency measure to ensure that the shift lever can be shifted:

STEP 1 Set the parking brake.

STEP 2 Vehicles without a smart entry & start system: Turn the engine switch to the "ACC" position.

Vehicles with a smart entry & start system: Turn the "ENGINE START STOP" switch to ACCESSORY mode.

STEP 3 Depress the brake pedal.



Press the shift lock override

The shift lever can be shifted while the button is pressed.

# 5-2. Steps to take in an emergency **If you lose your keys**


New genuine keys can be made by your Toyota dealer. For vehicles with the smart entry & start system, bring the other key and the key number stamped on the key number plate. For vehicles without the smart entry & start system, bring a master key and the key number stamped on the key number plate.

NotforReproduction

When trouble arises

For vehicles with a smart entry & start system: If communication between the electronic key and vehicle is interrupted ( $\rightarrow$ P. 27) or the electronic key cannot be used because the battery is depleted, the smart entry & start system and wireless remote control cannot be used. In such cases, the doors can be opened or the engine can be started by following the procedure below.


### Locking and unlocking the doors and key linked functions



# Changing "ENGINE START STOP" switch modes and starting the engine

# Automatic transmission

STEP 1 Ensure that the shift lever is in P and depress the brake pedal.



Touch the Toyota emblem side of the electronic key to the "ENGINE START STOP" switch.

If any of the doors is opened or closed while the key is being touched to the switch, an alarm will sound to indicate that the start function cannot detect the key.


STEP 3 To change "ENGINE START STOP" switch modes: Within 10 seconds of the buzzer sounding, release the brake pedal and press the "ENGINE START STOP" switch. Modes can be changed each time the switch is pressed. (→P. 180)

To start the engine: Press the "ENGINE START STOP" switch within 10 seconds of the buzzer sounding, keeping the brake pedal depressed.

In the event that the "ENGINE START STOP" switch still cannot be operated, contact your Toyota dealer.

### Manual transmission

STEP 1 Shift the shift lever to N and depress the clutch pedal.



Touch the Toyota emblem side of the electronic key to the "ENGINE START STOP" switch.

If any of the doors is opened or closed while the key is being touched to the switch, an alarm will sound to indicate that the start function cannot detect the key.

STEP 3 To change "ENGINE START STOP" switch modes: Within 10 seconds of the buzzer sounding, release the clutch pedal and press the "ENGINE START STOP" switch. Modes can be changed each time the switch is pressed. (→P. 180)

To start the engine: Press the "ENGINE START STOP" switch within 10 seconds of the bozer sounding, keeping the clutch pedal depressed.

In the event that the "ENGINE START STOP" switch still cannot be operated, contact your Toyota dealer.

### Stopping the engine

#### Vehicles with an automatic transmission

Shift the shift lever to P and press the "ENGINE START STOP" switch as you normally do when stopping the engine.

#### Vehicles with a manual transmission

Shift the shift lever to N and press the "ENGINE START STOP" switch as you normally do when stopping the engine.

#### Replacing the key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery is depleted.  $(\rightarrow P. 495)$ 

### Alarm

Using the mechanical key to lock the doors will not set the alarm system. If a door is unlocked using the mechanical key when the alarm system is set, the alarm may be triggered. ( $\rightarrow$ P. 116)



# 5-2. Steps to take in an emergency If the vehicle battery is discharged


The following procedures may be used to start the engine if the vehicle's battery is discharged.

You can call your Toyota dealer or qualified repair shop.

If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your Toyota following the steps below.


STEP 1 Open the hood. ( $\rightarrow$ P. 466)

Vehicles with 1GR-FE engine only: Remove the engine cover.



STEP 2 Connect the jumper cables according to the following procedures:

# Gasoline engine



- Positive (+) battery terminal on your vehicle
- 2 Positive (+) battery terminal on the second vehicle
- 3 Negative (-) battery terminal on the second vehicle
- Connect the jumper cable to ground on your vehicle as shown in the illustration.

- STEP 3 Start the engine of the second vehicle. Increase the engine speed slightly and maintain at that level for approximately 5 minutes to recharge the battery of your vehicle.
- STEP 4 Vehicles with a smart entry & start system: Open and close any of the doors with the "ENGINE START STOP" switch off.
- STEP 5 Maintain the engine speed of the second vehicle and start the engine of your vehicle by turning the "ENGINE START STOP" switch to IGNITION ON mode (vehicles with a smart entry & start system) or turning the engine switch to the "ON" position (vehicles without a smart entry & start system).
- STEP 6 Once the vehicle's engine has started, remove the jumper cables in the exact reverse order in which they were connected.
- STEP 7 Vehicles with 1GR-FE engine only: To install the engine cover, conduct the removal procedure in reverse. After installing, check that the fixed pins are inserted securely.

Once the engine starts have the vehicle checked at your Toyota dealer as soon as possible.

### Starting the engine when the battery is discharged (vehicles with an automatic transmission)

The engine cannot be started by push-starting.

### To prevent battery discharge

- Turn off the headlights and the audio system while the engine is off.
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic.

### Charging the battery

The electricity stored in the battery will discharge gradual even when the vehicle is not in use, due to natural discharge and the draining effects of certain electrical appliances. If the vehicle is left for a long time, the battery may discharge, and the engine may be unable to state. The battery recharges proc automatically during driving.)

## **A** CAUTION

### Avoiding battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the battery.

- Make sure the jumper cable is connected to the correct terminal and that it is not unintentionally in contact with any other than the intended terminal.
- Do not allow the and clamps of the jumper cables to come into contact with each other.
- Do not smoke, use matches, cigarette lighters or allow open flame near the battery.

# **CAUTION**

#### Battery precautions

The battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the battery:

- When working with the battery, always wear safety glasses and take care not to allow any battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- Do not lean over the battery.
- In the event that battery fluid comes into contact with the skin or eyes, immediately wash the affected area with water and seek medical attention.
   Place a wet sponge or cloth over the affected area until medical attention can be received.
- Always wash your hands after handling the battery support, terminals, and other battery-related parts.
- Do not allow children near the batter
- To prevent damaging the vehicle (vehicles with a manual transmission)

Do not pull- or push-start the vehicle, because the catalytic converter may overheat and become a fire hazard.

# 🕂 NOTICE 🔪

#### When handling jumper cables

When connecting the jumper cables, ensure that they do not become entangled in the cooling fans or belt.

#### To prevent damage to the engine cover

- When removing the cover, make sure that you pull the cover towards you after lifting the front edge to remove the fixed pins.
- When installing the cover, do not force the cover or subject it to strong shocks.

### If your engine overheats:

- STEP 1 Stop the vehicle in a safe place and turn off the air conditioning system.
- STEP 2 Check to see if steam is coming out from under the hood.
  - If you see steam:

Stop the engine. Carefully lift the hood after the steam subsides and then restart the engine.

If you do not see steam:


Leave the engine running and carefully lift the hood.

- STEP 3 Remove the engine compartment covers. (SP. 469)
- STEP 4 Check to see if the cooling fan is operating
  - If the fan is operating:


Wait until the engine coolant temperature gauge begins to fall and then stop the engine

If the fan is not operating:

Stop the engine and call your Toyota dealer.



After the engine has cooled down sufficiently, check the engine coolant level and inspect the radiator core (radiator) for any leaks.



Add engine coolant if necessary.


Water can be used in an emergency if engine coolant is unavailable. ( $\rightarrow$ P. 617)

Have the vehicle checked at the nearest Toyota dealer as soon as ductio possible.

#### Overheating

If you observe the following, your vehicle may be overheating:

- The engine coolant temperature gauge enters the red zone or a loss of power is experienced.



# **A** CAUTION

### To prevent an accident or injury when inspecting under the hood of vour vehicle

- If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot, causing serious injury such as burns.
- Keep hands and clothing away from the fan and other belts while the engine is running.
- Do not loosen the radiator cap, or the coolant reservoir cap while the engine and radiator are hot.

Serious injury, such as burns, may result from hor coolant and steam produc released under pressure.

# NOTICE

### When adding engine coolant


Wait until the engine has cooled down before adding engine coolant. When adding coolant, do so slowly. Adding cool coolant to a hot engine too quickly can cause damage to the engine.

Not

# 5-2. Steps to take in an emergency If you run out of fuel and the engine stalls (diesel engine only)

If you run out of fuel and the engine stalls:

STEP 1 Refuel your vehicle.



To bleed the fuel system, operate the priming pump until you feel more resistance.



STEP 3 Start the engine. ( $\rightarrow$ P. 177)

FOL

If the engine does not start after the above steps have been performed, wait for 10 seconds and the step 2 and 3 again. If the engine still does not start, contact your Toyota dealer.

After starting the engine, depress the accelerator pedal lightly until the engine runs smoothly.

# When restarting the engine

Do not crank the engine before refueling and operating the priming pump. This may damage the engine and fuel system. Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud, dirt, or snow:

- STEP 1 Stop the engine. Set the parking brake and put the shift lever in P (automatic transmission) or N (manual transmission).
- STEP 2 Remove the mud, snow, or sand from around the stuck tire.
- STEP 3 Place wood, stones or some other material to help provide traction under the tires.
- STEP 4 Restart the engine.
- STEP 5 Shift the shift lever to the D or R position (automatic transmission) or 1 or R position (manual transmission), and carefully apply the accelerator to free the vehicle.

Turn off TRC and VSC if these functions are hampering your attempts to free the vehicle. ( $\rightarrow$ P. 279)



# **CAUTION**

### When attempting to free a stuck vehicle

If you choose to push the vehicle back and forth to free it, make sure the surrounding area is clear, to avoid striking other vehicles, objects or people. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

### When shifting the shift lever

For vehicles with an automatic transmission, be careful not to shift the shift lever with the accelerator pedal depressed.

This may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury

# \land NOTICE

### To avoid damaging the transmission and other components

• Avoid spinning the wheels and do not rev the engine.

If the vehicle remains stuck even after these procedures are performed, the vehicle may require towing to be freed.

# 5-2. Steps to take in an emergency If your vehicle has to be stopped in an emergency

Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

STEP 1 Steadily step on the brake pedal with both feet and firmly depress it.

> Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.


STEP 2 Shift the shift lever to N.

### If the shift lever is shifted to N

If the shift lever is shifted to N STEP 3 After slowing down, stop the vehicle in a safe place by the road. STEP 4 Stop the engine.

### If the shift lever cannot be shifted to N

STEP 3 Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.



ENGINE

STARI

Press and hold for 3 seconds or more

Vehicles without a smart entry & start system: Stop the engine by turning the engine switch to "ACC".

Vehicles with a smart entry & start system: Stop the engine by pressing and holding the "ENGINE START STOP" switch for 3 consecutive seconds or more.

STEP 5 Stop the vehicle in a safe place by the road.

CTN52AF205

## **CAUTION**

### If the engine has to be turned off while driving

- Power assist for the brakes and steering wheel will be lost, making the brake pedal harder to depress and the steering wheel heavier to turn. Decelerate as much as possible before turning off the engine.
- Vehicles without a smart entry & start system: Never attempt to remove the key, as doing so will lock the steering wheel.



# 6

### 6-1. Specifications

# 6-1. Specifications Maintenance data (fuel, oil level, etc.)

## Dimensions


Overall length	5-door models	4760 mm (187.4 in.) ^{*1} 4930 mm (194.1 in.) ^{*2}
	3-door models	4485 mm (176.6 in.)
Overall width		1885 mm (74.2 in.)
Overall height ^{*3}	5-door models	1835 mm (72.2 in.) ^{*4,6} 1845 mm (72.6 in.) ^{*5,6} 1880 mm (74.0 in.) ^{*4,7} 1890 mm (74.4 in.) ^{*5,6}
	3-door models	1835 mm (72,2 in.) ^{*6} 1880 mm (74.0 in.) ^{*7}
Wheelbase	5-door models	2790 mm (109.8 in.)
	3-door models	2455 nm (96.7 in.)
Tread	Front	685 mm (62.4 in.) ^{*8} 605 mm (63.2 in.) ^{*9}
	Rear	1585 mm (62.4 in.) ^{*8} 1605 mm (63.2 in.) ^{*9}

- *1: Vehicles without back door mounted spare tire
- *2: Vehicles with back door mounted spare tire
- *3: Unladen vehicles
- *4: Vehicles with rear height control air suspension
- *5: Vehicles without rear height control air suspension
- *6: Vehicles without roof rail
- *7: Vehicles with roof rail
- *8: 265/65R17 or 265/60R18 tires
- *9: 245/70R17 tires

## Vehicle identification

### Vehicle identification number

The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Toyota. It is used in registering the ownership of your vehicle.




ITN61M004

### Engine number

The engine number is stamped on the engine block as shown.

## Gasoline engine



# Engine

# Gasoline engine

Model	1GR-FE
Туре	6-cylinder V type, 4-cycle, gasoline
Bore and stroke	94.0 × 95.0 mm (3.70 × 3.74 in.)
Displacement	3956 cm ³ (241.4 cu.in.)
Valve clearance (engine cold)	Automatic adjustment
Drive belt tension	Automatic adjustment
·	

# **Diesel engine**

Diesel engine	NICT NICT
Model	1KD-FTV
Туре	4-cylinder in line, 4-cycle, diesel (with turbocharger)
Bore and stroke	96.0 93.0 mm (3.78 × 4.06 in.)
Displacement	2982 cm ³ (182.0 cu.in.)
Valve clearance (engine cold)	Intake: 0.20 — 0.30 mm (0.008 — 0.012 in.) Exhaust: 0.35 — 0.45 mm (0.014 — 0.018 in.)
Drive belt tension	Automatic adjustment

#### Fuel

#### Gasoline engine

Fuel type		Unleaded gasoline only	
Research octane number		95 or higher	
Fuel tank capacity	Vehicles with sub fuel tank system	150 L (39.6 gal., 33.0 Imp.gal.)	
(Refer- ence) Vehicles without sub fuel tank system		87 L (23.0 gal., 19.1 Jino gal.)	
Diesel eng	ine	due	

#### **Diesel engine**

Fuel type		Diesel fuel only
Cetane number		48 or higher
Fuel tank capacity	Vehicles with sub fuel tank system	150 L (39.6 gal., 33.0 lmp.gal.)
(Refer- ence)	Vehicles without sub fuel tank system	87 L (23.0 gal., 19.1 Imp.gal.)
	7	

#### Lubrication system

#### **1GR-FE engine**

Oil capacity (Drain and refill — reference)	
With filter	6.2 L (6.6 qt., 5.5 Imp.qt.)
Without filter	5.7 L (6.0 qt., 5.0 Imp.qt.)

#### Engine oil selection

"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Use Toyota approved "Toyota Genuine Motor Oil" of equivalent to satisfy ,odul the following grade and viscosity.

Oil grade:


5W-30 and 10W-30:

API grade SL "Energy-Conserving", SM "Energy-Conserving", SN "Resource-Conserving" or ILSAC multigrade engine oil

15W-40 and 20W-50:

API grade SL, SM or SN-multigrade engine oil

Recommended viscosity (SAE):




If you use SAE 10W-30 or a higher viscosity engine oil in extremely low temperatures, the engine may become difficult to start, so SAE 5W-30 engine oil is recommended.

The 10W portion of the oil viscosity rating indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.

The 30 in 10W-30 indicates the oil viscosity when the oil is at its operating temperature. An oil with a higher viscosity may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

How to read oil container labels:

Either or both API registered marks are added to some oil containers to help you select the oil you should use.



## API Service Symbol

Top portion. The oil quality designation by API (American Petroleum Institute) (SN)

Genter portion: The SAE viscosity grade (SAE 10W-30)

Lower portion: "Resource-Conserving" means that the oil has fuel saving and environmental protection capabilities.

#### 2 ILSAC Certification Mark

The ILSAC (International Lubricant Standardization and Approval Committee) Certification Mark is displayed on the front of the container.

#### **1KD-FTV engine**


Oil capacity (Drain and refill — reference)	
With filter	7.0 L (7.4 qt., 6.2 lmp.qt.)
Without filter	6.7 L (7.1 qt., 5.9 lmp.qt.)

#### Engine oil selection

"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Use Toyota approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade: G-DLD-1, API CF-4, CF or ACEA Br (You may also use API CE or CD)

Recommended viscosity (SAE):




SAE 5W-30 is the best choice for good fuel economy and good starting in cold weather.

If you use SAE 10W-30 or a higher viscosity engine oil in extremely low temperatures, the engine may become difficult to start, so SAE 5W-30 engine oil is recommended.

The 5W portion of the oil viscosity rating indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.

The 30 in 5W-30 indicates the oil viscosity when the oil is at its operating temperature. An oil with a higher viscosity may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

DLD logo mark:



NotforRef

The Global DLD-1 logo mark, attached on some oil containers to help in selecting the oil you should use, indicates that the oil meets the guidelines recommended by the following associations:

 ACEA (Association des Constructeurs Europeens d'Automobiles)

 AAM (Aliance of Automobile Manufacturers)


EMA (Engine Manufacturers Association)

JAMA (Japan Automobile Manufacturers Association)

### Cooling system

	Gasoline	With automatic transmission	With rear heater 12.3 L (13.0 qt., 10.8 Imp.qt.) Without rear heater 10.5 L (11.1 qt., 9.2 Imp.qt.)	
Capacity		With manual transmission	With rear heater 12.5 L (13.2 qt., 11.0 Imp.qt.) Without rear heater 10.7 L (11.3 qt., 9.4 Imp.qt.)	
(Refer- ence)	Diesel	With automatic transmission	With rear heater 14.9 L (15.7 qt., 13.1 Imp.qt.) Without rear heater 13.1 L (13.8 qt., 11.5 Imp.qt.)	
engine		With manual transmission	With rear heater 15.0 L (15.9 qt., 13.2 Imp.qt.) Without rear heater 13.2 L (14.0 qt., 11.6 Imp.qt.)	
Coolant type		cork	<ul> <li>Use either of the following.</li> <li>"Toyota Super Long Life Coolant"</li> <li>A similar high-quality ethylene glycol-based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology</li> <li>Do not use plain water alone.</li> </ul>	

#### Ignition system (gasoline engine only)



Oil capacity	1.40 L (1.48 qt., 1.23 Imp.qt.)	
Oil type and viscosity*	Toyota Genuine Differential Gear Oil LT 75W-85 GL-5 or equivalent	

*: Your Toyota vehicle is filled with "Toyota Genuine Differential Gear Oil" at the factory.

Use Toyota approved "Toyota Genuine Differential Gear Oil" or an equivalent of matching quality to satisfy the above specification. Please contact your Toyota dealer for further details.

#### **Rear differential**

5-door		With rear differential lock system	2.65 L (2.80 qt., 2.33 lmp.qt.)
Oil capacity	models	Without rear differential lock system	2.70 L (2.85 qt., 2.38 lmp.qt.)
	3-door mode	els	2.20 L (2.32 qt., 1.94 Imp.qt.)
Oil type and viscosity*		Toyota Genuine Differential Gear Oil 775W-85 GL-5 or equivalent	

*: Your Toyota vehicle is filled with "Toyota Genuine Differential Gear Oil" at the factory.

Use Toyota approved "Toyota Genuine Differential Gear Oil" or an equivalent of matching quality to satisfy the above specification. Please contact your Toyota dealer for further details

#### Automatic transmission

Fluid capacity* Gasoline engine	10.9 L (11.5 qt., 9.6 lmp.qt.)
Diesel engine	10.6 L (11.2 qt., 9.3 Imp.qt.)
Fluid type	Toyota Genuine ATF WS

*: The fluid capacity is a reference quantity. If replacement is necessary, contact your Toyota dealer.


### 

#### Transmission fluid type

Using transmission fluid other than "Toyota Genuine ATF WS" may cause deterioration in shift quality, locking up of the transmission accompanied by vibration and, ultimately, damage to the vehicle's transmission.

#### **Manual transmission**

Gear oil capacity	2.1 L (2.2 qt., 1.8 Imp.qt.)	
Gear oil type	Toyota Genuine Transfer Gear oil LF or equivalent	
Recommended gear oil viscosity	SAE 75W	



*: Your Toyota vehicle is filled with "Toyota Genuine Transfer Gear oil LF" at the factory. Use Toyota approved "Toyota Genuine Transfer Gear oil LF" or an equivalent of matching quality to satisfy the above specification. Please contact your Toyota dealer for further details.

#### Brakes

Pedal clearance *1	101 mm (4.0 in.) Min.	
Pedal free play	1 — 6 mm (0.04 — 0.24 in.)	
Parking brake lever travel *2	5 — 7 clicks	
Fluid type	SAE J1703 or FMVSS No. 116 DOT 3	

- *1: Minimum pedal clearance when depressed with a force of 490 N (50 kgf, 110 lbf) while the engine is running
- *2: Parking brake lever travel when pulled up with a force of 200 N (20.4 kgf, 45.0 lbf)
   Chassis lubrication

	Spider	Lithium base chassis grease, NLGI No.2		
Propeller shafts Slide yoke		Molyndenum-disulfide lithium base chas- sis grease, NLGI No.2 or lithium base mul tipurpose grease, NLGI No.2		
Steering	Steering			
Free play Less than 30 mm (1.18 in.)				
Power steering fluid type		Automatic transmission fluid DEXRON [®] II or III		

#### Tires and wheels

#### 17-inch tires (type A)

Tire size	245/70R17 110S	
Tire inflation pressure (Recommended cold tire inflation pressure)	Front wheel kPa (kgf/cm ² or bar, psi)	Rear wheel kPa (kgf/cm ² or bar, psi)
	200 (2.0, 29)	200 (2.0, 29) 220 (2.2, 32)*
Wheel size	17 × 6 1/2J	
Wheel nut torque	112 N•m (11.4 kgf•m, \$3 tt•lbf)	

*: Standard inflation for all loads including full rated loads

#### 17-inch tires (type B)

Tire size	265/65R17112S	
Tire inflation pressure (Recommended cold tire	Frontwheel kPa (kgf/em ² or bar, psi)	Rear wheel kPa (kgf/cm ² or bar, psi)
inflation pressure)	200 (2.0, 29)	200 (2.0, 29)
Wheel size	17 × 7 1/2J	
Wheel nut torque	112 N•m (11.4 kgf•m, 8	3 ft∙lbf)

# 18-inch tires

Tire size	265/60R18 110H		
Tire inflation pressure (Recommended cold tire	Front wheel kPa (kgf/cm ² or bar, psi)	Rear wheel kPa (kgf/cm ² or bar, psi)	
inflation pressure)	200 (2.0, 29) 200 (2.0, 29) 220 (2.2, 32)*		
Wheel size	18 × 7 1/2J		
Wheel nut torque	112 N•m (11.4 kgf•m, 83 ft•lbf)		

*: Standard inflation for all loads including full rated loads

#### Light bulbs

	Light bulbs	W	Туре
	Headlights Low beam (discharge bulbs [*] ) Low beam (halogen bulbs [*] ) High beam	35 55 60	A B C
	Front turn signal lights	21	D
Exterior	Front position lights	5	Е
EXTEND	Front fog lights*	55	В
	Rear turn signal lights	1	D
	Back-up lights	16	Е
	License plate lights	5	E
	rior Headlights Low beam (discharge bulbs*) Low beam (halogen bulbs*) High beam Front turn signal lights Front position lights Front fog lights* Rear turn signal lights Back-up lights License plate lights Running board lights* Personal/interior lights Front Rear (without personal lights)*	5	E
Interior	Front Rear (without personal lights) [*] Rear (with personal lights) [*] Vanity lights	5 8 5 8 5	E F E E

- A: D4S discharge bulbs
- C: HB3 halogen bulbs
- B: H11 halogen bulbs
  - D: Wedge base bulbs (amber)
- E: Wedge base bulbs (clear) F: Double end bulbs

*: If equipped

Vehicle specifications

# 6-1. Specifications Fuel information

Gasoline engine	You must only use unleaded gas- oline in your vehicle. For optimum engine perfor- mance, select premium unleaded gasoline with a Research Octane Number of 95 or higher. If this premium type cannot be obtained, you can temporarily use unleaded gasoline with a Research Octane Number as low as 91.
Diesel engine	You must only use diesel fuel with a cetane number of 48 or higher.

#### Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your vehicle has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.

#### If you plan to drive in foreign countries

Low sulphur diesel the may not be available, so please check the availability with your distributor

#### If your engine knocks

- Consult your Toyota dealer.
- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.

#### **NOTICE**

#### Notice on fuel quality

- Do not use improper fuels. If improper fuels are used, the engine will be damaged.
- Do not use leaded gasoline.

Leaded gasoline will cause the three-way catalytic converter to lose its effectiveness and the emission control system to function improperly.



### 6-2. Customization Customizable features

Your vehicle includes a variety of electronic features that can be personalized to suit your preferences. Programing of these preferences can be performed by your Toyota dealer.


It is also possible to customize certain vehicle features yourself using the menu switch and the "ENTER" switch.

Some function settings are changed simultaneously with other functions being customized. Contact your Toyota dealer for further details.


#### **Customizing vehicle features**

It is possible to customize certain vehicle features using the menu switch and the "ENTER" switch.

When customizing vehicle features ensure that the vehicle is parked in a safe place with the shift lever in P (automatic transmission) or N (manual transmission) and the parking brake set.



Press and hold the menu switch to display customization mode.



 $\overline{}$ 

M

Ð

DISPLA

2 1

ENTER

2 2

ITN62M014

STEP 3

- Press the "ENTER" switch upwards or downwards to select the item to be customized.
- 2 Press the "ENTER" switch to confirm.
- Press the "ENTER" switch upwards or downwards to select the desired setting for the item being customized.
- 2 Press the "ENTER" switch to confirm.

When customization is completed press the menu switch to clear the customization screen.

#### Customizable features

- Settings that can be changed using the menu switch and the "ENTER" switch
- 2 Settings that can be changed by your Toyota dealer

Definition of symbols: O = Available, - =Not available

Item	Function	Default setting	Customized setting	1	2
Door lock (→P. 48, 590)	Unlocking using a key	All doors unlocked in one step	Driver scoor unlocked in one step, all doors unlocked in two steps	_	0
	NotForP	epte			

Item	Function	Default setting	Customized setting	1	2
	Operation	7	Off	0	0
	signal (buzzer)	1	1 to 6	U	0
	Operation signal (Emergency flashers)	On	Off	0	0
	Time elapsed before the automatic door lock function is	30 seconds	60 Conds	_	0
Smart entry & start system and wireless remote control (→P. 27, 44)	activated if a door is not opened after being unlocked	30 seconds	120 seconds		
	Open door warning function When locking the vehicle)	On	Off	_	0
			Push twice		
	Glass hatch	Push and hold	One short push		0
	opening operation ^{*1}	(Short)	Push and hold (Long)		
			Off		

ю

Item	Function	Default setting	Customized setting	1	2
Smart entry & start system	Smart door unlocking ^{*2}	All the doors	Driver's door	0	0
(→P. 27)	Smart entry & start system ^{*2}	On	Off	0	0
Wireless remote control (→P. 44)	Unlocking operation	All doors unlocked in one step	Driver's door unlocked in one step, all doors unlocked in two steps	0	0
	Time elapsed before the headlights turn off ^{*1}	30 seconds	Off	0	
			60 seconds		0
			90 seconds		
Automatic light control system $(\rightarrow P. 224)$	Light sensor sensitivity*1	Standard	-2 to 2	0	0
(→F. ∠24)	Time elapsed before head- lights automat- ically turn on*1	Standard	Long	_	0
40					

Item	Function	Default setting	Customized setting	1	2
	Time elapsed		Off		
	before the inte- rior lights turn	15 seconds	7.5 seconds	0	0
	off		30 seconds		
	Time elapsed		Off		
	before the exte- rior lights turn off	15 seconds	7.5 seconds	0	0
off Sensitivity of		30 seconds	]		
Illumination (→P. 405)	Sensitivity of the ambient light sensor used for dim- ming the meter lights etc.*1	Standard	-2 to 2	_	0
	Sensitivity of the ambient light sensor used for bright- ening the meter lights etc.	Standard	-2 to 2	_	0
	O ^L				<u> </u>

7

Item	Function	Default setting	Customized setting	1	2
	Operation after the engine switch is turned to the "LOCK" position (with- out a smart entry & start system) or the "ENGINE START STOP" switch is turned to OFF (with a smart entry & start system)	On epiodul on	Off ction	_	0
Illumination (→P. 405)	Operation when the doors are unlocked with the smart entry & start system or wire- less remote control	eeto	Off	_	0
	Operation when you approach the vehicle with the electronic key on your per- son ^{*2}	On	Off	_	0
	Footwell light- ing	On	Off	_	0

Item	Function	Default setting	Customized setting	1	2
	Running board lights ^{*1}	On	Off	_	0
Running board lights (→P. 405)	Operation when you approach the vehicle with the electronic key on your per- son ^{*1}	On	Off	_	0
	Operation when the doors are unlocked with the smart entry & start system or wire- less remote control*1	eprodu	Off	_	0
	Operation when the doors are unlocked with the power toor lock switch ^{*1}	On	Off	_	0
	Operation when the door is opened ^{*1}	On	Off	_	0

Item	Function	Default setting	Customized setting	1	2
Front auto- matic air con- ditioning system	Switching between out- side air and recirculated air mode linked to automatic mode button operation ^{*1}	Auto	Manual	_	0
	A/C automatic mode button operation ^{*1}	Auto	Manual	_	0
Seat belt reminder buzzer (→P. 541, 542)	Speed-linked seat belt reminder func- tion ^{*1}	orodu	Off	_	0
Eco Driving Indicator Light (→P. 204, 209, 217)	Activating Eco Driving Indica- tor Light ^{*3}	On	Off	0	_
Power	Door key linked opera- tion	Off	On	_	0
windows (→P. 103)	Wireless remote control linked opera- tion	Off	On	_	0

Item	Function	Default setting	Customized setting	1	2
Moon roof (→P. 106)	Mechanical key linked operation ^{*1}	Off	On	_	0
	Wireless remote control linked opera- tion ^{*1,4}	Off	On	_	0
Toyota parking assist- sensor (→P. 256)	Buzzer volume ^{*1}	3	ctio ⁵	_	0

- *1: If equipped.
- *2: Vehicles with a smart entry & start system nly.
- *³: For vehicles with non-optitron type multi-information display, the setting can be changed by operating the multi-information display. ( $\rightarrow$ P. 204)
- *4: This function cannot be customized unless power window operation using the wireless remote control is enabled.

### Multi-information display ( $\rightarrow$ P. 204, 209, 217)

Settings that can be changed using the menu switch and the "ENTER" switch.

Available units

km & I (km/I) and km & I (I/100 km)

Available languages (accessory meters and optitron type meters)

English (UK) and Taiwanese

0

- In the following situations, customize mode will automatically be turned off.
  - •A warning message appears after the customize mode screen is displayed.
  - The "ENGINE START STOP" switch is turned to OFF.
  - The vehicle begins to move while the customize mode screen is displayed.

#### **A** CAUTION

#### Cautions during customization

As the engine needs to be running during customization, ensure that the vehicle is parked in a place with adequate vehicle is parked in a closed area such as a garage, exhaust gases including harmul carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.

During customization To prevent batter tomizing f To prevent battery discharge, ensure that the engine is running while cus-



Abbreviation list ..... 638

Alphabetical index..... 639

What to do if . Q..... 648

For vehicles with a navigation system, refer to the "Navigation System Owner's wanual" for information regarding the equipment listed below.

- Navigation system
- Air conditioning
- Hands-free system (for cellular phone)
- Toyota parking assist monitor
- Rear view monitor system
- Rear sear intertainment system
- Audio Andeo system
- Toyota parking assist-sensor
- Wide view front & side monitor

For details of information about off-road driving techniques and off-road assistance functions, refer to the "Off-road Driving Owner's Manual".

# Abbreviation list Abbreviation/Acronym list

ABBREVIATIONS	MEANING
ABS	Anti-lock Brake System
AFS	Adaptive Front-lighting System
AI-SHIFT	Artificial Intelligence Shift control
ALR	Automatic Locking Retractor
AVS	Adaptive Variable Suspension System
CRS	Child Restraint System
DAC	Downhill Assist Control
DISP	Display
ELR	Emergency Locking Retractor
KDSS	Kinetic Dynamic Suspension System
LED	Light Emitting Diode
PCS	Pre-Crash Safety
SRS	Supplemental Restraint System
TRC	Traction Control
VIN	Vehicle Identification Number
VSC	Vehicle Stability Control
10	
4	

## Alphabetical index Alphabetical index

Α	A/C310, 316	
	ABS278	
	Active head restraint63, 65	
	Active traction control ^{*1} 278	
	Adaptive Front-lighting	
	System227	
	Adaptive Variable	
	Suspension System ^{*1}	
	AFS227	
	Air conditioning filter492	
	Airbags	
	Airbag operating	
	conditions123	
	Airbag precautions for	
	your child127	
	Airbag warning light539	
	General airbag precautions127	l
	Locations of airbags120	1
	Modification and disposal of	
	airbags	
	Proper driving posture 118, 127	
	Side and curtain	
	shield airbags operating	
	conditions124	
	Side and curtain shield	
	airbags precautions127	
	SRS air <b>bags</b> 120	
	Air conditioning system	
	Air conditioning filter492	
	Front automatic	
	air conditioning system 316	
	Front manual	
	air conditioning system 310	
	Rear automatic	
	air conditioning system 329	
	Rear manual	
	air conditioning system 326	

Alarm	116
Antenna	
Anti-lock brake system	
Armrest	
Ashtray	
	431
Audio system Antenna	220
Audio input	
AUX adapter	
CD player/changer	
iPod	
MP3/WMA disc	
Optimal use	
Portable music player	
Radio	.337
Steering wheel audio	
switch	
Туре	
USB memory	. 365
Automatic air conditioning	
system	
Air conditioning filter	. 492
Front automatic	
air conditioning system	. 316
Rear automatic	
air conditioning system	. 329
Automatic headlight leveling	
system	. 229
Automatic light control	
system	.224
Automatic transmission	
Automatic transmission	185
If the shift lever cannot be	
shifted from P	588
S mode	. 188
AUX adapter	
Auxiliary box 420,	
Auxiliary tray	446
AVS ^{*1}	

*1: Refer to the "Off-road Driving Owner's Manual".

В	Back door
	Back door52
	Back door child-protector
	lock53
	Wireless remote control44
	Back-up lights
	Replacing light bulbs519
	Wattage623
	Battery
	Checking477
	If the vehicle has discharged
	battery594
	Preparing and checking
	before winter294
	Bluetooth [®]
	Mobile phone382
	Bottle holders/door
	pockets415
	Brake
	Fluid621
	Parking brake
	Brake assist278
	Brightness control
	Instrument panel light control 198
	Lounge illumination
	control408
	6
C	Care
	Exterior452
	Interior456
	Seat belts457
	Card holder412
	Cargo capacity291
	Cargo hooks444
	CD changer
	CD player
	Center differential lock ^{*1}
	Chains
	Child restraint system
	Baby seats, definition132

Baby seats, installation ...... 143

	Child seats, definition132
	Child seats, installation 143
	Installing CRS with ISOFIX
	rigid anchor150
	Installing CRS with seat
	belts144
	Installing CRS with top
	straps152
	Junior seats, definition 132
	Junior seats, installation 143
	Child safety
	Airbag precautions 127
	Back door precautions 54
	Battery precautions 477, 598
	Child restraint system 132
	Child-protectors50, 53
	Glass hatch precaution 59
5	How your child should wear
Q	
	Installing child restraints 143
	Moon roof precautions 110
	Power window lock switch 103
	Power window precautions 105
	Removed key battery
	precautions498
	Seat belt precautions94
	Seat heater
	precautions439
	Child-protectors50, 53
	Cleaning
	Exterior 452
	Interior
	Seat belts 457
	Clock
	Coat hooks
	Condenser
	Console box
	Cool box
	Cooling system
	Engine overheating599 Crawl Control ^{*1}

Cruise control	.240
Dynamic radar	
cruise control	.244
Cup holder	
Curtain shield airbags	.120
Customizable features	

#### D DAC*1

Deck rail	444
Defogger	
Rear window	333 E
Side mirrors	333
Dimension	608
Display	
Dynamic radar cruise	
control	244
Multi-information	
display204, 209	, 217
Trip information 204, 209	210
Toyota parking	
assist-sensor	256
Warning message	547
Do-it-yourself maintenance	462
Door courtesy lights	
Door courtes lights	405
Wattage	623
Doors	
Back door	52
Back door child-protector	
lock	53
Door glasses	103
Door lock27, 4	4, 48
Double locking system	115
Rear door child-protector	
lock	50
Side doors	48
Side mirrors	100
Downhill Assist Control Syste	em ^{*1}

Driver's seat belt reminder
light541
Driving
Correct posture 118
Off-road precautions ^{*1}
Procedures 160
Winter driving tips 294
Driving position memory
Dynamic radar cruise
control 244
$\mathbf{\Lambda}$
Electronic key
If the electronic key does not
operate properly 590
Emergency, in case of
If the electronic key does not
operate properly
If the engine will not start 586
If the shift lever cannot be
shifted from P588
If the vehicle has discharged
battery 594
If the warning buzzer
sounds537
If the warning light turns on 537
If the warning message is
displayed547
If you have a flat tire
If you lose your keys 589
If you think something is
wrong535
If you run out of fuel and
the engine stalls 602
If your vehicle becomes
stuck603
If your vehicle has to be stopped
in an emergency 605
If your vehicle needs to be
towed528
If your vehicle overheats 599

*1: Refer to the "Off-road Driving Owner's Manual".

	Emergency flashers	
	Switch	
	Engine	
	Compartment467	
	Engine switch177	
	Hood466	
	How to start the	
	engine177	
	Identification number609	
	If the engine will not start586	
	If you run out of fuel and	
	the engine stalls602	
	Ignition switch177	
	Overheating599	
	Engine compartment cover 469	
	Engine coolant	
	Capacity617	
	Checking474	
	Preparing and checking	<b>O</b>
	before winter	
	Engine coolant temperature	
	gauge196	
	Engine immobilizer system 115	
	Engine oil	
	Capacity613	
	Checking	
	Preparing and checking	
	before winter294	
	Engine switch177	
	Engine switch light405	
F	Floor mat442	
	Fluid	_
	Brake621	G
	Power steering621	
	Washer481	
	Fog lights	
	Replacing light bulbs515	
	Switch230	
	Wattage623	Н
	Foot well lighting405	

	Four-wheel drive system ^{*1}
	Front fog lights
	Replacing light bulbs
	Switch
	Wattage 623
	Front passenger's seat belt
	reminder light
	Front position lights
	Replacing light bulbs
	Switch
	Wattage
	Front seats
	Adjustment
	Driving position memory
	From turn signal lights
	Replacing light bulbs517
3	Switch 193
	vvallage
2	Fuel
•	Capacity612
	Fuel gauge196
	Fuel pump shut off system 536
	Gas station information652
	If you run out of fuel and
	the engine stalls 602
	Information 624
	Refueling111
	Туре 624
	Fuel door 111
	Fuel filler door111
	Fuel pump shut off system 536
	Fuses 499
G	Gas station information 652
	Gauges
	Glass hatch
	Glove box
	Glove box light
ы	
п	Hands-free system
	(for mobile phone) 382

	Head restraints		Κ
	Adjusting	87	
	Headlight cleaner	.238	
	Headlights		
	Adaptive front lighting		
	system	.227	
	Discharge headlights		
	precautions	.523	
	Replacing light bulbs513,	514	
	Switch	. 224	
	Wattage	.623	
	Heaters		
	Seat heaters	.437	
	Side mirror	. 333	
	Hill-start assist control ^{*1}	.278	
	Hood	.466	
	Hooks		.(
	Cargo	.444	
	Cargo net	. 445	
	Coat	.441	
		~	
	Identification	•	
	Engine	.609	
	Vehicle		
	Ignition switch		
	Ignition switch light		
	Illuminated entry system	. 409	
	Inside door handle light	.405	
	Indicator lights	.200	
	Inside rear view mirror	98	
	Instrument panel light		
	control		
	Intercooler	.476	

### J Jack

Vehicle-equipped jack	.567
Jack handle	.567

Κ	KDSS ^{*1} 278
	Keyless entry 44
	Keys
	Electronic key24
	Engine switch177
	If you lose your keys
	If your electronic key does
	not operate properly 590
	Key number24
	Keyless entry 44
	Keys
	Mechanicatkey25
	Wireless remote control key 44
	Kinetic dynamic suspension
	system ^{*1} 278
	Knee airbags120
. (	
C	License plate lights
	Replacing light bulbs
	Wattage 623
	Light bulbs
	Replacing511
	Wattage 623
	Lights
	Door courtesy lights 405
	Engine switch light 405
	Fog light switch 230
	Headlights switch224
	Inside door handle lights 405
	Interior light list405
	Personal/interior light
	switch 407
	Replacing light bulbs511
	Running board lights 405
	Shift lever light 405
	Turn signal lever 193
	Vanity lights 427
	Wattage 623
	Luggage cover447

*1: Refer to the "Off-road Driving Owner's Manual".

	Do-it-yourself maintenance 462	
	Maintenance data608	
	Maintenance requirements 459	
	Manual headlight leveling	
	dial225	
	Manual transmission 191	
	Meter	
	Instrument panel light	
	control198	
	Meters 196	
	Mirrors	
	Conversation mirror432	
	Inside rear view mirror98	R
	Side mirror heater	
	Side mirrors100	
	Vanity mirrors427	
	Moon roof106	~
	MP3 disc	<b>O</b>
	Multi-information	
	display204, 209, 217	
	Multi-terrain ABS ^{*1}	
	display204, 209, 217 Multi-terrain ABS ^{*1} Multi-terrain Monitor ^{*1}	
	Multi-terrain ABS ^{*1} Multi-terrain Monitor ^{*1} Multi-terrain Select	
	Multi-terrain Monitor ^{*1}	
0	Multi-terrain Monitor ^{*1} Multi-terrain Select	
0	Multi-terrain Monitor ^{*1} Multi-terrain Select	
0	Multi-terrain Monitor ^{*1} Multi-terrain Select	
0	Multi-terrain Monitor ^{*1} Multi-terrain Select ^{*1} Odometer	
0	Multi-terrain Monitor ^{*1} Multi-terrain Select ^{*1} Odometer	
0	Multi-terrain Monitor ^{*1} Multi-terrain Select ^{*1} Odometer	
0	Multi-terrain Monitor*1 Multi-terrain Select Odometer	
0	Multi-terrain Monitor ^{*1} Multi-terrain Select ^{*1} Odometer	
0	Multi-terrain Monitor ^{*1} Multi-terrain Select ^{*1} Odometer	
0	Multi-terrain Monitor ^{*1} Multi-terrain Select ^{*1} Odometer	
0	Multi-terrain Monitor*1 Multi-terrain Select*1 Odometer	
0	Multi-terrain Monitor*1 Multi-terrain Select*1 Odometer	
0	Multi-terrain Monitor ^{*1} Multi-terrain Select ^{*1} Odometer	
0	Multi-terrain Monitor*1 Multi-terrain Select*1 Odometer	
0	Multi-terrain Monitor ^{*1} Multi-terrain Select ^{*1} Odometer	

Ρ	Parking brake	
	PCS	. 284
	Personal/interior lights	
	Personal/interior lights	. 405
	Switch	. 407
	Wattage	. 623
	Pollen removal mode	. 323
	Power outlet	. 433
	Power steering	
	Fluid	. 621
	Power windows	. 103
	Pre-Crash Safety system	
R	Radiator	476
	Radio	
	Rear air conditioning system	
6	Automatic air conditioning	
$\langle \cdot \rangle$	system	320
	Manual air conditioning	020
	system	326
	Rear differential lock system	*1
	Rear height control	
	air suspension ^{*1}	
	Rear seat	
	Adjustment	66
	Folding down the second	00
	seatbacks7	1 70
	Folding down the third	1,72
	seats7	4 70
	Tumbling seats	
	Rear seat entertainment syste	em -
	Rear step bumper	94
	Rear turn signal lights	E40
	Replacing light bulbs	
	Wattage	
	Rear view monitor system	
	Rear window defogger	
	Rear window wiper	. 236
	Replacing	405
	Key battery Fuses	
		100

Roof luggage carrier29	91
Tires50	67
Light bulbs5	11

#### S Seat belts

Adjusting the seat belt	
Retractor92	
Child restraint system	
installation143	
Cleaning and maintaining	
the seat belts 457	
Emergency Locking	
Retractor92	
How to wear your seat belt 90	
How your child should wear	
the seat belt93	
Pre-crash seat belts	
Pregnant women, proper seat	
belt use93	
Reminder light 541	
Seat belt pretensioners91	
Seat heaters437	
Seats	
Adjustment83	
Adjustment	
precautions65	
Child seats/child restraint	
system installation143	
Cleaning456	
Driver's seat position	
memory83	
Front seat adjustment62	
Head restraint87	
Properly sitting in the seat118	
Rear seat adjustment66	
Seat heaters437	

Service reminder
indicators 200
Shift lever
Automatic transmission 185
If the shift lever cannot
be shifted from "P"588
Manual transmission
Shift lever lighting 405
Shift lock system 588
Side airbags 120
Side mirror
Adjusting and folding 100
Mirror position memory
Side turn signal lights
Replacing light bulbs522
Smart entry & start system
Antenna location
Entry function27
Starting the engine177
Spare tire
Inflation pressure622
Storage location 567
Spark plug618
Specifications 608
Speedometer 196
Steering
Column lock release 182
Fluid 621
Steering wheel
Adjustment96
Audio switches379
Steering wheel position
memory83
Stop lights
Replacing light bulbs522

*1: Refer to the "Off-road Driving Owner's Manual".
 *2: Refer to the "Navigation System Owner's Manual".

	Storage compartment444
	Storage feature410
	Storage precautions
	Stuck
	If your vehicle becomes
	stuck603
	Sun visors426
	Sunshade
	Roof107
	Switch
	Engine switch177
	"ENGINE START STOP"
	switch177
	Fog light switch230
	Ignition switch180
	Light switches224
	Power door lock switch
	Power window switch103
	Rear window wiper and
	washer switch 236
	Window lock switch
	Wipers and washer 🛛 🔹 🔭
	switch
Т	Tachometer196
	Tail lights
	Replacing light bulbs522
	Switch
	Talk switch ^{*2} 387
	Telephone switch ^{*2} 387
	Theft deterrent system
	Alarm116
	Engine immobilizer system 115
	Tire inflation pressure488
	Tires
	Chains294
	Checking485
	If you have a flat tire567
	Inflation pressure488
	Replacing567
l	Rotating tires485

Size62	2
Snow tires 29	4
Spare tire56	7
Tools	7
Towing	
Emergency towing52	8
Trailer towing 29	7
Toyota parking	
assist-sensor	6
Traction control27	8
Trailer towing	7
TRC	8
Trip information	
display	7
Trip meter19	6
X [×]	

V	90	
	Vanity lights	
	Vanity lights	427
N.	Wattage	623
0	Vanity mirrors	427
	Vehicle identification	
	number	609
	Vehicle stability control	278
	VSC	278

#### W Warning buzzers

3
1
2
6
3
2
5
6
5
0
9


Brake system537	
Charging system538	
Driver's seat belt reminder 541	
Front passenger's seat belt	
reminder	
Fuel system540	
KDSS	
Low engine oil level	
Low engine oil pressure538	
Low fuel level	
Malfunction indicator lamp 539	
Master warning light	
Open door	
Power steering system539	
Pre-crash safety system 539	
Slip indicator light	
Smart entry & start system543	C
SRS airbags539	
Timing belt replacement	
Warning messages	
Automatic transmission fluid	

Automatic transmission nulo
temperature549
Brake system 553
Clutch switch system
Crawl control. 566
Engine oil level554
Engine oil pressure548
Four-wheel drive system 565
Glass hatch553
Low fuel level556
Moon roof553
Open door 552
Pre-crash brake556
Pre-crash safety
system550, 554
Radar cruise control
system551, 555
Rear height control air
suspension system549
Smart entry & start system557

Steering lock system549
Timing belt replacement 554
Toyota parking assist 550, 555
Warning reflector holder 444
Washer
Checking 481
Preparing and checking
before winter294
Switch
Washing and waxing 452
Wheels
Wide view front &
side monitor270
Window glasses103
Window lock switch 103
Windows
Power windows103
Rear window defogger
Washer 231, 236
Windshield wipers 231
Wireless remote control key
Locking/Unlocking44
Replacing the battery 495
Wireless remote control key 44
WMA disc

 $^{\star_2}\!\!\!\!$ : Refer to the "Navigation System Owner's Manual".

## What to do if... What to do if...




The warning light or indicator light comes on


P. 537 If a warning light turns on

#### Instrument cluster

#### Non-Optitron type meters




Center panel



#### Warning lights





## **€Q-6**

Reproduction Not for a line of the line of

> Publication No. OM60D87E Part No. 01999-60D87 Printed in Japan 01-1110-00 ② ランドクルーザープラド(豪州E)