


Owner's Manual

For your safety and comfort, read carefully and keep in the vehicle.

RAV4





©2018 TOYOTA MOTOR CORPORATION

All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.

Pictorial index

Search by illustration

For safety and security	Make sure to read through them (Main topics: Child seat, theft deterrent system)	1
Vehicle status information and indicators	Reading driving-related information (Main topics: Meters, multi-information display)	2
Before driving	Opening and closing the doors and windows, adjustment before driving (Main topics: Keys, doors, seats)	3
Driving	Operations and advice which are necessary for driving (Main topics: Starting engine, refueling)	4
Interior features	Usage of the interior features (Main topics: Air conditioner, storage features)	5
Maintenance and care	Caring for your vehicle and maintenance procedures (Main topics: Interior and exterior, light bulbs)	6
When trouble arises	What to do in case of malfunction and emergency (Main topics: Battery discharge, flat tire)	7
Vehicle specifications	Vehicle specifications, customizable features (Main topics: Fuel, oil, tire inflation pressure)	8

Index

Search by symptom	
Search alphabetically	

For your information		3-2.	Opening, closing and locking the doors
	to search11		Side doors88
Pictorial index12			Back door93
1	For safety and security		Smart entry & start system .104
	, ,	3-3.	Adjusting the seats
1-1.	For safe use		Front seats108
	Before driving24		Rear seats
	For safe driving25		Driving position memory111
	Seat belts27		Head restraints114
	SRS airbags30	3-4.	Adjusting the steering wheel
	Exhaust gas precautions 37		and mirrors
1-2.	Child safety		Steering wheel116
	Riding with children		Inside rear view mirror117
			Outside rear view mirrors118
1-3.			Opening, closing the windows and moon roof
			Power windows120
	Double locking system	X	Moon roof123
Vehicle status information and indicators		_	Panoramic moon roof125
	Instrument cluster	4	Driving
	Warning lights and indicators 58 Gauges and meters (with 4.2-		Before driving
			Driving the vehicle132
	inch display)63		Cargo and luggage139
	Gauges and meters (with 7-inch display)66		Trailer towing (except for Austra-
	Multi-information display 70		lia and New Zealand)141
	Fuel consumption information79		Trailer towing (for Australia and New Zealand)141
3	Before driving	4-2.	Driving procedures
	J		Engine (ignition) switch (vehicles
3-1.	Key information		without smart entry & start system)148
	Keys84		,

	Engine (ignition) switch (vehicles with smart entry & start system)		Toyota parking assist-sensor243 Stop & Start system250
	Automatic transmission153		Driving mode select switch 257
	CVT (Continuously Variable Transaxle)157		Multi-terrain Select (AWD vehicles)259
	Manual transmission160		Snow mode switch262
	Turn signal lever163		Downhill assist control system
	Parking brake164		263
	Brake Hold167		Driving assist systems265
4-3 .	Operating the lights and wip-	4-6.	Driving tips
	ers		Winter driving tips272
	Headlight switch169		Utility vehicle precautions 275
	Automatic High Beam171	_	Interior features
	Fog light switch174	5	interior reatures
	Windshield wipers and washer174		
	Rear window wiper and washer	5-1.	Using the air conditioning system and defogger
	176	$\mathcal{O}_{\mathcal{I}}$	Manual air conditioning system
4-4.	Refueling	S	280
	Opening the fuel tank cap178	•	Automatic air conditioning sys-
4-5.	Using the driving support sys-		tem285
	tems		Seat heaters/Seat ventilators
	Toyota Safety Sense180		290
	PCS (Pre-Collision System) 184	5-2.	Using the interior lights
	LTA (Lane Tracing Assist) 192		Interior lights list292
	LDA (Lane Departure Alert with	5-3.	Using the storage features
	steering control)201		List of storage features294
	RSA (Road Sign Assist)209		Luggage compartment features
	Dynamic radar cruise control		298
•	with full-speed range211	5-4.	Using the other interior features
	Dynamic radar cruise control		Other interior features302
			Curor interior realures

Cruise control.....232
BSM (Blind Spot Monitor) ...235

water.....360

6 Maintenance and care		1		
6-1.	Maintenance and care Cleaning and protecting the vehicle exterior		If your vehicle needs to be towed	
	Tires	8	If the vehicle battery is discharged	
7	Checking and replacing fuses343 Light bulbs346 When trouble arises	8-1.	Specifications Maintenance data (fuel, oil level, etc.)	
7-1.	Essential information Emergency flashers	-	Customization Customizable features411 Initialization Items to initialize423	

Index

What to do if (Troubleshooting)
426
Alphabetical Index429

,

For your information

Main Owner's Manual

Please note that this manual applies to all models and explains all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Toyota policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustrations may differ from your vehicle in terms of equipment.

Accessories, spare parts and modification of your Tovota

A wide variety of non-genuine spare parts and accessories for Toyota vehicles are currently available in the market. Using these spare parts and accessories which are not genuine Toyota products may adversely affect the safety of your vehicle, even though these parts may be approved by certain authorities in your country. Toyota Motor Corporation therefore cannot accept any liability or guarantee spare parts and accessories which

are not genuine Toyota products, nor for replacement or installation involving such parts.

This vehicle should not be modified with non-genuine Toyota products. Modification with non-genuine Toyota products could affect its performance, safety or durability, and may even violate governmental regulations. In addition, damage or performance problems resulting from the modification may not be covered under warranty.

Installation of an RF-transmitter system

The installation of an RF-transmitter system in your vehicle could affect electronic systems such as:

- Multiport fuel injection system/sequential multiport fuel injection system
- Toyota Safety Sense
- Cruise control system
- Anti-lock brake system
- SRS airbag system
- Seat belt pretensioner system

Be sure to check with your Toyota dealer for precautionary measures or special instructions regarding installation of an RF-transmitter system.

Further information regarding frequency bands, power levels, antenna positions and installation provisions for the installation of RF-

transmitters, is available on request at your Toyota dealer.

Vehicle data recordings

The vehicle is equipped with sophisticated computers that will record certain data, such as:

The recorded data varies according to the vehicle grade level and options with which it is equipped.

These computers do not record conversations or sounds, and only record images outside of the vehicle in certain situations.

- Engine speed/Electric motor speed (traction motor speed)
- · Accelerator status
- Brake status
- · Vehicle speed
- Operation status of the driving assist systems, such as the ABS and pre-collision system
- Data usage

Toyota may use the data recorded in this computer to diagnose malfunctions, conduct research and development, and improve quality.

Toyota will not disclose the recorded data to a third party except:

- With the consent of the vehicle owner or with the consent of the lessee if the vehicle is leased
- In response to an official request by the police, a court of law or a government agency
- · For use by Toyota in a lawsuit
- For research purposes where the data is not tied to a specific vehicle or vehicle owner

Event data recorder

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an airbag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. However, data may not be recorded depending on the severity and type of a crash.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. How-

ever, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

Disclosure of the EDR data

Toyota will not disclose the data recorded in an EDR to a third party except when:

- An agreement from the vehicle's owner (or the lessee for a leased vehicle) is obtained
- In response to an official request by the police, a court of law or a government agency
- For use by Toyota in a lawsuit However, if necessary, Toyota may:
- Use the data for research on vehicle safety performance
- Disclose the data to a third party for research purposes without disclosing information about the specific vehicle or vehicle owner

Scrapping of your Toyota

The SRS airbag and seat belt pretensioner devices in your Toyota contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by your Toyota dealer before you scrap your vehicle.

Λ

WARNING

General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.



WARNING

■ General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the kev.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the side windows, the moon roof or the panoramic moon roof, or other features of the vehicle. In addition. heat build-up or extremely cold temperatures inside the vehicle can be fatal to children


Reading this manual

Explains symbols used in this manual


Symbols in this manual

Symbols	Meanings
	WARNING:
	Explains something that, if not obeyed, could cause death or serious injury to people.
	NOTICE:
À	Explains something that, if not obeyed, could cause damage to or a malfunction in the vehicle or its equipment.
1 ₂₃	Indicates operating or working procedures. Follow the steps in numerical order.

Symbols in illustrations




Symbols	Meanings
	Indicates the action (pushing, turning, etc.) used to operate switches and other devices.
	Indicates the outcome of an operation (e.g. a lid opens).




Symbols	Meanings
>	Indicates the component or position being explained.
0	Means Do not, Do not do this, or Do not let this happen.

How to search

- Searching by name
- Alphabetical index: →P.429



- Searching by installation position
- Pictorial index: →P.12




- Searching by symptom or sound
- What to do if... (Troubleshooting): →P.426




■ Searching by title

• Table of contents: →P.2



Pictorial index


■Exterior



Α	Side doors	P.88
	Locking/unlocking	P.88
	Opening/closing the side windows	P.120
	Locking/unlocking by using the key	P.89, 388
	Warning messages	P.375
В	Back door	P.93
	Opening from inside the cabin*	P.97
	Opening from outside	P.96, 97
7	Warning messages	P.375
Ċ	Outside rear view mirrors	P.118
	Adjusting the mirror angle	P.119
	Folding the mirrors	P.119
	Defogging the mirrors	P.281
D	Windshield wipers	P.174
	Precautions against winter season	P.272

	Precautions against car washP.313
	Replacing the wiper insertP.337
Ε	Fuel filler doorP.178
	Refueling methodP.178
	Fuel type/fuel tank capacityP.402
F	TiresP.331
	Tire size/inflation pressure
	Winter tires/tire chain
	Checking/rotation
	Coping with flat tiresP.378
G	HoodP.322
	Opening
	Engine oil
	Coping with overheat
	Warning messagesP.375
_ight	bulbs of the exterior lights for driving
Repl	acing method: P.346, Watts: P.409)
Н	Headlights/front position lights/daytime running lightsP.169
I	Turn signal lightsP.163
J	Fog lights
K	Stop lights/tail lights/turn signal lightsP.163, 169
L	License plate lightsP.169
M	Tail lightsP.169
•	Back-up lights
	Shifting the shift lever to RP.153, 157, 160
If equ	uipped

■Instrument panel




	Lingine Switch	
	Starting the engine/changing the modes	P.148, 149, 151
	Emergency stop of the engine	P.358
	When the engine will not start	P.386
	Warning messages	P.375
В	Shift lever	P.153, 157, 160
	Changing the shift position	P.154, 158, 160
	Precautions against towing	P.361
	When the shift lever does not move (vehicles with autor	
	transmission or CVT)	P.155, 158
С	Meters	P.63, 66
	Reading the meters/adjusting the instrument panel	
	light	P.63, 65, 66, 69
	Warning lights/indicator lights	P.58
	When the warning lights come on	P.368

D	Multi-information display	P.70
	Display	P.70
	When the warning messages are displayed	P.375
Ε	Turn signal lever Headlight switch	
	Headlights/front position lights/tail lights/ license plate lights/daytime running lights	P.169
	Fog lights	
F	Windshield wiper and washer switch	P.174
	Rear window wiper and washer switch	
	Usage	
	Adding washer fluid	P.330
	Warning messages	P.375
G	Emergency flasher switch	P.358
Н	Hood lock release lever	P.322
I	Tilt and telescopic steering control lever	P.116
	Adjustment	P.116
J	Air conditioning system	P.280, 285
	Usage	P.280, 285
	Rear window defogger	P.281, 287
K	Audio system*	
	Fuel filler door opener lever	P.179
Refe	r to "Navigation and Multimedia System Owner's Manual" or "M	lultimedia

^{*:} Refer to "Navigation and Multimedia System Owner's Manual" or "Multimedia Owner's Manual".


■Switches



Α	"ODO TRIP" switch	P.65, 69
В	Driving position memory switches 1	P.111
С	Outside rear view mirror switches	P.118
D	Window lock switch	P.122
Ε	Power window switches	P.120
F	Door lock switches	P.91
G	Automatic High Beam switch	P.171
Н	Camera switch*1, 2	
	Power back door switch*1	P.97

^{*1:} If equipped


^{*2:} Refer to "Navigation and Multimedia System Owner's Manual" or "Multimedia Owner's Manual".



	Weter Control Switches	
В	Vehicle-to-vehicle distance switch*2	P.215, 226
С	Cruise control switches*2	
	Dynamic radar cruise control with full-speed range*2	P.211
	Dynamic radar cruise control 2	P.222
	Cruise control ^{*2}	P.232
D	Audio remote control switches*1	
Ε	LTA (Lane Tracing Assist) switch*2	P.192
	LDA (Lane Departure Alert with steering control) switch*2.	P.201
F	Phone switch*1	
G	Talk switch*1, 2	


^{*1:} Refer to "Navigation and Multimedia System Owner's Manual" or "Multimedia Owner's Manual".

^{*2:} If equipped




	VSC OFF switch	
В	Seat heater switches*	P.291
	Seat heater/ventilator switches*	P.291
С	Stop & Start cancel switch*	P.251
D	Parking brake switch	P.164
	Applying/releasing	P.164
	Precautions against winter season	P.273
	Warning buzzer/message	P.373, 375
E	Brake hold switch	P.167
F	Driving mode select switch	P.257
G	Multi-terrain Select switch*	P.259
Н	"DAC" switch [*]	P.263
I	SNOW mode switch*	P.262
J	iMT switch*	P.161

*: If equipped




■Interior



Α	SRS airbags	P.30
	Floor mats	P.24
С	Front seats	P.108
D	Rear seats	P.109
	Head restraints	
	Seat belts	
	Console box	
	Inside lock buttons	
_	Cup holders	
_	Assist grips	
	Addidt gripd	F.309

■Ceiling




Α	Auxiliary box	P.296
В	Moon roof switches ^{*1}	P.123
C	Interior lights*3	P.292
	Personal lights	P.293
D	Electronic sunshade switch*1	P.125
Ε	Vanity mirrors	P.302
F	Sun visors*2	P.302
G	Inside rear view mirror	P.117

^{*1:} If equipped

^{*2:} NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur. (→P.42)



^{*3:} The illustration shows the front, but they are also equipped in the rear.



For safety and security

1-1.	For safe use
	Before driving24
	For safe driving25
	Seat belts27
	SRS airbags30
	Exhaust gas precautions 37
1-2.	Child safety
	Riding with children39
	Child restraint systems 40
1-3.	Theft deterrent system
	Engine immobilizer system. 54
	Double locking system55


Before driving

Observe the following before starting off in the vehicle to ensure safety of driving.


Installing floor mats

Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.

Insert the retaining hooks (clips) into the floor mat eyelets.



2 Turn the upper knob of each retaining hook (clip) to secure the floor mats in place.



Always align the \triangle marks lacktriangle

The shape of the retaining hooks (clips) may differ from that shown in the illus-


tration

A

WARNING

Observe the following precautions. Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle. This could lead to an accident, resulting in death or serious injury.

- When installing the driver's floor mat
- Do not use floor mats designed for other models or different model year vehicles, even if they are Toyota Genuine floor mats.
- Only use floor mats designed for the driver's seat.
- Always install the floor mat securely using the retaining hooks (clips) provided.
- Do not use two or more floor mats on top of each other.
- Do not place the floor mat bottomside up or upside-down.
- Before driving
- Check that the floor mat is securely fixed in the correct place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.



A


WARNING

 With the engine stopped and the shift lever in P (automatic transmission or CVT) or N (manual transmission), fully depress each pedal to the floor to make sure it does not interfere with the floor mat.

For safe driving

For safe driving, adjust the seat and mirror to an appropriate position before driving.

Correct driving posture



- Adjust the angle of the seatback so that you are sitting straight up and so that you do not have to lean forward to steer. (→P.108)
- B Adjust the seat so that you can depress the pedals fully and so that your arms bend slightly at the elbow when gripping the steering wheel. (→P.108)
- C Lock the head restraint in place with the center of the head restraint closest to the top of your ears. (→P.114)
- D Wear the seat belt correctly. (→P.28)

A

WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

- Do not adjust the position of the driver's seat while driving.
 Doing so could cause the driver to lose control of the vehicle.
- Do not place a cushion between the driver or passenger and the seatback. A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint.
- Do not place anything under the front seats.
 Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident and the adjustment mechanism may also be damaged.
- Always observe the legal speed limit when driving on public roads.
- When driving over long distances, take regular breaks before you start to feel tired.
 Also, if you feel tired or sleepy while

Also, if you feel tired or sleepy while driving, do not force yourself to continue driving and take a break immediately.

Correct use of the seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle. (→P.28)

Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.

 $(\rightarrow P.40)$

Adjusting the mirrors

Make sure that you can see backward clearly by adjusting the inside rear view mirror and outside rear view mirrors properly. (→P.117, 118)

Seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle.

A

WARNING

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident.

Failure to do so may cause death or serious injury.

Wearing a seat belt


- Ensure that all passengers wear a seat belt.
- Always wear a seat belt properly.
- Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- Toyota recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
- To achieve a proper seating position, do not recline the seat more than necessary. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- Do not wear the shoulder belt under your arm.
- Always wear your seat belt low and snug across your hips.

Pregnant women

Obtain medical advice and wear the seat belt in the proper way. (→P.28)

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants, extending the shoulder belt completely over the shoulder and avoiding belt contact with the rounding of the abdominal area

If the seat belt is not worn properly, not only the pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking or a collision.



■ People suffering illness

Obtain medical advice and wear the seat belt in the proper way. (→P.28)


- When children are in the vehicle →P.50
- ■Seat belt damage and wear
- Do not damage the seat belts by allowing the belt, plate, or buckle to be jammed in the door.

A

WARNING

- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do not use a damaged seat belt until it is replaced. Damaged seat belts cannot protect an occupant from death or serious injury.
- Ensure that the belt and plate are locked and the belt is not twisted.
 If the seat belt does not function correctly, immediately contact your Toyota dealer.
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- Do not attempt to install, remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by your Toyota dealer. Inappropriate handling may lead to incorrect operation.

Correct use of the seat belts



- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder
- Position the lap belt as low as possible over the hips.
- Adjust the position of the seat-

back.

Sit up straight and well back in the seat

Do not twist the seat belt.

■ Child seat belt usage


The seat belts of your vehicle were principally designed for persons of adult size.

- Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt. (→P.40)
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions regarding seat belt usage. (→P.27)

■ Seat belt regulations

If seat belt regulations exist in the country where you reside, please contact your Toyota dealer for seat belt replacement or installation.

Fastening and releasing the seat belt




- 1 To fasten the seat belt, push the plate into the buckle until a click sound is heard.
- 2 To release the seat belt, press the release button A.

■ Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. A slow, easy motion will allow the belt to extend so that you can move around fully.

Adjusting the seat belt shoulder anchor height (front seats)



- 1 Push the seat belt shoulder anchor down while pressing the release button A.
- 2 Push the seat belt shoulder anchor up.

Move the height adjuster up and down as needed until you hear a click.

A

WARNING


Adjustable shoulder anchor

Always make sure the shoulder belt is positioned across the center of your shoulder. The belt should be kept away from your neck, but not falling off your shoulder. Failure to do so could reduce the amount of protection in an accident and cause death or serious injuries in the event of a sudden stop, sudden swerve or accident.

Seat belt pretensioners (front and outboard rear seats)

The pretensioners help the seat belts to quickly restrain the occupants by retracting the seat belts when the vehicle is subjected to certain types of severe frontal or side collision.

The pretensioners do not activate in the event of a minor frontal impact, a minor side impact, a rear impact or a vehicle rollover.



Replacing the belt after the pretensioner has been activated

If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.



WARNING

■ Seat belt pretensioners

If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at your Toyota dealer.


Failure to do so may cause death or serious injury.

SRS airbags

The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.

SRS airbag system

■ Location of the SRS airbags



▶ SRS front airbags

A SRS driver airbag/front passenger airbag

Can help protect the head and chest of the driver and front passenger from impact with interior components

B SRS knee airbag

Can help provide driver protection


- SRS side and curtain shield airbags
- C SRS side airbags

Can help protect the torso of the front seat occupants

D SRS curtain shield airbags

Can help protect primarily the head of occupants in the outer seats

■ SRS airbag system components



- A Front impact sensors
- B SRS warning light
- C Side impact sensors (front door)
- D Curtain shield airbags
- E Seat belt pretensioners and force limiters
- F Side impact sensors (front)
- G Side airbags
- H Side impact sensors (rear)
- I Front passenger airbag
- Driver airbag
- K Knee airbag
- L Airbag sensor assembly

The main SRS airbag system components are shown above. The SRS airbag system is controlled by the airbag sensor assembly. As the airbags deploy, a chemical reaction in the inflators quickly fills the airbags with non-

toxic gas to help restrain the motion of the occupants.

■ If the SRS airbags deploy (inflate)

- Slight abrasions, burns, bruising etc., may be sustained from SRS airbags, due to the extremely high speed deployment (inflation) by hot gases.
- A loud noise and white powder will be emitted
- Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the front seats, parts of the front and rear pillars, and roof side rails, may be hot for several minutes. The airbag itself may also be hot.
- The windshield may crack.
- All of the doors will be unlocked.(→P.89)
- Vehicles with Secondary Collision Brake: The brakes and stop lights will be controlled automatically. (→P.266)
- The interior lights will turn on automatically. (→P.293)
- The emergency flashers will turn on automatically. (→P.358)
- Fuel supply to the engine will be stopped. (→P.367)

■ SRS airbag deployment conditions (SRS front airbags)


- The SRS front airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to an approximately 20-30 km/h [12-18 mph] frontal collision with a fixed wall that does not move or deform).
- However, this threshold velocity will be considerably higher in the following situations:
- If the vehicle strikes an object, such as a parked vehicle or sign pole, which can move or deform on impact
- If the vehicle is involved in an underride collision, such as a collision in which the front of the vehicle underrides, or goes under, the bed of a truck

- Depending on the type of collision, it is possible that only the seat belt pretensioners will activate
- SRS airbag deployment conditions (SRS side and curtain shield airbags)
- The SRS side and curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by an approximately 1500 kg [3300 lb.] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at an approximate speed of 20 -30 km/h [12 -18 mphl).
- Both SRS curtain shield airbags may also deploy in the event of a severe frontal collision.

Conditions under which the SRS airbags may deploy (inflate), other than a collision

The SRS front airbags and SRS curtain shield airbags may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.

- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or falling




■Types of collisions that may not deploy the SRS airbags (SRS front airbags)

The SRS front airbags do not generally inflate if the vehicle is involved in a side or rear collision, if it rolls over, or if it is

involved in a low-speed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags may occur.


- Collision from the side
- Collision from the rear
- Vehicle rollover



■Types of collisions that may not deploy the SRS airbags (SRS side and curtain shield airbags)


The SRS side and curtain shield airbags may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.

- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle




The SRS side airbags do not generally inflate if the vehicle is involved in a frontal or rear collision, if it rolls over, or if it is involved in a low-speed side collision.

- Collision from the front
- Collision from the rear
- Vehicle rollover



The SRS curtain shield airbags do not generally inflate if the vehicle is involved in a rear collision, if it rolls over, or if it is involved in a low-speed side or low-speed frontal collision.


- Collision from the rear
- Vehicle rollover




When to contact your Toyota dealer

In the following cases, the vehicle will require inspection and/or repair. Contact your Toyota dealer as soon as possible.


- Any of the SRS airbags have been inflated.
- The front of the vehicle is damaged or deformed, or was involved in an accident that was not severe enough to cause the SRS front airbags to inflate.




A portion of a door or its surrounding area is damaged, deformed or has had a hole made in it, or the vehicle was involved in an accident that was not severe enough to cause the SRS side and curtain shield airbags to inflate




The pad section of the steering wheel, dashboard near the front passenger airbag or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.



 The surface of the seats with the SRS side airbag is scratched, cracked, or otherwise damaged.



The portion of the front pillars, rear pillars or roof side rail garnishes (padding) containing the SRS curtain shield airbags inside is scratched, cracked, or otherwise damaged.



⚠ WARNING

SRS airbag precautions

Observe the following precautions regarding the SRS airbags. Failure to do so may cause death or serious injury.

- The driver and all passengers in the vehicle must wear their seat belts properly.
 - The SRS airbags are supplemental devices to be used with the seat belts.
- The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag.


Since the risk zone for the driver's airbag is the first 50 - 75 mm (2 - 3 in.) of inflation, placing yourself 250 mm (10 in.) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 250 mm (10 in.) away now, you can change your driving position in several ways:

- Move your seat to the rear as far as you can while still reaching the pedals comfortably.
- Slightly recline the back of the seat. Although vehicle designs vary, many drivers can achieve the 250 mm (10 in.) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm, non-slippery cushion, or raise the seat if your vehicle has that feature.


· If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended above, while still maintaining control of the foot pedals. steering wheel, and your view of the instrument panel controls.

- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Toyota strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are safer for infants and children than the front passenger seat. (\rightarrow P.40)
- Do not sit on the edge of the seat or lean against the dashboard.



Do not allow a child to stand in front of the SRS front passenger airbag unit or sit on the knees of a front passenger.



- Do not allow the front seat occupants to hold items on their knees.
- Do not lean against the door, the roof side rail or the front, side and rear pillars.



Do not allow anyone to kneel on the passenger seat toward the door or put their head or hands outside the vehicle.




A

WARNING

 Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad and lower portion of the instrument panel.

These items can become projectiles when the SRS driver, front passenger and knee airbags deploy.



 Do not attach anything to areas such as a door, windshield, side windows, front or rear pillar, roof side rail and assist grip.



• Vehicles without smart entry & start system: Do not attach any heavy, sharp or hard objects such as keys and accessories to the key. The objects may restrict the SRS knee airbag inflation or be thrust into the driver's seat area by the force of the deploying airbag, thus causing a danger.



- Do not hang coat hangers or other hard objects on the coat hooks. All of these items could become projectiles and may cause death or serious injury, should the SRS curtain shield airbags deploy.
- If a vinyl cover is put on the area where the SRS knee airbag will deploy, be sure to remove it.
- Do not use seat accessories which cover the parts where the SRS side airbags inflate as they may interfere with inflation of the SRS airbags. Such accessories may prevent the side airbags from activating correctly, disable the system or cause the side airbags to inflate accidentally, resulting in death or serious injury.
- Do not strike or apply significant levels of force to the area of the SRS airbag components or the front doors.
 - Doing so can cause the SRS airbags to malfunction.
- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.
- If breathing becomes difficult after the SRS airbags have deployed, open a door or side window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.
- If the areas where the SRS airbags are stored, such as the steering wheel pad and front and rear pillar garnishes, are damaged or cracked, have them replaced by your Toyota dealer.

Modification and disposal of SRS airbag system components

Do not dispose of your vehicle or perform any of the following modifications without consulting your Toyota dealer. The SRS airbags may malfunction or deploy (inflate) accidentally, causing death or serious injury.

- Installation, removal, disassembly and repair of the SRS airbags
- Repairs, modifications, removal or replacement of the steering wheel. instrument panel, dashboard, seats or seat upholstery, front, side and rear pillars, roof side rails, front door panels, front door trims or front door speakers
- Modifications to the front door panel (such as making a hole in it)
- Repairs or modifications of the front. fender, front bumper, or side of the occupant compartment
- Installation of a grille guard (bull bars, kangaroo bar, etc.), snow plows or winches
- Modifications to the vehicle's suspension system
- Installation of electronic devices such as mobile two-way radios (RFtransmitter) and CD players

Exhaust gas precautions

Harmful substance to the human body is included in exhaust gases if inhaled.



WARNING

Exhaust gases contain harmful carbon monoxide (CO), which is colorless and odorless. Observe the following precautions.

Failure to do so may cause exhaust gases enter the vehicle and may lead to an accident caused by light-headedness, or may lead to death or a serious health hazard.

- Important points while driving
- Keep the back door closed.
- If you smell exhaust gases in the vehicle even when the back door is closed, open the side windows and have the vehicle inspected at your Toyota dealer as soon as possible.
- When parking
- If the vehicle is in a poorly ventilated area or a closed area, such as a garage, stop the engine.
- Do not leave the vehicle with the engine running for a long time. If such a situation cannot be avoided, park the vehicle in an open space and ensure that exhaust fumes do not enter the vehicle interior
- Do not leave the engine running in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the engine is running, exhaust gases may collect and enter the vehicle.



Exhaust pipe

The exhaust system needs to be checked periodically. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by your Toyota dealer.

Riding with children

Observe the following precautions when children are in the vehicle.

Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt.

- It is recommended that children sit in the rear seats to avoid accidental contact with the shift lever, wiper switch, etc.
- Use the rear door child-protector lock or the window lock switch to avoid children opening the door while driving or operating the power window accidentally. (

 P.92, 122)
- Do not let small children operate equipment which may catch or pinch body parts, such as the power window, hood, back door, seats, etc.

WARNING

When children are in the vehicle

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the side windows, the moon roof (if equipped), the panoramic moon roof (if equipped) or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

Child restraint systems

Before installing a child restraint system in the vehicle, there are precautions that need to be observed, different types of child restraint systems, as well as installation methods, etc., written in this manual.

Use a child restraint system
 when riding with a small child
 that cannot properly use a seat
 belt. For the child's safety,
 install the child restraint system to a rear seat. Be sure to
 follow the installation method
 that is in the operation manual
 enclosed with the restraint system.

Table of contents

Points to remember: P.40

When using a child restraint sys-

tem: P.41

Child restraint system compatibility for each seating position: P.43

Child restraint system installation method: P.47

- Fixed with a seat belt: P.48
 Fixed with an ISOFIX rigid anchor: P.50
- Using a child restraint anchor fitting: P.51

Points to remember

Prioritize and observe the warn-

ings, as well as the laws and regulations for child restraint systems.

- Use a child restraint system until the child becomes large enough to properly wear the vehicle's seat belt.
- Choose a child restraint system appropriate to the age and size of the child.
- Note that not all child restraint systems can fit in all vehicles.
 Before using or purchasing a child restraint system, check the compatibility of the child restraint system with seat positions.
 (→P.43)

WARNING

When a child is riding

Observe the following precautions. Failure to do so may result in death or serious injury.

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system which is correctly installed. For installation details, refer to the operation manual enclosed with the child restraint system. General installation instructions are provided in this manual.
- Toyota strongly urges the use of a proper child restraint system that conforms to the weight and size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.

- Holding a child in your or someone else's arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield or between the holder and the interior of the vehicle
- Handling the child restraint sys-

If the child restraint system is not properly fixed in place, the child or other passengers may be seriously injured or even killed in the event of sudden braking, sudden swerving, or an accident

- If the vehicle were to receive a strong impact from an accident, etc.. it is possible that the child restraint system has damage that is not readily visible. In such cases. do not reuse the restraint system.
- Depending on the child restraint system, installation may be difficult or impossible. In those cases. check whether the child restraint system is suitable for installment in the vehicle (→P.43). Be sure to install and observe the usage rules after carefully reading the child restraint system fixing method in this manual, as well as the operation manual enclosed with the child restraint system.
- Keep the child restraint system properly secured on the seat even if it is not in use. Do not store the child restraint system unsecured in the passenger compartment.
- If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the luggage compartment.

When using a child restraint svstem


■ When installing a child restraint system to a front passenger seat

For the safety of a child, install a child restraint system to a rear seat. When installing a child restraint system to the front passenger seat is unavoidable, adjust the seat as follows and install the child restraint. system:

 Adjust the seatback angle to the most upright position.

If there is a gap between the child seat and the seatback, adjust the seatback angle until good contact is achieved.

- Move the front seat fully rearward
- If the head restraint interferes with the child restraint system installation and the head restraint can be removed, remove the head restraint. Otherwise, put the head restraint in the upper most position.






■ When using a child restraint system

Observe the following precautions. Failure to do so may result in death or serious injury.

Extreme Hazard! Do not use a rearward facing child restraint on a seat protected by an airbag in front of it! This is because the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child.

There is a label(s) on the passenger side sun visor, indicating it is forbidden to attach a rear-facing child restraint system to the front passenger seat.

Details of the label(s) are shown in the illustration below.





Only put a forward-facing child restraint system on the front seat when unavoidable. When installing a forward-facing child restraint on the front passenger seat, move the seat as far back as possible. Failing to do so may result in death or serious injury if the airbags deploy (inflate).



Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front or rear pillars, or roof side rails from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the SRS side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.



When a junior seat (booster seat) is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder.

- Use a child restraint system suitable to the age and size of the child and install it to the rear seat
- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the left-hand rear seat.



Adjust the front passenger seat so that it does not interfere with the child restraint system.

Child restraint system compatibility for each seating position


Child restraint system compatibility for each seating position

Compatibility of each seating position with child restraint systems (→P.45) displays the type of child restraint systems that can be used and possible seating positions for installation using symbols.

Check the selected child restraint system together with the following [Before confirming the compatibility of each seating position with child restraint systems].

- Before confirming the compatibility of each seating position with child restraint systems
- Checking the child restraint system standards.
 Use a child restraint system that conforms to UN(ECE) R44^{*1} or UN(ECE) R129^{*1, 2}.


The following approval mark is displayed on child restraint systems which are conformed. Check for an approval mark attached to the child restraint system.



Example of the displayed regulation Number


- A UN(ECE) R44 approval mark*3
 The weight range of the child
 who is applicable for an
 UN(ECE) R44 approval mark is
 indicated.
- B UN(ECE) R129 approval mark*3
 The height range of the child
 who is applicable as well as
 available weights for an


- UN(ECE) R129 approval mark is indicated
- 2 Checking the category of the child restraint system. Check the approval mark of the child restraint system for which of the following categories the child restraint system is suitable. Also, if there are any uncertainties, check the user's guide included with the child restraint system or contact the retailer of the child restraint system.
- "universal"
- "semi-universal"
- "restricted"
- "vehicle specific"



- *1: UN(ECE) R44 and UN(ECE) R129 are U.N. regulations for child restraint systems.
- *2: The child restraint systems mentioned in the table may not be available outside of the EU area.
- *3: The displayed mark may differ depending on the product.

Compatibility of each seating position with child restraint systems







Suitable for fixed with vehicle seat belt "universal" category child restraint system.



Suitable for i-Size and ISOFIX child restraint system.




Includes a top tether anchorage point.



Never use a rear-facing child restraint system on the front passenger seat.

- *1: Move the front seat fully rearward. If the passenger seat height can be adjusted, move it to the upper most position.
- *2: Adjust the seatback angle to the most upright position. When installing a forward-facing child seat, if there is a gap between the child seat and the seatback, adjust the seatback angle until good contact is achieved.



- If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.

 Otherwise, put the head restraint in the upper most position.
- *4: Use only a front-facing child restraint system.

■ Detail information for child restraint systems installation

Seating position					
Seat position number	1	2	3	4	
Seating position suitable for universal belted (Yes/No)	Yes Forward facing only	Yes	Yes	Yes	
i-Size seating position (Yes/No)	No	Yes	No	Yes	
Seating position suitable for lateral fixture (L1/L2/No)	No	No	No	No	
Suitable rearward facing fixture (R1/R2X/R2/R3/No)	No	R1, R2X, R2, R3	No	R1, R2X, R2, R3	
Suitable forward facing fixture (F2X/F2/F3/No)	No	F2X, F2, F3	No	F2X, F2, F3	
Suitable junior seat fixture (B2/B3/No)	No	B2, B3	No	B2, B3	

ISOFIX child restraint systems are divided into different "fixture". The child restraint system can be used in the seating positions for "fixture" mentioned in the table above. For kind of "fixture" relation, confirm the following table. If your child restraint system has no kind of "fixture" (or if you cannot find information in the table below), please refer to the child restraint system "vehicle list" for compatibility information or ask the retailer of your child seat.

Fixture	Description
F3	Full-height, forward-facing child restraint systems
F2	Reduced-height forward-facing child restraint systems
F2X	Reduced-height forward-facing child restraint systems
R3	Full-size, rearward-facing child restraint systems
R2	Reduced-size, rearward-facing child restraint systems
R2X	Reduced-size, rearward-facing child restraint systems
R1	Rearward-facing infant seat
L1	Left lateral-facing (carrycot) infant seat
L2	Right lateral-facing (carrycot) infant seat


Fixture	Description
B2	Junior seat
В3	Junior seat

When securing some types of child restraint systems in rear seat, it may not be possible to properly use the seat belts in positions next to the child restraint without interfering with it or affecting seat belt effectiveness. Be sure your seat belt fits snugly across your shoulder and low on your hips. If it does not, or if it interferes with the child restraint, move to a different position. Failure to do so may result in death or serious injury.

- When installing a child restraint in the rear seats, adjust the front seat so that it does not interfere with the child or child restraint system.
- When installing a child seat with support base, if the child seat interferes with the seatback when latching it into the support base, adjust the seatback rearward until there is no interfer-

ence

 If the seat belt shoulder anchor is ahead of the child seat belt guide, move the seat cushion forward.



When installing a junior seat, if the child in your child restraint system is in a very upright position, adjust the seatback angle to the most comfortable position. And if the seat belt shoulder anchor is ahead of the child seat belt guide, move the seat cushion forward.

Child restraint system installation method

Confirm with the operation manual enclosed with the child restraint system about the installation of the child restraint system.

Installation method		Page
Seat belt attachment		P.48
ISOFIX rigid anchor attachment		P.50
Child restraint anchor fit- ting attachment	TOP-TETHER CONTRICTOR	P.51

Child restraint system fixed with a seat belt


■ Installing child restraint system using a seat belt

Install the child restraint system in accordance to the operation manual enclosed with the child restraint system.


If the child restraint system on hand

is not within the "universal" category (or the necessary information is not in the table), refer to the "Vehicle List" provided by the child restraint system maker for various possible installation positions, or check the compatibility after asking the retailer of the child seat. $(\rightarrow P.44, 45)$

- If installing the child restraint system to the front passenger seat is unavoidable, refer to P.41 for the front passenger seat adjustment.
- Adjust the seatback angle to the most upright position. When installing a forward-facing child seat, if there is a gap between the child seat and the seatback, adjust the seatback angle until good contact is achieved.
- 3 If the head restraint interferes with the child restraint system installation and the head restraint can be removed, remove the head restraint. Otherwise, put the head restraint in the upper most position. (→P.114)
- 4 Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted. Securely fix the seat belt to the child restraint system in accordance to the directions enclosed with the child restraint system.



5 If your child restraint system is not equipped with a lock-off (a seat belt locking feature), secure the child restraint system using a locking clip.



- 6 After installing the child restraint system, rock it back and forth to ensure that it is installed securely. (→P.50)
- Removing a child restraint system installed with a seat belt

Press the buckle release button and fully retract the seat belt.

When releasing the buckle, the child restraint system may spring up due to the rebound of the seat cushion. Release the buckle while holding down the child restraint system.

Since the seat belt automatically reels itself, slowly return it to the stowing position.

■ When installing a child restraint system

You may need a locking clip to install the child restraint system. Follow the instructions provided by the manufacturer of the system. If your child restraint system does not provide a locking clip, you can purchase the following item from your Toyota dealer: Locking clip for

child restraint system (Part No. 73119-22010)

A

WARNING

When installing a child restraint system

Observe the following precautions. Failure to do so may result in death or serious injury.


- Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death. If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt
- Ensure that the belt and plate are securely locked and the seat belt is not twisted.
- Shake the child restraint system left and right, and forward and backward to ensure that it has been securely installed.
- After securing a child restraint system, never adjust the seat.
- When a junior seat (booster seat) is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder.
- Follow all installation instructions provided by the child restraint system manufacturer.

Child restraint system fixed with an ISOFIX rigid anchor

■ ISOFIX rigid anchors (ISOFIX child restraint system)

Lower anchors are provided for the

outboard rear seats. (Tags displaying the location of the anchors are attached to the seats.)



■ Installation with ISOFIX rigid anchor (ISOFIX child restraint system)

Install the child restraint system in accordance to the operation manual enclosed with the child restraint system.

If the child restraint system on hand is not within the "universal" category (or the necessary information is not in the table), refer to the "Vehicle List" provided by the child restraint system maker for various possible installation positions, or check the compatibility after asking the retailer of the child seat.


 $(\rightarrow P.44, 45)$

- Adjust the seatback angle to the most upright position. When installing a forward-facing child seat, if there is a gap between the child seat and the seatback, adjust the seatback angle until good contact is achieved.
- 2 If the head restraint interferes with the child restraint system installation and the head

restraint can be removed, remove the head restraint. Otherwise, put the head restraint in the upper most position. (\rightarrow P.114)

3 Check the positions of the exclusive fixing bars, and install the child restraint system to the seat.

The bars are installed in the clearance between the seat cushion and seat-back.



4 After installing the child restraint system, rock it back and forth to ensure that it is installed securely. (→P.50)



WARNING

When installing a child restraint system

Observe the following precautions. Failure to do so may result in death or serious injury.

After securing a child restraint system, never adjust the seat.

- When using the lower anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint system.
- Follow all installation instructions provided by the child restraint system manufacturer.

Using child restraint anchorages

WARNING: child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seatbelts, harnesses, or for attaching other items or equipment to the vehicle.


Using a child restraint anchor fitting

Child restraint anchor fitting

Anchor fittings are provided for each rear seat.


Use anchor fitting when fixing the strap.

Outboard rear seats



- A Anchor fittings
- B Upper anchorage strap

Center rear seat




- A Anchor fitting
- B Upper anchorage strap
- Fixing the strap to the anchor fitting

Install the child restraint system in accordance to the operation manual enclosed with the child restraint system.

1 Adjust the head restraint to the upmost position.


If the head restraint interferes with the child restraint system or top strap installation and the head restraint can be removed, remove the head restraint. (→P.114)



2 Latch the attaching clip onto the anchor fitting and tighten the upper anchorage strap.

Make sure the upper anchorage strap is securely latched. (→P.50)

When installing the child restraint system with the head restraint being raised, be sure to have the top strap pass underneath the head restraint.



- Attaching clip
- B Upper anchorage strap



WARNING

When installing a child restraint system

Observe the following precautions. Failure to do so may result in death or serious injury.

- Firmly attach the upper anchorage strap and make sure that the belt is not twisted.
- Do not attach the upper anchorage strap to anything other than the anchor fitting.
- After securing a child restraint system, never adjust the seat.
- Follow all installation instructions provided by the child restraint system manufacturer.
- When installing the child restraint system with the head restraint being raised, after the head restraint has been raised and then the top tether anchorage has been fixed, do not lower the head restraint



Using child restraint anchorages

WARNING: child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seatbelts, harnesses, or for attaching other items or equipment to the vehicle.

Engine immobilizer system

The vehicle's keys have builtin transponder chips that prevent the engine from starting if a key has not been previously registered in the vehicle's onboard computer.

Never leave the keys inside the vehicle when you leave the vehicle.


This system is designed to help prevent vehicle theft but does not guarantee absolute security against all vehicle thefts.

Operating the system

Vehicles without smart entry & start system

The indicator light flashes after the key has been removed from the engine switch to indicate that the system is operating.


The indicator light stops flashing after the registered key has been inserted into the engine switch to indicate that the system has been canceled.



Vehicles with smart entry & start system

The indicator light flashes after the engine switch has been turned to OFF to indicate that the system is operating.

The indicator light stops flashing after the engine switch has been turned to ACC or ON to indicate that the system has been canceled.



■ System maintenance

The vehicle has a maintenance-free type engine immobilizer system.

- Conditions that may cause the system to malfunction
- If the grip portion of the key is in contact with a metallic object
- If the key is in close proximity to or touching a key to the security system (key with a built-in transponder chip) of another vehicle



NOTICE

To ensure the system operates correctly


Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be quaranteed.

Double locking system

*: If equipped

Unauthorized access to the vehicle is prevented by disabling the door unlocking function from both the interior and exterior of the vehicle.

Vehicles employing this system have labels on the front side windows



Setting/canceling the double locking system

Setting

Turn the engine switch to OFF, have all the passengers exit the vehicle and ensure that all the doors are closed.

Using the entry function:

Touch the sensor area on the front outside door handle twice within 5 seconds.

Using the wireless remote control:

Press twice within 5 seconds.



■ Canceling

Using the entry function: Hold the front outside door handle.

Using the wireless remote control:

Press







WARNING

■ Double locking system precaution

Never activate the double locking system when there are people in the vehicle because all the doors cannot be opened from inside the vehicle.

Vehicle status information and indicators

2 4	Instr		4 -	
Z-1.	Instr	umer	IT C	iuster

Warning lights and indicators58
Gauges and meters (with 4.2-inch display)63
Gauges and meters (with 7-inch display)66
Multi-information display 70
Fuel consumption information
79


Warning lights and indicators

The warning lights and indicators on the instrument cluster, center panel and outside rear view mirrors inform the driver of the status of the vehicle's various systems.

Instrument cluster

For the purpose of explanation, the following illustrations display all warning lights and indicators illuminated.


■ With 4.2-inch display




■ With 7-inch display*

*: The display of the speedometer can be selected from two types, analog or digital. (→P.75)

▶ When analog speedometer is displayed



▶ When digital speedometer is displayed



Warning lights

Warning lights inform the driver of malfunctions in the indicated vehicle's systems.



Brake system warning light^{*1} (→P.368)



Brake system warning light*1 (→P.368)









ing light*1 (\rightarrow P.368) High coolant temperature warning light*2 (\rightarrow P.368) Low engine oil pressure warning light*2 (\rightarrow P.369)

Charging system warn-

Malfunction indicator $lamp^{*1}$ (\rightarrow P.369)



SRS warning $light^{*1}$ (\rightarrow P.369)



ABS warning $light^{*1}$ (\rightarrow P.369)



Electric power steering system warning light*1 (→P.370)



iMT indicator (if equipped) $(\rightarrow P.370)$



PCS warning light^{*1} (if equipped) (→P.370)



LTA indicator (if equipped) (→P.370)



LDA indicator (if equipped) (→P.370)



Stop & Start cancel indicator*1 (if equipped) (→P.371)



Toyota parking assistsensor OFF indicator*3 (if equipped) (→P.371)



RCTA OFF indicator*1 (if equipped) (→P.371)



Slip indicator light^{*1} (→P.372)



Brake Override System (if equipped)/Drive-Start Control warning light*2 (→P.372)



Brake hold operated indicator^{*1} (→P.373)




Parking brake indicator $(\rightarrow P.373)$



Low fuel level warning light (→P.373)



Driver's and front passenger's seat belt reminder light (\rightarrow P.373) Rear passengers' seat belt reminder light (\rightarrow P.374)



inspected by your Toyota dealer.

*2: This light illuminates on the multiinformation display with a message.

on, or turn off. Have the vehicle

*3. Toyota parking assist-sensor OFF indicator turns on when the engine switch is turned to ON while the Toyota parking assist-sensor function is on. It will turn off after a few seconds



WARNING

If a safety system warning light does not come on

Should a safety system light such as the ABS and SRS warning light not come on when you start the engine, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Toyota dealer immediately if this occurs.

2

Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn indicator signal (→P.163)



Tail light indicator (→P.169)



Headlight high beam indicator (→P.171)



Automatic High Beam indicator (if equipped) (→P.171)



Fog light indicator (→P.174)



Smart entry & Start system indicator*1 (if equipped) (→P.149)



(Green)

iMT indicator*2 (if equipped) (→P.161)



Cruise control indicator (if (→P.211, 222, equipped) 232)



Dynamic radar cruise control indicator (if equipped) (→P.211, 222)



Cruise control "SET" indicator (if equipped) (→P.211, 222, 232)



LTA indicator*3 (if equipped) (→P.197)



LDA indicator*3 (if equipped) (→P.205)



Toyota parking assist-sensor indicator*4, OFF (if equipped) (→P.244)



liaht*2 Slip indicator (→P.267)



indicator*2, 4 VSC OFF (→P.267)



PCS warning light*2, 4 (if equipped) (→P.186)



BSM outside rear view mirindicators*2, ror (if equipped) (\rightarrow P.236)



BSM indicator (if equipped) (→P.236)



RCTA OFF indicator*2, 4 (→P.236)



Stop & Start indicator*2 (if equipped) (→P.250)



Stop & Start cancel indicator*2, 4 (if equipped) (→P.251)



Brake hold standby indica $tor^{*2} (\rightarrow P.167)$



Brake hold operated indica $tor^{*2} (\to P.167)$



Security indicator (→P.54)



Low outside temperature indicator*7 (\rightarrow P.64, 68)



Eco Driving Indicator Light*2 (if equipped) (→P.73)



Parking brake indicator (→P.164)



AUTO EPB OFF indicator*2, ⁴ (if equipped) (→P.164)



Eco drive mode indicator $(\to P.257)$



indicator Sport mode $(\to P.257)$





Mud & sand mode indicator (if equipped) (→P.260)



Rock & dirt mode indicator (if equipped) (→P.260)



Snow mode indicator (if equipped) (→P.262)



Downhill assist control system indicator*2 (if equipped) (→P.263)

- *1: This light illuminates on the multiinformation display with a message.
- *2: These lights turn on when the engine switch is turned to ON to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if the lights do not turn on, or turn off. Have the vehicle inspected by your Toyota dealer.
- *3: Depending on the operating conditions of the system, the color and state (illuminated/blinking) of the indicator change.
- *4: The light comes on when the system is turned off.
- *5: Toyota parking assist-sensor OFF indicator turns on when the engine switch is turned to ON while the Toyota parking assist-sensor function is on. It will turn off after a few seconds.
- *6: This light illuminates on the outside rear view mirrors.
- *7: When the outside temperature is approximately 3°C (37°F) or lower, the indicator will flash for approximately 10 seconds, then stay on.

BSM (Blind Spot Monitor) outside rear view mirror indicators (if equipped)

In order to confirm operation, the BSM outside rear view mirror indicators illuminate in the following situations:

- When the engine switch is turned to ON while the BSM function is enabled on screen of the multi-information display.
- When the BSM function is enabled on

screen of the multi-information display while the engine switch is in ON.


If the system is functioning correctly, the BSM outside rear view mirror indicators will turn off after a few seconds.

If the BSM outside rear view mirror indicators do not illuminate or do not turn off, there may be a malfunction in the system. If this occurs, have the vehicle inspected by your Toyota dealer.

Gauges and meters (with 4.2-inch display)

The meters display various drive information.

Meter display



A Tachometer

Displays the engine speed in revolutions per minute

- B Outside temperature (→P.64)
- C Clock (→P.65)
- D Multi-information display

Presents the driver with a variety of driving-related data (→P.70)

Displays warning messages if a malfunction occurs (→P.375)

E Speedometer

Displays the vehicle speed

F Fuel gauge

Displays the quantity of fuel remaining in the tank

G Odometer, trip meter and instrument cluster light control display

Odometer:

Displays the total distance that the vehicle has been driven

Trip meter:

Displays the distance the vehicle has been driven since the meter was last reset. Trip meters "A" and "B" can be used to record and display different distances independently.

Instrument cluster light control:

Displays the brightness of the instrument cluster lights that can be adjusted.

H Shift position and shift range/gear step indicator

Displays the selected shift position or selected shift range/gear step (→P.153, 157)

I Engine coolant temperature gauge

Displays the engine coolant temperature

■ The meters and display illuminate when

The engine switch is in ON.

Outside temperature display

- In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.
- When stopped, or driving at low speeds (less than 20 km/h [12 mph])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)
- When "--" or "E" is displayed, the system may be malfunctioning.
 Take your vehicle to your Toyota dealer.
- Displays the outside temperature within the range of -40°C (-40°F) to 50°C (122°F).
- When the outside temperature is approximately 3°C (37°F) or lower, the indicator will flash for approximately 10 seconds, then stay on.
- Liquid crystal display

Λ

WARNING

The information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the display monitor may respond slowly, and display changes may be delayed.

For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or injury.



NOTICE


■ To prevent damage to the engine and its components

- Do not let the indicator needle of the tachometer enter the red zone, which indicates the maximum engine speed.
- The engine may be overheating if the engine coolant temperature gauge is in the red zone ("H"). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (→P.395)

Using the "ODO TRIP" switch

Switches the items of the odometer, trip meter A, trip meter B and the brightness of the instrument cluster lights by pressing the "ODO TRIP" switch.

- When the trip meter is displayed, pressing and holding the switch will reset the trip meter.
- When the instrument cluster light control display is displayed, pressing and holding the switch will adjust the brightness of the instrument cluster lights.



■ Instrument cluster brightness adjustment

The instrument cluster brightness levels when the tail lights are on and off can be adjusted individually. However, when the surroundings are bright (daytime, etc.), turning on the tail lights will not change the instrument cluster brightness.

Adjusting the clock

The clocks can be adjusted on the audio system screen.

Refer to "Navigation and Multime-

dia System Owner's Manual" or "Multimedia Owner's Manual"




Gauges and meters (with 7-inch display)

The meters display various drive information.

Meter display

The display of the speedometer can be selected from two types, analog or digital. $(\rightarrow P.75)$

▶ Analog speedometer



A Tachometer

Displays the engine speed in revolutions per minute

B Speedometer

Displays the vehicle speed

C Clock (→P.69)

D Fuel gauge

Displays the quantity of fuel remaining in the tank

E Engine coolant temperature gauge

Displays the engine coolant temperature

F Odometer, trip meter and instrument cluster light control display

Odometer:

Displays the total distance that the vehicle has been driven

Trip meter:

Displays the distance the vehicle has been driven since the meter was last reset.

Trip meters "A" and "B" can be used to record and display different distances independently.

Instrument cluster light control:

Displays the brightness of the instrument cluster lights that can be adjusted.

- G Outside temperature (→P.68)
- H Multi-information display


Presents the driver with a variety of driving-related data (→P.70)

Displays warning messages if a malfunction occurs (→P.375)

Shift position and shift range/gear step indicator

Displays the selected shift position or selected shift range/gear step (→P.153, 157)

▶ Digital speedometer



A Tachometer

Displays the engine speed in revolutions per minute

B Speedometer

Displays the vehicle speed

- Clock (→P.69)
- D Fuel gauge

Displays the quantity of fuel remaining in the tank

E Engine coolant temperature gauge

Displays the engine coolant temperature

F Odometer, trip meter and instrument cluster light control display

Odometer:

Displays the total distance that the vehicle has been driven

Trip meter:

Displays the distance the vehicle has been driven since the meter was last reset. Trip meters "A" and "B" can be used to record and display different distances independently.

Instrument cluster light control:

Displays the brightness of the instrument cluster lights that can be adjusted.

G Outside temperature (→P.68)

H Multi-information display

Presents the driver with a variety of driving-related data (→P.70)

Displays warning messages if a malfunction occurs (→P.375)

Shift position and shift range/gear step indicator

Displays the selected shift position or selected shift range/gear step (→P.153, 157)

■ The meters and display illuminate when

The engine switch is in ON.

■ When changing driving mode

- Speedometer color is changed following the selected driving mode. (→P.257)
- AWD models: Speedometer color is changed following the selected driving mode or Multi-terrain Select mode. (→P.257, 259)

Outside temperature display

- In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.
- When stopped, or driving at low speeds (less than 20 km/h [12 mph])
 When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)
- When "--" or "E" is displayed, the system may be malfunctioning.
 Take your vehicle to your Toyota dealer.
- Displays the outside temperature within the range of -40°C (-40°F) to 50°C (122°F).

When the outside temperature is approximately 3°C (37°F) or lower, the indicator / ↓ will flash for approximately 10 seconds, then stay on.

Liquid crystal display

→P.71

Customization

Settings (e. g. meter display) can be changed on screen of the multi-information display. (→P.75)



■The information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the display monitor may respond slowly, and display changes may be delayed.

For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or injury.



NOTICE

■ To prevent damage to the engine and its components


- Do not let the indicator needle of the tachometer enter the red zone. which indicates the maximum engine speed.
- The engine may be overheating if the engine coolant temperature gauge is in the red zone ("H"). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (→P.395)

Using the "ODO TRIP" switch

Switches the items of the odometer. trip meter A, trip meter B and the brightness of the instrument cluster lights by pressing the "ODO TRIP" switch.

 When the trip meter is displayed, pressing and holding the switch will reset the trip meter.

 When the instrument cluster light. control display is displayed. pressing and holding the switch will adjust the brightness of the instrument cluster lights.



■ Instrument cluster brightness adiustment

The instrument cluster brightness levels when the tail lights are on and off can be adjusted individually. However, when the surroundings are bright (daytime. etc.), turning on the tail lights will not change the instrument cluster brightness.

Adjusting the clock

The clocks can be adjusted on the audio system screen.

Refer to "Navigation and Multimedia System Owner's Manual" or "Multimedia Owner's Manual".


Multi-information display

The multi-information display is used to display fuel efficiency related information and various types of driving-related information. The multi-information display can also be used to change the display settings and other settings.

Display contents

Following information is displayed on the multi-information display.

■ Vehicles with 4.2-inch display



A Driving support system information

Displays a sign when the RSA system is operating and recognizes the sign. (\rightarrow P.209)

Displays an image when the following systems are operating and a menu icon

other than is selected:


- LTA (Lane Tracing Assist) (if equipped) (→P.192)
- LDA (Lane Departure Alert with steering control) (if equipped)
 (→P.201)
- · Dynamic radar cruise control with full-

- speed range (if equipped) (→P.211)
- Dynamic radar cruise control (if equipped) (→P.222)
- Cruise control (if equipped) (→P.232)
- B Menu icons (→P.71)
- C Information display area

A variety of information can be displayed by selecting a menu icon.

Additionally, warning or suggestion/advice pop-up displays will be displayed in some situations.

■ Vehicles with 7-inch display



A Driving support system information

Displays a sign when the RSA system is operating and recognizes the sign. $(\rightarrow P.209)$

Displays an image when the following systems are operating and a menu icon other than is selected:

- LTA (Lane Tracing Assist) (if equipped) (→P.192)
- LDA (Lane Departure Alert with steering control) (if equipped)
 (→P.201)
- Dynamic radar cruise control with fullspeed range (if equipped) (→P.211)
- Dynamic radar cruise control (if equipped) (→P.222)
- Cruise control (if equipped) (→P.232)

B Information display area

A variety of information can be displayed by selecting a menu icon.

Additionally, warning or suggestion/advice pop-up displays will be displayed in some situations.

C Menu icons (→P.71)

■ The multi-information display is displayed when

The engine switch is in ON.

■ When changing driving mode


- Background color of the multi-information display is changed following the selected driving mode. (→P.257)
- AWD models: Background color of the multi-information display is changed following the selected driving mode or Multi-terrain Select mode. (→P.257, 259)

■ Liquid crystal display

Small spots or light spots may appear on the display. This phenomenon is characteristic of liquid crystal displays, and there is no problem continuing to use the display.

Changing the display

The multi-information display is operated using the meter control switches.



- A Scroll the screen*/switch the display*/move the cursor
- B Press: Enter/Set
 Press and hold: Reset/Display
 customizable items
- C Return to the previous screen
- D Call sending/receiving and history display (if equipped)
 Linked with the hands-free system, sending or receiving call is displayed. For details regarding the hands-free system, refer to "Navigation and Multimedia System Owner's Manual" or "Multimedia Owner's Manual"
- *: On screens where the screen can be scrolled and the display can be switched, a scroll bar or a round icon that shows the number of registered screens is displayed.

A

WARNING

Caution for use while driving

For safety, avoid operating the meter control switch while driving as much as possible, and do not look continuously at the multi-information display while driving. Stop the vehicle and operate the meter control switch. Failure to do so may cause a steering wheel operation error, resulting in an unexpected accident.

Menu icons

Information related to each icon can be displayed by selecting the icon with the meter control switches.

Some of the information may be dis-

played automatically depending on the situation

Icon	Display	
	Driving information display (→P.72)	
	Driving support system information display (→P.74)	
1	Audio system-linked display (→P.74)	
(1)	Vehicle information display (→P.74)	
\$	Settings display (→P.75)	
\triangle	Warning message display (→P.78)	

Driving information display

Select to display fuel consumption data in various forms.

■ Speedometer display/Distance to empty (4.2-inch display)




- A Speedometer display Displays the vehicle speed.
- **B** Distance to empty

Displays the driving range with remaining fuel. (\rightarrow P.73)

■ Fuel Economy

Following information is displayed.



A Distance to empty

Displays the driving range with remaining fuel. (→P.73)

B Current fuel economy

Displays the instantaneous current fuel Economy.

C Average fuel economy

Displays the average fuel economy since the function was reset or the average fuel economy after starting or refueling.*1, 2, 3


The average fuel economy selected by "Fuel Economy" on the screen is

"Fuel Economy" on the
screen is displayed. (→P.75)

- *1: Use the displayed fuel consumption as a reference only.
- *2: Average fuel economy since the function was reset can be reset by pressing and holding ...
- *3: Average fuel economy after starting is reset each time the engine stops.

■ Eco Driving Indicator (if equipped)/Distance to empty


Display contents



- A Eco Driving Indicator
- **B** Distance to empty

Displays the driving range with remaining fuel. (\rightarrow P.73)

► Eco Driving Indicator



During Eco-friendly acceleration operation (Eco driving), the Eco Driving Indicator Light will turn on. When the acceleration exceeds Zone of Eco driving, or when the vehicle is stopped, the

B Eco Driving Indicator Zone Dis-

light turns off.

play

Suggests the Zone of Eco driving with current Eco driving ratio based on acceleration

© Eco driving ratio based on acceleration

If the acceleration exceeds Zone of Eco driving, the right side of Eco Driving Indicator Zone Display will illuminate. At this time, the Eco Driving Indicator Light will turn off.

D Zone of Eco driving

■ Distance to empty

- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated. When refueling, turn the engine switch off. If the vehicle is refueled without turning the engine switch off, the display may not be updated.
- When "Refuel" is displayed, the remaining fuel amount is low and the distance that can be driven with the remaining fuel cannot be calculated. Refuel immediately.

■ The ECO Driving indicator will not operate when

Eco Driving Indicator will not operate in the following conditions:

- The shift lever is in any position other than D.
- Neither normal mode nor Eco drive mode is selected.
- The vehicle speed is approximately 130 km/h (80 mph) or higher.

Driving support system information display

Driving support system information display

Select to display the operational status of the following systems:

- LTA (Lane Tracing Assist)^{*}
 (→P.192)
- LDA (Lane Departure Alert with steering control)^{*} (→P.201)
- Dynamic radar cruise control with full-speed range^{*} (→P.211)
- Dynamic radar cruise control^{*}
 (→P.222)
- Cruise control^{*} (→P.232)

*: If equipped

■ Navigation system-linked display (if equipped)

Select to display the following navigation system-linked information.

- Route guidance
- Compass display (north-up display/heading-up display)

Audio system-linked display

Select to enable selection of an audio source or track on the display.

Vehicle information display

Drive information

2 items that are selected using the "Drive Info Items" setting (average


speed, distance and total time) can be displayed vertically. The displayed information changes according to the "Drive Info Type" setting (since the system was started or between resets). (→P.75)

Use the displayed information as a reference only.

Following items will be displayed

- "Trip"
- "Average Speed": Displays the average vehicle speed since engine start
- "Distance": Displays the distance driven since engine start*
- "Total Time": Displays the elapsed time since engine start*
- *: These items are reset each time the engine stops.
- "Total"
- "Average Speed": Displays the average vehicle speed since the display was reset*
- "Distance": Displays the distance driven since the display was reset
- "Total Time": Displays the elapsed time since the display was reset
- *: To reset, display the desired item and press and hold os.

AWD system display (AWD models)



A Front tire direction display

Displays the operation amount and direction of the steering wheel via changes to the front tires on the display.

- B Torque distribution display
 Displays the drive status of each wheel in 6 steps from 0 to 5.
- C G-force display*

Displays the size and direction of the Gforce applied to the vehicle via changes to the position of the ball on the display.

D Maximum G-force course*

This item is linked with the G-force display and the course of the past movement of the ball is displayed.

Press and hold ox to reset the record.

E Wheel spin display

When a tire is spinning, its icon on the display changes its color and blinks.

*: This item is displayed only when driving mode is set to sport mode.

Settings display

Vehicle settings and the content displayed on the screen can be changed by using the meter control switches

Setting procedure

- 1 Operate or of the meter control switches and select .
- 2 Operate or of the meter control switches and select the desired item.
- off or the volume, etc. is changed on the setting screen, the setting is changed each time is pressed.
- For functions that allow operation contents, display contents, etc., of function to be selected, the setting screen is displayed by pressing and holding . When the setting screen is displayed, select the setting or desired value (time, etc.) with .
- After changing the settings,press of the meter control switches

■ 🏠 LTA (Lane Tracing Assist) (if equipped) (→P.192)

Select to set up the following items.

"Lane Center"

Select to enable/disable the lane centering function.

"Steering Assist"

Select to enable/disable steering wheel assistance.

"Sensitivity"

Select to set the lane departure alert

sensitivity.

"Sway Warning"

Select to enable/disable the vehicle sway warning.

"Sway Sensitivity"

Select to set the vehicle sway warning sensitivity.

Select to set up the following items.

"Steering Assist"

Select to enable/disable steering wheel assistance.

"Sensitivity"

Select to set the warning sensitivity.

"Sway Warning"

Select to enable/disable the vehicle sway warning.

"Sway Sensitivity"

Select to set the vehicle sway warning sensitivity.

■ 🏂 PCS (Pre-Collision System) (if equipped) (→P.184)

Select to set up the following items.

PCS on/off

Select to enable/disable the pre-collision system.

"Sensitivity"

Select to change the pre-collision warning timing.

■ ⓐ_{//•} BSM (Blind Spot Monitor) (if equipped) (→P.235)

Select to set up the following items.

BSM (Blind Spot Monitor) on/off

Select to enable/disable the BSM system.

• "Brightness"

Select to switch the brightness of the outside rear view mirror indicators. (→P.236)

"Sensitivity"

Select to change the alert timing for an approaching vehicle.

■ Pwi (Toyota parking assistsensor) (if equipped) (→P.243)

Select to set up the following items.

 Toyota parking assist-sensor on/off

Select to enable/disable the Toyota parking assist-sensor.

"Volume"

Select to set the volume of the buzzer which sounds when the Toyota parking assist-sensor is operated.

■ RCTA (Rear Cross Traffic Alert) (if equipped) (→P.235)

 RCTA (Rear Cross Traffic Alert) on/off

Select to enable/disable the RCTA system.

• "Volume"

Select to change the RCTA buzzer volume.

■ PSA (Road Sign Assist) (if equipped) (→P.209)

Select to set up the following items.

Road Sign Assist on/off

Select to enable/disable the RSA system.

"Notification method"

Select to change each notification method used to warn the driver when the system recognizes excess speed, no overtaking and no-entry sign.

"Notification Level"

Select to change each notification level used to warn the driver when the system recognizes a speed limit sign.

■ DRCC (RSA) (if equipped) (→P.219)

Select to enable/disable the Dynamic Radar Cruise Control with Road Sign Assist.

■ ➡ Vehicle Settings

 PBD (Power Back Door) (if equipped) (→P.97)*

Select to set up the following items.

System settings

Select to enable/disable the power back door system.

"Opening Adjustment"

Select the open position when power back door is fully open.

"Volume"

Select to set the volume of the buzzer which sounds when the power back door system operates.

*: Vehicles with power back door

• (A) (Stop & Start) (if equipped) (→P.250)

Select to set the length of time the Stop & Start system will operate when the "A/C" switch of the air conditioning system is on.

■ (∑C) Settings

• "Language"

Select to change the language on the multi-information display.

• "Units"

Select to change the unit of measure for fuel consumption.

- "Meter Type" (7-inch display)
 Select to change the speedometer display.
- ECO (Eco Driving Indicator Light) (if equipped) (→P.73)

Select to activate/deactivate the Eco Driving Indicator Light.

(Driving information display settings)

Select to change the display on Fuel Economy (→P.72).

(Audio settings)

Select to enable/disable \(\bar{\chi} \) screen.

- (Vehicle information display settings)
- "Display Contents"

Select to enable/disable the AWD system display (→P.75). (AWD models)

· "Drive Info Type"

Select to change the drive information type display between trip and total. (→P.74).

· "Drive Info Items"

Select to set the items on the upper and lower side of the drive information screen. from three items, average speed, distance and total time.

• "Pop-Up Display"

Select to enable/disable the following pop-up displays, which may appear in some situations.

- Intersection guidance display of the navigation system-linked system (if equipped)
- · Incoming call display of the handsfree phone system
- Audio operation
- Volume operation
- Voice control
- · Stop & Start system duration (if equipped)
- · Stop & Start system status (if equipped)
- "MID OFF"

A blank screen is displayed

"Default Settings"

Select to reset the meter display settinas.

Suspension of the settings display

- In the following situations, operation of the settings display will be temporarily suspended.
- When a warning message appears on the multi-information display
- When the vehicle begins to move
- Settings for functions not equipped to the vehicle are not displayed.
- When a function is turned off, the related settings for that function are not selectable.

WARNING

Cautions during setting up the display

As the engine needs to be running during setting up the display, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.



NOTICE

During setting up the display

To prevent battery discharge, ensure that the engine is running while setting up the display features.

Warning message display

Select to display warning messages and measures to be taken if a malfunction is detected. $(\rightarrow P.375)$

Suggestion function

Displays suggestions to the driver in the following situations. To select a response to a displayed suggestion, use the meter control switches.

Suggestion to turn on the headlights

If the headlight switch is in other than **I**O or AUTO, and the vehicle speed is 5 km/h (3 mph) or higher for a certain amount of time when the surroundings are dark, a suggestion message will be displayed.

■ Suggestion to turn off the headlights

If the headlights are left on for a certain amount of time after the engine switch has been turned off, a suggestion message will be displayed.

When the headlight switch is in the AUTO position:

The message asking if you wish to turn the headlights off is displayed. To turn the headlights off, select "Yes".

If the driver's door is opened after the engine switch is turned off, this suggestion message will not be displayed.

Suggestion to close the power windows (linked to windshield wiper operation)

If the windshield wipers are operated with a power window open, a suggestion message will be displayed asking if you wish to close the power windows. To close all of the power windows, select "Yes".

Customization


The suggestion function can be turned on/off. (Customizable features: →P.412)

Fuel consumption information*

*: If equipped

The fuel consumption information can be displayed on the audio system screen.

System components



A Audio system screen

Consumption

■ Trip information

- Audio system without navigation function
- 1 Press the "MENU" button.
- 2 Select "Info" on the "Menu" screen.


If the "History" screen is displayed, select "Trip information".

- Audio system with navigation function
- 1 Press the "MENU" button.
- 2 Select "Info" on the "Menu" screen.

3 Select "ECO" on the "Information" screen.

If the "History" screen is displayed, select "Trip information".

The image is an example only, and may vary slightly from actual conditions.



- A Fuel consumption in the past 15 minutes
- B Current fuel consumption
- C Resetting the consumption data
- Average vehicle speed since the engine was started
- E Elapsed time since the engine was started
- F Cruising range (→P.81)

Average fuel consumption for the past 15 minutes is divided by color into past averages and averages attained since the engine switch was last turned to ON. Use the displayed average fuel consumption as a reference.

■ History

- Audio system without navigation function
- 1 Press the "MENU" button.


2 Select "Info" on the "Menu" screen.

If the "Trip Information" screen is displayed, select "History".

- Audio system with navigation function
- 1 Press the "MENU" button.
- 2 Select "Info" on the "Menu" screen.
- 3 Select "ECO" on the "Information" screen.

If the "Trip Information" screen is displayed, select "History".

The image is an example only, and may vary slightly from actual conditions.



- A Best recorded fuel consumption
- **B** Latest fuel consumption
- C Previous fuel consumption record
- Audio system without navigation function:

Displays the daily average fuel consumption. (Instead of the date, "Trip 1" through "Trip 5" will be displayed.)

Audio system with navigation function:

Displays the daily average fuel consumption.

D Updating the latest fuel con-

sumption data

E Resetting the history data

The average fuel consumption history is divided by color into past averages and the average fuel consumption since the last time updated. Use the displayed average fuel consumption as a reference.

■ Updating the history data

Update the average fuel consumption by selecting "Clip" to measure the current fuel consumption again.


■ Resetting the data

The fuel consumption data can be deleted by selecting "Clear".

■ Cruising range

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining.

This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.



Before driving

3


3-1.	Key information	
	Keys84	
3-2.	Opening, closing and locking the doors	
	Side doors88	• • •
	Back door93	
	Smart entry & start system104	
3-3.	Adjusting the seats	
	Front seats108	
	Rear seats109	
	Driving position memory111	
	Head restraints114	
3-4.	Adjusting the steering wheel and mirrors	
	Steering wheel	
	Inside rear view mirror	-
	Outside rear view mirrors .118	
3-5.	Opening, closing the win- dows and moon roof	
	Power windows120	
	Moon roof123	
	Panoramic moon roof125	

Keys

Key types

The following keys are provided with the vehicle


Vehicles without smart entry & start system



A Master keys

Operating the wireless remote control function (→P.86)

- B Key number plate
- Vehicles with smart entry & start system



A Electronic keys

- Operating the smart entry & start system (→P.104)
- Operating the wireless remote control function (→P.86)
- **B** Mechanical keys

C Key number plate

■ When riding in an aircraft

When bringing a key with wireless remote control function onto an aircraft, make sure you do not press any buttons on the key while inside the aircraft cabin. If you are carrying the key in your bag etc., ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the key to emit radio waves that could interfere with the operation of the aircraft.

■ Key battery depletion

- Vehicles without smart entry & start system
- The standard battery life is 1 to 2 years.
- The battery will become depleted even if the wireless key is not used. The following symptoms indicate that the wireless key battery may be depleted. Replace the battery when necessary. (→P.341)
- The wireless remote control does not operate.
- The detection area becomes smaller.
- ▶ Vehicles with smart entry & start system
- The standard battery life is 1 to 2
- If the battery becomes low, an alarm will sound in the cabin when the engine stops.
- To reduce key battery depletion when the electronic key is to not be used for long periods of time, set the electronic key to the battery-saving mode. (→P.105)
- As the electronic key always receives radio waves, the battery will become depleted even if the electronic key is not used. The following symptoms indicate that the electronic key battery may be depleted. Replace the battery when necessary.
- The smart entry & start system or the wireless remote control does not oper-

ate

- The detection area becomes smaller.
- The LED indicator on the key surface does not turn on.

You can replace the battery by yourself (→P.341). However, as there is a danger that the electronic key may be damaged, it is recommended that replacement is carried out by your Toyota dealer.

- To avoid serious deterioration, do not leave the electronic key within 1 m (3 ft.) of the following electrical appliances that produce a magnetic field:
- TVs
- · Personal computers
- Cellular phones, cordless phones and battery chargers
- Table lamps
- · Induction cookers
- If a message regarding the state of the electronic key or engine switch mode, etc. is shown (vehicles with smart entry & start system)

To prevent trapping the electronic key inside the vehicle, leaving the vehicle carrying the electronic key on your person without turning the engine switch to OFF or other passengers from unintentionally taking the key out of the vehicle, etc., a message that prompts the user to confirm the state of the electronic key or engine switch mode may be shown on the multi-information display. In those cases, follow the instructions on the display immediately.

■If "Key Battery Low Replace Key Battery" is displayed on the multiinformation display (vehicles with smart entry & start system)

The electronic key has a low battery. Replace the electronic key battery. (→P.341)

- Replacing the battery
- →P.341
- Confirmation of the registered key number

The number of keys already registered

to the vehicle can be confirmed. Ask your Toyota dealer for details.

■If "A New Key has been Registered Contact Your Dealer for Details" is displayed on the multi-information display (vehicles with smart entry & start system)

This message will be displayed each time the driver's door is opened when the doors are unlocked from the outside for approximately 10 days after a new electronic key has been registered. If this message is displayed but you have not had a new electronic key registered, ask your Toyota dealer to check if an unknown electronic key (other than those in your possession) has been registered.



NOTICE

■ To prevent key damage

- Do not drop the keys, subject them to strong shocks or bend them.
- Do not expose the keys to high temperatures for long periods of time.
- Do not get the keys wet or wash them in an ultrasonic washer, etc.
- Do not attach metallic or magnetic materials to the keys or place the keys close to such materials.
- Do not disassemble the keys.
- Do not attach a sticker or anything else to the surface of the keys.
- Do not place the keys near objects that produce magnetic fields, such as TVs, audio systems and induction cookers.
- Do not place the keys near medical electrical equipment such as lowfrequency therapy equipment or microwave therapy equipment, and do not receive medical attention with the keys on your person.

<u>^</u>

NOTICE

Carrying the electronic key on your person (vehicles with smart entry & start system)


Carry the electronic key 10 cm (3.9 in.) or more away from electric appliances that are turned on. Radio waves emitted from electric appliances within 10 cm (3.9 in.) of the electronic key may interfere with the key, causing the key to not function properly.

- In case of a smart entry & start system malfunction or other keyrelated problems (vehicles with smart entry & start system)
- →P.388
- When an electronic key is lost (vehicles with smart entry & start system)
- →P.388

Wireless remote control


The keys are equipped with the following wireless remote control:

Vehicles without smart entry & start system



- A Locks all the doors (→P.88)
- B Closes the side windows^{*} (→P.88)
- C Unlocks all the doors (→P.88)

- D Opens the side windows*
 (→P.88)
- *: These settings must be customized at your Toyota dealer.
- Vehicles with smart entry & start system



- A Locks all the doors (→P.88)
- B Closes the side windows^{*1} and the moon roof^{*1, 2} or panoramic moon roof^{*1, 2} (→P.88)
- C Unlocks all the doors (→P.88)
- D Opens the side windows^{*1} and the moon roof^{*1, 2} or panoramic moon roof^{*1, 2} (→P.88)
- E Opens and closes the power back door*2 (→P.97)
- *1: These settings must be customized at your Toyota dealer.
- *2: If equipped

■ Conditions affecting operation

► Vehicles without smart entry & start system


The wireless remote control function may not operate normally in the following situations.

When the wireless key battery is

depleted

- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone or other wireless communication device
- When the wireless key is in contact with, or is covered by a metallic object
- When other wireless key (that emits radio waves) is being used nearby
- If window tint with a metallic content or metallic objects are attached to the rear window
- Vehicles with smart entry & start system
- →P.105

Using the master key (vehicles without smart entry & start system)



Releasing

To release the key, press the button.

Folding


To stow the key back in its case, push the key back to the stowed position while pressing the button.

Using the mechanical key (vehicles with smart entry & start system)

To take out the mechanical key, slide the release lever A and take the key out.

The mechanical key can only be inserted in one direction, as the key only has grooves on one side. If the key cannot be inserted in a lock cylinder, turn it over and re-attempt to insert it.

After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery is depleted or the entry function does not operate properly, you will need the mechanical key. (\rightarrow P.388)



■ If you lose your keys

→P.388

■ If a wrong key is used

The key cylinder rotates freely to isolate inside mechanism.


Side doors

The vehicle can be locked and unlocked using the entry function, wireless remote control, key or door lock switch.

Unlocking and locking the doors from the outside

Using the entry function (vehicles with smart entry & start system)

Carry the electronic key to enable this function



1 Grip the front door handle to unlock the doors.

Make sure to touch the sensor on the back of the handle.

The doors cannot be unlocked for 3 seconds after the doors are locked.

Touch the lock sensor (the indentation on the upper part of the door handle) to lock the doors.

Check that the door is securely locked.

■ Using the wireless remote control

Vehicles without smart entry & start system




1 Locks all the doors

Check that the door is securely locked. Press and hold to close the side windows.

2 Unlocks all the doors

Press and hold to open the side windows.*

- *. These settings must be customized at your Toyota dealer.
- Vehicles with smart entry & start system



Locks all the doors

Check that the door is securely locked. Press and hold to close the side windows and moon roof (if equipped) or panoramic moon roof (if equipped).*


2 Unlocks all the doors

Press and hold to open the side windows and moon roof (if equipped) or panoramic moon roof (if equipped).*

*: These settings must be customized at your Toyota dealer.

■ Using the key

Vehicles without smart entry & start system



Locks all the doors

Turn and hold to close the side windows.*

2 Unlocks all the doors

Turn and hold to open the side windows.*

- *: These settings must be customized at your Toyota dealer.
- Vehicles with smart entry & start system

The doors can also be locked and unlocked with the mechanical key. (>P.388)

Switching the door unlock function (vehicles with smart entry & start system)

It is possible to set which doors the entry function unlocks using the wireless remote control.

1 Turn the engine switch to OFF.

When the indicator light on the key surface is not on, press and hold

or for approximately 5 seconds while pressing and hold-

ing 🚹

The setting changes each time an operation is performed, as shown below. (When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat step 2.)

	Multi-information display/Beep	Unlocking function
	Exterior: Beeps 3 times Interior: Pings once	Holding the driver's door handle unlocks only the driver's door.
		Holding the front passenger's door handle or pressing the back door opener switch unlocks all the doors.
	Exterior: Beeps twice Interior: Pings once	Holding either front door handle or pressing the back door opener switch unlocks all the doors.

Impact detection door lock release system

In the event that the vehicle is subject to a strong impact, all the doors are unlocked. Depending on the force of the impact or the type of accident, however, the system may not operate.

Operation signals

Vehicles without smart entry & start system

Doors: The emergency flashers flash to indicate that the doors have been locked/unlocked using the wireless

remote control. (Locked: Once; Unlocked: Twice)

Side windows: A buzzer sounds to indicate that the side windows are operating using the wireless remote control.

► Vehicles with smart entry & start system

Doors: A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked using the entry function or wireless remote control. (Locked: Once; Unlocked: Twice)

Side windows and moon roof (if equipped) or panoramic moon roof (if equipped): A buzzer sounds to indicate that the side windows and moon roof or panoramic moon roof are operating using the wireless remote control.

■ Security feature

Vehicles without smart entry & start system

If a door is not opened within approximately 30 seconds after the vehicle is unlocked using the wireless remote control, the security feature automatically locks the vehicle again.

▶ Vehicles with smart entry & start system


If a door is not opened within approximately 30 seconds after the vehicle is unlocked using the entry function or wireless remote control, the security feature automatically locks the vehicle again. (However, depending on the location of the electronic key, the key may be detected as being in the vehicle. In this case, vehicle may be unlocked.)

■ When the door cannot be locked by the lock sensor on the upper part of the door handle (vehicles with smart entry & start system)

If the door will not lock even when the

topside sensor area is touched, try touching both the topside and underside sensor areas at the same time

When gloves are being worn, remove the gloves.



■ Door lock buzzer (vehicles with smart entry & start system)

If an attempt to lock the doors using the entry function or wireless remote control is made when a door is not fully closed, a buzzer sounds continuously for 5 seconds. Fully close the door to stop the buzzer, and lock the vehicle once more.

- Conditions affecting the operation of the smart entry & start system or wireless remote control
- Vehicles without smart entry & start system
- →P.86
- Vehicles with smart entry & start system
- →P 105
- If the smart entry & start system (if equipped) or the wireless remote control does not operate properly
- Vehicles with smart entry & start system: Use the mechanical key to lock and unlock the doors. (→P.388)
- Replace the key battery with a new one if it is depleted. (→P.341)

■ If the battery is discharged

The doors cannot be locked and unlocked using the smart entry & start system (if equipped) or wireless remote control. Lock or unlock the doors using the key (vehicles without smart entry & start system) or mechanical key (vehicles with smart entry & start system).

(→P.89, 388)

■ Customization

Settings (e.g. unlocking function using a key) can be changed.

(Customizable features: →P.413)



WARNING

■ To prevent an accident

Observe the following precautions while driving the vehicle. Failure to do so may result in a door opening and an occupant could be thrown out of the vehicle, resulting in death or serious injury.

- Ensure that all doors are properly closed and locked.
- Do not pull the inside handle of the doors while driving.
 Be especially careful for the driver's door, as the door may be opened even if the inside lock button is in locked position.
- Set the rear door child-protector locks when children are seated in the rear seats.

■ When opening or closing a door


Check the surroundings of the vehicle such as whether the vehicle is on an incline, whether there is enough space for a door to open and whether a strong wind is blowing. When opening or closing the door, hold the door handle tightly to prepare for any unpredictable movement.

When using the wireless remote control, key or mechanical key and operating the power windows, moon roof (if equipped) or panoramic moon roof (if equipped)

Operate the power window, moon roof or panoramic moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the side window, moon roof or panoramic moon roof. Also, do not allow children to operate the wireless remote control, key or mechanical key. It is possible for children and other passengers to get caught in the side window, moon roof or panoramic moon roof.


Unlocking and locking the doors from the inside

Using the door lock switch



- Locks all the doors
- 2 Unlocks all the doors

■ Using the inside lock buttons



- Locks the door
- 2 Unlocks the door

The driver's door can be opened by pulling the inside handle even if the lock button is in the lock position.

Locking the front doors from the outside without a key

- 1 Move the inside lock button to the lock position.
- 2 Close the door while pulling the door handle.
- Vehicles without smart entry & start system

The door cannot be locked if the key is in the engine switch.

➤ Vehicles with smart entry & start system

The door cannot be locked if the engine switch is in ACC or ON, or the electronic key is left inside the vehicle.

Depending on the position of the electronic key, the key may not be detected correctly and the door may be locked.


Open door warning buzzer

If the vehicle speed reaches 5 km/h (3 mph), the master warning light flashes and a buzzer sounds to indicate that the door(s) or the hood is not fully closed. The open door(s) or hood is displayed on the multi-information display.

- When all the doors are locked with the entry function (vehicles with smart entry & start system), wireless remote control or key
- The doors cannot be unlocked with the door lock switch.
- The door lock switch can be reset by unlocking all the doors with the entry function (vehicles with smart entry & start system), wireless remote control or key.

Rear door child-protector lock

The door cannot be opened from inside the vehicle when the lock is set.



- 1 Unlock
- 2 Lock

These locks can be set to prevent children from opening the rear doors. Push down on each rear door switch to lock both rear doors

Automatic door locking and unlocking systems

The following functions can be set

or canceled.

For instructions on customizing, refer to P 411

Function	Operation
Speed linked door locking function	All doors are automatically locked when vehicle speed is approximately 20 km/h (12mph) or higher.
Shift position linked door lock- ing function (vehi- cles with automatic trans- mission or CVT)	All doors are automatically locked when shifting the shift lever to position other than P.
Shift position linked door unlock- ing function (vehi- cles with automatic trans- mission or CVT)	All doors are automatically unlocked when shifting the shift lever to P.
Driver's door linked door unlock- ing function	All doors are automatically unlocked when driver's door is opened.

Back door

The back door can be locked/unlocked and opened/closed by the following procedures.

WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

■ Before driving

- Make sure that the back door is fully closed. If the back door is not fully closed, it may open unexpectedly while driving and hit near-by objects or luggage in the luggage compartment may be thrown out, causing an accident.
 - Do not allow children to play in the luggage compartment. If a child is accidentally locked in the luggage compartment, they could get heat exhaustion or other injuries.
- Do not allow a child to open or close the back door.
 Doing so may cause the back door to operate unexpectedly, or cause the child's hands, head, or neck to be caught by the closing back door.

Important points while driving

- Keep the back door closed while driving.
 If the back door is left open, it may
 - If the back door is left open, it may hit near-by objects or luggage in the luggage compartment may be thrown out, causing an accident.
- Never let anyone sit in the luggage compartment.
 In the event of sudden braking, sudden swerving or a collision, they are susceptible to death or serious injury.



WARNING

Back door handles

Do not hang any object to the back door handles.


If any object is hung, the back door may suddenly shut, causing parts of the body to be caught, resulting in death or serious injury.

Operating the back door

Observe the following precautions. Failure to do so may cause parts of the body to be caught, resulting in death or serious injury.

- Remove any heavy loads, such as snow and ice, from the back door before opening it. Failure to do so may cause the back door to suddenly shut again after it is opened.
- When opening or closing the back door, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the back door is about to open or close.
- Use caution when opening or closing the back door in windy weather as it may move abruptly in strong wind.

Vehicles without power back door: The back door may suddenly shut if it is not opened fully. It is more difficult to open or close the back door on an incline than on a level surface, so beware of the back door unexpectedly opening or closing by itself. Make sure that the back door is fully open and secure before using the luggage compartment.



- Vehicles with power back door: The back door may suddenly shut if it is not opened fully, while on a steep incline. Make sure that the back door is secured before using the luggage compartment.
- When closing the back door, take extra care to prevent your fingers, etc. from being caught.



• Vehicles without power back door: When closing the back door, make sure to press it lightly on its outer surface. If the back door handle is used to fully close the back door, it may result in hands or arms being caught.

WARNING

Do not pull on the back door damper stay (vehicles without power back door) (→P.97) or back door spindle (vehicles with power back door) (\$\rightarrow\$P.102) to close the back door, and do not hang on the back door damper stay (vehicles without power back door) or back door spindle (vehicles with power back door).


Doing so may cause hands to be caught or the back door damper stay (vehicles without power back door) or back door spindle (vehicles with power back door) to break, causing an accident.

Vehicles without power back door: If a bicycle carrier or similar heavy object is attached to the back door. it may suddenly shut again after being opened, causing someone's hands, head or neck to be caught and injured. When installing an accessory part to the back door, using a genuine Toyota part is recommended

Unlocking and locking the back door from the outside

■ Using the entry function (vehicles with smart entry & start system)

Carry the electronic key to enable this function.



Unlocks all the doors

The doors cannot be unlocked for 3 seconds after the doors are locked

2 Locks all the doors

Check that the door is securely locked.

Using the wireless remote control

→P 88

Operation signals

A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked using the entry function (if equipped) or wireless remote control. (Locked: once; Unlocked: twice)

■ Security feature

➤ Vehicles without smart entry & start system

If a door is not opened within approximately 30 seconds after the vehicle is unlocked using the wireless remote control, the security feature automatically locks the vehicle again.

▶ Vehicles with smart entry & start sys-

If a door is not opened within approximately 30 seconds after the vehicle is unlocked using the entry function or wireless remote control, the security feature automatically locks the vehicle again. (However, depending on the location of the electronic key, the key may be detected as being in the vehicle. In this case, vehicle may be unlocked.)

Unlocking and locking the back door from the inside


Using the door lock switch

→P.91

Opening/closing the back door (vehicles without power back door)

Open


Raise the back door while pressing up the back door opener switch.



■ Close

Lower the back door using the back door handle A, and make sure to push the back door down from the outside to close it


Be careful not to pull the back door sideways when closing the back door with the handle



■ Luggage compartment light

The luggage compartment light turns on when the back door is opened with the luggage compartment light switch on.
When the engine switch is turned to OFF, the light will go off automatically

after 20 minutes.




- 1 On
 - 2 Off

■ If the back door opener is inoperative


The back door can be unlocked from the inside.

Remove the cover.


To prevent damage, cover the tip of the screwdriver with a rag.




2 Loosen the screw.



3 Turn the cover.



4 Move the lever



5 When installing, reverse the steps listed.




NOTICE

■ Back door damper stays

The back door is equipped with damper stays that hold the back door in place.

Observe the following precautions. Failure to do so may cause damage to the back door damper stay, resulting in malfunction.



- Do not attach any foreign objects, such as stickers, plastic sheets, or adhesives to the damper stay rod.
- Do not touch the damper stay rod with gloves or other fabric items.
- Do not attach any accessories other than genuine Toyota parts to the back door.
- Do not place your hand on the damper stay or apply lateral forces to it.

Opening/closing the back door (vehicles with power back door)


■ Using the wireless remote control

Press and hold the switch.

The power back door automatically opens/closes.

Unlock the back door before operating.

Pressing the switch while the power back door is opening/closing stops the operation. When the switch is pressed again during the halted operation, the back door will perform the reverse operation.




Using the power back door switch on the instrument panel

Press and hold the switch.

The power back door automatically opens/closes.

Unlock the back door before operating.

Pressing the switch while the power back door is opening/closing stops the operation. When the switch is pressed again during the halted operation, the back door will perform the reverse operation.




Using the back door opener switch

When the back door is unlocked: Press the back door opener switch.

When the back door is locked: While carrying the electronic key on your person, press the back door opener switch.

The power back door automatically opens.

Pressing the switch while the power back door is opening/closing stops the operation.




Using the power back door switch on the back door

Press the switch.

The power back door automatically closes.


Pressing the switch while the power back door is operating will stop the operation. When the switch is pressed again during the halted operation, the back door will perform the reverse operation.



■ Using the back door handles

Lower the back door using the back door handle A.


The back door closing assist will be activated, and the power back door will fully close automatically.



■ Luggage compartment light

The luggage compartment light turns on when the back door is opened with the luggage compartment light switch on.

When the engine switch is turned to OFF, the light will go off automatically after 20 minutes.



- On
- Off

■ Back door closer

In the event that the back door is left. slightly open, the back door closer will automatically close it to the fully closed position.

Whatever the state of the engine switch, the back door closer operates.

■ Power back door operating conditions

The power back door can automatically open and close under the following conditions:

- When the power back door system is enabled. $(\rightarrow P.75)$
- When the back door is unlocked.

However, if the back door opener switch is pressed while carrying the electronic key on your person, the power back door will be operated even if the back door is locked. (→P.98)

- When the engine switch is in ON, in addition to the above for the opening operations, the back door operates for any of the following conditions: Parking brake is engaged
- The brake pedal is depressed
- The shift lever is in P.


Operation of the power back door

- A buzzer sounds and the emergency flashers flash twice to indicate that the back door is opening/closing.
- When the power back door system is disabled, the power back door does not operate but it can be opened and closed by hand.

When the power back door automatically opens, if an abnormality due to people or objects is detected, operation will stop.

■ Jam protection function

Sensors are equipped on both sides of the power back door. If anything obstructs the power back door while it is closing, the back door will automatically operate in the opposite direction or stop.



■ Fall-down protection function

While the power back door is opening automatically, applying excessive force to it will stop the opening operation to prevent the power back door from suddenly shutting.

Back door closing assist

If the back door is lowered manually when the back door is stopped at an open position, the back door will fully close automatically.

■ Back door reserve lock function (if equipped)

This function is a function which reserves locking of all doors, beforehand, when the power back door is open.

When the following procedure is performed, all the doors except the power back door are locked and then power back door will also be locked at the same time it is closed.

- 1 Close all doors, except the back door.
- 2 During the power back door closing operation, lock the doors using the smart entry & start system from the front doors (→P.88) or the wireless remote control. (→P.88)

A buzzer sounds and the emergency flashers flash to indicate that all the doors have been closed and locked

- If the electronic key is placed inside the vehicle after starting a close operation via the door reserve lock function, the electronic key may become locked inside the vehicle.
- If the power back door does not fully close due to the operation of the jam protection function, etc., while the back door is automatically closing after a door reserve lock operation is performed, the door reserve lock function is canceled and all the doors will unlock
- Before leaving the vehicle, make sure that all the doors are closed and locked.

■ When reconnecting the battery


To enable the power back door to operate properly, close the back door manually.

■ If the back door opener is inoperative


The back door can be unlocked from the inside.

1 Remove the cover.


To prevent damage, cover the tip of the screwdriver with a rag.




2 Loosen the screw.



3 Turn the cover.



4 Move the lever.



5 When installing, reverse the steps listed.

Customization


Settings (e.g. power back door opening angle) can be changed. (Customizable features: →P.415)



WARNING

Back door closer

• In the event that the back door is left slightly open, the back door closer will automatically close it to the fully closed position. It takes several seconds before the back door closer begins to operate. Be careful not to catch fingers or anything else in the back door, as this may cause bone fractures or other serious injuries.



 Use caution when using the back door closer as it still operates when the power back door system is canceled.

Power back door

Observe the following precautions when operating the power back door. Failure to do so may cause death or serious injury.

- Check the safety of the surrounding area to make sure there are no obstacles or anything that could cause any of your belongings to get caught.
- If anyone is in the vicinity, make sure they are safe and let them know that the back door is about to open or close.
- If the power back door system is turned off while the back door is operating automatically, the automatic operation is stopped. The back door then has to be operated manually. Take extra care when on an incline, as the back door may open or close unexpectedly.

- If the operating conditions of the power back door are no longer met, a buzzer may sound and the back door may stop opening or closing. The back door then has to be operated manually. Take extra care when on an incline, as the back door may open or close abruptly.
- On an incline, the back door may suddenly shut after it opens. Make sure the back door is fully open and secure.
- In the following situations, the power back door may detect an abnormality and automatic operation may be stopped. In this case, the back door has to be operated manually. Take extra care when on an incline, as the back door may open or close abruptly.
- When the back door contacts an obstacle
- When the battery voltage suddenly drops, such as when the engine switch is turned to ON or the engine is started during automatic operation
- If a bicycle carrier or similar heavy object is attached to the back door, it may suddenly shut again after being opened, causing someone's hands, head or neck to be caught and injured. When installing an accessory part to the back door, using a genuine Toyota part is recommended.

Jam protection function

Observe the following precautions. Failure to do so may cause death or serious injury.

 Never use any part of your body to intentionally activate the jam protection function.

A

WARNING


- The jam protection function may not work if something gets caught just before the back door fully closes.
 Be careful not to catch fingers or anything else.
- The jam protection function may not work depending on the shape of the object that is caught. Be careful not to catch fingers or anything else.



NOTICE

■ Back door spindles

The back door is equipped with spindles that hold the back door in place. Observe the following precautions. Failure to do so may cause damage to the back door spindle, resulting in malfunction.



- Do not attach any foreign objects, such as stickers, plastic sheets, or adhesives to the spindle rod.
- Do not touch the spindle rod with gloves or other fabric items.
- Do not attach heavy accessories to the back door. When attaching, ask your Toyota dealer for details.
- Do not place your hand on the spindle or apply lateral forces to it.

■ To prevent back door closer malfunction

Do not apply excessive force to the back door while the back door closer is operating. Applying excessive force may cause the back door closer to malfunction.

- To prevent damage to the power back door
- Make sure that there is no ice between the back door and frame that would prevent movement of the back door. Operating the power back door when excessive load is present on the back door may cause a malfunction.
- Do not apply excessive force to the back door while the power back door is operating.
- Take care not to damage the sensors (installed on the right and left edges of the power back door) with a knife or other sharp object. If the sensor is disconnected, the power back door will not close automatically.

Changing settings of the power back door system (vehicles with power back door)

The settings of the power back door system can be changed by displaying the "Vehicle Settings" - "PBD" screen from the screen of the multi-information display. (→P.75)

The changed power back door settings are not reset by turning the engine switch to OFF. In order to restore the original settings, they need to be

changed back on the screen of the multi-information display.


Adjusting the open position of the back door (vehicles with power back door)

The open position of the power back door can be adjusted.

- 1 Stop the back door in the desirable position. (→P.97)
- 2 Press and hold the power back door switch on the back door for approximately 2 seconds.

When the settings are completed, the buzzer sounds 4 times.


When opening the back door the next time, the back door will stop at that position.



Canceling the adjusted open position of the back door

Press and hold the power back door switch on the back door for approximately 7 seconds.

After the buzzer sounds 4 times, it sounds twice more. When the power back door does the opening operation the next time, the door will open to the initial settings position.



■ Customization

The opening position can be set with the multi-information display. (→P.75)

Priority for the stop position is given to the last position set by either the power back door switch on the back door or multi-information display.


Smart entry & start system*

: If equipped

The following operations can be performed simply by carrying the electronic key on your person, for example in your pocket. The driver should always carry the electronic key.


- Locks and unlocks the side doors (→P.88)
- Locks and unlocks the back door (→P.95)
- Starts the engine (→P.149)

Antenna location



- Antennas outside the cabin
- **B** Antenna outside the luggage compartment
- C Antennas inside the cabin

■ Effective range (areas within which the electronic key is detected)



A When locking or unlocking the doors

The system can be operated when the electronic key is within about 0.7 m (2.3 ft.) of either of the outside front door handles and back door opener switch. (Only the doors detecting the key can be operated.)

B When starting the engine or changing engine switch modes

The system can be operated when the electronic key is inside the vehicle.

If an alarm sounds or a warning message is displayed

An alarm sounds and warning message displays shown on the multi-information display are used to protect against unexpected accidents or theft of the vehicle resulting from erroneous operation. When a warning message is displayed, take appropriate measures based on the displayed message.

When only an alarm sounds, circumstances and correction procedures are as follows

 When an exterior alarm sounds once for 5 seconds

Situation	Correction proce- dure
An attempt was made to lock the vehicle while a door was open.	Close all of the doors and lock the doors again.

When an interior alarm pings continuously

-	
Situation	Correction proce- dure
The engine switch was turned to ACC while the driver's door was open (or the driver's door was opened while the engine switch was in ACC).	Turn the engine switch to OFF and close the driver's door.

■ Battery-saving function

The battery-saving function will be activated in order to prevent the electronic key battery and the battery from being discharged while the vehicle is not in operation for a long time.

- In the following situations, the smart entry & start system may take some time to unlock the doors.
- The electronic key has been left in an area of approximately 2 m (6 ft.) of the outside of the vehicle for 10 minutes or longer.
- The smart entry & start system has not been used for 5 days or longer.
- If the smart entry & start system has not been used for 14 days or longer, the doors cannot be unlocked at any doors except the driver's door. In this case, take hold of the driver's door handle, or use the wireless remote control or the mechanical key, to unlock the doors.

Turning an electronic key to battery-saying mode

When battery-saving mode is set, battery depletion is minimized by stopping the electronic key from receiving radio waves.

Press



twice while pressing and

holding



Confirm that the electronic key indicator flashes 4 times.

While the battery-saving mode is set, the smart entry & start system cannot be used. To cancel the function, press any of the electronic key buttons.



 Electronic keys that will not be used for long periods of time can be set to the battery-saving mode in advance.

■ Conditions affecting operation

The smart entry & start system uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart entry & start system, wireless remote control and engine immobilizer system from operating properly.

(Ways of coping: →P.388)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When the electronic key is in contact with, or is covered by the following metallic objects
- Cards to which aluminum foil is attached
- Cigarette boxes that have aluminum foil inside
- Metallic wallets or bags
- Coins
- Hand warmers made of metal.
- · Media such as CDs and DVDs
- When other wireless key (that emits radio waves) is being used nearby
- When carrying the electronic key together with the following devices

that emit radio waves

- Portable radio, cellular phone, cordless phone or other wireless communication devices
- Another vehicle's electronic key or a wireless key that emits radio waves
- Personal computers or personal digital assistants (PDAs)
- Digital audio plavers
- · Portable game systems
- If window tint with a metallic content or metallic objects are attached to the rear window
- When the electronic key is placed near a battery charger or electronic devices
- When parking in a coin-operated parking lot (Radio waves used to detect vehicles may affect the smart entry & start system.)

■ Note for the entry function

- Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases:
- The electronic key is too close to the window or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
- The electronic key is on the instrument panel, luggage cover or floor, or in the door pockets or glove box when the engine is started or engine switch modes are changed.
- Do not leave the electronic key on top of the instrument panel or near the door pockets when exiting the vehicle. Depending on the radio wave reception conditions, it may be detected by the antenna outside the cabin and the door will become lockable from the outside, possibly trapping the electronic key inside the vehicle.
- As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone. However, only the doors detecting the electronic key can be used to unlock the vehicle.

- Even if the electronic key is not inside the vehicle, it may be possible to start the engine if the electronic key is near the window.
- The doors may unlock if a large amount of water splashes on the door handle, such as in the rain or in a car wash when the electronic key is within the effective range. (The doors will automatically be locked after approximately 30 seconds if the doors are not opened and closed.)
- If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)
- Touching the door lock sensor while wearing gloves may delay or prevent lock operation. Remove the gloves and touch the lock sensor again.
- When the lock operation is performed using the lock sensor, recognition signals will be shown up to two consecutive times. After this, no recognition signals will be given.
- If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In that case, follow the following correction procedures to wash the vehicle:
- Place the electronic key in a location 2 m (6 ft.) or more away from the vehicle. (Take care to ensure that the key is not stolen.)
- Set the electronic key to battery-saving mode to disable the smart entry & start system. (→P.105)
- If the electronic key is inside the vehicle and a door handle becomes wet during a car wash, a message may be shown on the multi-information display and a buzzer will sound outside the vehicle. To turn off the alarm, lock all the doors.
- The lock sensor may not work properly if it comes into contact with ice,

snow, mud, etc. Clean the lock sensor and attempt to operate it again, or use the lock sensor on the lower part of the door handle

- A sudden approach to the effective range or door handle may prevent the doors from being unlocked. In this case, return the door handle to the original position and check that the doors unlock before pulling the door handle again.
- If there is another electronic key in the detection area, it may take slightly longer to unlock the doors after the door handle is gripped.

■ When the vehicle is not driven for extended periods

- To prevent theft of the vehicle, do not leave the electronic key within 2 m (6 ft.) of the vehicle.
- The smart entry & start system can be deactivated in advance. (→P.414)
- Battery-saving mode can reduce the power consumption of electronic keys. (→P.105)

■ To operate the system properly

Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off accidentally, or the door lock prevention may not operate.)

If the smart entry & start system does not operate properly

- Locking and unlocking the doors: Use the mechanical key. (→P.388)
- Starting the engine: →P.389

Customization

Settings (e.g. smart entry & start system) can be changed.
(Customizable features: →P.413)

If the smart entry & start system has

been deactivated in a customized setting, refer to the explanations for the following operations.

- Locking and unlocking the doors: Use the wireless remote control or mechanical key. (→P.88, 388)
- Starting the engine and changing engine switch modes: →P.389
- Stopping the engine: →P.151

♠ w

WARNING

Caution regarding interference with electronic devices

- People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should maintain a reasonable distance between themselves and the smart entry & start system antennas. (→P.104)
 - The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask your Toyota dealer for details, such as the frequency of radio waves and timing of the emitted radio waves. Then, consult your doctor to see if you should disable the entry function.
- Users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves. Radio waves could have unexpected effects on the operation of such medical devices.


Ask your Toyota dealer for details on disabling the entry function.

Front seats

The seats can be adjusted (longitudinally, vertically, etc.).
Adjust the seat to ensure the correct driving posture.

Adjustment procedure

▶ Manual seat



- Seat position adjustment lever
- 2 Seatback angle adjustment lever
- 3 Vertical height adjustment lever (driver's side only)

Power seat (driver's side only)



- 1 Seat position adjustment switch
- 2 Seatback angle adjustment switch
- 3 Seat cushion (front) angle adjustment switch
- 4 Vertical height adjustment switch
- 5 Lumbar support adjustment switch

■ When adjusting the seat

Take care when adjusting the seat so that the head restraint does not touch the ceiling.



WARNING

■When adjusting the seat position

- Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- Do not put your hands under the seat or near the moving parts to avoid injury.

Fingers or hands may become jammed in the seat mechanism.



WARNING

Manual seat only: After adjusting the seat, make sure that the seat is locked in position.

Seat adjustment

To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary. If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.


Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.

Rear seats

Reclining adjustments and folding the seatbacks can be done with lever operation.

Adjustment procedure

Pull the seatback angle adjustment lever A , and adjust the seatback angle.



WARNING

When operating the seatback

Observe the following precautions. Failure to do so may cause death or serious iniurv.

- Keep other passengers from being hit with the seatback.
- Do not bring your hands close to the moving parts or between the seats, as well as do not let any part of your body get caught.

A

WARNING

 After adjusting the seat, make sure that the seat is locked in position.
 If the seatback is not securely locked, the red marking will be visible. Make sure that the red marking is not visible



Folding down the rear seatbacks

- Before folding down the seatbacks
- 1 Park the vehicle in a safe place.

Apply the parking brake (→P.164) and shift the shift lever to P (automatic transmission or CVT) or N (manual transmission).(→P.154, 158, 160)

2 Adjust the position of the front seat and the angle of the seatback. (→P.108)

Depending on the position of the front seat, if the seatback is folded backward, it may interfere with the operation of the rear seat.


- 3 Lower the head restraint of the rear seat. (→P.114)
- 4 Stow the armrest of the rear seat if it is pulled out. (→P.309)

This step is not necessary when operating the left side seat only.

■ Folding down the seatbacks


While pulling the seatback angle

adjustment lever A, fold the seat-back down.



■ Returning the rear seatbacks

To avoid trapping the seat belt between the seat and the inside of the vehicle, pass the seat belt inside the seat belt guide A and then return the seatback securely to the locked position.



A

WARNING


Observe the following precautions. Failure to do so may result in death or serious injury.

- When folding the rear seatbacks down
- Do not fold the seatbacks down while driving.

WARNING

- Stop the vehicle on level ground, set the parking brake and shift the shift lever to P (automatic transmission or CVT) or N (manual transmission).
- Do not allow anyone to sit on a folded seatback or in the luggage compartment while driving.
- Do not allow children to enter the luggage compartment.
- Do not operate the rear seat if it is occupied.
- Be careful not to get feet or hands caught in the moving parts or joints of the seats during operation.
- Do not allow children to operate the seat
- After returning the rear seatback to the upright position
- Make sure that the seatback is securely locked in position by lightly pushing it back and forth.

If the seatback is not securely locked. the red marking will be visible. Make sure that the red marking is not visible.



Check that the seat belts are not twisted or caught in the seatback.

Driving position memorv

: If equipped

This feature automatically adjusts the driver's seat to suit vour preferences.


Your preferred driving position (the position of the driver's seat) can be recorded and recalled by pressing a button.

Two different driving positions can be recorded into memory. Each electronic key can be registered to recall your preferred driving position.

Recording/recalling a driving position


- Recording procedure
- Check that the shift lever is in P.
- 2 Turn the engine switch to ON.
- 3 Adjust the driver's seat to the desired positions.
- 4 While pressing the "SET" button, press button "1" or "2" until the buzzer sounds.

If the selected button has already been preset, the previously recorded position will be overwritten



■ Recall procedure

- 1 Check that the shift lever is in P.
- 2 Turn the engine switch to ON.
- 3 Press one of the buttons for the driving position you want to recall until the buzzer sounds.



■ To stop the position recall operation part-way through

Perform any of the following:

- Press the "SET" button.
- Press button "1" or "2".
- Operate any of the seat adjustment switches.

Seat positions that can be memorized (→P.108)

The adjusted positions other than the position adjusted by lumbar support switch can be recorded.

Operating the driving position memory after turning the engine switch to OFF

Recorded seat positions can be activated up to 180 seconds after the driver's door is opened and another 60 seconds after it is closed again.

In order to correctly use the driving position memory function

If a seat position is already in the furthest possible position and the seat is operated in the same direction, the recorded position may be slightly different when it is recalled.

■ When recalling the driving position

Take care when recalling the driving position so that the head restraint does not touch the ceiling.

■ If the battery is disconnected

The memorized positions are erased.

WARNING

Seat adjustment caution

Take care during seat adjustment so that the seat does not strike the rear passenger or squeeze your body against the steering wheel.

Registering/recall/canceling an electronic key to driving position (memory recall function)

■ Registering procedure

Record your driving position to button "1" or "2" before performing the following:


Carry only the key you want to register, and then close the driver's door.

If 2 or more keys are in the vehicle, the driving position cannot be

recorded properly.

- 1 Check that the shift lever is in P
- 2 Turn the engine switch to ON.
- 3 Recall the driving position that you want to record.
- 4 While pressing the recalled button, press and hold the door lock switch (either lock or unlock) until the buzzer sounds.

If the button could not be registered, the buzzer sounds continuously for approximately 3 seconds.



■ Recall procedure

Make sure that the doors are locked before recalling the driving position. Carry the electronic key that has been registered to the driving position, and then unlock and open the driver's door using the smart entry & start system or wireless remote control.

The driving position will move to the recorded position.

If the driving position is in a position that has already been recorded, the seat will not move.

■ Cancelation procedure

Carry only the key you want to cancel and then close the driver's door. If 2 or more keys are in the vehicle, the driving position cannot be canceled properly.

- Check that the shift lever is in P.
- 2 Turn the engine switch to ON.
- While pressing the "SET" button, press and hold the door lock switch (either lock or unlock) until the buzzer sounds twice

If the button could not be canceled, the buzzer sounds continuously for approximately 3 seconds.

Recalling the driving position using the memory recall function

- Different driving positions can be registered for each electronic key. Therefore, the driving position that is recalled may be different depending on the key being carried.
- If a door other than the driver's door is unlocked with the smart entry & start system, the driving position cannot be recalled. In this case, press the driving position button which has been set.

Customization

Settings (e.g. the unlock door settings of the memory recall function) can be customized. (Customizable features: →P.416)

Head restraints

Head restraints are provided for all seats.



WARNING


Head restraint precautions

Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- After adjusting the head restraints, push down on them and make sure they are locked in position.
- Do not drive with the head restraints removed

Vertical adjustment

■ Front seats




Up

Pull the head restraints up.

2 Down

Push the head restraint down while pressing the lock release button **A** .

■ Rear seats



1 Up


Pull the head restraints up.

2 Down

Push the head restraint down while pressing the lock release button A.

Adjusting the height of the head restraints (front seats)

Make sure that the head restraints are adjusted so that the center of the head restraint is closest to the top of your ears.



Adjusting the rear seat head restraint


Always raise the head restraint one level from the stowed position when using.

Removing the head restraints

Pull the head restraint up while pressing the lock release button



If the head restraint touches the ceiling, making the removal difficult, change the seat height or angle. (→P.108)




Installing the head restraints

Align the head restraint with the installation holes and push it down to the lock position.

Press and hold the lock release


button A when lowering the head restraint.



Steering wheel


Adjustment procedure

1 Hold the steering wheel and push the lever down.



Adjust to the ideal position by moving the steering wheel horizontally and vertically.

After adjustment, pull the lever up to secure the steering wheel.



WARNING

Caution while driving

Do not adjust the steering wheel while driving.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.


After adjusting the steering wheel

Make sure that the steering wheel is securely locked.

Otherwise, the steering wheel may move suddenly, possibly causing an accident, and resulting in death or serious injury. Also, the horn may not sound if the steering wheel is not securely locked.

Sounding the horn

To sound the horn, press on or close to the mark.




Inside rear view mirror

The rear view mirror's position can be adjusted to enable sufficient confirmation of the rear view

Adjusting the height of rear view mirror

The height of the rear view mirror can be adjusted to suit your driving posture.

Adjust the height of the rear view mirror by moving it up and down.



A

WARNING

Caution while driving


Do not adjust the position of the mirror while driving.

Doing so may lead to mishandling of the vehicle and cause an accident, resulting in death or serious injury.

Anti-glare function

Manual anti-glare inside rear view mirror

Reflected light from the headlights of vehicles behind can be reduced by operating the lever.




- Normal position
- 2 Anti-glare position
- Auto anti-glare inside rear view mirror

Responding to the level of brightness of the headlights of vehicles behind, the reflected light is automatically reduced.

Changing automatic anti-glare function mode on/off


When the automatic anti-glare function is in ON mode, the indicator A illuminates.

The function will set to ON mode each time the engine switch is turned to ON. Pressing the button turns the function to OFF mode. (The indicator A also turns off.)



■ To prevent sensor error (vehicles with auto anti-glare inside rear view mirror)

To ensure that the sensors operate properly, do not touch or cover them.



Outside rear view mirrors

The rear view mirror's position can be adjusted to enable sufficient confirmation of the rear view.

■ Defogging the mirrors

The outside rear view mirrors can be cleared using the mirror defoggers. Turn on the rear window defogger to turn on the outside rear view mirror defoggers. (→P.281, 287)



WARNING

Important points while driving

Observe the following precautions while driving.

Failing to do so may result in loss of control of the vehicle and cause an accident, resulting in death or serious injury.


- Do not adjust the mirrors while driving.
- Do not drive with the mirrors folded.
- Both the driver and passenger side mirrors must be extended and properly adjusted before driving.

When the mirror defoggers are operating


Do not touch the rear view mirror surfaces, as they can become very hot and burn you.

Adjustment procedure

1 To select a mirror to adjust, press the switch.



- A Left
- **B** Right
- 2 To adjust the mirror, press the switch.




- A Up
- **B** Right
- C Down
- D Left
- Mirror angle can be adjusted when

The engine switch is in ACC or ON.


Folding the mirrors

Manual type

Push the mirror back in the direction of the vehicle's rear.



▶ Power type



- 1 Folds the mirrors
- 2 Extends the mirrors



WARNING

■When a mirror is moving


To avoid personal injury and mirror malfunction, be careful not to get your hand caught by the moving mirror.

Power windows

Opening and closing the power windows

The power windows can be opened and closed using the switches.

Operating the switch moves the side windows as follows:



- 1 Closing
- 2 One-touch closing*
- 3 Opening
- 4 One-touch opening

*: To stop the side window partway, operate the switch in the opposite direction.

■ The power windows can be operated when

The engine switch is in ON.

Operating the power windows after turning the engine off

The power windows can be operated for approximately 45 seconds even after the engine switch is turned to ACC or OFF. They cannot, however, be operated once either front door is opened.

■ Jam protection function

If an object becomes jammed between the side window and the window frame while the side window is closing, side window movement is stopped and the side window is opened slightly.

■ Catch protection function

If an object becomes caught between the door and side window while the side window is opening, side window movement is stopped.

When the power window cannot be opened or closed

When the jam protection function or catch protection function operates unusually and the side window cannot be opened and closed, perform the following operations with the power window switch of that door.

- Stop the vehicle. With the engine switch in ON, within 4 seconds of the jam protection function or catch protection function activating, continuously operate the power window switch in the one-touch closing direction or one-touch opening direction so that the side window can be opened and closed.
- If the side window cannot be opened and closed even when performing the above operations, perform the following procedure for function initialization.
- **1** Turn the engine switch to ON.
- Pull and hold the power window switch in the one-touch closing direction and completely close the side window.
- 3 Release the power window switch for a moment, resume pulling the switch in the one-touch closing direction, and hold it there for approximately 6 seconds or more.
- 4 Press and hold the power window switch in the one-touch opening direction. After the side window is completely opened, continue holding the switch for an additional 1 second or more.
- 5 Release the power window switch for a moment, resume pushing the switch in the one-touch opening

- direction, and hold it there for approximately 4 seconds or more.
- 6 Pull and hold the power window switch in the one-touch closing direction again. After the side window is completely closed, continue holding the switch for a further 1 second or more

If you release the switch while the side window is moving, start again from the beginning.

If the side window reverses and cannot be fully closed or opened, have the vehicle inspected by your Toyota dealer.

■ Door lock linked power window operation

- The power windows can be opened and closed using the key (vehicles without smart entry & start system) or mechanical key (vehicles with smart entry & start system).* (→P.89, 389)
- The power windows can be opened and closed using the wireless remote control.* (→P.88)
- *: These settings must be customized at your Toyota dealer.

■ Power window open reminder function

➤ Vehicles without smart entry & start system

The buzzer sounds and a message is shown on the multi-information display when the key has been removed from the engine switch and the driver's door is opened with the power windows open.

Vehicles with smart entry & start system

The buzzer sounds and a message is shown on the multi-information display when the engine switch is turned to OFF and the driver's door is opened with the power windows open.

Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable fea-

tures: \rightarrow P.416)

A

WARNING

Observe the following precautions. Failing to do so may result in death or serious injury.

Closing the power windows

- The driver is responsible for all the power window operations, including the operation for the passengers. In order to prevent accidental operation, especially by a child, do not let a child operate the power windows. It is possible for children and other passengers to have body parts caught in the power window. Also, when riding with a child, it is recommended to use the window lock switch. (→P.122)
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a power window is being operated.



When using the wireless remote control, key or mechanical key and operating the power windows, operate the power window after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the side window. Also, do not let a child operate the power window by the wireless remote control, key or mechanical key. It is possible for children and other passengers to get caught in the power window.

A

WARNING

• When exiting the vehicle, turn the engine switch to OFF, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

■ Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets jammed just before the side window is fully closed. Be careful not to get any part of your body jammed in the side window.

Catch protection function

- Never use any part of your body or clothing to intentionally activate the catch protection function.
- The catch protection function may not work if something gets caught just before the side window is fully opened. Be careful not to get any part of your body or clothing caught in the side window.


Preventing accidental operation (window lock switch)

This function can be used to prevent children from accidentally opening or closing a passenger window.

Press the switch.

The indicator **A** will come on and the passenger windows will be locked.

The passenger windows can still be opened and closed using the driver's switch even if the lock switch is on.



The window lock switch can be operated when

The engine switch is in ON.

■ When the battery is disconnected

The window lock switch is disabled. If necessary, press the window lock switch after reconnecting the battery.


Moon roof*

: If equipped

Use the overhead switches to open and close the moon roof and tilt it up and down.

Operating the moon roof

Opening and closing




Opens the moon roof*

The moon roof stops slightly before the fully open position to reduce wind noise.

Press the switch again to fully open the moon roof.

- 2 Closes the moon roof
- *: Lightly press either side of the moon roof switch to stop the moon roof partway.

■ Tilting up and down



- 1 Tilts the moon roof up*
- 2 Tilts the moon roof down*
- *: Lightly press either side of the moon roof switch to stop the moon roof partway.

■ The moon roof can be operated when

The engine switch is in ON.

Operating the moon roof after turning the engine off

The moon roof can be operated for approximately 45 seconds after the engine switch is turned to ACC or OFF. It cannot, however, be operated once either front door is opened.

■ Jam protection function

If an object is detected between the moon roof and the frame while the moon roof is closing or tilting down, travel is stopped and the moon roof opens slightly.

■ Sunshade

The sunshade can be opened and closed manually. However, the sunshade will open automatically when the moon roof is opened.

■ Door lock linked moon roof operation

- The moon roof can be opened and closed using the mechanical key.* (→P.389)
- The moon roof can be opened and closed using the wireless remote control.^{*} (→P.88)
- *: These settings must be customized at your Toyota dealer.

When the moon roof does not close normally

Perform the following procedure:

- Stop the vehicle.
- **2** Press and hold the "CLOSE" switch.* The moon roof will close, reopen and

pause for approximately 10 seconds. Then it will close again and stop at the completely closed position.

- 3 Check to make sure that the moon roof is completely closed and then release the switch.
- *: If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by your Toyota dealer.

■ If the moon roof does not move normally

If the moon roof does not open or close normally or the automatic opening function does not operate, perform the following initialization procedure.

- 1 Stop the vehicle.
- 2 Press and hold the "DOWN" switch *

The moon roof will stop at the tilt-up position. After that, it will open, close, tilt up, tilt down, and stop at the fully closed position.

- 3 Confirm that the moon roof has completely stopped and release the switch.
- *: If you release the switch while the moon roof is moving, perform the procedure again from the beginning.

If, after performing the above procedures correctly, the moon roof still does not open or close normally or the automatic opening function does not operate, have the vehicle inspected by your Toyota dealer.

Moon roof open reminder function

The buzzer sounds and a message is shown on the multi-information display when the engine switch is turned to OFF and the driver's door is opened with the moon roof open.

■ Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable features: →P.416)

A

WARNING


Observe the following precautions. Failure to do so may cause death or serious injury.

Opening the moon roof

- Do not allow any passengers to put their hands or head outside the vehicle while it is moving.
- Do not sit on top of the moon roof.

Opening and closing the moon roof

- The driver is responsible for moon roof opening and closing operations.
- In order to prevent accidental operation, especially by a child, do not let a child operate the moon roof. It is possible for children and other passengers to have body parts caught in the moon roof.
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when the moon roof is being operated.



WARNING

- When using the wireless remote control or mechanical key and operating the moon roof, operate the moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the moon roof. Also, do not let a child operate moon roof by the wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the moon roof.
- When exiting the vehicle, turn the engine switch to OFF, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

Jam protection function

- Never use any part of your body to intentionally activate the iam protection function.
- The jam protection function may not work if something gets caught just before the moon roof is fully closed. Also, the iam protection function is not designed to operate while the switch is being pressed. Take care so that your fingers, etc. do not get caught.


Panoramic moon roof

*: If equipped

Use the overhead switches to operate the panoramic moon roof and electronic sunshade.

Operating the electronic sunshade and panoramic moon roof

Opening and closing the electronic sunshade



Opens the electronic sunshade*

Slide and hold the switch backward. The electronic sunshade will fully open automatically.

Closes the electronic sunshade*

Slide and hold the switch forward. The electronic sunshade will fully close automatically.

If the panoramic moon roof is not fully closed, it will close fully before the electronic sunshade closes.

*: Quickly slide and release the switch in either direction to stop the electronic sunshade partway.

■ Tilting the panoramic moon roof up and down


Press the switch to tilt the panoramic moon roof up.*

When the panoramic moon roof is tilted up, the electronic sunshade will open to the half-open position of the roof.

*: Lightly press the switch again to stop the panoramic moon roof partway.

Press and hold the switch to tilt the panoramic moon roof down.

The panoramic moon roof can be tilted down only when it is in the tilt-up position.



Opening and closing the panoramic moon roof


Opens the panoramic moon roof*

Slide and hold the 🕏 switch back-

ward. The panoramic moon roof and electronic sunshade will open automatically.


The panoramic moon roof can be opened from the tilt-up position.

*: Quickly slide and release the switch in either direction to stop the panoramic moon roof partway.



Closes the panoramic moon roof

Slide and hold the switch forward. The panoramic moon roof will fully close automatically.



■ The panoramic moon roof can be operated when

The engine switch is in ON.

Operating the panoramic moon roof after turning the engine off

The panoramic moon roof and electronic sunshade can be operated for approximately 45 seconds after the engine switch is turned to ACC or OFF. They cannot, however, be operated once either front door is opened.

■ Jam protection function

If an object is detected between the panoramic moon roof and the frame in the following situations, travel is stopped and the panoramic moon roof opens slightly.

- The panoramic moon roof is closing or tilting down.
- The electronic sunshade is closing.
- Closing both the panoramic moon roof and electronic sunshade

Slide the switch forward.

The electronic sunshade will close to the half-open position and pause. The panoramic moon roof will then fully close. Then the electronic sunshade will fully close.

■ Door lock linked panoramic moon roof operation

- The panoramic moon roof can be opened and closed using the mechanical key.* (→P.389)
- The panoramic moon roof can be opened and closed using the wireless remote control.* (→P.88)
- *: These settings must be customized at your Toyota dealer.
- When the panoramic moon roof or electronic sunshade does not close normally

Perform the following procedure:

- 1 Stop the vehicle.
- 2 Turn the engine switch to ON.
- 3 Slide and hold the switch or
 - ing and holding the switch for approximately 10 seconds after the panoramic moon roof or electronic sunshade closes and reopens. The panoramic moon roof and electronic sunshade will start to close.*

switch forward. Continue slid-

- 4 Check that the panoramic moon roof and electronic sunshade are fully closed and release the switch.
- *: If the switch is released at the incor-

rect time, the procedure will have to be performed again from the beginning.

If the panoramic moon roof or electronic sunshade does not fully close even after performing the above procedure correctly, have the vehicle inspected by your Toyota dealer.

■ Panoramic moon roof open reminder function

A buzzer sounds and a message is shown on the multi-information display when the engine switch is turned to OFF and the driver's door is opened with the panoramic moon roof open.

■ Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable features: →P.416)

WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

Opening and closing the electronic sunshade

 Check to make sure that all passengers do not have any part of their body in a position where it could be caught when the electronic sunshade is being operated.



Do not let a child operate the electronic sunshade. Closing the electronic sunshade on someone can cause death or serious injury.

A

WARNING

Opening the panoramic moon roof

- Do not allow any passengers to put their hands or head outside the vehicle while it is moving.
- Do not sit on top of the panoramic moon roof.

Opening and closing the panoramic moon roof

- The driver is responsible for panoramic moon roof opening and closing operations.
 In order to prevent accidental operation, especially by a child, do not let a child operate the panoramic moon roof. It is possible for children and other passengers to have body parts caught in the panoramic moon roof.
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when the panoramic moon roof is being operated.



- When using the wireless remote control or mechanical key and operating the panoramic moon roof, operate the panoramic moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the panoramic moon roof. Also, do not let a child operate panoramic moon roof by the wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the panoramic moon roof.
- When exiting the vehicle, turn the engine switch to OFF, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

■ Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the panoramic moon roof or electronic sunshade is fully closed. Also, the jam protection function is not designed to operate while the switch is being pressed. Take care so that your fingers, etc. do not get caught.

■ To prevent burns or injuries

Do not touch the area between the underside of the panoramic moon roof and the electronic sunshade. Your hand may get caught and you could injure yourself. Also, if the vehicle is left in direct sunlight for a long time, the underside of the panoramic moon roof could become very hot and could cause burns.



NOTICE

- To prevent damage to the panoramic moon roof
- Before opening the panoramic moon roof, make sure that there are no foreign objects, such as stones or ice, around the opening.
- Do not hit the surface or edge of the panoramic moon roof with hard objects.
- After the vehicle has been washed or rained on

Before opening the panoramic moon roof, wipe any water off the panoramic moon roof. Otherwise, water may enter the cabin when the panoramic moon roof is opened.



Driving

4

4-1.	Before driving	4-5.	Using the driving support
	Driving the vehicle132		systems
	Cargo and luggage139		Toyota Safety Sense180
	Trailer towing (except for Australia and New Zealand) .141		PCS (Pre-Collision System)
	Trailer towing (for Australia and		LTA (Lane Tracing Assist) .192
	New Zealand)141		LDA (Lane Departure Alert with
4-2.	Driving procedures		steering control)201
	Engine (ignition) switch (vehi-		RSA (Road Sign Assist)209
	cles without smart entry & start system)148		Dynamic radar cruise control with full-speed range211
	Engine (ignition) switch (vehi-		Dynamic radar cruise control
	cles with smart entry & start		222
	system)149		Cruise control232
	Automatic transmission153		BSM (Blind Spot Monitor) .235
	CVT (Continuously Variable Transaxle)57		Toyota parking assist-sensor
	Manual transmission160		Stop & Start system250
	Turn signal lever163		Driving mode select switch
	Parking brake164		257
	Brake Hold167		Multi-terrain Select (AWD vehi-
4-3.	Operating the lights and wip-		cles)259
	ers		Snow mode switch262
	Headlight switch169		Downhill assist control system
	Automatic High Beam171		263
2	Fog light switch174		Driving assist systems265
	Windshield wipers and washer	4-6.	Driving tips
	174		Winter driving tips272
	Rear window wiper and washer176		Utility vehicle precautions .275
4-4.	Refueling		

Opening the fuel tank cap. 178

Driving the vehicle

The following procedures should be observed to ensure safe driving:

Driving procedure

■ Starting the engine

→P.148, 149

Driving

- Automatic transmission or CVT
- With the brake pedal depressed, shift the shift lever to D. (→P.153, 157)
- 2 Release the parking brake. (→P.164)

If the parking brake is in automatic mode, the parking brake is released automatically when shifting the shift lever to any position other than P. $(\rightarrow P.164)$

- 3 Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.
- ► Manual transmission
- While depressing the clutch pedal, shift the shift lever to 1.
 (→P.160)
- 2 Release the parking brake. (→P.164)
- 3 Gradually release the clutch pedal. At the same time, depress the accelerator pedal to accelerate the vehicle.

■ Stopping

- Automatic transmission or CVT
- 1 With the shift lever in D, depress the brake pedal.
- 2 If necessary, set the parking brake. (→P.164)

If the vehicle is to be stopped for an extended period of time, shift the shift lever to P. (→P.153, 157)

- ▶ Manual transmission
- 1 While depressing the clutch pedal, depress the brake pedal.
- 2 If necessary, set the parking brake. (→P.164)

If the vehicle is to be stopped for an extended period of time, shift the shift lever to N. $(\rightarrow P.160)$

Parking the vehicle

- Automatic transmission or CVT
- With the shift lever in D, depress the brake pedal.
- 2 Set the parking brake (→P.164), and shift the shift lever to P (→P.153, 157).
- **3** Turn the engine switch to OFF to stop the engine.
- 4 Lock the door, making sure that you have the key on your person.

If parking on a hill, block the wheels as needed.

- Manual transmission
- While depressing the clutch pedal, depress the brake pedal.
- 2 Shift the shift lever to N. (→P.160)

- 3 Set the parking brake. (→P.164) If parking on a hill, shift the shift lever to 1 or R as needed.
- **4** Turn the engine switch to OFF to stop the engine.
- 5 Lock the door, making sure that you have the key on your person.

If parking on a hill, block the wheels as needed

■ Starting off on a steep uphill

- Automatic transmission or CVT
- With the brake pedal depressed, shift the shift lever to D. (→P.153, 157)
- Pull the parking brake switch and parking brake is set manually. (→P.164)
- 3 Release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.
- 4 Press the parking brake switch and parking brake is released manually. (→P.164)
- Manual transmission
- With the brake pedal and the clutch pedal fully depressed, shift the shift lever to 1.
 (→P.160)
- Pull the parking brake switch to set the parking brake manually.
 (→P.164)
- 3 Lightly depress the accelerator pedal at the same time as gradually releasing the clutch pedal.

4 Press the parking brake switch and parking brake is released manually. (→P.164)

■ When starting off on a uphill

The hill-start assist control will activate. $(\rightarrow P.266)$

■ Driving in the rain

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road could be slippery.
- Drive carefully when it starts to rain, as the road surface could be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

Engine speed while driving (except manual transmission)

In the following conditions, the engine speed may become high while driving. This is due to automatic up-shifting control or down-shifting implementation to meet driving conditions. It does not indicate sudden acceleration.

- The vehicle is judged to be driving uphill or downhill
- When the accelerator pedal is released
- When the brake pedal is depressed while sport mode is selected

Restraining the engine output (Brake Override System)

- When the accelerator and brake pedals are depressed at the same time, the engine output may be restrained.
- A warning message is displayed on the multi-information display while the system is operating.

Restraining sudden start (Drive-Start Control) (vehicles with automatic transmission or CVT)

- When the following unusual operation is performed, the engine output may be restrained
- When the shift lever is shifted from R to D, D to R, N to R, P to D, or P to R (D includes S [vehicles with automatic transmission] or M [vehicles with CVT]) with the accelerator pedal depressed, a warning message appears on the multi-information display. If a warning message is shown on the multi-information display, read the message and follow the instructions
- When the accelerator pedal is depressed too much while the vehicle is in reverse.
- While Drive-Start Control is being activated, your vehicle may have trouble escaping from the mud or fresh snow. In such case, deactivate TRC (→P.267) to cancel Drive-Start Control so that the vehicle may be able to escape from the mud or fresh snow.
- Drive-Start Control does not work when Mud & Sand or Rock & Dirt mode is selected for Multi-terrain Select (AWD models).

■ Breaking in your new Toyota

To extend the life of the vehicle, observing the following precautions is recommended:

- For the first 300 km (200 miles): Avoid sudden stops.
- For the first 800 km (500 miles): Do not tow a trailer.
- For the first 1000 km (600 miles):
- Do not drive at extremely high speeds.
- Avoid sudden acceleration.
- Do not drive continuously in low gears.
- Do not drive at a constant speed for extended periods.

Operating your vehicle in a foreign country

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel. (\rightarrow P.402)

A

WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

When starting the vehicle

On vehicles with automatic transmission or CVT, always keep your foot on the brake pedal while stopped with the engine running. This prevents the vehicle from creeping.

When driving the vehicle

- Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
- Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident.
- When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
- Make sure to keep a correct driving posture even when moving the vehicle only slightly. This allows you to depress the brake and accelerator pedals properly.
- Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- Do not drive the vehicle over or stop the vehicle near flammable materials such as leaves, paper or rags.

The exhaust system and exhaust gases can be extremely hot. These hot parts may cause a fire if there is any flammable material nearby.

WARNING

- During normal driving, do not turn off the engine. Turning the engine off while driving will not cause loss of steering or braking control, but the power assist to these systems. will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so However, in the event of an emergency, such as if it becomes impossible to stop the vehicle in the normal way: →P.358
- Use engine braking (downshift) to maintain a safe speed when driving down a steep hill. Using the brakes continuously may cause the brakes to overheat and lose effectiveness. (→P.153, 157, 160)
- Do not adjust the position of the steering wheel, the seat, or the inside or outside rear view mirrors while driving. Doing so may result in a loss of vehicle control.
- Always check that all passengers' arms, head or other parts of their body are not outside the vehicle.
- Do not drive the vehicle off-road. This is not an AWD vehicle designed for off-road driving. Proceed with all due caution if it becomes unavoidable to drive offroad.
- Do not drive across river crossings or through other bodies of water. This may cause electric/electronic components to short circuit, damage the engine or cause other serious damage to the vehicle.

When driving on slippery road surfaces

- Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle
- Sudden acceleration, engine braking due to shifting, or changes in engine speed could cause the vehicle to skid.
- After driving through a puddle. lightly depress the brake pedal to make sure that the brakes are functioning properly. Wet brake pads may prevent the brakes from functioning properly. If the brakes on only one side are wet and not functioning properly, steering control may be affected.

When shifting the shift lever

- On vehicles with automatic transmission or CVT, do not let the vehicle roll backward while the shift lever is in a driving position, or roll forward while the shift lever is in R. Doing so may cause the engine to stall or lead to poor brake and steering performance, resulting in an accident or damage to the vehi-
- On vehicles with automatic transmission or CVT. do not shift the shift lever to P while the vehicle is mov-
 - Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to R while the vehicle is moving forward. Doing so can damage the transmission and may result in a loss of vehicle control.

A

WARNING

- Do not shift the shift lever to a driving position while the vehicle is moving backward.
 Doing so can damage the transmission and may result in a loss of vehicle control.
- Moving the shift lever to N while the vehicle is moving will disengage the engine from the transmission.
 Engine braking is not available when N is selected.
- On vehicles with automatic transmission or CVT, be careful not to shift the shift lever with the accelerator pedal depressed.
 Shifting the shift lever to a gear other than P or N may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury. Doing so can damage the transmission and may result in a loss of vehicle control
- If you hear a squealing or scraping noise (brake pad wear indicators)

Have the brake pads checked and replaced by your Toyota dealer as soon as possible.

Rotor damage may result if the pads are not replaced when needed. It is dangerous to drive the vehicle when the wear limits of the brake pads and/or those of the brake discs are exceeded.

■ When the vehicle is stopped

Do not race the engine.

If the vehicle is in any gear other than P (vehicles with automatic transmission or CVT only) or N, the vehicle may accelerate suddenly and unexpectedly, causing an accident.

- In order to prevent accidents due to the vehicle rolling away, always keep depressing the brake pedal while the engine is running, and apply the parking brake as necessary.
- If the vehicle is stopped on an incline, in order to prevent accidents caused by the vehicle rolling forward or backward, always depress the brake pedal and securely apply the parking brake as needed
- Avoid revving or racing the engine. Running the engine at high speed while the vehicle is stopped may cause the exhaust system to overheat, which could result in a fire if combustible material is nearby.

When the vehicle is parked

- Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun.
- Doing so may result in the following:
- Gas may leak from a cigarette lighter or spray can, and may lead to a fire.
- The temperature inside the vehicle may cause the plastic lenses and plastic material of glasses to deform or crack.
- Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
- Do not leave cigarette lighters in the vehicle. If a cigarette lighter is in a place such as the glove box or on the floor, it may be lit accidentally when luggage is loaded or the seat is adjusted, causing a fire.



WARNING

- Do not attach adhesive discs to the windshield or windows. Do not place containers such as air fresheners on the instrument panel or dashboard. Adhesive discs or containers may act as lenses, causing a fire in the vehicle
- Do not leave a door or window open if the curved glass is coated with a metallized film such as a silver-colored one. Reflected sunlight may cause the glass to act as a lens, causing a fire.
- Always apply the parking brake, shift the shift lever to P (vehicles with automatic transmission or CVT only), stop the engine and lock the vehicle

Do not leave the vehicle unattended while the engine is running. If the vehicle is parked with the shift lever in P (vehicles with automatic transmission or CVT only) but the parking brake is not set, the vehicle may start to move, possibly leading to an accident.

- Do not touch the exhaust pipes while the engine is running or immediately after turning the engine off
 - Doing so may cause burns.

When taking a nap in the vehicle Always turn the engine off. Otherwise, if you accidentally move the shift lever or depress the accelerator pedal, this could cause an accident or fire due to engine overheating, Additionally, if the vehicle is parked in a poorly ventilated area, exhaust gases may collect and enter the vehicle, leading to death or a serious health hazard

When braking

- When the brakes are wet, drive more cautiously. Braking distance increases when the brakes are wet, and this may cause one side of the vehicle to brake differently than the other side. Also, the parking brake may not securely hold the vehicle.
- If the brake booster device does not operate, do not follow other vehicles closely and avoid hills or sharp turns that require braking. In this case, braking is still possible. but the brake pedal should be depressed more firmly than usual. Also, the braking distance will increase. Have your brakes fixed immediately.
- Do not pump the brake pedal if the engine stalls.
 - Each push on the brake pedal uses up the reserve for the powerassisted brakes.
- The brake system consists of 2 individual hydraulic systems: if one of the systems fails, the other will still operate. In this case, the brake pedal should be depressed more firmly than usual and the braking distance will increase. Have your brakes fixed immediately.

If the vehicle becomes stuck (AWD models)

Do not spin the wheels excessively when any of the tires is up in the air. or the vehicle is stuck in sand, mud. etc. This may damage the driveline components or propel the vehicle forward or backward, causing an accident.

<u>^</u>

NOTICE

- When driving the vehicle (vehicles with automatic transmission or CVT)
- Do not depress the accelerator and brake pedals at the same time during driving, as this may restrain the engine output.
- Do not use the accelerator pedal or depress the accelerator and brake pedals at the same time to hold the vehicle on a hill.
- When driving the vehicle (vehicles with manual transmission)
- Do not depress the accelerator and brake pedals at the same time during driving, as this may restrain the engine output.
- Do not shift gears unless the clutch pedal is fully depressed. After shifting, do not release the clutch pedal abruptly. Doing so may damage the clutch, transmission and gears.
- Observe the following to prevent the clutch from being damaged.
- Do not rest your foot on the clutch pedal while driving.
 Doing so may cause clutch trouble.
- Do not use any gears other than the 1st gear when starting off and moving forward.
 - Doing so may damage the clutch.
- Do not use the clutch to hold the vehicle when stopping on an uphill grade.
 - Doing so may damage the clutch.
- Do not shift the shift lever to R without the vehicle completely stopped. Doing so may damage the clutch, transmission and gears.

Avoiding damage to vehicle parts

- Do not turn the steering wheel fully in either direction and hold it there for an extended period of time.
 Doing so may damage the power steering motor.
- When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

If you get a flat tire while driving

A flat or damaged tire may cause the following situations.

- It may be difficult to control your vehicle.
- The vehicle will make abnormal sounds or vibrations.
- The vehicle will lean abnormally. Hold the steering wheel firmly and gradually depress the brake pedal to slow down the vehicle. Information on what to do in case of a flat tire (→P.378)

When encountering flooded roads

Do not drive on a road that has flooded after heavy rain, etc. Doing so may cause the following serious damage to the vehicle:

- Engine stalling
- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have your Toyota dealer check the following:

- Brake function
- Changes in quantity and quality of oil and fluid used for the engine, transaxle, transfer (AWD vehicles), rear differential (AWD vehicles), etc.



NOTICE

- Lubricant condition for the propeller shaft (AWD models), bearings and suspension joints (where possible), and the function of all joints, bearings, etc.
- When parking the vehicle (vehicles with automatic transmission or CVT)

Always set the parking brake, and shift the shift lever to P. Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if the accelerator pedal is accidentally depressed.

Cargo and luggage

Take notice of the following information about storage precautions, cargo capacity and load.



WARNING

■ Things that must not be carried in the luggage compartment

The following things may cause a fire if loaded in the luggage compartment:

- Receptacles containing gasoline
- Aerosol cans
- Storage precautions

Observe the following precautions. Failure to do so may prevent the pedals from being depressed properly, may block the driver's vision, or may result in items hitting the driver or passengers, possibly causing an accident.

- Stow cargo and luggage in the luggage compartment whenever possible.
- Do not stack anything in the luggage compartment higher than the seathacks
- When you fold down the rear seats, long items should not be placed directly behind the front seats.
- Never allow anyone to ride in the luggage compartment. It is not designed for passengers. They should ride in their seats with their seat belts properly fastened. Otherwise, they are much more likely to suffer death or serious bodily injury, in the event of sudden braking, sudden swerving or an accident.



WARNING

- Do not place cargo or luggage in or on the following locations.
- · At the feet of the driver
- On the front passenger or rear seats (when stacking items)
- · On the luggage cover
- On the instrument panel
- On the dashboard
- Secure all items in the occupant compartment.
- Load and distribution
- Do not overload your vehicle.
- Do not apply loads unevenly.
 Improper loading may cause deterioration of steering or braking control which may cause death or serious injury.
- When loading cargo on the roof luggage carrier (if equipped)

Observe the following precautions:

- Place the cargo so that its weight is distributed evenly between the front and rear axles
- If loading long or wide cargo, never exceed the vehicle overall length or width. (→P.400)
- Before driving, make sure the cargo is securely fastened on the roof luggage carrier.
- Loading cargo on the roof luggage carrier will make the center of gravity of the vehicle higher. Avoid high speeds, sudden starts, sharp turns, sudden braking or abrupt maneuvers, otherwise it may result in loss of control or vehicle rollover due to failure to operate this vehicle correctly and result in death or serious injury.

- If driving for a long distance, on rough roads, or at high speeds, stop the vehicle now and then during the trip to make sure the cargo remains in its place.
- Do not exceed 80 kg (176.4 lb.) cargo weight on the roof luggage carrier



NOTICE

When loading cargo on the roof luggage carrier (if equipped)

Be careful not to scratch the surface of the moon roof (if equipped) or the panoramic moon roof (if equipped).

Trailer towing (except for Australia and New Zealand)

Toyota does not recommend towing a trailer with your vehicle. Toyota also does not recommend the installation of a tow hitch or the use of a tow hitch carrier for a wheelchair, scooter, bicycle, etc. Your vehicle is not designed for trailer towing or for the use of tow hitch mounted carriers.



Trailer towing (for Australia and New Zealand)

Your vehicle is designed primarily as a passenger carrying vehicle. Towing a trailer will have an adverse effect on handling, performance, braking, durability, and fuel consumption. For your safety and the safety of others, do not overload the vehicle or trailer.

Toyota warranties do not apply to damage or malfunction caused by towing a trailer for commercial purposes.

For towing purposes, when the total trailer weight is greater than the vehicle weight, we recommended use of a sway control device.

■ Before towing

Check that the following conditions are met:

- The vehicle's tires are properly inflated. (→P.407)
- Trailer tires are inflated according to the trailer manufacturer's recommendation.
- All trailer lights work.
- All lights work each time you connect them.
- The trailer ball is set up at the proper height for the coupler on the trailer.
- The trailer is level when it is hitched. Do not drive if the trailer is not level, and check for improper tongue weight, overloading, worn suspension, or other possible causes.
- The trailer cargo is securely loaded.

The rear view mirrors conform to all applicable federal, state/provincial or local regulations. If they do not, install rear view mirrors appropriate for towing purposes.

A

WARNING

■ To avoid accident or injury

- The total trailer weight (trailer weight plus the weight of cargo) must not exceed the following:
- ► M20A-FKS engine: 800 kg (1764 lb.)
- ► A25A-FKS engine: 1500 kg (3307 lb.)
- The gross combined weight (sum of your vehicle weight plus its load and the total trailer weight) must not exceed the following:
- ► M20A-FKS engine

Vehicles with CVT: 2925 kg (6449 lb.) Vehicles with manual transmission: 2820 kg (6217 lb.)

- ► A25A-FKS engine 3715 kg (8190 lb.)
- Do not exceed the trailer hitch assembly weight, gross vehicle weight, gross axle weight and trailer tongue load capacities.
- Never load more weight in the back than in the front of the trailer. About 60% of the load should be in the front half of the trailer, and the remaining 40% in the rear.
- Vehicles with compact spare tire:
 Do not tow a trailer when the compact spare tire is installed on your vehicle.

When towing a trailer

 If the total trailer weight exceeds 750 kg (1653 lb.), trailer brakes are required.

- Never tap into your vehicle's hydraulic system, as this will lower the vehicle's braking effectiveness.
- Never tow a trailer without using a safety chain securely attached to both the trailer and the vehicle. If damage occurs to the coupling unit or hitch ball, there is a risk of the trailer wandering into another lane.



NOTICE

Brakes

Toyota recommends trailers with brakes that conform to all applicable federal and state/provincial regulations.

Weight limits

Confirm that the total trailer weight, gross vehicle weight, gross axle weight and trailer tongue load are all within the limits.

Gross vehicle weight

The gross vehicle weight must not exceed the following:

▶ M20A-FKS engine

Vehicles with CVT: 2125 kg (4685 lb.)

Vehicles with manual transmission: 2020 kg (4453 lb.)

A25A-FKS engine

2215 kg (4883 lb.)

The gross vehicle weight is the sum weight of the unloaded vehicle, driver, passengers, luggage, hitch and trailer tongue load. Also included is the weight of any spe-

cial equipment installed on your vehicle

Gross axle weight

The load on either the front or rear axle resulting from distribution of the gross vehicle weight on both axles must not exceed the following:

▶ 2WD models

Front: 1150 kg (2535 lb.) Rear: 1150 kg (2535 lb.)

AWD models

Front: 1220 kg (2690 lb.) Rear: 1220 kg (2690 lb.)

Trailer tongue load


The trailer cargo load should be distributed so that the tongue load is 9 to 11% of the total trailer weight, not exceed the following:

▶ 2WD models: 80 kg (176 lb.)

► AWD models: 150 kg (331 lb.)

(Tongue load/Total trailer weight \times 100 = 9 to 11%)

The total trailer weight and tongue load can be measured with platform scales found at a highway weighing stations, building supply companies, trucking companies, junk yards, etc.



- A Total trailer weight
- **B** Tongue load

Towing a trailer

Contact your Toyota dealer for further information about additional requirements such as a towing kits etc.

Hitch

Trailer hitch assemblies have different weight capacities established by the hitch manufacturer. Even though the vehicle may be rated for towing a higher weight, the operator must never exceed the maximum weight rating specified for the trailer hitch.



WARNING

- Hitches
- Use only a hitch that conforms to the total trailer weight requirement.
- Follow the directions supplied by the hitch manufacturer.



WARNING

- Depending on the type of trailer coupler you use, the trailer ball may need to be coated with grease. If so, apply grease to the trailer ball in accordance with the instructions of the manufacturer of the trailer coupler.
- Remove the hitch ball whenever you are not towing a trailer. Remove the trailer hitch if you do not need it. After removing the hitch, seal any mounting holes in the vehicle body to prevent entry of any substances into the vehicle.

A


NOTICE

When installing a trailer hitch

- Use only the position recommended by your Toyota dealer. Do not install the trailer hitch on the bumper; this may cause body damage.
- Do not use axle-mounted hitches, as they can cause damage to the axle housing, wheel bearings, wheels or tires.

Selecting a trailer ball

Use the correct trailer ball for your application.



A Trailer ball load rating

Matches or exceeds the gross trailer weight rating of the trailer.

B Shank length

Protrudes beyond the bottom of the lock washer and nut at least 2 threads.

C Shank diameter

Matches the ball mount hole diameter size

D Ball diameter

Matches the size of the trailer coupler. Most couplers are stamped with the required trailer ball size.

Connecting trailer lights

Please consult your dealer when installing trailer lights, as incorrect installation may cause damage to the vehicle's lights. Please take care to comply with your state's laws when installing trailer lights.



NOTICE

Do not directly splice trailer lights

Directly splicing trailer lights may damage your vehicle's electrical system and cause a malfunction.

Trailer towing tips

Your vehicle will handle differently when towing a trailer. In order to avoid accident, death or serious injury, keep the following in mind when towing:

 Before starting out, check the trailer lights and the vehicletrailer connections. Recheck

- after driving a short distance.
- Practice turning, stopping and reversing with the trailer attached in an area away from traffic until you become accustomed to the feel of the vehicle.
- Reversing with a trailer attached is difficult and requires practice. Grip the bottom of the steering wheel and move your hand to the left to move the trailer to the left. Move your hand to the right to move the trailer to right. (This is generally opposite to reversing without a trailer attached.) Avoid sharp or prolonged turning. Have someone guide you when reversing to reduce the risk of an accident
- As stopping distance is increased when towing a trailer, vehicle-to-vehicle distance should be increased. For each 10 km/h (6 mph) of speed, allow at least one vehicle and trailer length.
- Avoid sudden braking as you may skid, resulting in jackknifing and loss of control. This is especially true on wet or slippery surfaces.
- Avoid jerky starts or sudden acceleration.
- Avoid jerky steering and sharp turns, and slow down before making turns.
- Note that when making a turn,

- the trailer wheels will be closer than the vehicle wheels to the inside of the turn. Compensate by making a larger than normal turning radius.
- Crosswinds and rough roads will adversely affect handling of your vehicle and trailer, causing sway. Periodically check the rear to prepare for being passed by large trucks or buses, which may cause your vehicle and trailer to sway. If swaying occurs, firmly grip the steering wheel, reduce speed immediately but gradually, and steer straight ahead. Never increase speed. If you make no extreme correction with the steering or brakes, your vehicle and trailer will stabilize.
- ◆ Take care when passing other vehicles. Passing requires considerable distance. After passing a vehicle, do not forget the length of your trailer, and be sure you have plenty of room before changing lanes.
- Vehicles with automatic transmission: To maintain engine braking efficiency and charging system performance, when using engine braking, do not use the transmission in D. If in the S mode, the transmission shift range position must be in 6 or lower. (→P.153)
- Vehicles with CVT:
 To maintain engine braking effi-

- ciency, and charging system performance, when using engine braking, do not use the transmission in D. (→P.157)
- Vehicles with manual transmission:
 To maintain engine braking efficiency and charging system performance, when using engine
 - braking, do not use the transmission in 5th gear or above. $(\rightarrow P.160)$
- Due to the added load of the trailer, your vehicle's engine may overheat on hot days (at temperatures over 30°C [85°F]) when driving up a long or steep grade. If the engine coolant temperature gauge indicates overheating, immediately turn off the air conditioning (if in use), pull your vehicle off the road and stop

in a safe spot. (\rightarrow P.395)

- Always place wheel blocks under both the vehicle and the trailer wheels when parking. Apply the parking brake firmly, and put the transmission in P (automatic transmission or CVT) or in the 1st gear or R gear (manual transmission). Avoid parking on a slope, but if unavoidable, do so only after performing the following:
- Apply the brakes and keep them applied.

- 2 Have someone place wheel blocks under both the vehicle and trailer wheels.
- When the wheel blocks are in place, release the brakes slowly until the blocks absorb the load.
- 4 Apply the parking brake firmly
- 5 Shift into the 1st gear or R gear (manual transmission) or P (automatic transmission or CVT) and turn off the engine.
- When restarting after parking on a slope:
- 1 With the transmission in the P position (automatic transmission or CVT) or the clutch pedal (manual transmission) depressed, start the engine. On vehicles with automatic transmission or CVT, be sure to keep the brake pedal depressed.
- 2 Shift into forward gear or R gear position (if reversing).
- 3 If the parking brake is in manual mode, release the parking brake. (→P.164)
- 4 Release the brake pedal (vehicles with automatic transmission or CVT), and slowly pull or back away from the wheel blocks.
 Stop and apply the brakes.
- 5 Have someone retrieve the blocks.

■ Break-in schedule

Toyota recommends that you do not use a new vehicle or a vehicle with any new

power train components (engine, transmission, differential, wheel bearings, etc.) to tow a trailer for the first 800 km (500 miles) of driving.

■ Maintenance

- If you tow a trailer, your vehicle will require more frequent maintenance due to the additional load. (See "Warranty and Service Booklet".)
- Retighten the fixing bolts of the towing ball and bracket after approximately 1000 km (600 miles) of trailer towing.

■ If trailer swav occurs

One or more factors (crosswinds, passing vehicles, rough roads, etc.) can adversely affect handling of your vehicle and trailer, causing instability.

- If trailer swaving occurs:
- Firmly grip the steering wheel. Steer straight ahead.
 - Do not try to control trailer swaying by turning the steering wheel.
- Begin releasing the accelerator pedal immediately but very gradually to reduce speed.

Do not increase speed. Do not apply vehicle brakes.

If you make no extreme correction with the steering or brakes, your vehicle and trailer should stabilize (if enabled, Trailer Sway Control can also help to stabilize the vehicle and trailer.).

- After the trailer swaying has stopped:
- Stop in a safe place. Get all occupants out of the vehicle.
- Check the tires of the vehicle and the trailer.
- Check the load in the trailer.
 Make sure the load has not shifted.
 Make sure the tongue weight is appropriate, if possible.
- Check the load in the vehicle.
 Make sure the vehicle is not overloaded after occupants get in.

If you cannot find any problems, the speed at which trailer swaying occurred is beyond the limit of your particular vehicle-trailer combination. Drive at a lower speed to prevent instability. Remember that swaying of the towing

vehicle-trailer increases as speed increases

A

WARNING

To avoid an accident

- Observe the legal maximum speeds for trailer towing.
- Slow down and downshift before descending steep or long downhill grades. Do not make sudden downshifts while descending steep or long downhill grades.
- Avoid holding the brake pedal down too long or applying the brakes too frequently. This could cause the brakes to overheat and result in reduced braking efficiency.
- Do not use cruise control or dynamic radar cruise control (if equipped) when trailer towing.

Engine (ignition) switch (vehicles without smart entry & start system)

Starting the engine

Pull the parking brake switch to check that the parking brake is set. (→P.164)

The parking brake indicator will come on.


- 2 Check that the shift lever is set in P (automatic transmission or CVT) or N (manual transmission).
- Firmly depress the brake pedal (automatic transmission or CVT) or clutch pedal (manual transmission).
- **4** Turn the engine switch to START to start the engine.

■ If the engine does not start

The engine immobilizer system may not have been deactivated. (→P.54) Contact your Toyofa dealer.

■ When the steering lock cannot be released

When starting the engine, the engine switch may seem stuck in OFF. To free it, turn the key while turning the steering wheel slightly left and right.



A V

WARNING

■When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances.

Doing so may cause an accident resulting in death or serious injury.




NOTICE

When starting the engine

- Do not crank the engine for more than 30 seconds at a time. This may overheat the starter and wiring system.
- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have your vehicle checked by your Toyota dealer immediately.

Changing the engine switch positions



A OFF ("LOCK" position)

The steering wheel is locked and the key can be removed. (Vehicles with automatic transmission or CVT: The key can be removed only when the shift lever is in P.)

B ACC ("ACC" position)

Some electrical components such as

the audio system can be used.

C ON ("ON" position)


All electrical components can be used.

D START ("START" position)

For starting the engine.

■ Turning the key from ACC to OFF

- Shift the shift lever to P (automatic transmission or CVT) or N (manual transmission).
- 2 Push in the key and turn it to OFF.



■ Key reminder function

A buzzer sounds if the driver's door is opened while the engine switch is in OFF or ACC to remind you to remove the key.



WARNING

■ Caution when driving

Do not turn the engine switch to OFF while driving. If, in an emergency and you must turn the engine off while the vehicle is moving, turn the engine switch only to ACC to stop the engine. An accident may result if the engine is stopped while driving. (→P.358)



NOTICE

To prevent battery discharge

Do not leave the engine switch in ACC or ON for long periods of time without the engine running.

Engine (ignition) switch (vehicles with smart entry & start system)

Performing the following operations when carrying the electronic key on your person starts the engine or changes engine switch modes.

Starting the engine

1 Pull the parking brake switch to check that the parking brake is set. (→P.164)

The parking brake indicator will come

- Check that the shift lever is set in P (automatic transmission or CVT) or N (manual transmission).
- 3 Firmly depress the brake pedal (automatic transmission or CVT) or clutch pedal (manual transmission).



and a message will be dis-

played on the multi-information display. If it is not displayed, the engine cannot be started.

4 Press the engine switch shortly and firmly.


When operating the engine switch, one short, firm press is enough. It is not necessary to press and hold the switch.

The engine will crank until it starts or for up to 30 seconds, whichever is less.

Continue depressing the brake pedal (automatic transmission or CVT) or clutch pedal (manual transmission) until

the engine is completely started.

The engine can be started from any engine switch mode.



■ If the engine does not start

- The engine immobilizer system may not have been deactivated. (→P.54) Contact your Toyota dealer.
- If a message related to start-up is shown on the multi-information display, read the message and follow the instructions.

■ If the battery is discharged

The engine cannot be started using the smart entry & start system. Refer to P.391 to restart the engine.

■ Electronic key battery depletion

→P.84

■ Conditions affecting operation

→P 105


■ Note for the entry function

→P.106

■ Steering lock function

- After turning the engine switch to OFF and opening and closing the doors, the steering wheel will be locked due to the steering lock function. Operating the engine switch again automatically cancels the steering lock.
- When the steering lock cannot be released, "Push Engine Switch while Turning Steering Wheel in Either Direction" will be displayed on the multi-information display. Press the engine switch shortly and

firmly while turning the steering wheel left and right.



To prevent the steering lock motor from overheating, operation of the motor may be suspended if the engine is turned on and off repeatedly in a short period of time. In this case, refrain from running the engine. After about 10 seconds, the steering lock motor will resume functioning.

If there is a malfunction in the smart entry & start system

If "Smart Entry & Start System Malfunction" is displayed on the multi-information display, the system may be malfunctioning. Have the vehicle inspected by your Toyota dealer immediately.

■ Electronic key battery

→P.341

Operation of the engine switch

- If the switch is not pressed shortly and firmly, the engine switch mode may not change or the engine may not start.
- If attempting to restart the engine immediately after turning the engine switch to OFF, the engine may not start in some cases. After turning the engine switch to OFF, please wait a few seconds before restarting the engine.

■ Customization

If the smart entry & start system has been deactivated in a customized setting, refer to P.389.



WARNING

When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances. Doing so may cause an accident resulting in death or serious injury.

Caution while driving

If engine failure occurs while the vehicle is moving, do not lock or open the doors until the vehicle reaches a safe and complete stop. Activation of the steering lock in this circumstance may lead to an accident, resulting in death or serious injury.



NOTICE

When starting the engine

- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have your vehicle checked by your Toyota dealer immediately.
- Symptoms indicating a malfunction with the engine switch

If the engine switch seems to be operating somewhat differently than usual. such as the switch sticking slightly. there may be a malfunction. Contact your Toyota dealer immediately.

Stopping the engine

- Stop the vehicle completely.
- If the parking brake is in manual mode, set the parking brake. $(\to P.164)$

Check the parking brake indicator is illuminated.

- 3 Shift the shift lever to P (automatic transmission or CVT) or N (manual transmission).
- 4 Press the engine switch shortly and firmly.

The engine will stop, and the meter display will be extinguished.

5 Release the brake pedal and check that "ACCESSORY" or "IGNITION ON" is not shown on the multi-information display.




WARNING

- Stopping the engine in an emeraencv
- If you want to stop the engine in an emergency while driving the vehicle, press and hold the engine switch for more than 2 seconds, or press it briefly 3 times or more in succession. (→P.358) However, do not touch the engine switch while driving except in an emergency. Turning the engine off while driving will not cause loss of
- steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so. If the engine switch is operated
- while the vehicle is running, a warning message will be shown on the multi-information display and a buzzer sounds.
- When restarting the engine after an emergency shutdown, press the engine switch shortly and firmly.

Changing engine switch modes

Modes can be changed by pressing

the engine switch with brake pedal (automatic transmission or CVT) or clutch pedal (manual transmission) released. (The mode changes each time the switch is pressed.)



1 OFF

The emergency flashers can be used.

The multi-information display will not be displayed.

2 ACC

Some electrical components such as the audio system can be used. "ACCESSORY" will be displayed on the multi-information display.

3 ON

All electrical components can be used. "IGNITION ON" will be displayed on the multi-information display.

vehicles with automatic transmission or CVT: If the shift lever is in a position other than P when turning off the engine, the engine switch will be turned to ACC. not to OFF.

■ Auto power off function

► Vehicles with automatic transmission or CVT

If the vehicle is left in ACC for more than 20 minutes or ON (the engine is not running) for more than an hour with the shift lever in P, the engine switch will automatically turn to OFF. However, this function cannot entirely prevent battery discharge. Do not leave the vehicle with the engine switch in ACC or ON for long periods of time when the engine is not running.

▶ Vehicles with manual transmission If the vehicle is left in ACC for more than 20 minutes or ON (the engine is not running) for more than an hour, the engine switch will automatically turn to OFF. However, this function cannot entirely prevent battery discharge. Do not leave the vehicle with the engine switch in ACC or ON for long periods of time when the engine is not running.

Λ

NOTICE

■To prevent battery discharge

- Do not leave the engine switch in ACC or ON for long periods of time without the engine running.
- If "ACCESSORY" or "IGNITION ON" is displayed on the multi-information display, the engine switch is not in OFF. Exit the vehicle after turning the engine switch to OFF.

When stopping the engine with the shift lever in a position other than P (vehicles with automatic transmission or CVT only)

If the engine is stopped with the

shift lever in a position other than P, the engine switch will not be turned to OFF but instead be turned to ACC. Perform the following procedure to turn the switch to OFF:

- Check that the parking brake is set.
- 2 Shift the shift lever to P
- 3 Check that "ACCESSORY" is displayed on the multi-information display and press the engine switch shortly and firmly.
- 4 Check that "ACCESSORY" or "IGNITION ON" on the multiinformation display is off.



NOTICE

■ To prevent battery discharge

Do not stop the engine when the shift lever is in a position other than P. If the engine is stopped in another shift lever position, the engine switch will not be turned to OFF but instead be turned to ACC. If the vehicle is left in ACC, battery discharge may occur.

Automatic transmission

*: If equipped

Select the shift position depending on your purpose and situation.

Shift position purpose and functions

Shift position	Objective or function
Р	Parking the vehicle/start- ing the engine
R	Reversing
N	Neutral
D	Normal driving*1
S	S mode driving ^{*2} (→P.155)

- *1: Shifting to the D position allows the system to select a gear suitable for the driving conditions. Setting the shift lever to the D position is recommended for normal driving.
- *2: Selecting shift ranges using S mode restricts the upper limit of the possible gear ranges, controls engine braking force, and prevents unnecessary upshifting.
- When driving with dynamic radar cruise control with full-speed range or cruise control activated (if equipped)

Even when performing the following actions with the intent of enabling engine braking, engine braking will not activate because dynamic radar cruise control with full-speed range, dynamic

radar cruise control or cruise control will not be canceled.

- While driving in S mode, downshifting to 7, 6, 5, or 4. (→P.155)
- When switching the driving mode to sport mode while driving in D. (→P.257)
- ■If "High Transmission Fluid Temp See Owner's Manual" is displayed on the multi-information display (AWD models)

Make sure to return to D position driving and reduce speed by easing off the accelerator pedal. Stop the vehicle in a safe place, shift the shift lever to P and let the engine idle until the warning message goes out.

When the warning message goes out, the vehicle can be driven again.

If the warning message does not go out after waiting a while, have your vehicle inspected by your Toyota dealer.

Restraining sudden start (Drive-Start Control)

→P 134

■ AI-SHIFT

The AI-SHIFT automatically selects the suitable gear according to driver performance and driving conditions.

The AI-SHIFT automatically operates when the shift lever is in D. (Shifting the shift lever to S cancels the function.)




WARNING

When driving on slippery road surfaces

Do not accelerate or shift gears suddenly.

Sudden changes in engine braking may cause the vehicle to spin or skid, resulting in an accident.

Shifting the shift lever



While the engine switch is

in ON and the brake pedal depressed*, shift the shift lever while pushing the shift release button on the shift knob



Shift the shift lever while

pushing the shift release button on the shift knob.



Shift the shift lever nor-

mally.

When shifting the shift lever between P and D, make sure that the vehicle is completely stopped.

*: For the vehicle to be able to be shifted from P, the brake pedal must

be depressed before the shift release button is pushed. If the shift release button is pushed first, the shift lock will not be released.

■ Shift lock system

The shift lock system is a system to prevent accidental operation of the shift lever in starting.

The shift lever can be shifted from P only when the engine switch is in ON, the brake pedal is depressed and the shift release button is pushed.

■ If the shift lever cannot be shifted from P


First, check whether the brake pedal is being depressed.

If the shift lever cannot be shifted even though the brake pedal is depressed and the shift release button is pushed, there may be a problem with the shift lock system. Have the vehicle inspected by your Toyota dealer immediately. The following steps may be used as an


emergency measure to ensure that the shift lever can be shifted.

Releasing the shift lock:

- Pull the parking brake switch to check that the parking brake is set. (→P.164)
- 2 Turn the engine switch to OFF.
- 3 Depress the brake pedal.
- 4 Pry the cover up with a flathead screwdriver or equivalent tool. To prevent damage to the cover, cover the tip of the screwdriver with a rag.



5 Press and hold the shift lock override button and then push the button on the shift knob. The shift lever can be shifted while both buttons are pressed.



A

WARNING

■ To prevent an accident when releasing the shift lock

Before pressing the shift lock override button, make sure to set the parking brake and depress the brake pedal.


If the accelerator pedal is accidentally depressed instead of the brake pedal when the shift lock override button is pressed and the shift lever is shifted out of P, the vehicle may suddenly start, possibly leading to an accident resulting in death or serious injury.

Selecting the driving mode and snow mode

→P.257, 262

Changing shift ranges in S mode

When the shift lever is in the S position, the shift lever can be operated as follows:



1 Upshifting

2 Downshifting

The selected shift range, from S1 to S8 will be displayed on the multi-information display.

The initial shift range in S mode is set automatically to 4, 5 or 6 according to vehicle speed. However, the initial shift range may be set to 3 if Al-SHIFT has operated while the shift lever was in the D position. (→P.154)

S mode

- You can choose from 8 levels of accelerating force and engine braking force.
- A lower shift range will provide greater accelerating force and engine braking force than a higher shift range, and the engine revolutions will also increase.
- To prevent the engine from over-revving, upshifting may automatically occur.
- To protect the automatic transmission, a function is adopted that automatically selects a higher shift range when the fluid temperature is high.
- When the shift range is 7 or lower, holding the shift lever toward "+" sets the shift range to 8.

■ Downshifting restriction warning

To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some circumstances, downshifting may not be possible even when the shift lever is operated. (A buzzer will sound twice.)

If the "S" indicator does not come on or the "D" indicator is displayed even after shifting the shift lever to S

This may indicate a malfunction in the automatic transmission system. Have the vehicle inspected by your Toyota dealer immediately. (In this situation, the transmission will operate in the same manner as when the shift lever is in D.)

CVT (Continuously Variable Transaxle)*

*: If equipped

Select the shift position depending on your purpose and situation.

Shift position purpose and functions

Shift position	Objective or function
Р	Parking the vehicle/start- ing the engine
R	Reversing
N	Neutral
D	Normal driving ^{*1}
М	10-speed sport sequential shiftmatic mode driving *2 (→P.159)

- *1: To improve fuel efficiency and reduce noises, set the shift lever in the D position for normal driving.
- *2: Selecting gear step using the M position achieves suitable engine braking force by operating shift lever.

Continuously variable transmission fail-safe control

The system detects malfunctioning parts targeted (all of the solenoids that perform the shifting function) by the On-Board Diagnostics, and performs failsafe mechanisms, such as restricting the shifting function or transmission ratio control. In this event, the malfunction indicator lamp turns on.

■ When driving with dynamic radar cruise control with full-speed range or cruise control activated (if equipped)

Even when switching the driving mode to sport mode while driving in D with the intent of enabling engine braking, engine braking will not activate because dynamic radar cruise control with full-speed range or cruise control will not be canceled. (\rightarrow P.257)

■If "Transmission Oil Temp. High Stop in a Safe Place and See Owner's Manual" is displayed on the multi-information display

Make sure to return to D position driving and reduce speed by easing off the accelerator pedal. Stop the vehicle in a safe place, shift the shift lever to P and let the engine idle until the warning message goes out.

When the warning message goes out, the vehicle can be driven again.

If the warning message does not go out after waiting a while, have your vehicle inspected by your Toyota dealer.

Restraining sudden start (Drive-Start Control)

→P.134

■ G AI-SHIFT

G AI-SHIFT automatically selects a suitable gear for sporty driving according to driver's input and driving conditions. G AI-SHIFT operates automatically when the shift lever is in D and sport mode is selected for the driving mode. (Selecting normal mode or shifting the shift lever to M cancels the function.)




WARNING

When driving on slippery road surfaces

Do not accelerate or shift gears suddenly.

Sudden changes in engine braking may cause the vehicle to spin or skid, resulting in an accident.

Shifting the shift lever



—

While the engine switch is

in ON and the brake pedal depressed*, shift the shift lever while pushing the shift release button on the shift knob.



Shift the shift lever while

pushing the shift release button on the shift knob.



Shift the shift lever nor-

mally.

When shifting the shift lever between P and D, make sure that the vehicle is completely stopped.

*: For the vehicle to be able to be shifted from P, the brake pedal must

be depressed before the shift release button is pushed. If the shift release button is pushed first, the shift lock will not be released.

■ Shift lock system

The shift lock system is a system to prevent accidental operation of the shift lever in starting.

The shift lever can be shifted from P only when the engine switch is in ON, the brake pedal is depressed and the shift release button is pushed.

If the shift lever cannot be shifted from P


First, check whether the brake pedal is being depressed.

If the shift lever cannot be shifted even though the brake pedal is depressed and the shift release button is pushed, there may be a problem with the shift lock system. Have the vehicle inspected by your Toyota dealer immediately.

The following steps may be used as an emergency measure to ensure that the shift lever can be shifted.


Releasing the shift lock:

- Pull the parking brake switch to check that the parking brake is set. (→P.164)
- 2 Turn the engine switch to OFF.
- 3 Depress the brake pedal.
- 4 Pry the cover up with a flathead screwdriver or equivalent tool. To prevent damage to the cover, cover the tip of the screwdriver with a rag.



5 Press and hold the shift lock override button and then push the button on the shift knoh

The shift lever can be shifted while both buttons are pressed.



A

WARNING

■ To prevent an accident when releasing the shift lock

Before pressing the shift lock override button, make sure to set the parking brake and depress the brake pedal.


If the accelerator pedal is accidentally depressed instead of the brake pedal when the shift lock override button is pressed and the shift lever is shifted out of P, the vehicle may suddenly start, possibly leading to an accident resulting in death or serious injury.

Selecting the driving mode

→P.257

Changing gear steps in the M position

To enter 10-speed sport sequential shiftmatic mode, shift the shift lever to M. Gear steps can then be selected by operating the shift lever, allowing you to drive in the gear step of your choosing.



1 Upshifting

2 Downshifting

The gear changes once every time the shift lever is operated.

The selected gear step, from M1 to M10, will be displayed in the meter.

However, even when in the M position, the gear steps will be automatically changed if the engine speed is too high, or too low.

Gear step functions

- You can choose from 10 levels of accelerating force and engine braking force.
- A lower gear step will provide greater accelerating force and engine braking force than a higher gear step, and the engine revolutions will also increase.
- Automatic gear selection when the vehicle stopped after driving with the shift lever in M
- The transmission will automatically downshift to gear step 1 when the vehicle comes to a stop.
- 1 is automatically selected when the vehicle moves forward again.
- The gear step is fixed in 1 while the vehicle is stopped.

Downshifting restriction warning buzzer

To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some cir-

cumstances, downshifting may not be possible even when the shift lever is operated. (A buzzer will sound twice.)

■ If the "M" indicator does not come on or the "D" indicator is displayed even after shifting the shift lever to M

This may indicate a malfunction in the transmission system. Have the vehicle inspected by your Toyota dealer immediately.


(In this situation, the transmission will operate in the same manner as when the shift lever is in D.)

Manual transmission

*: If equipped

Operating instructions

■ Shifting the shift lever




- 1 Depress the clutch pedal firmly.
- 2 Shift the shift lever to the desired gear.

Make sure to only shift gears sequentially.

- **3** Gradually release the clutch pedal.
- Shifting the shift lever to R

Shift the shift lever to R while lifting up the ring section.



■ Maximum downshifting speed

Observe the downshifting speeds in the following table to prevent over-revving the engine.

▶ Vehicles with 225/65R17 102H tires

Shift position	Maximum speed
1	52 km/h (32 mph)
2	100 km/h (62 mph)
3	150 km/h (93 mph)

▶ Vehicles with 225/60R18 100H tires

Shift position	Maximum speed
1	53 km/h (33 mph)
2	101 km/h (63 mph)
3	152 km/h (94 mph)

▶ Vehicles with 235/55R19 101V tires


Shift position	Maximum speed	
	54 km/h (34 mph)	
2	103 km/h (64 mph)	
3	155 km/h (96 mph)	

♠ NOTICE

■ To prevent damage to the transmission

When shifting gears, observe the following precautions. Failure to do so may cause damage to the engine, manual transmission, and/or clutch.

 Do not shift the shift lever to R without depressing the clutch pedal.




- Do not lift up the ring section except when shifting the lever to R.
- Shift the shift lever to R only when the vehicle is stationary.
- Do not rest your hand on or hold the shift lever any time other than when shifting.
- In order to not cause the engine to overrev, make sure to only shift gears sequentially.
- Do not release the clutch pedal suddenly.

iMT (Intelligent Manual Transmission)

The iMT optimally controls the engine speed to suit the driver's operation of the clutch pedal and

shift lever, helping the driver to shift gears more smoothly. Additionally, when the clutch pedal is operated, the iMT helps reduce shift shock, allowing for lighter shift operations when driving on a winding road or incline.

Press the "iMT" switch.



The "iMT" indicator will illuminate in green. Press the switch again to cancel iMT.

■ When changing driving mode

In the following situations, iMT will operate even if the "iMT" switch is not pressed.

- When driving mode is set to sports mode. (→P.257)
- AWD models: When Mud & Sand or Rock & Dirt mode is selected for Multiterrain Select. (→P.259)

Press the "iMT" switch to cancel iMT.

- iMT is also canceled if the driving mode is switched to normal or Ecodrive mode.
- AWD models: iMT is also canceled if the normal mode is selected for Multiterrain Select.

■ The iMT may not operate when

In the following situations, iMT may not operate.

However, this does not indicate a malfunction.

- The clutch pedal is not fully depressed
- The clutch pedal is not fully released, such as if a foot is resting on the clutch pedal*
- Shift operation is performed after the vehicle has been coasting with the shift lever in N
- The shift lever is not operated for a long time after the clutch pedal is depressed
- *: After the shift lever is moved, unless your foot is completely removed from the clutch pedal, the iMT may not operate and the engine speed may not be controlled optimally for the next gear change. To enable the iMT, release the clutch pedal completely and then depress it again before operating the shift lever.

If the "iMT" indicator illuminates in vellow

The iMT may be temporarily unavailable or malfunctioning. Have the vehicle inspected at your Toyota dealer.

A

WARNING

■ Limitations of the iMT

iMT is not a system that prevents shift lever operation error or engine over revving.


Depending on the situation, iMT may not operate normally and the shift position may not be changed smoothly. Overly relying on iMT may cause an unexpected accident.

Selecting the driving mode

→P.257

Turn signal lever

Operating instructions



- 1 Right turn
- 2 Lane change to the right (move the lever partway and release it)

The right hand signals will flash 3 times.

3 Lane change to the left (move the lever partway and release it)

The left hand signals will flash 3 times.

- 4 Left turn
- Turn signals can be operated when The engine switch is in ON.

If the indicator flashes faster than usual

Check that a light bulb in the front or rear turn signal lights has not burned out.

If the turn signals stop flashing before a lane change has been performed

Operate the lever again.

■ To discontinue flashing of the turn signals during a lane change

Operate the lever in the opposite direction.

Parking brake


The parking brake can be set or released automatically or manually. In automatic mode, the parking brake can be set or released automatically according to shift lever operation.

Also, even in automatic mode, the parking brake can be set or released manually.

Operating instructions

■ Using the manual mode

The parking brake can be set and released manually.



- A Parking brake indicator light
- B Parking brake lamp
- 1 Pull the switch to set the parking brake

The parking brake indicator light and parking brake lamp will turn on.

Pull and hold the parking brake switch if an emergency occurs and it is necessary to operate the parking brake while driving.


- Push the switch to release the parking brake
- Operate the parking brake switch while depressing the brake pedal.
- Parking brake automatic release function (→P.165)

Make sure that the parking brake indicator light and parking brake lamp turn off.

If the parking brake indicator light and parking brake lamp flashes, operate the switch again. (→P.373)

■ Turning the automatic mode on

While the vehicle is stopped, pull and hold the parking brake switch until a buzzer sounds and a message A is shown on the multi-information display (vehicles with automatic transmission or CVT) or auto EPB OFF indicator B turns off (vehicles with manual transmission).



When the automatic mode is turned on, the parking brake operates as follows.

- Vehicles with automatic transmission or CVT
- When the shift position is shifted from P, the parking brake will be released, and the parking brake indicator light and parking brake lamp will turn off.
- When the shift position is shifted to P, the parking brake will be set, and the parking brake indicator light and parking brake lamp will turn on.

Operate the shift lever with the vehicle stopped and the brake pedal depressed.


Vehicles with manual transmission

When the engine is off, the parking brake will be set, and the parking brake indicator light and parking brake lamp will turn on.

■ Turning the automatic mode off

While the vehicle is stopped and depressing the brake pedal, press and hold the parking brake switch until a message A is shown on the multi-information display (vehicles with automatic transmission or CVT) or auto EPB OFF indicator

comes on (vehicles with manual transmission)



■ Parking brake operation

- When the engine switch is not in ON, the parking brake cannot be released using the parking brake switch.
- When the engine switch is not in ON, automatic mode (automatic brake setting and releasing) is not available.

Parking brake automatic release function

The parking brake will be released automatically when the accelerator pedal is slowly depressed under the following conditions:

- The driver's door is closed.
- The driver is wearing the seat belt
- The shift lever is in a forward or reverse position.
- The malfunction indicator lamp or brake system warning light is not illuminated

If the automatic release function does not operate, release the parking brake manually.

If "Parking Brake Temporarily Unavailable" is displayed on the multi-information display

If the parking brake is operated repeatedly over a short period of time, the system may restrict operation to prevent overheating. If this happens, refrain from operating the parking brake. Normal operation will return after about 1 minute.

■If "Parking Brake Unavailable" is displayed on the multi-information display

Operate the parking brake switch. If the message does not disappear after operating the switch several times, the system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

■ Parking brake operation sound

When the parking brake operates, a motor sound (whirring sound) may be heard. This does not indicate a malfunction.

■ Parking brake indicator light

Depending on the engine switch position/mode, the parking brake indicator light will turn on and stay on as described below:

ON: Comes on until the parking brake is released.

Not in ON: Stays on for approximately 15 seconds

 When the engine switch is turned off with the parking brake set, the parking brake indicator light will stay on for about 15 seconds. This does not indicate a malfunction.

■ When the parking brake switch malfunctions

Automatic mode (automatic brake setting and releasing) will be turned on automatically.

■ Parking the vehicle

→P.132

Parking brake engaged warning buzzer

A buzzer will sound if the vehicle is driven with the parking brake engaged. "Parking Brake ON" is displayed on the multi-information display (with the vehicle reaching a speed of 5 km/h [3 mph]).

■ If the brake system warning light comes on

→P.368

■ Usage in winter time

→P.273

WARNING

■When parking the vehicle

Do not leave a child in the vehicle alone. The parking brake may be released unintentionally and there is the danger of the vehicle moving that may lead to an accident resulting in death or serious injury.

Parking brake switch

Do not set any objects near the parking brake switch. Objects may interfere with the switch and may lead the parking brake to unexpectedly operate.



NOTICE

■ When parking the vehicle

Before you leave the vehicle, shift the shift position to P, set the parking brake and make sure that the vehicle does not move.

When the system malfunctions

Stop the vehicle in a safe place and check the warning messages.

When the parking brake cannot be released due to a malfunction

Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear. Have the vehicle inspected by your Toyota dealer immediately if this occurs.


Brake Hold

The brake hold system keeps the brake applied when the shift lever is in a forward driving position or N with the system on and the brake pedal has been depressed to stop the vehicle. The system releases the brake when the accelerator pedal is depressed with the shift lever in the forward driving position to allow smooth start off.

Enabling the system

Press the brake hold switch to turn the brake hold system on

The brake hold standby indicator (green) A comes on. While the system is holding the brake, the brake hold operated indicator (yellow) B comes on.



■ Brake hold system operating conditions

The brake hold system cannot be turned on in the following conditions:

The driver's door is not closed.

• The driver is not wearing the seat belt.

If any of the conditions above are detected when the brake hold system is enabled, the system will turn off and the brake hold standby indicator light will go off. In addition, if any of the conditions are detected while the system is holding the brake, a warning buzzer will sound and a message will be shown on the multi-information display. The parking brake will then be set automatically.

■ Brake hold function

- If the brake pedal is left released for a period of about 3 minutes after the system has started holding the brake, the parking brake will be set automatically. In this case, a warning buzzer sounds and a message is shown on the multi-information display.
- To turn the system off while the system is holding the brake, firmly depress the brake pedal and press the button again.
- The brake hold function may not hold the vehicle when the vehicle is on a steep incline. In this situation, it may be necessary for the driver to apply the brakes. A warning buzzer will sound and the multi-information display will inform the driver of this situation. If a warning message is shown on the multi-information display, read the message and follow the instructions.
- When the parking brake is set automatically while the system is holding the brakes

Perform any of the following operations to release the parking brake:

- Depress the accelerator pedal. (The parking brake will not be released automatically if the seat belt is not fastened.)
- Operate the parking brake switch with the brake pedal depressed.

Make sure that the parking brake indicator light goes off. (→P.164)

■ When an inspection at your Toyota dealer is necessary

When the brake hold standby indicator (green) does not illuminate even when the brake hold switch is pressed with the brake hold system operating conditions met, the system may be malfunctioning. Have the vehicle inspected at your Toyota dealer.

■ If "Brake Hold Malfunction Press Brake to Deactivate Visit Your Dealer" or "Brake Hold Malfunction Visit Your Dealer" is displayed on the multi-information display

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

■ Warning messages and buzzers

Warning messages and buzzers are used to indicate a system malfunction or to inform the driver of the need for caution. If a warning message is shown on the multi-information display, read the message and follow the instructions.

If the brake hold operated indicator flashes

→P 373



WARNING

When the vehicle is on a steep incline

When using the brake hold system on a steep incline, exercise caution. The brake hold function may not hold the vehicle in such a situation.

When stopped on a slippery road

The system cannot stop the vehicle when the gripping ability of the tires has been exceeded. Do not use the system when stopped on a slippery road.



NOTICE

■When parking the vehicle

The brake hold system is not designed for use when parking the vehicle for a long period of time. Turning the engine switch off while the system is holding the brake may release the brake, which would cause the vehicle to move. When operating the engine switch, depress the brake pedal, shift the shift lever to P (vehicles with automatic transmission or CVT) or N (vehicles with manual transmission) and set the parking brake.


Headlight switch

The headlights can be operated manually or automatically.

Turning on the headlights


Operating the -\hat{\tilde{\ti

▶ Type A



- 1 FOG The front position, tail, license plate and instrument panel lights turn on.
- 2 The headlights and all lights listed above turn on.
- Aυτο The headlights, daytime running lights (→P.169) and all the lights listed above turn on and off automatically.
- 4 O The daytime running lights turn on. (→P.169)

▶ Type B



- 1 FOR The front position, tail, license plate and instrument panel lights turn on.
- 2 The headlights and all lights listed above turn on.
 - AUTO The headlights, daytime running lights (→P.169) and all the lights listed above turn on and off automatically.

■ AUTO mode can be used when

The engine switch is in ON.


■ Daytime running light system

To make your vehicle more visible to other drivers during daytime driving, the daytime running lights turn on automatically whenever the engine is started and the parking brake is released with the

headlight switch in the O or AUTO position. (Illuminate brighter than the front position lights.) Daytime running lights are not designed for use at night.

■ Headlight control sensor

The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield. Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.



■ Automatic light off system

When the headlights are on: The lights turn off 30 seconds after the engine switch is turned to ACC or OFF and a door is opened and closed. (The lights turn off immediately if

on the key is pressed after all the doors are closed.)

 When only the tail lights are on: The tail lights turn off automatically if the engine switch is turned to ACC or OFF and the driver's door is opened.

To turn the lights on again, turn the engine switch to ON or turn the light

switch off once and then back to so or



■ Light reminder buzzer

➤ Vehicles without smart entry & start system

A buzzer sounds when the engine switch is turned to ACC or OFF, the key is removed and the driver's door is opened while the lights are turned on.

Vehicles with smart entry & start system

A buzzer sounds when the engine switch is turned to ACC or OFF and the driver's door is opened while the lights are turned on.

Automatic headlight leveling system

The level of the headlights is automatically adjusted according to the number of passengers and the loading condition of the vehicle to ensure that the headlights do not interfere with other road users.

■ Battery-saving function

In order to prevent the battery of the vehicle from discharging, if the head-lights and/or tail lights are on when the engine switch is turned to OFF, the battery saving function will operate and automatically turn off all the lights after approximately 20 minutes.

When any of the following are performed, the battery-saving function is canceled once and then reactivated. All the lights will turn off automatically 20 minutes after the battery-saving function has been reactivated:

- When the headlight switch is operated
- When a door is opened or closed

If "Headlight System Malfunction Visit Your Dealer" is displayed on the multi-information display

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

Customization

Settings (e.g. light sensor sensitivity) can be changed. (Customizable features: →P.417)




NOTICE

■To prevent battery discharge

Do not leave the lights on longer than necessary when the engine is not running.

Turning on the high beam headlights



With the headlights on, push the lever away from you to turn on the high beams.

Pull the lever toward you to the center position to turn the high beams off.

Pull the lever toward you and release it to flash the high beams once.

You can flash the high beams with the headlights on or off.

Automatic High Beam^{*}

: If equipped

The Automatic High Beam uses an in-vehicle camera sensor to assess the brightness of streetlights, the lights of vehicles ahead etc., and automatically turns the high beam on or off as necessary.



WARNING

Limitations of the Automatic High Beam


Do not overly rely on the Automatic High Beam. Always drive safely, taking care to observe your surroundings and turning the high beam on or off manually if necessary.

To prevent incorrect operation of the Automatic High Beam system

Do not overload the vehicle.


Activating the Automatic High Beam system

1 Press the Automatic High Beam switch



2 Push the lever away from you with the headlight switch in the AUTO or **■** position.

The Automatic High Beam indicator will come on when the system is operating.



■ High beam automatic turning on or off conditions

- When all of the following conditions are fulfilled, the, high beam will be automatically turned on (after approximately 1 second):
- Vehicle speed is above approximately 30 km/h (19 mph) or more.
- The area ahead of the vehicle is dark.
- There are no vehicles ahead with headlights or tail lights turned on.
- There are few streetlights on the road ahead.
- If any of the following conditions are fulfilled, the, high beam will be automatically turned off:
- Vehicle speed drops below approximately 25 km/h (16 mph).
- The area ahead of the vehicle is not dark.
- Vehicles ahead have headlights or tail lights turned on.
- There are many streetlights on the road ahead.

Camera sensor detection information

- The high beam may not be automatically turned off in the following situations:
- When oncoming vehicles suddenly appear from a curve
- When the vehicle is cut in front of by another vehicle
- When vehicles ahead are hidden from sight due to repeated curves, road dividers or roadside trees

- When vehicles ahead appear from the faraway lane on a wide road
- · When vehicles ahead have no lights
- The high beam may be turned off if a vehicle ahead that is using fog lights without using the headlights is detected.
- House lights, street lights, traffic signals, and illuminated billboards or signs may cause the high beam to switch to the low beams, or the low beams to remain on.
- The following factors may affect the amount of time taken to turn the high beam on or off:
- The brightness of headlights, fog lights, and tail lights of vehicles ahead
- The movement and direction of vehicles ahead
- When a vehicle ahead only has operational lights on one side
- When a vehicle ahead is a twowheeled vehicle
- The condition of the road (gradient, curve, condition of the road surface etc.)
- The number of passengers and amount of luggage
- The high beam may be turned on or off when the driver does not expect it.
- Bicycles or similar objects may not be detected.
- In the situations shown below, the system may not be able to accurately detect surrounding brightness levels. This may cause the low beams to remain on or the high beams to cause problems for pedestrians, vehicles ahead or other parties. In these cases, manually switch between the high and low beams.
- In bad weather (rain, snow, fog, sandstorms, etc.)
- The windshield is obscured by fog, mist, ice, dirt, etc.
- The windshield is cracked or damaged
- The camera sensor is deformed or dirty
- When the temperature of the camera

- sensor is extremely high
- Surrounding brightness levels are equal to those of headlights, tail lights or fog lights
- When headlights or tail lights of vehicles ahead are turned off, dirty, changing color, or not aimed properly
- When the vehicle is hit by water, snow, dust, etc. from a preceding vehicle
- When driving through an area of intermittently changing brightness and darkness
- When frequently and repeatedly driving ascending/descending roads, or roads with rough, bumpy or uneven surfaces (such as stone-paved roads, gravel roads, etc.)
- When frequently and repeatedly taking curves or driving on a winding road
- There is a highly reflective object ahead of the vehicle, such as a sign or mirror
- The back of a vehicle ahead is highly reflective, such as a container on a truck
- The vehicle's headlights are damaged or dirty, or are not aimed properly
- The vehicle is listing or titling due to a flat tire, a trailer being towed, etc.
- The high beam and low beam are repeatedly being switched between in an abnormal manner
- The driver believes that the high beam may be causing problems or distress to other drivers or pedestrians nearby
- If "Headlight System Malfunction Visit Your Dealer" is displayed on the multi-information display

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.


Turning the high beam on/off manually

■ Switching to the low beam

Pull the lever to original position.

The Automatic High Beam indicator will turn off

Push the lever away from you to activate the Automatic High Beam system again.




■ Switching to the high beam

Press the Automatic High Beam switch.

The Automatic High Beam indicator will turn off and the high beam indicator will turn on.


Press the switch to activate the Automatic High Beam system again.



Fog light switch

The fog lights offer improved visibility in difficult driving conditions, such as in rain and fog.

Operating procedure



- 1 O Turns the fog lights off
- 2 ‡ Turns the fog lights on

■ Fog lights can be used when The headlights or the front position lights are turned on.

Windshield wipers and washer

Operating the lever can switch between automatic operation and manual operation, or can use the washer.

Λ


NOTICE

■When the windshield is dry

Do not use the wipers, as they may damage the windshield.

Operating the wiper lever

Operating the lever operates the wipers or washer as follows:




- 1 0 Off
- 2 AUTO Rain-sensing operation
- 3 ▼ Low speed operation
- 4 ▼ High speed operation
- 5 riangle Temporary operation


When "AUTO" is selected, the wipers will operate automatically when the

sensor detects falling rain. The system automatically adjusts wiper timing in accordance with rain volume and vehicle speed.

The sensor sensitivity can be adjusted when "AUTO" is selected.



- 6 Increases the sensitivity
- 7 Decreases the sensitivity




Pulling the lever operates the wipers and washer.

The wipers will automatically operate a couple of times after the washer squirts.

The windshield wipers and washer can be operated when

The engine switch is in ON.

- Raindrop sensor
- The raindrop sensor judges the amount of raindrops.



- If the wiper switch is turned to the "AUTO" position while the engine switch is in ON, the wipers will operate once to show that "AUTO" mode is activated.
- If the wiper sensitivity is adjusted to higher, the wiper may operate once to indicate the change of sensitivity.
- If the temperature of the raindrop sensor is 85°C (185°F) or higher, or -15°C (5°F) or lower, the automatic operation may not occur. In this case, operate the wipers in any mode other than "AUTO"

If no windshield washer fluid sprays

Check that the washer nozzles are not blocked if there is washer fluid in the windshield washer fluid reservoir.

WARNING

Caution regarding the use of windshield wipers in "AUTO" mode

The windshield wipers may operate unexpectedly if the sensor is touched or the windshield is subject to vibration in "AUTO" mode. Take care that your fingers or anything else does not become caught in the windshield wipers.

Caution regarding the use of washer fluid

When it is cold, do not use the washer fluid until the windshield becomes warm. The fluid may freeze on the windshield and cause low visibility. This may lead to an accident, resulting in death or serious injury.

NOTICE

When the washer fluid tank is empty

Do not operate the switch continually as the washer fluid pump may overheat.

When a nozzle becomes blocked

In this case, contact your Toyota dealer

Do not try to clear it with a pin or other object. The nozzle will be damaged.

■ To prevent battery discharge

Do not leave the wipers on longer than necessary when the engine is off.

Rear window wiper and washer

Operating the lever can switch between automatic operation and manual operation, or can use the washer.




NOTICE

■ When the rear window is dry


Do not use the wiper, as it may damage the rear window.

Operating the wiper lever

Operating the witch operates the rear wiper as follows:



- 1 0 Off
- 2 --- Intermittent operation
- 3 Normal operation



4 Washer/wiper dual operation

Pushing the lever operates the wiper and washer.

The wiper will automatically operate a couple of times after the washer squirts.

■ The rear window wiper and washer can be operated when

The engine switch is in ON.

■ If no washer fluid sprays

Check that the washer nozzle is not blocked if there is washer fluid in the washer fluid reservoir

■ Back door opening linked rear window wiper stop function

When the rear window wiper is operating, if the back door is opened while the vehicle is stopped, operation of the rear window wiper will be stopped to prevent anyone near the vehicle from being sprayed by water from the wiper. When the back door is closed, wiper operation will resume.

The setting must be customized at your Toyota dealer.

Reverse-linked rear window wiper function

When the shift lever is shifted to R when the front wipers are operating, the rear window wiper will operate once.

Customization

Setting of the reverse-linked function can be changed.

(Customizable features: →P.418)

<u>^</u>

NOTICE

When the washer fluid tank is empty

Do not operate the switch continually as the washer fluid pump may overheat.

When a nozzle becomes blocked

In this case, contact your Toyota dealer

Do not try to clear it with a pin or other object. The nozzle will be damaged.

■ To prevent battery discharge

Do not leave the wiper on longer than necessary when the engine is off.

Opening the fuel tank cap

Perform the following steps to open the fuel tank cap:

Before refueling the vehicle

- Close all the doors and windows, and turn the engine switch to OFF
- Confirm the type of fuel.

■ Fuel types

→P.410

■ Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your vehicle has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.



WARNING

When refueling the vehicle

Observe the following precautions while refueling the vehicle. Failure to do so may result in death or serious injury.

After exiting the vehicle and before opening the fuel door, touch an unpainted metal surface to discharge any static electricity. It is important to discharge static electricity before refueling because sparks resulting from static electricity can cause fuel vapors to ignite while refueling. Always hold the grips on the fuel tank cap and turn it slowly to remove it.

A whooshing sound may be heard when the fuel tank cap is loosened. Wait until the sound cannot be heard before fully removing the cap. In hot weather, pressurized fuel may spray out of the filler neck and cause injury.

- Do not allow anyone that has not discharged static electricity from their body to come close to an open fuel tank.
- Do not inhale vaporized fuel.
 Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle.
 Doing so may cause the fuel to ignite and cause a fire.
- Do not return to the vehicle or touch any person or object that is statically charged. This may cause static electricity to build up, resulting in a possible ignition hazard.

When refueling

Observe the following precautions to prevent fuel overflowing from the fuel tank:

- Securely insert the fuel nozzle into the fuel filler neck.
- Stop filling the tank after the fuel nozzle automatically clicks off.
- Do not top off the fuel tank.




NOTICE

Refueling


Do not spill fuel during refueling. Doing so may damage the vehicle, such as causing the emission control system to operate abnormally or damaging fuel system components or the vehicle's painted surface.

Opening the fuel tank cap

1 Pull up the opener to open the fuel filler door.




2 Turn the fuel tank cap slowly to open it and put it into the holder on the fuel filler door.



Closing the fuel tank cap

After refueling, turn the fuel tank cap until you hear a click. Once the cap is released, it will turn slightly in the opposite direction.



WARNING

When replacing the fuel tank cap

Do not use anything but a genuine Toyota fuel tank cap designed for your vehicle. Doing so may cause a fire or other incident which may result in death or serious injury.

Tovota Safetv Sense^{*}

: If equipped

The Toyota Safety Sense consists of the following drive assist systems and contributes to a safe and comfortable driving experience:

Driving assist system

- PCS (Pre-Collision System)
- →P 184
- LTA (Lane Tracing Assist) (if (baggiups
- →P.192
- LDA (Lane Departure Alert with steering control) (if equipped)
- →P 201
- Automatic High Beam
- →P 171
- RSA (Road Sign Assist)
- →P.209
- Dynamic radar cruise control with full-speed range (if equipped)
 - →P.211
- Dynamic radar cruise control (if equipped)
- →P.222

WARNING


■ Tovota Safety Sense

The Toyota Safety Sense is designed to operate under the assumption that the driver will drive safely, and is designed to help reduce the impact to the occupants and the vehicle in the case of a collision or assist the driver in normal driving conditions.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide. do not overly rely on this system. The driver is always responsible for paying attention to the vehicle's surroundings and driving safely.

Sensors

Two types of sensors, located behind the front grille and windshield, detect information necessary to operate the drive assist systems.




- A Radar sensor
- B Front camera



To avoid malfunction of the radar sensor

Observe the following precautions. Otherwise, the radar sensor may not operate properly, possibly leading to an accident resulting in death or serious injury.

Keep the radar sensor and the grille cover clean at all times



- A Radar sensor
- B Grille cover

If the front of the radar sensor or the front or back of the grille cover is dirty or covered with water droplets, snow, etc.. clean it.

Clean the radar sensor and grille cover with a soft cloth to avoid damaging them.

- Do not attach accessories, stickers (including transparent stickers) or other items to the radar sensor. grille cover or surrounding area.
- Do not subject the radar sensor or its surrounding area to a strong impact.
 - If the radar sensor, front grille, or front bumper has been subjected to a strong impact, have the vehicle inspected by your Toyota dealer.
- Do not disassemble the radar sensor.
- Do not modify or paint the radar sensor or grille cover.

- If the radar sensor front grille, or front humber needs to be removed. and installed, or replaced, contact vour Tovota dealer.
- To avoid malfunction of the front camera


Observe the following precautions. Otherwise, the front camera may not operate properly, possibly leading to an accident resulting in death or serious injury.

- Keep the windshield clean at all times
- · If the windshield is dirty or covered with an oily film, water droplets, snow, etc., clean the windshield.
- If a glass coating agent is applied to the windshield, it will still be necessary to use the windshield wipers to remove water droplets, etc. from the area of the windshield in front of the front camera.
 - If the inner side of the windshield where the front camera is installed is dirty, contact your Toyota dealer.

A

WARNING

 Do not attach objects, such as stickers, transparent stickers, etc., to the outer side of the windshield in front of the front camera (shaded area in the illustration).



- A From the top of the windshield to approximately 1 cm (0.4 in.) below the bottom of the front camera
- Approximately 20 cm (7.9 in.)

 (Approximately 10 cm [4.0 in.] to the right and left from the center of the front camera)
- If the part of the windshield in front of the front camera is fogged up or covered with condensation, or ice, use the windshield defogger to remove the fog, condensation, or ice. (→P.281, 286)
- If water droplets cannot be properly removed from the area of the windshield in front of the front camera by the windshield wipers, replace the wiper insert or wiper blade.
- To replace a wiper insert: →P.337
- If the wiper blades need to be replaced, contact your Toyota dealer.
- Do not attach window tint to the windshield.
- Replace the windshield if it is damaged or cracked.
 If the windshield needs to be replaced, contact your Toyota dealer.

- Do not allow liquids to contact the front camera.
- Do not allow bright lights to shine into the front camera.
- Do not dirty or damage the front camera.

When cleaning the inside of the windshield, do not allow glass cleaner to contact the lens of the front camera. Also, do not touch the lens.

If the lens is dirty or damaged, contact your Toyota dealer.

- Do not subject the front camera to a strong impact.
- Do not change the installation position or direction of the front camera or remove it.
- Do not disassemble the front camera.
- Do not modify any components of the vehicle around the front camera (inside rear view mirror, etc.) or ceiling.
- Do not attach any accessories to the hood, front grille or front bumper that may obstruct the front camera. Contact your Toyota dealer for details.
- If a surfboard or other long object is to be mounted on the roof, make sure that it will not obstruct the front camera.
- Do not modify the headlights or other lights.

If a warning message is displayed on the multi-information display

A system may be temporarily unavailable or there may be a malfunction in the system.

 In the following situations, perform the actions specified in the table. When the normal operating conditions are detected, the message will disappear and the system will become operational.

If the message does not disappear, contact your Toyota dealer.

Situation	Actions
When the area around a sensor is covered with dirt, moisture (fogged up, covered with condensation, ice, etc.), or other foreign matter	To clean the part of the windshield in front of the front camera, use the windshield wipers or the windshield defogger of the air conditioning system (→P.281, 286).

Situation	Actions
When the temperature around the front camera is outside of the operational range, such as when the vehicle is in the sun or in an extremely cold environment	If the front camera is hot, such as after the vehicle had been parked in the sun, use the air conditioning system to decrease the temperature around the front camera. If a sunshade was used when the vehicle was parked, depending on its type, the sunlight reflected from the surface of the sunshade may cause the temperature of the front camera to become excessively high.
	If the front camera is cold, such as after the vehicle is parked in an extremely cold environment, use the air conditioning system to increase the temperature around the front camera.

Situation	Actions
The area in front of the front camera is obstructed, such as when the hood is open or a sticker is attached to the part of the wind- shield in front of the front camera.	Close the hood, remove the sticker, etc. to clear the obstruction.

• In the following situations, if the situation has changed (or the vehicle has been driven for some time) and the normal operating conditions are detected, the message will disappear and the system will become operational

If the message does not disappear, contact your Toyota dealer.

- When the temperature around the radar sensor is outside of the operational range, such as when the vehicle is in the sun or in an extremely cold environment
- When the front camera cannot detect objects in front of the vehicle, such as when driving in the dark, snow, or fog, or when bright lights are shining into the front camera

PCS (Pre-Collision System)*

*: If equipped

The pre-collision system uses a radar sensor and front camera to detect objects (→P.184) in front of the vehicle. When the system determines that the possibility of a frontal collision with an object is high, a warning operates to urge the driver to take evasive action and the potential brake pressure is increased to help the driver avoid the collision. If the system determines that the possibility of a frontal collision with an object is extremely high, the brakes are automatically applied to help avoid the collision or help reduce the impact of the collision.

The pre-collision system can be disabled/enabled and the warning timing can be changed. $(\rightarrow P.186)$

Detectable objects


The system can detect the following:

- Vehicles
- Bicyclists
- Pedestrians

System functions

■ Pre-collision warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the multi-information display to urge the driver to take evasive action.



■ Pre-collision brake assist

When the system determines that the possibility of a frontal collision is high, the system applies greater braking force in relation to how strongly the brake pedal is depressed.

■ Pre-collision braking

If the system determines that the possibility of a frontal collision is extremely high, the brakes are automatically applied to help avoid the collision or reduce the impact of the collision.

▲ WARNING

Limitations of the pre-collision system

 The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

Do not use the pre-collision system instead of normal braking operations under any circumstances. This system will not prevent collisions or lessen collision damage or injury in every situation. Do not overly rely on this system. Failure to do so may lead to an accident, resulting in death or serious injury.

 Although this system is designed to help avoid a collision or help reduce the impact of the collision, its effectiveness may change according to various conditions, therefore the system may not always be able to achieve the same level of performance.

Read the following conditions carefully. Do not overly rely on this system and always drive carefully.

- Conditions under which the system may operate even if there is no possibility of a collision: →P.188
- Conditions under which the system may not operate properly: →P.190
- Do not attempt to test the operation of the pre-collision system yourself. Depending on the objects used for testing (dummies, cardboard objects imitating detectable objects, etc.), the system may not operate properly, possibly leading to an accident.

Pre-collision braking

 When the pre-collision braking function is operating, a large amount of braking force will be applied.

A

WARNING

- If the vehicle is stopped by the operation of the pre-collision braking function, the pre-collision braking function operation will be canceled after approximately 2 seconds. Depress the brake pedal as necessary.
- The pre-collision braking function may not operate if certain operations are performed by the driver. If the accelerator pedal is being depressed strongly or the steering wheel is being turned, the system may determine that the driver is taking evasive action and possibly prevent the pre-collision braking function from operating.
- In some situations, while the precollision braking function is operating, operation of the function may be canceled if the accelerator pedal is depressed strongly or the steering wheel is turned and the system determines that the driver is taking evasive action
- If the brake pedal is being depressed, the system may determine that the driver is taking evasive action and possibly delay the operation timing of the pre-collision braking function.
- When to disable the pre-collision system

In the following situations, disable the system, as it may not operate properly, possibly leading to an accident resulting in death or serious injury:

- When the vehicle is being towed
- When your vehicle is towing another vehicle
- When transporting the vehicle via truck, boat, train or similar means of transportation

- When the vehicle is raised on a lift with the engine running and the tires are allowed to rotate freely
- When inspecting the vehicle using a drum tester such as a chassis dynamometer or speedometer tester, or when using an on vehicle wheel balancer
- When a strong impact is applied to the front bumper or front grille, due to an accident or other reasons.
- If the vehicle cannot be driven in a stable manner, such as when the vehicle has been in an accident or is malfunctioning
- When the vehicle is driven in a sporty manner or off-road
- When the tires are not properly inflated
- When the tires are very worn
- When tires of a size other than specified are installed
- When tire chains are installed.
- When a compact spare tire or an emergency tire puncture repair kit is used
- If equipment (snow plow, etc.) that may obstruct the radar sensor or front camera is temporarily installed to the vehicle


Changing settings of the pre-collision system

■ Enabling/disabling the pre-collision system

The pre-collision system can be enabled/disabled on the ♣ screen (→P.75) of the multi-information display.

The system is automatically enabled each time the engine switch is turned to ON


If the system is disabled, the PCS warning light will turn on and a message will be displayed on the multi-information display.



Changing the pre-collision warning timing

The pre-collision warning timing can be changed on the ♠ screen (→P.75) of the multi-information display.

The warning timing setting is retained when the engine switch is turned to OFF. However, if the pre-collision system is disabled and re-enabled, the operation timing will return to the default setting (middle).



- Early
- Middle
- This is the default setting.
- 3 Late

■ Operational conditions

The pre-collision system is enabled and the system determines that the possibility of a frontal collision with a detected object is high. Each function is operational at the following speed

Pre-collision warning

	Detectable objects	Vehicle speed	Relative speed between your vehicle and object
	Vehicles	Approx. 10 to 180 km/h (7 to 110 mph)	Approx. 10 to 180 km/h (7 to 110 mph)
	Bicyclists and pedestrians	Approx. 10 to 80 km/h (7 to 50 mph)	Approx. 10 to 80 km/h (7 to 50 mph)

Pre-collision brake assist

Detectable objects	Vehicle speed	Relative speed between your vehicle and object
Vehicles	Approx. 30 to 180 km/h (20 to 110 mph)	Approx. 30 to 180 km/h (20 to 110 mph)
Bicyclists and pedestrians	Approx. 30 to 80 km/h (20 to 50 mph)	Approx. 30 to 80 km/h (20 to 50 mph)

Pre-collision braking

Detectable objects	Vehicle speed	Relative speed between your vehicle and object
Vehicles	Approx. 10 to 180 km/h (7 to 110 mph)	Approx. 10 to 180 km/h (7 to 110 mph)
Bicyclists and pedestrians	Approx. 10 to 80 km/h (7 to 50 mph)	Approx. 10 to 80 km/h (7 to 50 mph)

The system may not operate in the following situations:

- If a battery terminal has been disconnected and reconnected and then the vehicle has not been driven for a certain amount of time
- If the shift lever is in R
- When the VSC OFF indicator is illuminated (only the pre-collision warning function will be operational)

■ Object detection function.


The system detects objects based on their size, profile, motion, etc. However, an object may not be detected depending on the surrounding brightness and the motion, posture, and angle of the detected object, preventing the system from operating properly. (→P.190) The illustration shows an image of detectable objects.




■ Cancelation of the pre-collision braking

If either of the following occur while the pre-collision braking function is operating, it will be canceled:


- The accelerator pedal is depressed strongly.
- The steering wheel is turned sharply or abruptly.
- Conditions under which the system may operate even if there is no possibility of a collision
- In some situations such as the following, the system may determine that there is a possibility of a frontal collision and operate.
- When passing a detectable object, etc.
- When changing lanes while overtaking a detectable object, etc.
- When approaching a detectable object in an adjacent lane or on the roadside, such as when changing the course of travel or driving on a winding road




- When rapidly closing on a detectable object, etc.
- When approaching objects on the roadside, such as detectable objects, guardrails, utility poles, trees, or walls
- When there is a detectable object or other object by the roadside at the entrance of a curve




- When there are patterns or paint in front of your vehicle that may be mistaken for a detectable object
- When the front of your vehicle is hit by water, snow, dust, etc.
- When overtaking a detectable object that is changing lanes or making a right/left turn




 When passing a detectable object in an oncoming lane that is stopped to make a right/left turn



- When a detectable object approaches very close and then stops before entering the path of your vehicle
- If the front of your vehicle is raised or lowered, such as when on an uneven or undulating road surface
- When driving on a road surrounded by a structure, such as in a tunnel or on an iron bridge
- When there is a metal object (manhole cover, steel plate, etc.), steps, or a protrusion in front of your vehicle
- When passing under an object (road sign, billboard, etc.)



- When approaching an electric toll gate barrier, parking area barrier, or other barrier that opens and closes
- When using an automatic car wash
- When driving through or under objects that may contact your vehicle, such as thick grass, tree branches, or a banner




- · When driving through steam or smoke
- · When driving near an object that

- reflects radio waves, such as a large truck or quardrail
- When driving near a TV tower, broadcasting station, electric power plant, or other location where strong radio waves or electrical noise may be present


Situations in which the system may not operate properly

- In some situations such as the following, an object may not be detected by the radar sensor and front camera, preventing the system from operating properly:
- When a detectable object is approaching your vehicle
- When your vehicle or a detectable object is wobbling
- If a detectable object makes an abrupt maneuver (such as sudden swerving, acceleration or deceleration)
- When your vehicle approaches a detectable object rapidly
- When a detectable object is not directly in front of your vehicle




- When a detectable object is near a wall, fence, guardrail, manhole cover, vehicle, steel plate on the road, etc.
- When a detectable object is under a structure
- When part of a detectable object is hidden by an object, such as large baggage, an umbrella, or guardrail
 When multiple detectable objects are close together
- If the sun or other light is shining directly on a detectable object
- When a detectable object is a shade of white and looks extremely bright
- When a detectable object appears to be nearly the same color or brightness as its surroundings

- If a detectable object cuts or suddenly emerges in front of your vehicle
- When the front of your vehicle is hit by water, snow, dust, etc.
- When a very bright light ahead, such as the sun or the headlights of oncoming traffic, shines directly into the front camera
- When approaching the side or front of a vehicle ahead
- · If a vehicle ahead is a motorcycle
- If a vehicle ahead is narrow, such as a personal mobility vehicle
- If a preceding vehicle has a small rear end, such as an unloaded truck
- If a preceding vehicle has a low rear end, such as a low bed trailer




 If a vehicle ahead has extremely high ground clearance



- If a vehicle ahead is carrying a load which protrudes past its rear bumper
- If a vehicle ahead is irregularly shaped, such as a tractor or side car
- If a vehicle ahead is a child sized bicycle, a bicycle that is carrying a large load, a bicycle ridden by more than one person, or a uniquely shaped bicycle (bicycle with a child seat, tandem bicycle, etc.)
- If a pedestrian/or the riding height of a bicyclist ahead is shorter than approximately 1 m (3.2 ft.) or taller than approximately 2 m (6.5 ft.)

- If a pedestrian/bicyclist is wearing oversized clothing (a rain coat, long skirt, etc.), making their silhouette obscure
- If a pedestrian is bending forward or squatting or bicyclist is bending forward
- If a pedestrian/bicvclist is moving fast
- If a pedestrian is pushing a stroller, wheelchair, bicycle or other vehicle
- When driving in inclement weather such as heavy rain, fog, snow or a sandstorm
- · When driving through steam or smoke
- When the surrounding area is dim, such as at dawn or dusk, or while at night or in a tunnel, making a detectable object appear to be nearly the same color as its surroundings
- When driving in a place where the surrounding brightness changes suddenly, such as at the entrance or exit of a tunnel
- After the engine has started the vehicle has not been driven for a certain amount of time
- While making a left/right turn and for a few seconds after making a left/right turn
- While driving on a curve and for a few seconds after driving on a curve
- If your vehicle is skidding
- If the front of the vehicle is raised or lowered



- If the wheels are misaligned
- If a wiper blade is blocking the front camera
- The vehicle is being driven at extremely high speeds
- When driving on a hill
- If the radar sensor or front camera is misaligned
- In some situations such as the follow-

- ing, sufficient braking force may not be obtained, preventing the system from performing properly:
- If the braking functions cannot operate to their full extent, such as when the brake parts are extremely cold, extremely hot, or wet
- If the vehicle is not properly maintained (brakes or tires are excessively worn, improper tire inflation pressure, etc.)
- When the vehicle is being driven on a gravel road or other slippery surface

■ If VSC is disabled

- If VSC is disabled (→P.267), the precollision brake assist and pre-collision braking functions are also disabled.
- The PCS warning light will turn on and "VSC Turned Off Pre-Collision Brake System Unavailable" will be displayed on the multi-information display.


LTA (Lane Tracing Assist)*

: If equipped

When driving on highways and freeways with white (yellow) lane lines, this function alerts the driver when the vehicle might depart from its lane or course* and provides assistance by operating the steering wheel to keep the vehicle in its lane or course*. Furthermore, the system provides steering assistance when dynamic radar cruise control with full-speed range is operating to keep the vehicle in its lane.

The LTA system recognizes white (yellow) lane lines or a course using the front camera. Additionally, it detects preceding vehicles using the front camera and radar.

*: Boundary between asphalt and the side of the road, such as grass, soil, or a curb



WARNING

■ Before using LTA system

- Do not rely solely upon the LTA system. The LTA system does not automatically drive the vehicle or reduce the amount of attention that must be paid to the area in front of the vehicle. The driver must always assume full responsibility for driving safely by paying careful attention to the surrounding conditions and operating the steering wheel to correct the path of the vehicle. Also, the driver must take adequate breaks when fatigued, such as from driving for a long period of time.
- Failure to perform appropriate driving operations and pay careful attention may lead to an accident, resulting in death or serious injury.
- When not using the LTA system, use the LTA switch to turn the system off.

Situations unsuitable for LTA system

In the following situations, use the LTA switch to turn the system off. Failure to do so may lead to an accident, resulting in death or serious injury.


- Vehicle is driven on a road surface which is slippery due to rainy weather, fallen snow, freezing, etc.
- Vehicle is driven on a snow-covered road.
- White (yellow) lines are difficult to see due to rain, snow, fog, dust, etc.
- Vehicle is driven in a temporary lane or restricted lane due to construction work.
- Vehicle is driven in a construction zone.
- A spare tire, tire chains, etc. are equipped.



- When the tires have been excessively worn, or when the tire inflation pressure is low.
- When tires of a size other than specified are installed
- Vehicle is driven in traffic lanes. other than that highways and freewavs.
- When your vehicle is towing a trailer or during emergency towing
- * Vehicles that can tow a tailer. (→P.141)
- Preventing LTA system malfunctions and operations performed by mistake
- Do not modify the headlights or place stickers, etc. on the surface of the lights.
- Do not modify the suspension etc. If the suspension etc. needs to be replaced, contact your Toyota dealer.
- Do not install or place anything on the hood or grille. Also, do not install a grille guard (bull bars, kangaroo bar, etc.).
- If your windshield needs repairs. contact your Toyota dealer.
- Conditions in which functions may not operate properly

In the following situations, the functions may not operate properly and the vehicle may depart from its lane. Drive safely by always paying careful attention to your surroundings and operate the steering wheel to correct the path of the vehicle without relying solely on the functions.


When the follow-up cruising display is displayed (-P.197) and the preceding vehicle changes lanes. Your vehicle may follow the preceding vehicle and also change lanes.)




- When the follow-up cruising display is displayed (>P.197) and the preceding vehicle is swaving. (Your vehicle may sway accordingly and depart from the lane.)
- When the follow-up cruising display is displayed (→P.197) and the preceding vehicle departs from its lane. (Your vehicle may follow the preceding vehicle and depart from the lane.)
- When the follow-up cruising display is displayed (→P.197) and the preceding vehicle is being driven extremely close to the left/right lane line. (Your vehicle may follow the preceding vehicle and depart from the lane.)
- Vehicle is being driven around a sharp curve.




 Objects or patterns that could be mistaken for white (yellow) lines are present on the side of the road (guardrails, curbs, reflective poles, etc.).



 Vehicle is driven where the road diverges, merges, etc.



 Repair marks of asphalt, white (yellow) lines, etc. are present due to road repair.



 There are shadows on the road that run parallel with, or cover, the white (yellow) lines.

- The vehicle is driven in an area without white (yellow) lines, such as in front of a tollgate or checkpoint, or at an intersection, etc.
- The white (yellow) lines are cracked, "Raised pavement marker" or stones are present.
- The white (yellow) lines cannot be seen or are difficult to see due to sand, etc.
- The vehicle is driven on a road sur face that is wet due to rain, puddles, etc.
- The traffic lines are yellow (which may be more difficult to recognize than lines that are white).
- The white (yellow) lines cross over a curb, etc.
- The vehicle is driven on a bright surface, such as concrete.
- If the edge of the road is not clear or straight.
- The vehicle is driven on a surface that is bright due to reflected light, etc.
- The vehicle is driven in an area where the brightness changes suddenly, such as at the entrances and exits of tunnels, etc.
- Light from the headlights of an oncoming vehicle, the sun, etc. enters the camera.
- The vehicle is driven on a slope.
- The vehicle is driven on a road which tilts left or right, or a winding road.
- The vehicle is driven on an unpaved or rough road.
- The traffic lane is excessively narrow or wide.



- The vehicle is extremely tilted due to carrying heavy luggage or having improper tire pressure.
- The distance to the preceding vehicle is extremely short.
- The vehicle is moving up and down a large amount due to road conditions during driving (poor roads or road seams).
- When driving in a tunnel or at night with the headlights off or when a headlight is dim due to its lens being dirty or it being misaligned.
- The vehicle is struck by a crosswind
- The vehicle is affected by wind from a vehicle driven in a nearby lane.
- The vehicle has just changed lanes or crossed an intersection.
- Tires which differ by structure, manufacturer, brand or tread pattern are used.
- Snow tires, etc. are equipped.
- The vehicle is being driven at extremely high speeds.

Functions included in LTA system

■ Lane departure alert function


When the system determines that the vehicle might depart from its lane or course*, a warning is displayed on the multi-information display, and a warning buzzer will sound to alert the driver.

When the warning buzzer sounds, check the area around your vehicle and carefully operate the steering wheel to

move the vehicle back to the center of the lane

Vehicles with Blind Spot Monitor: When the system determines that the vehicle might depart from its lane and that the possibility of a collision with an overtaking vehicle in the adjacent lane is high, the lane departure alert will operate even if the turn signals are operating.

*: Boundary between asphalt and the side of the road, such as grass, soil, or a curb



■ Steering assist function


When the system determines that the vehicle might depart from its lane or course*, the system provides assistance as necessary by operating the steering wheel in small amounts for a short period of time to keep the vehicle in its lane.

If the system detects that the steering wheel has not been operated for a fixed amount of time or the steering wheel is

not being firmly gripped, a warning is displayed on the multi-information display and the function is temporarily canceled.


Vehicles with Blind Spot Monitor: When the system determines that the vehicle might depart from its lane and that the possibility of a collision with an overtaking vehicle in the adjacent lane is high, the steering assist function will operate even if the turn signals are operating.

*: Boundary between asphalt and the side of the road, such as grass, soil, or a curb



Vehicle sway warning function

When the vehicle is swaying within a lane, the warning buzzer will sound and a message will be displayed on the multi-information display to alert the driver.



■ Lane centering function


This function is linked with dynamic radar cruise control with full-speed range and provides the required assistance by operating the steering wheel to keep the vehicle in its current lane.

When dynamic radar cruise control with full-speed range is not operating, the lane centering function does not operate.

In situations where the white (yellow) lane lines are difficult to see or are not visible, such as when in a traffic jam, this function will operate to help follow a preceding vehicle by monitoring the position of the preceding vehicle.

If the system detects that the steering wheel has not been operated for a fixed amount of time or the steering wheel is not being firmly gripped, a warning is displayed on the multi-information display and the function is temporarily

canceled.




Turning LTA system on

Press the LTA switch to turn the LTA system on.


The LTA indicator illuminates and a message is displayed on the multi-information display.

Press the LTA switch again to turn the LTA system off.

When the LTA system is turned on or off, operation of the LTA system continues in the same condition the next time the engine is started.



Indications on multi-information display



A LTA indicator

The illumination condition of the indicator informs the driver of the system operation status.

Illuminated in white: LTA system is operating.

Illuminated in green: Steering wheel assistance of the steering assist function or lane centering function is operating.

Flashing in orange: Lane departure alert function is operating.

B Operation display of steering wheel operation support

Displayed when the multi-information display is switched to the driving support system information display.

Indicates that steering wheel assistance of the steering assist function or

lane centering function is operating. Both outer sides of the lane are displayed: Indicates that steering wheel assist of the lane centering function is operating.

One outer side of the lane is displayed: Indicates that steering wheel assist of the steering assist function is operating. Both outer sides of the lane are flashing: Alerts the driver that their input is necessary to stay in the center of the lane (lane centering function).

C Follow-up cruising display
Displayed when the multi-information
display is switched to the driving support system information display.
Indicates that steering assist of the lane
centering function is operating by monitoring the position of a preceding vehicle.

When the follow-up cruising display is displayed, if the preceding vehicle moves, your vehicle may move in the same way. Always pay careful attention to your surroundings and operate the steering wheel as necessary to correct the path of the vehicle and ensure safety.

D Lane departure alert function display


Displayed when the multi-information display is switched to the driving support system information display.

Inside of displayed lines is white



Indicates that the system is recognizing white (yellow) lines or a course*. When the vehicle departs from its lane, the white line displayed on the side the vehicle departs from flashes orange.

Inside of displayed lines is black



Indicates that the system is not able to recognize white (yellow) lines or a course* or is temporarily canceled.

*: Boundary between asphalt and the side of the road, such as grass, soil, or a curb

■ Operation conditions of each function

Lane departure alert function This function operates when all of the following conditions are met.

- LTA is turned on.
- Vehicle speed is approximately 50 km/h (32 mph) or more.*1
- System recognizes white (yellow) lane

- lines or a course^{*2}. (When a white [yellow] line or course^{*2} is recognized on only one side, the system will operate only for the recognized side.)
- Width of traffic lane is approximately 3 m (9.8 ft.) or more.
- Turn signal lever is not operated. (Vehicles with Blind Spot Monitor: Except when another vehicle is in the lane on the side where the turn signal was operated)
- Vehicle is not being driven around a sharp curve.
- No system malfunctions are detected. (→P.201)
- *1: The function operates even if the vehicle speed is less than approximately 50 km/h (32 mph) when the lane centering function is operating.
- *2: Boundary between asphalt and the side of the road, such as grass, soil, or a curb
- Steering assist function

This function operates when all of the following conditions are met in addition to the operation conditions for the lane departure alert function.

- Setting for "Steering Assist" in the screen of the multi-information display is set to "ON". (→P.70)
- Vehicle is not accelerated or decelerated by a fixed amount or more.
- Steering wheel is not operated with a steering force level suitable for changing lanes.
- ABS, VSC, TRC and PCS are not operating.
- TRC or VSC is not turned off.

following conditions are met.

- Hands off steering wheel warning is not displayed. (→P.200)
- Vehicle sway warning functionThis function operates when all of the

- Vehicle speed is approximately 50 km/h (32 mph) or more.
- Width of traffic lane is approximately 3 m (9.8 ft.) or more.
- No system malfunctions are detected. (→P.201)
- Lane centering function

This function operates when all of the following conditions are met.

- · LTA is turned on.
- Setting for "Steering Assist" and "Lane Center" in the screen of the multiinformation display are set to "ON". (→P.70)
- This function recognizes white (yellow) lane lines of the position of a preceding vehicle (except when the preceding vehicle is small, such as a motorcycle).
- The dynamic radar cruise control with full-speed range is operating in vehicle-to-vehicle distance control mode.
- Width of traffic lane is approximately 3 to 4 m (10 to 13 ft.).
- Turn signal lever is not operated.
 Vehicle is not being driven around a sharp curve.
- No system malfunctions are detected. (→P.201)
- Vehicle does not accelerate or decelerate by a fixed amount or more.
- Steering wheel is not operated with a steering force level suitable for changing lanes.
- ABS, VSC, TRC and PCS are not operating.
- TRC or VSC is not turned off.
- Hands off steering wheel warning is not displayed. (→P.200)
- The vehicle is being driven in the center of a lane.
- Steering assist function is not operating.

■ Temporary cancelation of functions

When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. (→P.198)

• If the operation conditions (→P.198) are no longer met while the lane centering function is operating, the buzzer may sound to indicate that the function has been temporarily canceled.

Steering assist function/lane centering function

- Depending on the vehicle speed, lane departure situation, road conditions, etc., the driver may not feel the function is operating or the function may not operate at all.
- The steering control of the function is overridden by the driver's steering wheel operation.
- Do not attempt to test the operation of the steering assist function.

■ Lane departure alert function

- The warning buzzer may be difficult to hear due to external noise, audio playback, etc.
- If the edge of the course^{*} is not clear or straight, the lane departure alert function may not operate.
- Vehicles with Blind Spot Monitor: It may not be possible for the system to determine if there is a danger of a collision with a vehicle in an adjacent lane.
- Do not attempt to test the operation of the lane departure alert function.
- *: Boundary between asphalt and the side of the road, such as grass, soil, or a curb

Hands off steering wheel warning

In the following situations, a warning message urging the driver to hold the steering wheel and the symbol shown in the illustration are displayed on the multi-information display to warn the driver. The warning stops when the system determines that the driver holds the steering wheel. Always keep your hands on the steering wheel when using this system, regardless of warnings.



 When the system determines that the driver is driving without holding the steering wheel while the system is operating

If the driver continues to keep their hands off of the steering wheel, the buzzer sounds, the driver is warned and the function is temporarily canceled. This warning also operates in the same way when the driver continuously operates the steering wheel only a small amount.

When the system determines that the vehicle may not turn and instead depart from its lane while driving around a curve

Depending on the vehicle condition and road conditions, the warning may not operate. Also, if the system determines that the vehicle is driving around a curve, warnings will occur earlier than during straight-lane driving.

• When the system determines that the driver is driving without holding the steering wheel while the steering wheel assist of the steering assist function is operating.

If the driver continues to keep their hands off of the steering wheel and the steering wheel assist is operating, the buzzer sounds and the driver is warned. Each time the buzzer sounds, the continuing time of the buzzer becomes longer.

■ Vehicle sway warning function

When the system determines that the vehicle is swaying while the vehicle

sway warning function is operating, a buzzer sounds and a warning message urging the driver to rest and the symbol shown in the illustration are simultaneously displayed on the multi-information display.



Depending on the vehicle and road conditions, the warning may not operate.

■ Warning message

If the following warning message is displayed on the multi-information display and the LTA indicator illuminates in orange, follow the appropriate trouble-shooting procedure. Also, if a different warning message is displayed, follow the instructions displayed on the screen.

"LTA Malfunction Visit Your Dealer" The system may not be operating properly. Have the vehicle inspected by your Toyota dealer.

"LTA Unavailable"

The system is temporarily canceled due to a malfunction in a sensor other than the front camera. Turn the LTA system off, wait for a little while, and then turn the LTA system back on.

"LTA Unavailable at Current Speed" The function cannot be used as the vehicle speed exceeds the LTA operation range. Drive slower.

■ Customization

Function settings can be changed. $(\rightarrow P.75)$


LDA (Lane Departure Alert with steering control)^{*}

: If equipped

When driving on highways and freeways with white (yellow) lane lines, this function alerts the driver when the vehicle might depart from its lane or course* and provides assistance by operating the steering wheel to keep the vehicle in its lane or course*.

The LDA system recognizes white (yellow) lane lines or a course using the front camera. Additionally, it detects preceding vehicles using the front camera and radar.

*: Boundary between asphalt and the side of the road, such as grass, soil, or a curb



A

WARNING

■ Before using LDA system

- Do not rely solely upon the LDA system. The LDA system does not automatically drive the vehicle or reduce the amount of attention that must be paid to the area in front of the vehicle. The driver must always assume full responsibility for driving safely by paying careful attention to the surrounding conditions and operating the steering wheel to correct the path of the vehicle. Also, the driver must take adequate breaks when fatigued, such as from driving for a long period of time.
- Failure to perform appropriate driving operations and pay careful attention may lead to an accident, resulting in death or serious injury.
- When not using the LDA system, use the LDA switch to turn the system off
- Situations unsuitable for LDA system

In the following situations, use the LDA switch to turn the system off. Failure to do so may lead to an accident, resulting in death or serious injury.

- Vehicle is driven on a road surface which is slippery due to rainy weather, fallen snow, freezing, etc.
- Vehicle is driven on a snow-covered road.
- White (yellow) lines are difficult to see due to rain, snow, fog, dust, etc.
- A spare tire, tire chains, etc. are equipped.
- When the tires have been excessively worn, or when the tire inflation pressure is low.


- When tires of a size other than specified are installed.
- Vehicle is driven in traffic lanes other than that highways and freeways.
- When your vehicle is towing a trailer or during emergency towing
 *: Vehicles that can tow a tailer.
 (→P.141)
- Preventing LDA system malfunctions and operations performed by mistake
- Do not modify the headlights or place stickers, etc. on the surface of the lights.
- Do not modify the suspension etc. If the suspension etc. needs to be replaced, contact your Toyota dealer.
- Do not install or place anything on the hood or grille. Also, do not install a grille guard (bull bars, kangaroo bar, etc.).
- If your windshield needs repairs, contact your Toyota dealer.
- Conditions in which functions may not operate properly

In the following situations, the functions may not operate properly and the vehicle may depart from its lane. Drive safely by always paying careful attention to your surroundings and operate the steering wheel to correct the path of the vehicle without relying solely on the functions.


 Vehicle is being driven around a sharp curve.




Objects or patterns that could be mistaken for white (vellow) lines are present on the side of the road quardrails, curbs, reflective poles. etc.).



Vehicle is driven where the road. diverges, merges, etc.



Repair marks of asphalt, white (yellow) lines, etc. are present due to road repair.



There are shadows on the road that run parallel with, or cover, the white (yellow) lines.

- The vehicle is driven in an area without white (vellow) lines, such as in front of a tollgate or checkpoint. or at an intersection, etc.
- The white (vellow) lines are cracked, "Raised pavement marker" or stones are present.
- The white (vellow) lines cannot be. seen or are difficult to see due to sand, etc.
- The vehicle is driven on a road sur face that is wet due to rain, puddles, etc.
- The traffic lines are vellow (which may be more difficult to recognize than lines that are white).
- The white (yellow) lines cross over a curb, etc.
- The vehicle is driven on a bright surface, such as concrete.
- If the edge of the road is not clear or straight.
- The vehicle is driven on a surface that is bright due to reflected light. etc.
- The vehicle is driven in an area. where the brightness changes suddenly, such as at the entrances and exits of tunnels, etc.
- Light from the headlights of an oncoming vehicle, the sun, etc. enters the camera.
- The vehicle is driven on a slope.
- The vehicle is driven on a road which tilts left or right, or a winding road.
- The vehicle is driven on an unpaved or rough road.
- The traffic lane is excessively narrow or wide.

A

WARNING

- The vehicle is extremely tilted due to carrying heavy luggage or having improper tire pressure.
- The distance to the preceding vehicle is extremely short.
- The vehicle is moving up and down a large amount due to road conditions during driving (poor roads or road seams).
- When driving in a tunnel or at night with the headlights off or when a headlight is dim due to its lens being dirty or it being misaligned.
- The vehicle is struck by a crosswind.
- The vehicle has just changed lanes or crossed an intersection.
- Tires which differ by structure, manufacturer, brand or tread pattern are used.
- Snow tires, etc. are equipped.

Functions included in LDA system

■ Lane departure alert function


When the system determines that the vehicle might depart from its lane or course*, a warning is displayed on the multi-information display, and a warning buzzer will sound to alert the driver.

When the warning buzzer sounds, check the area around your vehicle and carefully operate the steering wheel to move the vehicle back to the center of the lane.

Vehicles with Blind Spot Monitor: When the system determines that the vehicle

might depart from its lane and that the possibility of a collision with an overtaking vehicle in the adjacent lane is high, the lane departure alert will operate even if the turn signals are operating.

*: Boundary between asphalt and the side of the road, such as grass, soil, or a curb




■ Steering assist function

When the system determines that the vehicle might depart from its lane or course*, the system provides assistance as necessary by operating the steering wheel in small amounts for a short period of time to keep the vehicle in its lane.

If the system detects that the steering wheel has not been operated for a fixed amount of time or the steering wheel is not being firmly gripped, a warning is displayed on the multi-information display and the function is temporarily canceled.


Vehicles with Blind Spot Monitor: When the system determines that the vehicle might depart from its lane and that the possibility of a collision with an overtaking vehicle in the adjacent lane is high, the steering assist function will operate even if the turn signals are operating.

*: Boundary between asphalt and the side of the road, such as grass, soil, or a curb



■ Vehicle sway warning function

When the vehicle is swaying within a lane, the warning buzzer will sound and a message will be displayed on the multi-information display to alert the driver.




Turning LDA system on

Press the LDA switch to turn the LDA system on.


The LDA indicator illuminates and a message is displayed on the multi-information display.

Press the LDA switch again to turn the LDA system off.

When the LDA system is turned on or off, operation of the LDA system continues in the same condition the next time the engine is started.



Indications on multi-information display



A LDA indicator

The illumination condition of the indicator informs the driver of the system operation status.

Illuminated in white: LDA system is operating.

Illuminated in green: Steering wheel assistance of the steering assist function is operating.

Flashing in orange: Lane departure alert function is operating.

B Operation display of steering wheel operation support

Displayed when the multi-information display is switched to the driving support system information display.

Indicates that steering wheel assistance of the steering assist function is operating.

C Lane departure alert function display

Displayed when the multi-information display is switched to the driving support system information display.

Inside of displayed lines is white



Indicates that the system is recognizing white (yellow) lines or a course*. When the vehicle departs from its lane, the white line displayed on the side the vehicle departs from flashes orange.

Inside of displayed lines is black



Indicates that the system is not able to recognize white (yellow) lines or a course* or is temporarily canceled.

*: Boundary between asphalt and the side of the road, such as grass, soil, or a curb

■ Operation conditions of each function

Lane departure alert function This function operates when all of the following conditions are met.

- · LDA is turned on.
- Vehicle speed is approximately 50 km/h (32 mph) or more.
- System recognizes white (yellow) lane

lines or a course*. (When a white [yellow] line or course* is recognized on only one side, the system will operate only for the recognized side.)

- Width of traffic lane is approximately 3 m (9.8 ft.) or more.
- Turn signal lever is not operated. (Vehicles with Blind Spot Monitor: Except when another vehicle is in the lane on the side where the turn signal was operated)
- Vehicle is not being driven around a sharp curve.
- No system malfunctions are detected. (→P.208)
- *: Boundary between asphalt and the side of the road, such as grass, soil, or a curb

Steering assist function

This function operates when all of the following conditions are met in addition to the operation conditions for the lane departure alert function.

- Setting for "Steering Assist" in the screen of the multi-information display is set to "ON". (→P.70)
- Vehicle is not accelerated or decelerated by a fixed amount or more.
- Steering wheel is not operated with a steering force level suitable for changing lanes.
- ABS, VSC, TRC and PCS are not operating.
- TRC or VSC is not turned off.
- Hands off steering wheel warning is not displayed. (→P.207)
- Vehicle sway warning function
 This function operates when all of the following conditions are met.
- Setting for "Sway Warning" in the screen of the multi-information display is set to "ON". (→P.70)
- Vehicle speed is approximately 50 km/h (32 mph) or more.
- Width of traffic lane is approximately 3 m (9.8 ft.) or more.
- No system malfunctions are detected. (→P.208)

■ Temporary cancelation of functions

When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. (→P.206)

■ Steering assist function

- Depending on the vehicle speed, lane departure situation, road conditions, etc., the driver may not feel the function is operating or the function may not operate at all.
- The steering control of the function is overridden by the driver's steering wheel operation.
- Do not attempt to test the operation of the steering assist function.

■ Lane departure alert function

- The warning buzzer may be difficult to hear due to external noise, audio playback, etc.
- If the edge of the course* is not clear or straight, the lane departure alert function may not operate.
- Vehicles with Blind Spot Monitor: It may not be possible for the system to determine if there is a danger of a collision with a vehicle in an adjacent lane.
- Do not attempt to test the operation of the lane departure alert function.
- *: Boundary between asphalt and the side of the road, such as grass, soil, or a curb

■ Hands off steering wheel warning

In the following situations, a warning message urging the driver to hold the steering wheel and the symbol shown in the illustration are displayed on the multi-information display to warn the driver. The warning stops when the system determines that the driver holds the steering wheel. Always keep your hands on the steering wheel when using this system, regardless of warnings.



 When the system determines that the driver is driving without holding the steering wheel while the system is operating

If the driver continues to keep their hands off of the steering wheel, the buzzer sounds, the driver is warned and the function is temporarily canceled. This warning also operates in the same way when the driver continuously operates the steering wheel only a small amount.

 When the system determines that the vehicle may not turn and instead depart from its lane while driving around a curve

Depending on the vehicle condition and road conditions, the warning may not operate. Also, if the system determines that the vehicle is driving around a curve, warnings will occur earlier than during straight-lane driving.

• When the system determines that the driver is driving without holding the steering wheel while the steering wheel assist of the steering assist function is operating.

If the driver continues to keep their hands off of the steering wheel and the steering wheel assist is operating, the buzzer sounds and the driver is warned. Each time the buzzer sounds, the continuing time of the buzzer becomes longer.

■ Vehicle sway warning function

When the system determines that the vehicle is swaying while the vehicle

sway warning function is operating, a buzzer sounds and a warning message urging the driver to rest and the symbol shown in the illustration are simultaneously displayed on the multi-information display.



Depending on the vehicle and road conditions, the warning may not operate.

■ Warning message

If the following warning message is displayed on the multi-information display and the LDA indicator illuminates in orange, follow the appropriate trouble-shooting procedure. Also, if a different warning message is displayed, follow the instructions displayed on the screen.

"LDA Malfunction Visit Your Dealer"
The system may not be operating properly. Have the vehicle inspected by your Toyota dealer.

"LDA Unavailable"

The system is temporarily canceled due to a malfunction in a sensor other than the front camera. Turn the LDA system off, wait for a little while, and then turn the LDA system back on.

- "LDA Unavailable at Current Speed" The function cannot be used as the vehicle speed exceeds the LDA operation range. Drive slower.
- "LDA Unavailable Below Approx. 50km/h"

The LDA system cannot be used as the vehicle speed is less than approximately 50 km/h (32 mph). Drive the vehicle at approximately 50 km/h (32 mph) or

more


■ Customization

Function settings can be changed. (→P.75)

RSA (Road Sign Assist)

*: If equipped

The RSA system recognizes specific road signs using the front camera to provide information to the driver via the display.



If the system judges that the vehicle is being driven over the speed limit in relation to the recognized road signs, it alerts the driver using a warning display and warning buzzer.




WARNING

Before using the RSA

Do not rely solely upon the RSA system. RSA is a system which supports the driver by providing information, but it is not a replacement for a driver's own vision and awareness. Drive safely by always paying careful attention to the traffic rules.

Indication on the multi-information display

When the front camera recognizes a sign, the sign will be displayed on the multi-information display.



Supported types of road signs

The following types of road signs, including electronic signs and blinking signs, are recognized.

A non-official or a recently introduced traffic sign may not be recognized.



Speed limit

Warning display

In the following situations, the RSA system will alert the driver.

 When the vehicle speed exceeds the speed warning threshold of the speed limit sign displayed, the sign display will be emphasized and a buzzer will sound.

Depending on the situation, traffic environment (traffic direction, speed unit) may be detected incorrectly and a warning display may not operate properly.

■ Setting procedure

→P.75

■ Automatic turn-off of RSA sign display

In the following situations, a displayed speed limit sign will stop being displayed automatically:

- A new sign is not recognized for a certain distance
- The road changes due to a left or right turn, etc.

Conditions in which the function may not operate or detect correctly

In the following situations, RSA does not operate normally and may not recognize signs, display the incorrect sign, etc. However, this does not indicate a malfunction

- The front camera is misaligned due to a strong impact being applied to the sensor, etc.
- Dirt, snow, stickers, etc. are on the windshield near the front camera.
- In inclement weather such as heavy rain, fog, snow or sand storms
- Light from an oncoming vehicle, the sun, etc. enters the front camera.
- The sign is dirty, faded, tilted or bent, and if an electronic sign, the contrast is poor.
- All or part of the sign is hidden by the leaves of a tree, a pole, etc.
- The sign is only visible to the front camera for a short amount of time.
- The driving scene (turning, lane change, etc.) is judged incorrectly.
- Even if it is a sign not appropriate for the currently traveled lane, such a sign exists directly after a freeway branches, or in an adjacent lane just before merging.
- Stickers are attached to the rear of the preceding vehicle.
- A sign resembling a system compatible sign is recognized.
- Side road speed signs may be detected and displayed (if positioned in sight of the front camera) while the

vehicle is traveling on the main road.

- Roundabout exit road speed signs may be detected and displayed (if positioned in sight of the front camera) while traveling on a roundabout.
- The front of the vehicle is raised or lowered due to the carried load
- The surrounding brightness is not sufficient or changes suddenly.
- When a sign intended for trucks, etc. is recognized.

■ Speed limit sign display

If the engine switch was last turned to OFF while a speed limit sign was displayed on the multi-information display, the same sign displays again when the engine switch is turned to ON.

■ If "RSA Malfunction Visit Your Dealer" is shown

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

Customization

Some functions can be customized. $(\rightarrow P.75)$

Dynamic radar cruise control with full-speed range*

: If equipped


In vehicle-to-vehicle distance control mode, the vehicle automatically accelerates, decelerates and stops to match the speed changes of the preceding vehicle even if the accelerator pedal is not depressed. In constant speed control mode, the vehicle runs at a fixed speed.

Use the dynamic radar cruise control with full-speed range on freeways and highways.

- Vehicle-to-vehicle distance control mode (→P.214)
- Constant speed control mode (→P.218)

System Components


■ Meter display



- A Multi-information display
- B Set speed

C Indicators

■ Operation switches



- A Vehicle-to-vehicle distance switch
- B "+RES" switch
- Cruise control main switch
- D Cancel switch
- E "-SET" switch



WARNING

- Before using dynamic radar cruise control with full-speed range
- Driving safely is the sole responsibility of the driver. Do not rely solely on the system, and drive safely by always paying careful attention to your surroundings.
- The dynamic radar cruise control with full-speed range provides driving assistance to reduce the driver's burden. However, there are limitations to the assistance provided.

Read the following conditions carefully. Do not overly rely on this system and always drive carefully.

When the sensor may not be correctly detecting the vehicle ahead:
 →P.221

- Conditions under which the vehicleto-vehicle distance control mode may not function correctly: →P.221
- Set the speed appropriately depending on the speed limit, traffic flow, road conditions, weather conditions, etc. The driver is responsible for checking the set speed.
- Even when the system is functioning normally, the condition of the preceding vehicle as detected by the system may differ from the condition observed by the driver.

 Therefore, the driver must always remain alert, assess the danger of each situation and drive safely. Relying solely on this system or assuming the system ensures safety while driving can lead to an accident, resulting in death or serious injury.
- Switch the dynamic radar cruise control with full-speed range setting to off, using the cruise control main switch when not in use.



Cautions regarding the driving assist systems

Observe the following precautions, as there are limitations to the assistance provided by the system. Failure to do so may cause an accident resulting in death or serious injury.

Assisting the driver to measure following distance

The dynamic radar cruise control with full-speed range is only intended to help the driver in determining the following distance between the driver's own vehicle and a designated vehicle traveling ahead. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions

It is still necessary for driver to pay close attention to the vehicle's surroundinas.

 Assisting the driver to judge proper following distance

The dynamic radar cruise control with full-speed range determines whether the following distance between the driver's own vehicle and a designated vehicle traveling ahead is within a set range. It is not capable of making any other type of judgement. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger in any given situation.

Assisting the driver to operate the vehicle

The dynamic radar cruise control with full-speed range does not include functions which will prevent or avoid collisions with vehicles ahead of your vehicle. Therefore, if there is ever any possibility of danger, the driver must. take immediate and direct control of the vehicle and act appropriately in order to ensure the safety of all involved

Situations unsuitable for dynamic radar cruise control with full-speed range

Do not use dynamic radar cruise control with full-speed range in any of the following situations. Doing so may result in inappropriate speed control and could cause an accident resulting in death or serious injury.

- Roads where there are pedestrians. cvclists, etc.
- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slipperv roads, such as those covered with rain, ice or snow
- On steep downhills, or where there are sudden changes between sharp up and down gradients

Vehicle speed may exceed the set speed when driving down a steep hill.

- At entrances to freeways and highways
- When weather conditions are bad enough that they may prevent the sensors from detecting correctly (fog. snow, sandstorm, heavy rain, etc.)

A


WARNING

- When there is rain, snow, etc. on the front surface of the radar or front camera
- In traffic conditions that require frequent repeated acceleration and deceleration
- When your vehicle is towing a trailer or during emergency towing
- *: Vehicles that can tow a tailer. (→P.141)
- When an approach warning buzzer is heard often

Driving in vehicle-to-vehicle distance control mode

This mode employs a radar to detect the presence of vehicles up to approximately 100 m (328 ft.) ahead, determines the current vehicle-to-vehicle following distance, and operates to maintain a suitable following distance from the vehicle ahead. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance switch.

When driving on downhill slopes, the vehicle-to-vehicle distance may become shorter.



A Example of constant speed cruising When there are no vehicles ahead

The vehicle travels at the speed set by the driver.

B Example of deceleration cruising and follow-up cruising

When a preceding vehicle driving slower than the set speed appears

When a vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes (the stop lights will come on at this time). The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. Approach warning warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.

When the vehicle ahead of you stops, your vehicle will also stop (vehicle is stopped by system control). After the vehicle ahead starts off, pressing the "+RES" switch or depressing the accelerator pedal (start-off operation) will resume follow-up cruising. If the start-off operation is not performed, system control continues to keep your vehicle stopped.

When the turn signal lever is operated and your vehicle moves to a right lane while driving at 80 km/h (50 mph) or more, the vehicle will quickly accelerate to help to overtake a passing vehicle.

C Example of acceleration

When there are no longer any preceding vehicles driving slower than the set speed


The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Setting the vehicle speed (vehicle-to-vehicle distance control mode)

 Press the cruise control main switch to activate the cruise control.

Dynamic radar cruise control indicator will come on and a message will be displayed on the multi-information display. Press the switch again to deactivate the cruise control.

If the cruise control main switch is pressed and held for 1.5 seconds or more, the system turns on in constant speed control mode. (→P.218)




2 Accelerate or decelerate, with accelerator pedal operation, to the desired vehicle speed (at or above approximately 30 km/h [20 mph]) and press the "-SET" switch to set the speed.

Cruise control "SET" indicator will come


on.

The vehicle speed at the moment the switch is released becomes the set speed.



Adjusting the set speed

To change the set speed, press the "+RES" or "-SET" switch until the desired set speed is displayed.



- 1 Increases the speed (Except when the vehicle has been stopped by system control in vehicle-to-vehicle distance control mode)
- Decreases the speed

Fine adjustment: Press the switch.

Large adjustment: Press and hold the switch to change the speed, and release when the desired speed is reached.

In the vehicle-to-vehicle distance control mode, the set speed will be

increased or decreased as follows:

Fine adjustment: By 1 km/h $(0.6 \text{ mph})^{*1}$ or 1 mph $(1.6 \text{ km/h})^{*2}$ each time the switch is pressed

Large adjustment: Increases or decreases in 5 km/h (3.1 mph)^{*1} or 5 mph (8 km/h)^{*2} increments for as long as the switch is held

In the constant speed control mode (→P.218), the set speed will be increased or decreased as follows:


Fine adjustment: By 1 km/h (0.6 mph)^{*1} or 1 mph (1.6 km/h)^{*2} each time the switch is pressed

Large adjustment: The speed will continue to change while the switch is held.

- *1: When the set speed is shown in "km/h"
- *2: When the set speed is shown in "MPH"

Changing the vehicle-tovehicle distance (vehicle-tovehicle distance control mode)

Pressing the switch changes the vehicle-to-vehicle distance as follows:



- 1 Long
- Medium
- 3 Short

The vehicle-to-vehicle distance is set automatically to long mode when the engine switch is turned to ON.

If a vehicle is running ahead of you, the preceding vehicle mark A will also be displayed.


Vehicle-to-vehicle distance settings (vehicle-to-vehicle distance control mode)

Select a distance from the table below. Note that the distances shown correspond to a vehicle speed of 80 km/h (50 mph). Vehicle-to-vehicle distance increases/decreases in accordance with vehicle speed. When the vehicle is stopped by system control, the vehicle stops at a certain vehicle-to-vehicle distance depending on the situation.


Distance options	Vehicle-to-vehicle distance
Long	Approximately 50 m (160 ft.)
Medium	Approximately 40 m (130 ft.)
Short	Approximately 30 m (100 ft.)

Resuming follow-up cruising when the vehicle has been stopped by system control (vehicle-to-vehicle distance control mode)

After the vehicle ahead of you starts off, press the "+RES" switch. Your vehicle will also resume follow-up cruising if the accelerator pedal is depressed after the vehicle ahead of you starts off.



Canceling and resuming the speed control



 Pressing the cancel switch cancels the speed control.


The speed control is also canceled when the brake pedal is depressed. (When the vehicle has been stopped by system control, depressing the brake

pedal does not cancel the setting.)

Pressing the "+RES" switch resumes the cruise control and returns vehicle speed to the set speed.

Approach warning (vehicleto-vehicle distance control mode)

When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Depress the brake pedal to ensure an appropriate vehicle-to-vehicle distance.



- Warnings may not occur when
- In the following instances, warnings may not occur even when the vehicle-to-vehicle distance is small.
- When the speed of the preceding vehicle matches or exceeds your vehicle speed
- When the preceding vehicle is traveling at an extremely slow

- speed
- Immediately after the cruise control speed was set
- When depressing the accelerator pedal


Selecting constant speed control mode

When constant speed control mode is selected, your vehicle will maintain a set speed without controlling the vehicle-to-vehicle distance. Select this mode only when vehicle-to-vehicle distance control mode does not function correctly due to a dirty radar, etc.

With the cruise control off, press and hold the cruise control main switch for 1.5 seconds or more.

Immediately after the switch is pressed, the dynamic radar cruise control indicator will come on. Afterwards, it switches to the cruise control indicator.

Switching to constant speed control mode is only possible when operating the switch with the cruise control off.




2 Accelerate or decelerate, with accelerator pedal operation, to the desired vehicle speed (at or above approximately 30 km/h [20 mph]) and press the "-SET" switch to set the speed.

Cruise control "SET" indicator will come on

The vehicle speed at the moment the switch is released becomes the set speed.

Adjusting the speed setting: \rightarrow P.216 Canceling and resuming the speed setting: \rightarrow P.217




Dynamic Radar Cruise Control with Road Sign Assist (vehicles with RSA)

When this function is enabled and the system is operating in vehicle-to-vehicle distance control mode (→P.214), when a speed limit sign is detected, the recognized speed limit will be displayed with an up/down arrow. The set speed can be increased/reduced to the recognized speed limit by pressing and holding the "+RES"/"-SET" switch.


When the current set speed is lower than the recognized speed limit

Press and hold the "+RES" switch.



 When the current set speed is higher than the recognized speed limit

Press and hold the "-SET" switch.



Enabling/Disabling the Dynamic Radar Cruise Control with Road Sign Assist (vehicles with RSA)

Dynamic Radar Cruise Control with Road Sign Assist can be enabled/disabled in the \bigcirc screen on the multi-information display. (\rightarrow P.75)

- Dynamic radar cruise control with full-speed range can be set when
- The shift lever is in D.
- The desired set speed can be set when the vehicle speed is approximately 30 km/h (20 mph) or more. (However, when the vehicle speed is

set while driving at below approximately 30 km/h [20 mph], the set speed will be set to approximately 30 km/h [20 mph].)

Accelerating after setting the vehicle speed

The vehicle can accelerate by operating the accelerator pedal. After accelerating, the set speed resumes. However, during vehicle-to-vehicle distance control mode, the vehicle speed may decrease below the set speed in order to maintain the distance to the preceding vehicle

■ When the vehicle stops while follow-up cruising

- Pressing the "+RES" switch while the vehicle ahead stops will resume follow-up cruising if the vehicle ahead starts off within approximately 3 seconds after the switch is pressed.
- If the vehicle ahead starts off within 3 seconds after your vehicle stops, follow-up cruising will be resumed.

Automatic cancelation of vehicleto-vehicle distance control mode

Vehicle-to-vehicle distance control mode is automatically canceled in the following situations.

- VSC is activated.
- TRC is activated for a period of time.
- When the VSC or TRC system is turned off
- The sensor cannot detect correctly because it is covered in some way.
- Pre-collision braking is activated.
- The parking brake is operated.
- The vehicle is stopped by system control on a steep incline.
- The following are detected when the vehicle has been stopped by system control:
- The driver is not wearing a seat belt.
- The driver's door is opened.
- The vehicle has been stopped for about 3 minutes

If vehicle-to-vehicle distance control mode is automatically canceled for any reasons other than the above, there may be a malfunction in the system. Contact your Toyota dealer.

Automatic cancelation of constant speed control mode

Constant speed control mode is automatically canceled in the following situations:

- Actual vehicle speed is more than approximately 16 km/h (10 mph) below the set vehicle speed.
- Actual vehicle speed falls below approximately 30 km/h (20 mph).
- VSC is activated.
- TRC is activated for a period of time.
- When the VSC or TRC system is turned off.
- Pre-collision braking is activated.

If constant speed control mode is automatically canceled for any reasons other than the above, there may be a malfunction in the system. Contact your Toyota dealer.

■ The Dynamic Radar Cruise Control with Road Sign Assist may not operate properly when (vehicles with RSA)

As the Dynamic Radar Cruise Control with Road Sign Assist may not operate properly in conditions in which RSA may not operate or detect correctly (\rightarrow P.210), when using this function, make sure to check the speed limit sign displayed.

In the following situations, the set speed may not be changed to the recognized speed limit by pressing and holding the "+RES"/"-SET" switch.

- If speed limit information is not available
- When the recognized speed limit is the same as the set speed
- When the recognized speed limit is

outside of the speed range that the dynamic radar cruise control system can operate

■ Brake operation

A brake operation sound may be heard and the brake pedal response may change, but these are not malfunctions.

Warning messages and buzzers for dynamic radar cruise control with full-speed range


Warning messages and buzzers are used to indicate a system malfunction or to inform the driver of the need for caution while driving. If a warning message is shown on the multi-information display, read the message and follow the instructions. (\rightarrow P.182, 375)

■ When the sensor may not be correctly detecting the vehicle ahead

In the case of the following and depending on the conditions, operate the brake pedal when deceleration of the system is insufficient or operate the accelerator pedal when acceleration is required.


As the sensor may not be able to correctly detect these types of vehicles, the approach warning (→P.218) may not be activated.

- Vehicles that cut in suddenly
- Vehicles traveling at low speeds
- Vehicles that are not moving in the same lane
- Vehicles with small rear ends (trailers with no load on board, etc.)




- Motorcycles traveling in the same lane
- When water or snow thrown up by the surrounding vehicles hinders the detecting of the sensor

 When your vehicle is pointing upwards (caused by a heavy load in the luggage compartment, etc.)



 Preceding vehicle has an extremely high ground clearance




Conditions under which the vehicle-to-vehicle distance control mode may not function correctly


In the case of the following conditions, operate the brake pedal (or accelerator pedal, depending on the situation) as necessary.

As the sensor may not be able to correctly detect vehicles ahead, the system may not operate properly.

 When the road curves or when the lanes are narrow



 When steering wheel operation or your position in the lane is unstable



- When the vehicle ahead of you decelerates suddenly
- When driving on a road surrounded by a structure, such as in a tunnel or on a bridge
- While the vehicle speed is decreasing to the set speed after the vehicle accelerates by depressing the accelerator pedal

Dynamic radar cruise control*

*: If equipped


In vehicle-to-vehicle distance control mode, the vehicle automatically accelerates and decelerates to match the speed changes of the preceding vehicle even if the accelerator pedal is not depressed. In constant speed control mode, the vehicle runs at a fixed speed.

Use the dynamic radar cruise control on freeways and highways.

- Vehicle-to-vehicle distance control mode (→P.225)
- Constant speed control mode (→P.228)


System Components

■ Meter display



- A Multi-information display
- B Set speed
- C Indicators

■ Operation switches



- A Vehicle-to-vehicle distance switch
- B "+RES" switch
- Cruise control main switch
- D Cancel switch
- E "-SET" switch



WARNING

- Before using dynamic radar cruise control
- Driving safely is the sole responsibility of the driver. Do not rely solely on the system, and drive safely by always paying careful attention to your surroundings.
- The dynamic radar cruise control provides driving assistance to reduce the driver's burden. However, there are limitations to the assistance provided.

Read the following conditions carefully. Do not overly rely on this system and always drive carefully.

- When the sensor may not be correctly detecting the vehicle ahead: →P.231
- Conditions under which the vehicleto-vehicle distance control mode may not function correctly: →P.232

- Set the speed appropriately depending on the speed limit, traffic flow, road conditions, weather conditions, etc. The driver is responsible for checking the set speed.
- Even when the system is functioning normally, the condition of the preceding vehicle as detected by the system may differ from the condition observed by the driver. Therefore, the driver must always remain alert, assess the danger of each situation and drive safely. Relying solely on this system or assuming the system ensures safety while driving can lead to an accident, resulting in death or serious injury.
 - Switch the dynamic radar cruise control setting to off, using the cruise control main switch when not in use.
- Cautions regarding the driving assist systems

Observe the following precautions, as there are limitations to the assistance provided by the system. Failure to do so may cause an accident resulting in death or serious injury.

Assisting the driver to measure following distance

The dynamic radar cruise control is only intended to help the driver in determining the following distance between the driver's own vehicle and a designated vehicle traveling ahead. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions.

It is still necessary for driver to pay close attention to the vehicle's surroundings.

WARNING

Assisting the driver to judge proper following distance

The dynamic radar cruise control determines whether the following distance between the driver's own vehicle and a designated vehicle traveling ahead is within a set range. It is not capable of making any other type of judgement. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger in any given situation.

Assisting the driver to operate the vehicle

The dvnamic radar cruise control does not include functions which will prevent or avoid collisions with vehicles ahead of your vehicle. Therefore. if there is ever any possibility of danger, the driver must take immediate and direct control of the vehicle and act appropriately in order to ensure the safety of all involved.

Situations unsuitable for dynamic radar cruise control

Do not use dynamic radar cruise control in any of the following situations. Doing so may result in inappropriate speed control and could cause an accident resulting in death or serious injury.

- Roads where there are pedestrians, cyclists, etc.
- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow

On steep downhills, or where there are sudden changes between sharp up and down gradients


Vehicle speed may exceed the set speed when driving down a steep hill.

- At entrances to freeways and high-
- When weather conditions are bad enough that they may prevent the sensors from detecting correctly (fog. snow, sandstorm, heavy rain, etc.)
- When there is rain, snow, etc. on the front surface of the radar or front camera
- In traffic conditions that require frequent repeated acceleration and deceleration
- When your vehicle is towing a trailer or during emergency towing Vehicles that can tow a tailer. (→P.141)
- When an approach warning buzzer is heard often

Driving in vehicle-to-vehicle distance control mode

This mode employs a radar to detect the presence of vehicles up to approximately 100 m (328 ft.) ahead, determines the current vehicle-to-vehicle following distance, and operates to maintain a suitable following distance from the vehicle ahead. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance switch.

When driving on downhill slopes, the vehicle-to-vehicle distance may become shorter.



A Example of constant speed cruising When there are no vehicles ahead

The vehicle travels at the speed set by the driver.

B Example of deceleration cruising and follow-up cruising
When a preceding vehicle driving slower than the set speed appears

When a vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes (the stop lights will come on at this time). The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. Approach warning warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.

When the turn signal lever is operated and your vehicle moves to a right lane while driving at 80 km/h (50 mph) or more, the vehicle will quickly accelerate to help to overtake a passing vehicle.

Example of acceleration

When there are no longer any preceding vehicles driving slower than the

set speed


The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Setting the vehicle speed (vehicle-to-vehicle distance control mode)

 Press the cruise control main switch to activate the cruise control.

Dynamic radar cruise control indicator will come on and a message will be displayed on the multi-information display. Press the switch again to deactivate the cruise control.

If the cruise control main switch is pressed and held for 1.5 seconds or more, the system turns on in constant speed control mode. (→P.228)




2 Accelerate or decelerate, with accelerator pedal operation, to the desired vehicle speed (at or above approximately 30 km/h [20 mph]) and press the "-SET" switch to set the speed.

Cruise control "SET" indicator will come on.


The vehicle speed at the moment the switch is released becomes the set

speed.



Adjusting the set speed

To change the set speed, press the "+RES" or "-SET" switch until the desired set speed is displayed.



- 1 Increases the speed
- 2 Decreases the speed

Fine adjustment: Press the switch.

Large adjustment: Press and hold the switch to change the speed, and release when the desired speed is reached.

In the vehicle-to-vehicle distance control mode, the set speed will be increased or decreased as follows:

Fine adjustment: By 1 km/h (0.6 mph)*1

or 1 mph (1.6 km/h)*2 each time the switch is pressed

Large adjustment: Increases or decreases in 5 km/h (3.1 mph)^{*1} or 5 mph (8 km/h)^{*2} increments for as long as the switch is held

In the constant speed control mode (→P.228), the set speed will be increased or decreased as follows:


Fine adjustment: By 1 km/h (0.6 mph)^{*1} or 1 mph (1.6 km/h)^{*2} each time the switch is pressed

Large adjustment: The speed will continue to change while the switch is held.

- *1: When the set speed is shown in "km/h"
- *2: When the set speed is shown in "MPH"

Changing the vehicle-tovehicle distance (vehicle-tovehicle distance control mode)

Pressing the switch changes the vehicle-to-vehicle distance as follows:



- 1 Long
- 2 Medium

3 Short

The vehicle-to-vehicle distance is set automatically to long mode when the engine switch is turned to ON.


If a vehicle is running ahead of you, the preceding vehicle mark A will also be displayed.

Vehicle-to-vehicle distance settings (vehicle-to-vehicle distance control mode)

Select a distance from the table below. Note that the distances shown correspond to a vehicle speed of 80 km/h (50 mph). Vehicle-to-vehicle distance increases/decreases in accordance with vehicle speed.

Distance options	Vehicle-to-vehicle distance
Long	Approximately 50 m (160 ft.)
Medium	Approximately 40 m (130 ft.)
Short	Approximately 30 m (100 ft.)

Canceling and resuming the speed control



 Pressing the cancel switch cancels the speed control.


The speed control is also canceled when the brake pedal is depressed.

2 Pressing the "+RES" switch resumes the cruise control and returns vehicle speed to the set speed.

However, cruise control does not resume when the vehicle speed is approximately 25 km/h (16 mph) or less.

Approach warning (vehicleto-vehicle distance control mode)

When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Depress the brake pedal to ensure an appropriate vehicle-to-vehicle distance.



■ Warnings may not occur when

In the following instances, warnings may not occur even when the vehicle-to-vehicle distance is small.


- When the speed of the preceding vehicle matches or exceeds your vehicle speed
- When the preceding vehicle is traveling at an extremely slow speed
- Immediately after the cruise control speed was set
- When depressing the accelerator pedal

Selecting constant speed control mode

When constant speed control mode is selected, your vehicle will maintain a set speed without controlling the vehicle-to-vehicle distance. Select this mode only when vehicle-to-vehicle distance control mode does not function correctly due to a dirty radar, etc.

With the cruise control off, press and hold the cruise control main switch for 1.5 seconds or more. Immediately after the switch is pressed, the dynamic radar cruise control indicator will come on. Afterwards, it switches to the cruise control indicator.

Switching to constant speed control mode is only possible when operating the switch with the cruise control off




2 Accelerate or decelerate, with accelerator pedal operation, to the desired vehicle speed (at or above approximately 30 km/h [20 mph]) and press the "-SET" switch to set the speed.

Cruise control "SET" indicator will come on.

The vehicle speed at the moment the switch is released becomes the set speed.

Adjusting the speed setting: →P.226 Canceling and resuming the speed setting: →P.228




Dynamic Radar Cruise Control with Road Sign Assist (vehicles with RSA)

When this function is enabled and the system is operating in vehicle-to-vehicle distance control mode (→P.225), when a speed limit sign is detected, the recognized speed limit will be displayed with an up/down arrow. The set speed can be increased/reduced to the recognized speed limit by pressing and holding the "+RES"/"-SET" switch.


 When the current set speed is lower than the recognized speed limit

Press and hold the "+RES" switch.



 When the current set speed is higher than the recognized speed limit

Press and hold the "-SET" switch.



Enabling/Disabling the Dynamic Radar Cruise Control with Road Sign Assist (vehicles with RSA)

Dynamic Radar Cruise Control with Road Sign Assist can be

enabled/disabled in the \bigcirc screen on the multi-information display. (\rightarrow P.75)

Dynamic radar cruise control can be set when

- The shift lever is in range 2nd or higher.
- Depending on the control mode, this item can be set at the following speeds.
- Vehicle-to-vehicle distance control mode: Approximately 30 km/h (20 mph) or more
- Constant speed control mode: Approximately 30 km/h (20 mph) or more

Accelerating after setting the vehicle speed

The vehicle can accelerate by operating the accelerator pedal. After accelerating, the set speed resumes. However, during vehicle-to-vehicle distance control mode, the vehicle speed may decrease below the set speed in order to maintain the distance to the preceding vehicle.

■ Shift position selection

Select a shift position according to the vehicle speed. If the engine speed is too high or too low, control may be automatically canceled.

■ Automatic cancelation of vehicleto-vehicle distance control mode

Vehicle-to-vehicle distance control mode is automatically canceled in the following situations.

- Actual vehicle speed falls below approximately 25km/h (16 mph).
- VSC is activated.
- TRC is activated for a period of time.
- When the VSC or TRC system is turned off.
- The sensor cannot detect correctly because it is covered in some way.
- Pre-collision braking is activated.
- When the shift lever is in N or the clutch pedal is depressed for a certain amount of time or more.

If vehicle-to-vehicle distance control mode is automatically canceled for any reasons other than the above, there may be a malfunction in the system. Contact your Toyota dealer.

■ Automatic cancelation of constant speed control mode

Constant speed control mode is automatically canceled in the following situations:

- Actual vehicle speed is more than approximately 16 km/h (10 mph) below the set vehicle speed.
- Actual vehicle speed falls below approximately 30 km/h (20 mph).
- VSC is activated.
- TRC is activated for a period of time.
- When the VSC or TRC system is turned off.
- Pre-collision braking is activated.
- When the shift lever is in N or the clutch pedal is depressed for a certain amount of time or more.

If constant speed control mode is automatically canceled for any reasons other than the above, there may be a malfunction in the system. Contact your Toyota dealer

■The Dynamic Radar Cruise Control with Road Sign Assist may not operate properly when (vehicles with RSA)

As the Dynamic Radar Cruise Control with Road Sign Assist may not operate properly in conditions in which RSA may not operate or detect correctly (\rightarrow P.210), when using this function, make sure to check the speed limit sign displayed.

In the following situations, the set speed may not be changed to the recognized speed limit by pressing and holding the "+RFS"/"-SFT" switch.

- If speed limit information is not available
- When the recognized speed limit is the same as the set speed
- When the recognized speed limit is outside of the speed range that the dynamic radar cruise control system can operate

■ Brake operation

A brake operation sound may be heard and the brake pedal response may change, but these are not malfunctions.

Warning messages and buzzers for dynamic radar cruise control


Warning messages and buzzers are used to indicate a system malfunction or to inform the driver of the need for caution while driving. If a warning message is shown on the multi-information display, read the message and follow the instructions. (\rightarrow P.182, 375)

■When the sensor may not be correctly detecting the vehicle ahead


In the case of the following and depending on the conditions, operate the brake pedal when deceleration of the system is insufficient or operate the accelerator pedal when acceleration is required.

As the sensor may not be able to correctly detect these types of vehicles, the approach warning (→P.228) may not be activated.


- Vehicles that cut in suddenly
- Vehicles traveling at low speeds
- Vehicles that are not moving in the same lane
- Vehicles with small rear ends (trailers with no load on board, etc.)



- Motorcycles traveling in the same lane
- When water or snow thrown up by the surrounding vehicles hinders the detecting of the sensor
- When your vehicle is pointing upwards (caused by a heavy load in the luggage compartment, etc.)



 Preceding vehicle has an extremely high ground clearance




■ Conditions under which the vehicle-to-vehicle distance control mode may not function correctly


In the case of the following conditions, operate the brake pedal (or accelerator pedal, depending on the situation) as necessary.

As the sensor may not be able to correctly detect vehicles ahead, the system may not operate properly.

When the road curves or when the lanes are narrow



When steering wheel operation or your position in the lane is unstable



- When the vehicle ahead of you decelerates suddenly
- When driving on a road surrounded by a structure, such as in a tunnel or on a bridge
- While the vehicle speed is decreasing to the set speed after the vehicle accelerates by depressing the accelerator pedal


Cruise control*

*: If equipped


Use the cruise control to maintain a set speed without depressing the accelerator pedal.

System Components

■ Meter display



- A Set speed
- **B** Indicators
- Operation switches



- A "+RES" switch
- B Cruise control main switch
- C "-SET" switch
- D Cancel switch



WARNING

To avoid operating the cruise control by mistake

Switch the cruise control off using the cruise control main switch when not in LISE

Situations unsuitable for cruise control

Do not use cruise control in any of the following situations.

Doing so may result in loss of control and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep hills Vehicle speed may exceed the set speed when driving down a steep hill.
- When your vehicle is towing a trailer or during emergency towing *: Vehicles that can tow a tailer. (→P.141)


Setting the vehicle speed

1 Press the cruise control main switch to activate the cruise control.

Cruise control indicator will be displayed.

Press the switch again to deactivate the


cruise control



Accelerate or decelerate, with accelerator pedal operation, to the desired speed (at or above approximately 30 km/h [20] mphl) and press the "- SET" switch to set the speed.


Cruise control "SET" indicator will be displayed.

The vehicle speed at the moment the switch is released becomes the set speed.



Adjusting the set speed

To change the set speed, operate the "+ RES" or "- SET" switch until the desired set speed is obtained.



- 1 Increases the speed
- 2 Decreases the speed

Fine adjustment: Press the switch.


Large adjustment: Press and hold the switch to change the speed, and release when the desired speed is reached.

The set speed will be increased or decreased as follows:

Fine adjustment: By 1 km/h (0.6 mph) each time the switch is operated.

Large adjustment: The set speed can be increased or decreased continually until the switch is released.

Canceling and resuming the constant speed control



 Pressing the cancel switch cancels the constant speed control. The speed setting is also canceled when the brakes are applied or the clutch pedal (manual transmission only) is depressed.

2 Pressing the "+ RES" switch resumes the constant speed control.

Resuming is available when the vehicle speed is more than approximately 30 km/h (20 mph).

Cruise control can be set when

- The shift lever is in D.
- Vehicle speed is above approximately 30 km/h (20 mph).
- Accelerating after setting the vehicle speed
- The vehicle can be accelerated normally. After acceleration, the set speed resumes.
- Even without canceling the cruise control, the set speed can be increased by first accelerating the vehicle to the desired speed and then pushing the "- SET" switch to set the new speed.

Automatic cancelation of cruise control

Cruise control will stop maintaining the vehicle speed in any of the following situations

- Actual vehicle speed falls more than approximately 16 km/h (10 mph) below the preset vehicle speed.
- Actual vehicle speed is below approximately 30 km/h (20 mph).
- VSC is activated.
- TRC is activated for a period of time.
- When the VSC or TRC system is turned off.

■ If the warning message for the cruise control is shown on the multi-information display

Press the cruise control main switch

once to deactivate the system, and then press the switch again to reactivate the system.

If the cruise control speed cannot be set or if the cruise control cancels immediately after being activated, there may be a malfunction in the cruise control system. Have the vehicle inspected by your Toyota dealer.

BSM (Blind Spot Monitor)*

*: If equipped

The Blind Spot Monitor is a system that has 2 functions:

 The BSM (Blind Spot Monitor) function

Assists the driver in making a decision when changing lanes

 The RCTA (Rear Cross Traffic Alert) function (if equipped)

Assists the driver when backing up

These functions use the same sensors.

WARNING

Cautions regarding the use of the BSM function

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The BSM function is a supplementary function which alerts the driver that a vehicle is in a blind spot of the outside rear view mirrors or is approaching rapidly from behind into a blind spot. Do not overly rely on the BSM function. As the function cannot judge if it is safe to change lanes, over reliance could lead to an accident resulting in death or serious injury.

As the system may not function correctly under certain conditions, the driver's own visual confirmation of safety is necessary.



WARNING


Cautions regarding the use of the RCTA function

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The RCTA function is only a supplementary function which alerts the driver that a vehicle is approaching from the right or left at the rear of the vehicle. As the RCTA function may not function correctly under certain conditions, the driver's own visual confirmation of safety is necessary.

Over reliance on this function may lead to an accident resulting death or serious injury.

System components



A Multi-information display
Turning the BSM function/RCTA function on/off.

B Outside rear view mirror indica-

tors

BSM function:

When a vehicle is detected in a blind spot of the outside rear view mirrors or approaching rapidly from behind into a blind spot, the outside rear view mirror indicator on the detected side will illuminate. If the turn signal lever is operated toward the detected side, the outside rear view mirror indicator will flash.

RCTA function:

When a vehicle approaching from the right or left at the rear of the vehicle is detected, both outside rear view mirror indicators will flash.

© BSM indicator/RCTA OFF indicator

When the Blind Spot Monitor is enabled, the BSM indicator illuminates.

When the RCTA function is disabled, the RCTA OFF indicator illuminates.

Monitor screen display (RCTA function only)

If a vehicle approaching from the right or left at the rear of the vehicle is detected, the RCTA icon (→P.241) for the detected side will be displayed.

E RCTA buzzer (RCTA function only)

If a vehicle approaching from the right or left at the rear of the vehicle is detected, a buzzer will sound from behind the rear seat.

Turning the BSM function/RCTA function on/off

The BSM function and the RCTA function can be enabled/disabled

on screen of the multi-information display. (→P.75)

Outside rear view mirror indicators visibility

In strong sunlight, the outside rear view mirror indicator may be difficult to see.

■ Hearing the RCTA buzzer

The RCTA buzzer may be difficult to hear over loud noises such as high audio volume

■ When "Blind Spot Monitor Unavailable" or "Rear Cross Traffic Alert Unavailable" is shown on the multiinformation display

The sensor voltage has become abnormal, or water, snow, mud, etc., may be built up in the vicinity of the sensor area of the rear bumper. (→P.237)
Removing the water, snow, mud, etc., from the vicinity of the sensor area should return it to normal.

Also, the sensor may not function normally when used in extremely hot or cold weather.

When "Blind Spot Monitor Malfunction Visit Your Dealer" or "Rear Cross Traffic Alert Malfunction Visit Your Dealer" is shown on the multi-information display

There may be a sensor malfunction or misaligned. Have the vehicle inspected at a Toyota dealer.


■ Customization

Some functions can be customized. $(\rightarrow P.75)$

WARNING

Handling the radar sensor

Blind Spot Monitor sensors are installed inside the left and right sides of the rear bumper respectively. Observe the following to ensure the Blind Spot Monitor can function correctly.



 Keep the sensors and the surrounding areas on the rear bumper clean at all times.

If a sensor or its surrounding area on the rear bumper is dirty or covered with snow, the Blind Spot Monitor may not operate and a warning message (→P.237) will be displayed. In this situation, clear off the dirt or snow and drive the vehicle with the operation conditions of the BSM function (→P.239) satisfied for approximately 10 minutes. If the warning message does not disappear, have the vehicle inspected by your Toyota dealer.

- Do not subject a sensor or its surrounding area on the rear bumper to a strong impact. If a sensor is moved even slightly off position, the system may malfunction and vehicles may not be detected correctly. In the following situations, have your vehicle inspected by your Toyota dealer.
- A sensor or its surrounding area is subject to a strong impact.
- If the surrounding area of a sensor is scratched or dented, or part of them has become disconnected.




WARNING

- Do not disassemble the sensor
- Do not attach accessories, stickers (including transparent stickers), aluminum tape, etc. to a sensor or its surrounding area on the rear bumper.
- Do not modify the sensor or surrounding area on the rear bumper.
- If a sensor or the rear bumper needs to be removed/installed or replaced, contact your Toyota dealer.
- Do not paint the rear bumper any color other than an official Toyota color.

The Blind Spot Monitor function

■ Vehicles that can be detected by the Blind Spot Monitor


The BSM function uses radar sensors to detect the following vehicles traveling in adjacent lanes and advises the driver of the presence of such vehicles via the indicators on the outside rear view mirrors.



- A Vehicles that are traveling in areas that are not visible using the outside rear view mirrors (the blind spots)
- B Vehicles that are approaching rapidly from behind in areas that are not visible using the outside rear view mirrors (the blind spots)

■ The BSM function detection areas

The areas that vehicles can be detected in are outlined below.



The range of each detection area is:

Approximately 0.5 m (1.6 ft.) to 3.5 m (11.5 ft.) from either side of the vehicle

The area between the side of the vehicle and 0.5 m (1.6 ft.) from the side of the vehicle cannot be detected.

- B Approximately 1 m (3.3 ft.) forward of the rear bumper
- C Approximately 3 m (9.8 ft.) from the rear bumper
- D Approximately 3 m (9.8 ft.) to 60 m (197 ft.) from the rear bumper

The greater the difference in speed between your vehicle and the detected vehicle is, the farther away the vehicle will be detected, causing the outside rear view mirror indicator to illuminate or flash.

The BSM function is operational when

The BSM function is operational when all of the following conditions are met:

- The BSM function is on.
- The shift lever is in a position other than R.
- The vehicle speed is greater than approximately 16 km/h (10 mph).

The BSM function will detect a vehicle when

The BSM function will detect a vehicle present in the detection area in the following situations:

- A vehicle in an adjacent lane overtakes your vehicle.
- You overtake a vehicle in an adjacent lane slowly.
- Another vehicle enters the detection

area when it changes lanes.

■ Conditions under which the BSM function will not detect a vehicle

The BSM function is not designed to detect the following types of vehicles and/or objects:

- Small motorcycles, bicycles, pedestrians, etc.*
- Vehicles traveling in the opposite direction
- Guardrails, walls, signs, parked vehicles and similar stationary objects*
- Following vehicles that are in the same lane*
- Vehicles traveling 2 lanes away from your vehicle*
- Vehicles which are being overtaken rapidly by your vehicle
- *: Depending on the conditions, detec-

tion of a vehicle and/or object may

■ Conditions under which the BSM function may not function correctly


- The BSM function may not detect vehicles correctly in the following situations:
- When the sensor is misaligned due to a strong impact to the sensor or its surrounding area
- When mud, snow, ice, a sticker, etc. is covering the sensor or surrounding area on the rear bumper
- When driving on a road surface that is wet with standing water during bad weather, such as heavy rain, snow, or fog
- When multiple vehicles are approaching with only a small gap between each vehicle
- When the distance between your vehicle and a following vehicle is short
- When there is a significant difference in speed between your vehicle and the vehicle that enters the detection area.
- When the difference in speed between your vehicle and another vehicle is changing
- When a vehicle enters a detection area traveling at about the same speed as your vehicle
- As your vehicle starts from a stop, a vehicle remains in the detection area
- When driving up and down consecutive steep inclines, such as hills, dips in the road, etc.
- When driving on roads with sharp bends, consecutive curves, or uneven surfaces
- When vehicle lanes are wide, or when driving on the edge of a lane, and the vehicle in an adjacent lane is far away from your vehicle
- When an accessory (such as a bicycle carrier) is installed to the rear of the vehicle
- When there is a significant difference in height between your vehicle and the vehicle that enters the detection area

- Immediately after the BSM function/RCTA function are turned on
- · When towing a trailer
- Instances of the BSM function unnecessarily detecting a vehicle and/or object may increase in the following situations:
- When the sensor is misaligned due to a strong impact to the sensor or its surrounding area
- When the distance between your vehicle and a guardrail, wall, etc. that enters the detection area is short
- When driving up and down consecutive steep inclines, such as hills, dips in the road, etc.
- When vehicle lanes are narrow, or when driving on the edge of a lane, and a vehicle traveling in a lane other than the adjacent lanes enters the detection area
- When driving on roads with sharp bends, consecutive curves, or uneven surfaces
- When the tires are slipping or spinning
- When the distance between your vehicle and a following vehicle is short
- When an accessory (such as a bicycle carrier) is installed to the rear of the vehicle
- When the vehicle throws up water or snow behind.

The Rear Cross Traffic Alert function (if equipped)

Operation of the RCTA function

The RCTA function uses radar sensors to detect vehicles approaching from the right or left at the rear of the vehicle and alerts the driver of the presence of such vehicles by flashing the outside rear view mirror indicators and sounding a buzzer.




- A Approaching vehicles
- **B** Detection areas


■ RCTA icon display (if equipped)

When a vehicle approaching from the right or left at the rear of the vehicle is detected, the following will be displayed on the navigation system (if equipped) or multimedia system (if equipped) screen.

 When the Toyota parking assist monitor (if equipped) is displayed




When the panoramic view monitor (if equipped) is displayed



: The RCTA function is malfunctioning (→P.237)

■ The RCTA function detection areas

The areas that vehicles can be detected in are outlined below.



The buzzer can alert the driver of faster vehicles approaching from farther away.

Example:

,	Approach- ing vehicle	Speed	A Approximate alert distance
	Fast	28 km/h (18 mph)	20 m (65 ft.)
	Slow	8 km/h (5 mph)	5.5 m (18 ft.)

■ The RCTA function is operational when

The RCTA function operates when all of the following conditions are met:

- The RCTA function is on.
- The shift lever is in R
- The vehicle speed is less than approximately 8 km/h (5 mph).
- The approaching vehicle speed is between approximately 8 km/h (5 mph) and 28 km/h (17 mph).


■ Setting the buzzer volume

The buzzer volume can be adjusted on the multi-information display. (→P.75)

■ Conditions under which the RCTA function will not detect a vehicle

The RCTA function is not designed to detect the following types of vehicles and/or objects.


- Vehicles approaching from directly behind
- Vehicles backing up in a parking space next to your vehicle
- Vehicles that the sensors cannot detect due to obstructions




- Guardrails, walls, signs, parked vehicles and similar stationary objects*
- Small motorcycles, bicycles, pedestrians, etc.*
- Vehicles moving away from your vehicle
- Vehicles approaching from the parking spaces next to your vehicle*
- *: Depending on conditions, detection of a vehicle and/or object may occur.

■ Conditions under which the RCTA function may not function correctly


- The RCTA function may not detect vehicles correctly in the following situations:
- When the sensor is misaligned due to a strong impact to the sensor or its surrounding area
- When mud, snow, ice, a sticker, etc. is covering the sensor or surrounding area on the rear bumper
- When driving on a road surface that is wet with standing water during bad weather, such as heavy rain, snow, or for
- When multiple vehicles are approaching with only a small gap between each vehicle
- When a vehicle is approaching at high speed
- When parking on a steep incline, such as hills, a dip in the road, etc.
- When an accessory (such as a bicycle carrier) is installed to the rear of the vehicle
- When backing up on a slope with a sharp change in grade




 When backing out of a shallow angle parking spot



- Immediately after the RCTA function is turned on
- Immediately after the engine is started with the RCTA function on
- When towing a trailer
- When the sensors cannot detect a vehicle due to obstructions



- Instances of the RCTA function unnecessary detecting a vehicle and/or object may increase in the following situations:
- When a vehicle passes by the side of your vehicle
- When the parking space faces a street and vehicles are being driven on the street




- When the distance between your vehicle and metal objects, such as a guardrail, wall, sigh, or parked vehicle, which may reflect electrical waves toward the rear of the vehicle, is short
- When an accessory (such as a bicycle carrier) is installed to the rear of the vehicle

Toyota parking assistsensor

The distance from your vehicle to objects, such as a wall, when parallel parking or maneuvering into a garage is measured by the sensors and communicated via the navigation system or multimedia system screen and a buzzer. Always check the surrounding area when using this system.


System components

■ Location and types of sensors



- A Front corner sensors
- **B** Front center sensors
- C Rear corner sensors
- D Rear center sensors
- Display (Multi-information display)

When the sensors detect an object, such as a wall, a graphic is shown on the multi-information display depending on the position and distance to the object.




- A Front corner sensor detection
- B Front center sensor detection*1
- C Rear corner sensor detection*2
- D Rear center sensor detection*2
- *1: Displayed when the shift lever is in a driving position
- *2: Displayed when the shift lever is in R

■ Display (Audio system screen)

When the sensors detect an object, such as a wall, a graphic is shown on the navigation system (if equipped) or multimedia system (if equipped) screen depending on the position and distance to the object.

 When the Toyota parking assist monitor (if equipped) is displayed




A simplified image is displayed on the upper corner of the screen when an obstacle is detected.

- When the panoramic view monitor (if equipped) is displayed
- ▶ Panoramic view*



A graphic is shown when the panoramic view monitor is displayed.

- *: A simplified image is displayed on the upper corner of the screen when an obstacle is detected while magnified display is shown.
 - Except panoramic view



A simplified image is displayed on the upper corner of the screen when an obstacle is detected.

Turning Toyota parking assist-sensor on/off

The Toyota parking assist-sensor function can be enabled/disabled on screen of the multi-information display. (→P.75)

When the Toyota parking assist-sensor function is disabled, the Toyota parking assist-sensor OFF indicator (→P.61) illuminates on the multi-information display.

To re-enable the system, select on the multi-information display, select

Pw and turn it on.

If the system is disabled, it will remain off even if the engine switch is turned to ON after the engine switch has been turned off.

A

WARNING

■ Toyota parking assist-sensor precautions

Observe the following precautions. Failing to do so may result in the vehicle being unable to be driven safely and possibly cause an accident.

- Do not use the sensor at speeds in excess of 10 km/h (6 mph).
- The sensors' detection areas and reaction times are limited. When moving forward or reversing, check the areas surrounding the vehicle (especially the sides of the vehicle) for safety, and drive slowly, using the brake to control the vehicle's speed.
- Do not install accessories near the bumpers as those areas are within the sensors' detection areas.
- The area directly under the bumpers is not detected.
 Thin posts or objects lower than the

Thin posts or objects lower than the sensor may not be detected when approached, even if they have been detected once.

When to disable the function

In the following situations, disable the function as it may operate even though there is no possibility of a collision

- The vehicle is equipped with a commercial fender pole, wireless antenna or fog lights.
- The front or rear bumper or a sensor receives a strong impact.
- A non-genuine Toyota suspension (lowered suspension, etc.) is installed.
- Towing eyelets are installed.
- A backlit license plate is installed.

When using the Toyota parking assist-sensor

In the following situations, the system may not function correctly due to a sensor malfunction, etc. Have the vehicle checked by your Toyota dealer.

- The Toyota parking assist-sensor operation display flashes or shows continuously, and a beep sounds when no objects are detected.
- If the area around a sensor collides with something, or is subjected to strong impact.
- If the bumper or grille collides with something.
- If the display flashes or is displayed continuously and a buzzer does not sound, except when the mute function has been turned on.

■ Notes when washing the vehicle

Do not apply intensive bursts of water or steam to the sensor area.

Doing so may result in the sensor malfunctioning.

A

WARNING

- When using a high pressure washer to wash the vehicle, do not spray the sensors directly, as doing so may cause a sensor to malfunction.
- When using steam to clean the vehicle, do not direct steam too close to the sensors as doing so may cause a sensor to malfunction.
- The system can be operated when
- The engine switch is in ON.
- Toyota parking assist-sensor function is on.
- The vehicle speed is less than about 10 km/h (6 mph).
- The shift lever is in other than P.
- ■If "Parking Assist Unavailable Clean Parking Assist Sensor" is displayed on the multi-information display

A sensor may be covered with ice, snow, dirt, etc. Remove the ice, snow, dirt, etc., from the sensor to return the system to normal.

Also, due to ice forming on a sensor at low temperatures, a warning message may be displayed or the sensor may not be able to detect an object. Once the ice melts, the system will return to normal.

If a warning message is displayed even if the sensor is clean, there may be a sensor malfunction. Have the vehicle inspected by your Toyota dealer.

Sensor detection information

- The sensor's detection areas are limited to the areas around the vehicle' front and rear bumpers.
- The following situations may occur during use.
- Depending on the shape of the object and other factors, the detection distance may shorten, or detection may be impossible.

- Detection may be impossible if static objects draw too close to the sensor.
- There will be a short delay between static object detection and display (warning buzzer sounds). Even at low speeds, there is a possibility that the object will come within 30 cm before the display is shown and the warning buzzer sounds
- It might be difficult to hear the buzzer due to the volume of the audio system or air flow noise of the air conditioning system.
- It may be difficult to hear the sound of this system due to the buzzers of other systems.

Conditions under which the function may not function correctly

Certain vehicle conditions and the surrounding environment may affect the ability of a sensor to correctly detect objects. Particular instances where this may occur are listed below.

- There is dirt, snow or ice on a sensor. (Cleaning the sensors will resolve this problem.)
- A sensor is frozen. (Thawing the area will resolve this problem.)
 In especially cold weather, if a sensor is frozen the sensor display may be displayed abnormally, or objects, such as a wall, may not be detected.
- A sensor is covered in any way.
- When a sensor or the area around a sensor is extremely hot or cold.
- On an extremely bumpy road, on an incline, on gravel, or on grass.
- The vicinity of the vehicle is noisy due to vehicle horns, motorcycle engines, air brakes of large vehicles, or other loud noises producing ultrasonic waves.
- There is another vehicle equipped with parking assist sensors in the vicinity.
- A sensor is coated with a sheet of spray or heavy rain.
- If a sensor is hit by a large amount of

water, such as when driving on a flooded road

- If the vehicle is significantly tilted.
- The vehicle is approaching a tall or curved curb.
- If objects draw too close to the sensor.

Objects which may not be properly detected


The shape of the object may prevent the sensor from detecting it. Pay particular attention to the following objects:

- Wires, fences, ropes, etc.
- Cotton, snow and other materials that absorb sound waves
- Sharply-angled objects
- Low objects
- Tall objects with upper sections projecting outwards in the direction of your vehicle

People may not be detected if they are wearing certain types of clothing.

Sensor detection display, object distance

■ Detection range of the sensors



- A Approximately 100 cm (3.3 ft.)
- B Approximately 150 cm (4.9 ft.)
- Approximately 65 cm (2.1 ft.)
- D Approximately 60 cm (2.0 ft.)

The diagram shows the detection range of the sensors. Note that the sensors cannot detect objects that are extremely close to the vehicle.

The range of the sensors may change depending on the shape of the object, etc.

■ Distance display

When an object is detected by a sensor, the approximate distance to the object will be displayed on the multi-information display, navigation system (if equipped) or multimedia system (if equipped) screen. (As the distance to the object becomes short, the distance segments may blink.)

The images may differ from that shown in the illustrations.

- Approximate distance to object
- Front center sensor: 100 cm (3.3 ft.) to 60 cm (2.0 ft.)

Rear center sensor: 150 cm (4.9 ft.) to 65 cm (2.1 ft.)

Multi-information display	Navigation or multimedia system screen	

- Approximate distance to object
- Front center sensor: 60 cm (2.0 ft.) to 47.5 cm (1.56 ft.)
- Rear center sensor: 65 cm (2.1 ft.) to 50 cm (1.63 ft.)

Multi-information display	Navigation or multimedia system screen	

- Approximate distance to object
- Front center sensor: 47.5 cm (1.56 ft.) to 35 cm (1.1 ft.)
- Rear center sensor: 50 cm (1.63 ft.) to 35 cm (1.1 ft.)

Multi-information display	Navigation or multin	nedia system screen

• Approximate distance to object: 35 cm (1.1 ft.) to 28 cm (0.9 ft.)

Multi-information display*	Navigation or multimedia system screen	

: The distance segments will blink slowly.

• Approximate distance to object: Less than 28 cm (0.9 ft.)

Multi-information display*	Navigation or multimedia system screen	

^{*:} The distance segments will blink rapidly.

Buzzer operation and distance to an object

A buzzer sounds when the sensors are operating.

- The buzzer beeps faster as the vehicle approaches an object.
 When the vehicle comes within approximately 35 cm (1.1 ft.) of the object, the buzzer sounds continuously.
- When 2 or more sensors simultaneously detect a static object, the buzzer sounds for the nearest object.

■ Customization

The buzzer volume can be adjusted on the multi-information display. (→P.75)

Stop & Start system

: If equipped


The Stop & Start system stops and starts the engine according to brake pedal (vehicles with automatic transmission or CVT) or clutch pedal (vehicles with manual transmission), or shift lever operation when the vehicle is stopped, such as at a stoplight, intersection, etc., in order to improve fuel economy and reduce noise pollution caused by the engine idling.

Stop & Start system operation

- Stopping the engine
- Vehicles with automatic transmission or CVT


While driving with the D shift position selected, depress the brake pedal and stop the vehicle. The engine will stop automatically.

When the engine stops, the Stop & Start indicator will illuminate.



- Vehicles with manual transmission
- 1 Fully depress the clutch pedal and depress the brake pedal to stop the vehicle.
- 2 Move the shift lever to N and release the clutch pedal. The engine will stop automatically.

When the engine is stopped by the Stop & Start system, the Stop & Start indicator will illuminate.



- Restarting the engine
- Vehicles with automatic transmission or CVT

Release the brake pedal. The engine will start automatically.

When the engine starts, the Stop & Start indicator will turn off.

Vehicles with manual transmission

With the shift lever in N, depress the clutch pedal. The engine will start automatically.

When the engine starts, the Stop & Start indicator will turn off.

- When the brake hold system is operating (vehicles with automatic transmission or CVT)
- When the engine is stopped by

the Stop & Start system, if the brake pedal is released the engine will remain stopped.


- If the accelerator pedal is depressed while the engine is stopped by the Stop & Start system, the engine will restart.
- While the engine is stopped by the Stop & Start system, if the engine is restarted, the brake hold system will continue to apply the brakes, unless the operation conditions of the brake hold system are no longer met. (→P.167)
- When the dynamic radar cruise control with full-speed range is operating (vehicles with a dynamic radar cruise control with full-speed range)
- When the vehicle is stopped by the dynamic radar cruise control with full-speed range, the engine will stop automatically even though the brake pedal is not depressed.
- When the preceding vehicle starts off, the engine will restart automatically.
- If the engine is restarted automatically by the Stop & Start system during a controlled stop by the dynamic radar cruise control with full-speed range, the controlled stop will continue.

Disabling the Stop & Start system

Press the Stop & Start cancel switch to disable the Stop & Start system.

The Stop & Start cancel indicator will illuminate.

Pressing the switch again will enable the Stop & Start system and the Stop & Start cancel indicator will turn off.



Automatic enabling of the Stop & Start system

If the Stop & Start system is disabled using the Stop & Start cancel switch, it will be automatically re-enabled once the engine switch is turned off and then the engine is started.

Hill-start assist control (vehicles with automatic transmission or CVT)

When the engine is stopped by the Stop & Start system when the vehicle is on an incline, when the brake pedal is released, brake force is temporarily maintained to prevent the vehicle from rolling backwards before the engine is restarted and drive force is generated. When

drive force is generated, the maintained brake force is automatically canceled.

- This function operates on flat surfaces as well as steep inclines
- Sound may be generated from the brake system, but this does not indicate a malfunction.
- Brake pedal response may change and vibration may occur, but this does not indicate a malfunction.

■ Points for use

- If the engine switch is pressed when the engine is stopped by the Stop & Start system, the engine will not be able to be restarted by the automatic engine start function. In this case, restart the engine using the normal engine starting procedure. (→P.148, 149)
- When the engine is being restarted by the Stop & Start system, the power outlets may be temporarily unusable, but this does not indicate a malfunction.
- Installation and removal of electrical components and wireless devices may affect the Stop & Start system.
 Contact your Toyota dealer for details.
- When stopping the vehicle for a longer period of time, turn the engine switch off to stop the engine completely.
- When the engine is restarted by the Stop & Start system, the steering wheel may temporarily feel heavy.

Operating conditions

- The Stop & Start system is operational when all of the following conditions are met:
- The vehicle has been driven a certain

- amount of time.
- The brake pedal is being depressed firmly.

(except when the vehicle is stopped by the dynamic radar cruise control with full-speed range when in vehicle-tovehicle distance control mode)

- The clutch pedal is not depressed (vehicles with manual transmission).
- The D shift position is selected (vehicles with automatic transmission or CVT).
- The shift lever is in N (vehicles with manual transmission).
- · The driver's seat belt is fastened.
- The driver's door is closed.
- The selected driving mode is normal or Eco drive mode.
- The selected driving mode is not snow mode (if equipped).
- Mud & Sand or Rock & Dirt mode is not selected for Multi-terrain Select (4WD models).
- The windshield defogger is off. (vehicles without a manual air conditioning system)
- The accelerator pedal is not being depressed (vehicles with automatic transmission or CVT).
- The engine is adequately warmed up.
- The outside temperature is -5°C (23°F) or higher.
- The hood is closed. (→P.253)
- In the following situations the engine may not be stopped by the Stop & Start system. This is not a malfunction of the Stop & Start system.
- When the air conditioning system is being used.
- When the battery is undergoing a periodic recharge.
- When the battery is not sufficiently charged, such as if the vehicle has been parked for a long time and the battery charge has decreased, the electric load is large, the battery fluid temperature is excessively low or the battery has deteriorated.
- When the brake booster vacuum is
- When the elapsed time since the

- engine was restarted is short.
- When the vehicle is stopped frequently, such as when in a traffic jam.
- When the engine coolant temperature or transmission fluid temperature is extremely low or high.
- When the vehicle is stopped on a steep incline (vehicles with automatic transmission or CVT).
- When the steering wheel is being operated.
- When the vehicle is being driven in a high altitude area.
- When the battery fluid temperature is extremely low or high.
- For a while after the battery terminals have been disconnected and reconnected.
- When the engine is stopped by the Stop & Start system, the engine will be restarted automatically if any of the following conditions are met:

(To enable the engine to be stopped by the Stop & Start system again, drive the vehicle.)

- The air conditioning system is turned on. (vehicles without a manual air conditioning system)
- The windshield defogger is turned on. (vehicles without a manual air conditioning system)
- The shift lever is shifted from D (vehicles with automatic transmission or CVT).
- The driver's seat belt is unfastened.
- The driver's door is opened.
- The driving mode is changed from normal or Eco drive mode to another mode.
- The driving mode is changed to snow mode (if equipped).
- Mud & Sand or Rock & Dirt mode is selected for Multi-terrain Select (4WD models).
- The Stop & Start cancel switch is pressed.
- The steering wheel is operated.
- The accelerator pedal is depressed (vehicles with automatic transmission or CVT).
- · The vehicle starts to roll on an incline.

- When the engine is stopped by the Stop & Start system, the engine may restart automatically in the following situations: (To enable the engine to be stopped by the Stop & Start system again, drive the vehicle.)
- When the brake pedal is pumped or strongly depressed.
- When the air conditioning system is being used.
- When a switch of the air conditioning system is operated (windshield defogger switch, etc.).
- The battery is not sufficiently charged.

When the hood is opened

- If the hood is opened while the engine is stopped by the Stop & Start system, the engine will stall and will not be able to be restarted by the automatic engine start function. In this case, restart the engine using the normal engine starting procedure. (→P.148, 149)
- If the hood is closed after the engine is started with the hood open, the Stop & Start system will not operate. Close the hood, turn the engine switch off, wait 30 seconds or more, and then start the engine.

Air conditioning system operation while the engine is stopped by the Stop & Start system

Vehicles with an automatic air conditioning system: When the air conditioning is in automatic mode and the engine is stopped by the Stop & Start system, the fan may operate at a low speed in order to prevent the temperature in the cabin from increasing or decreasing or may be stopped.

To prioritize air conditioning system performance when the vehicle is stopped, disable the Stop & Start system by pressing the Stop & Start cancel switch.

 If the windshield is fogged up Turn the windshield defogger on.
 (→P.281)

If the windshield fogs up frequently, press the Stop & Start cancel switch to

disable the Stop & Start system.

- If an odor is emitted from the air conditioning system
- Vehicles with a manual air conditioning system:

If the idling stop time setting is set to "Extended", change it to "Standard". If an odor is emitted when the idling stop time setting is set to "Standard", press the Stop & Start cancel switch to deactivate the Stop & Start system.

Vehicles with an automatic air conditioning system:

Press the Stop & Start cancel switch to deactivate the Stop & Start system.

■ Changing the idling stop time with the air conditioning system on

The length of time the Stop & Start system will operate when the air condition-

ing system is on can be changed in of the multi-information display (→P.75). (The length of time the Stop & Start system will operate when the air conditioning system is off cannot be changed.)

■ Displaying the Stop & Start system status

After Start:

Displays the cumulative time that the engine is stopped by the Stop & Start system from when the engine is started until the engine is stopped. This item is reset each time the engine stops.

■ Multi-information display messages

If the following situations,



message may be displayed on the multiinformation display.

When the engine cannot be stopped by the Stop & Start system



"Press Brake More to Activate"

 The brake pedal is not sufficiently depressed.

- →If the brake pedal is depressed further, the system will operate.
- *: Vehicles with automatic transmission or CVT



"Non-Dedicated Battery"

- A battery not designed for use with a Stop & Start system may have been installed.
- →Have the vehicle inspected by any authorized Toyota retailer or Toyota authorized repairer, or any reliable repairer.



"Battery Charging"

- The battery charge may be low.
- →Stopping of the engine is temporarily prohibited to prioritize charging of the battery. After the engine runs for a certain amount of time, the system will be enabled.
- A refresh charge may be occurring (Examples: For a while after the battery terminals have been disconnected and reconnected. For a while after the battery has been replaced. etc.)
- →After a refresh charge of approximately 5 to 60 minutes completes, the system can be operated.
- If displayed continuously for a long time (more than 60 minutes)
- →The battery may be deteriorated. Contact your Toyota dealer for details.



"Stop & Start System Unavail-

able"

- The Stop & Start system is temporarily disabled.
- →Allow the engine to run for some time.
- The engine may have been started with the hood open.

→Close the hood, turn the engine switch off, wait for 30 seconds or more, and then start the engine.



"In Preparation"

- The vehicle is being driven in a high altitude area.
- Vehicles with automatic transmission or CVT: The brake booster vacuum is low
- →When the brake booster vacuum reaches a predetermined level, the system will be enabled.
- *: Vehicles with automatic transmission or CVT



"For Climate Control"

- The air conditioning system is being used when the ambient temperature is high or low.
- →If the difference between the set temperature and cabin temperature becomes small, the system will be enabled.
- The windshield defogger is on.
- When the engine automatically restarts while stopped by the Stop & Start system



"In Preparation"*

- The brake pedal has been depressed further or pumped.
- →The system will be enabled after the engine runs and the brake booster vacuum reaches a predetermined level.
- : Vehicles with automatic transmission or CVT



"For Climate Control"

• The air conditioning system has been turned on or is being used.

The windshield defogger has been turned on



"Battery Charging"

- The battery charge may be low.
- →The engine is restarted to prioritize battery charging. After the engine runs for a certain amount of time, the system will be enabled
- When the engine cannot be restarted by the Stop & Start system
- "Stop & Start system active Shift to N and press clutch to restart"
- When the engine is stopped by the Stop & Start system, the shift lever was moved to a position other than N without depressing the clutch pedal.
- →Shift the shift lever to N and depress the clutch pedal to restart.
- * Vehicles with manual transmission

When a buzzer sounds

If the driver's door is opened when the engine is stopped by the Stop & Start system and the shift lever is in D, a buzzer will sound and the Stop & Start system indicator will flash. To stop the buzzer, close the driver's door.

■ The Stop & Start system protection function

- When the volume of the audio system is excessively high, sound output from the audio system may suddenly be cut off in order to reduce battery consumption. To prevent the audio system from being cut off, keep the volume of audio system at a moderate level. If the audio system has been cut off, turn the engine switch off, wait for 3 seconds or more and then turn it to ACC or ON to re-enable the audio system.
- The audio system may not be activated if the battery terminals are disconnected and then reconnected. If this occurs, turn the engine switch off

and then repeat the following operation twice to activate the audio system normally.

- Turn the engine switch to ON and then to off.
- Replacing the battery
- →P.393
- If the Stop & Start cancel indicator flashes continuously

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

■If "Stop & Start System Malfunction Visit Your Dealer" is displayed on the multi-information display

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.



WARNING

When the Stop & Start system is operating

Make sure to disable the Stop & Start system while the vehicle is in a poorly ventilated area.

If not disabled, the engine may be automatically restarted unexpectedly, causing exhaust gases to collect and enter the vehicle, possibly resulting in death or a serious health hazard.

- Do not leave the vehicle while the engine is stopped by the Stop & Start system (while the Stop & Start indicator is on). An accident may occur due to the automatic engine start function.
- Depress the brake pedal and apply the parking brake when necessary while the engine is stopped by the Stop & Start system (while the Stop & Start indicator is on).

\triangle

NOTICE

■ To ensure the system operates correctly

If any of the following situations occur, the Stop & Start system may not operate correctly. Have your vehicle inspected by your Toyota dealer.

- While the driver's seat belt is fastened, the driver's and front passenger's seat belt reminder light flashes.
- Even though the driver's seat belt is not fastened, the driver's and front passenger's seat belt reminder light does not illuminate.
- Even though the driver's door is closed, the open door warning light is illuminated or the interior light is illuminated when the interior light switch is in the door position.
- Even though the driver's door is open, the open door warning light does not illuminate or the interior light does not illuminate when the interior light switch is in the door position.
- If the engine stalls (vehicles with manual transmission)


If the Stop & Start system is enabled and the clutch pedal is depressed quickly, the engine may restart.

Driving mode select switch

The driving modes can be selected to suit the driving and usage conditions.

Selecting a driving mode

■ FF vehicles/Dynamic Torque Control AWD vehicles



1 Eco drive mode

Suitable for driving to improve fuel economy by more smoothly generating torque in response to accelerator pedal operations compared to normal mode and restraining air conditioning system operations (heating/cooling).

When the switch is pressed while not in Eco drive mode, the system switches to Eco drive mode and the Eco drive mode indicator illuminates on the multi-information display.

2 Normal mode

Suitable for normal driving.


The driving mode returns to normal mode if the switch is pressed while in Eco drive mode or sport mode.

3 Sport mode

Controls the steering feeling and engine to create an acceleration response that is suitable for sporty driving. Suitable for when crisp handling is desired, such as when driving on mountainous roads.

When the switch is pressed while not in sport mode, the system switches to sport mode and the sport mode indicator illuminates on the multi-information display.

Dynamic Torque VectoringAWD vehicles



1 Eco drive mode

Suitable for driving to improve fuel economy by more smoothly generating torque in response to accelerator pedal operations compared to normal mode and restraining air conditioning system operations (heating/cooling).

When the switch is pressed while not in Eco drive mode, the system switches to Eco drive mode and the Eco drive mode indicator illuminates on the multi-information display.

2 Normal mode

Suitable for normal driving.

The driving mode returns to normal mode if the switch is pressed while in Eco drive mode or sport mode.

3 Sport mode

Controls the steering feeling and engine to create an acceleration response that is suitable for sporty driving. Suitable for when crisp handling is desired, such as when driving on mountainous roads.

When the switch is pressed while not in sport mode, the system switches to sport mode and the sport mode indicator illuminates on the multi-information display.

When changing to a driving mode other than normal mode

- The background color of the multiinformation display changes according to the selected driving mode.
- When the speedometer is set to analog display, the speedometer display color also changes. (For vehicles with the 7-inch multi-information display only)
- Switches to AWD control suitable for the selected mode. (For Dynamic Torque Vectoring AWD vehicles only)

■ Air conditioning system operation in Eco drive mode

In Eco drive mode, heating/cooling operations and the fan speed is controlled to improve fuel efficiency. Perform the fol-

lowing procedures to increase the air conditioning performance.

- Vehicles with automatic air conditioning system: Turn eco air conditioning mode off (→P.287)
- Adjust the fan speed (→P.280, 286)
- Cancel Eco drive mode

■ Canceling a driving mode

- Sport mode is automatically canceled and the driving mode returns to normal mode when the engine switch is turned off
- Normal mode and Eco drive mode are not canceled until another driving mode is selected. (Even if the engine switch is turned off, normal mode and Eco drive mode will not be automatically canceled.)

Multi-terrain Select (AWD vehicles)

Multi-terrain Select is a system that improves drivability in off-road situations.

When driving over muddy. sandy or rough road surfaces. the system selects a suitable driving mode to switch AWD, brake and drive force control to perform control suitable for the road condition.



WARNING

■ Before using Multi-terrain Select

Make sure to observe the following precautions. Failure to observe these precautions may result in an unexpected accident.

- Check that the Mud & Sand and Rock & Dirt indicators are illuminated before driving. Multi-terrain Select will not operate when the indicators are off
- Do not rely solely upon the Multiterrain Select. This function is not intended to expand the limits of the vehicle. If the system is continuously used for a long period of time, the load on related parts increases and the system may be unable to operate normally, which may lead to an accident. Thoroughly check the road conditions and driving route before driving, and drive with caution.

The road conditions listed in Guidelines for selecting each mode are for reference only. There is a chance that the function may not be the most appropriate in terms of road conditions such as pitch, slipperiness, undulation, etc. Thoroughly check the road conditions before driving.

Guidelines for selecting each mode

Control that is suitable for the following road conditions can be performed by switching to either of the two modes. Select a mode that is appropriate for the road condition.

■ Mud & Sand mode


Suitable for driving on roads with increased driving resistance such as sandy roads, muddy roads, etc.

Rock & Dirt mode

Suitable for driving in bumpy road conditions, such as on unpayed forest roads

Changing the mode

Dynamic Torque Control AWD vehicles



1 Mud & Sand mode

When the switch is pressed while not in Mud & Sand mode, the system switches to Mud & Sand mode and the Mud & Sand mode indicator, VSC OFF indicator and PCS warning light illuminate on the multi-information display.

2 Normal mode

Mode that performs AWD, brake and drive force control suitable for driving on general roads. Use normal mode when not driving off-road.


The driving mode returns to normal mode if the switch is pressed while in Mud & Sand mode or Rock & Dirt mode.

3 Rock & Dirt mode

When the switch is pressed while not in Rock & Dirt mode, the system switches

to Rock & Dirt mode and the Rock & Dirt mode indicator illuminates on the multi-information display.

Dynamic Torque Vectoring AWD vehicles



1 Mud & Sand mode

When the switch is turned to the left while not in Mud & Sand mode, the system switches to Mud & Sand mode and the Mud & Sand mode indicator, VSC OFF indicator and PCS warning light illuminate on the multi-information display.

2 Normal mode

Mode that performs AWD, brake and drive force control suitable for driving on general roads. Use normal mode when not driving off-road.

The driving mode returns to normal mode if the switch is pressed while in Mud & Sand mode or Rock & Dirt mode.

3 Rock & Dirt mode

When the switch is turned to the right while not in Rock & Dirt mode, the system switches to Rock & Dirt mode and the Rock & Dirt mode indicator illuminates on the multi-information display.

■ Multi-terrain Select

- Multi-terrain Select is intended for use when driving on rough roads. Drive in normal mode during normal driving.
- The Mud & Sand and Rock & Dirt modes control the vehicle so that it can maximize the drive force and improve drivability on rough roads. As a result, fuel efficiency may diminish when compared to driving in normal mode

■ If Mud & Sand or Rock & Dirt mode is selected

- The background of the multi-information display will change following the Multi-terrain Select mode.
- The AWD operation status display will automatically switch on the multi-information display.
- Manual transmission vehicles: iMT operates.

AWD control for Mud & Sand and Rock & Dirt modes

If the vehicle speed exceeds the speeds listed below, AWD control is performed similar to that performed in Normal mode, even if Mud & Sand or Rock & Dirt mode is selected.

- Mud & Sand mode: Vehicle speed is approximately 40 km/h (25 mph) or more
- Rock & Dirt mode: Vehicle speed is approximately 25 km/h (16 mph) or more

If the vehicle speed drops below the above speeds, the system automatically switches to the AWD control suitable for each mode.

When Multi-terrain Select brake control temporarily stops operating

If Mud & Sand or Rock & Dirt mode is continuously used for a long period of time, the brakes may overheat, and Multi-terrain Select brake control may temporarily stop operating.

- At this time, the buzzer sounds intermittently and "Traction Control Turned OFF" is displayed on the multi-information display.
- If Multi-terrain Select brake control stops operating, stop the vehicle in a safe location as soon as possible and wait until the system temperature decreases. Once the display message on the multi-information display turns off, the brake control returns to normal. Note that normal driving is still possible even when Multi-terrain Select brake control is not operating.
- *: After stopping the vehicle, do not stop the engine until the display message has turned off.

When Mud & Sand or Rock & Dirt mode is canceled

In the following situations, Mud & Sand mode or Rock & Dirt mode are automatically canceled even if they are selected.

- When the driving mode is changed (→P.257)
- When the engine switch is turned off

■ Driving in Mud & Sand or Rock & Dirt mode

The following types of situations may occur, but they are not malfunctions.

- Vibrations may be felt throughout the vehicle or steering wheel
- Operating noise may be heard from the engine compartment

When an inspection at your Toyota dealer is necessary

In the following situations, the system may be malfunctioning. Have the vehicle inspected by your Toyota dealer immediately.

- When the slip indicator light illuminates while Mud & Sand or Rock & Dirt mode is selected
- When the indicator for each mode does not illuminate even though Mud & Sand or Rock & Dirt mode is selected

Snow mode switch

*: If equipped

Snow mode can be selected to suit the conditions when driving on slippery road surfaces, such as on snow.


System operation

Dynamic Torque Control AWD vehicles

Press the snow mode switch.

When the switch is pressed, the system switches to snow mode and the snow mode indicator illuminates on the multi-information display.

When the switch is pressed again, the snow mode indicator turns off.




Dynamic Torque Vectoring AWD vehicles

Press the snow mode switch.

When the switch is pressed, the system switches to snow mode and the snow mode indicator illuminates on the multi-information display.

When the switch is pressed again, the snow mode indicator turns off.



■ When changing to snow mode

The background of the multi-information display changes.

■ Canceling the snow mode

Snow mode is automatically canceled when the engine switch is turned off or Mud & Sand or Rock & Dirt mode is selected for Multi-terrain Select.

Downhill assist control system*

*: If equipped

The downhill assist control system helps to prevent excessive speed on steep downhill slopes.

The system will operate when the vehicle is traveling under 25 km/h (15 mph) with the accelerator and brake pedals released.



WARNING

When using downhill assist control system


Do not rely overmuch on the downhill assist control system. This function does not extend the vehicle's performance limitations. Always thoroughly check the road conditions, and drive safely.

System operation

Press the "DAC" switch.

The downhill assist control system indicator will come on and the system will operate.

When the system is in operation, the slip indicator light will flash, and the stop lights/high mounted stop lights will be lit. A sound may also occur during the operation. This does not indicated a malfunction.



Turning off the system

Press the "DAC" switch while the system is in operation.

The downhill assist control system indicator will flash as the system gradually ceases operation, and will turn off when the system is fully off.

Press the "DAC" switch while the downhill assist control system indicator is flashing to start the system again.

■ Operating tips

The system will operate when the shift lever is in a D or 1 range of S mode or R.

If the downhill assist control system indicator flashes

- In the following situations, the indicator flashes and the system will not operate:
- The shift lever is in a position other than D or 1 range of S (vehicles with automatic transmission) or M mode (vehicles with CVT), mode or R.
- The accelerator or brake pedal is depressed.
- The vehicle speed exceeds approximately 25 km/h (15 mph).
- The brake system overheats.
- In the following situation, the indicator flashes to alert the driver, but the system will operate:
- The "DAC" switch is turned off while the system is operating.

The system will gradually ceases operation. The indicator will flash during operation, and then go off when the system is fully off.

■ When the downhill assist control system is operated continuously

This may cause the brake actuator to overheat. In this case, the downhill assist control system will stop operating, a buzzer will sound and the downhill assist control system indicator will start flashing. Refrain from using the system until the downhill assist control system indicator stays on and the message goes off. (The vehicle can be driven normally during this time.)

■ Sounds and vibrations caused by the downhill assist control system

- A sound may be heard from the engine compartment when the engine is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has occurred in downhill assist control system.
- Either of the following conditions may occur when the downhill assist control system is operating. None of these are indicators that a malfunction has occurred.
- Vibrations may be felt through the vehicle body and steering.
- A motor sound may be heard after the vehicle comes to a stop.

■ System malfunction

In the following cases, have your vehicle checked by your Toyota dealer.

- The downhill assist control system indicator does not come on when the engine switch is turned to ON.
- The downhill assist control system indicator does not come on when the "DAC" switch is pressed.
- The slip indicator light comes on.



WARNING

- The system may not operate on the following surfaces, which may lead to an accident causing death or serious injury
- Slipperv surfaces such as wet or muddy roads
- Icv surface
- Unpaved roads

Driving assist systems

To keep driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however. that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

Summary of the driving assist systems

■ ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface

Brake assist

Generates an increased level of braking force after the brake pedal is depressed when the system detects a panic stop situation

■ VSC (Vehicle Stability Control)

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces.

Provides cooperative control of the ABS, TRC, VSC and EPS.

Helps to maintain directional stability when swerving on slippery road surfaces by controlling steering performance.

■ Trailer Sway Control

Helps the driver to control trailer sway by selectively applying brake pressure for individual wheels and reducing driving torque when trailer sway is detected.

Secondary Collision Brake (if equipped)

When the airbag sensor detects a collision, the brakes and brake lights are automatically controlled to reduce the vehicle speed and that helps reduce the possibility of further damage due to a secondary collision

■ TRC (Traction Control)

Helps to maintain drive power and prevent the drive wheels from spinning when starting the vehicle or accelerating on slippery roads

■ Active Cornering Assist (ACA)

Helps to prevent the vehicle from drifting to the outer side by performing inner wheel brake control when attempting to accelerate during cornering

■ Hill-start assist control

Helps to reduce the backward movement of the vehicle when starting on an uphill

EPS (Electric Power Steering)

Employs an electric motor to reduce the amount of effort needed to turn the steering wheel

Dynamic Torque Control AWD system (AWD models)

Automatically switches from front-wheel drive to all-wheel drive (AWD) according to the driving conditions, helping to ensure reliable handling and stability. Examples of conditions where the system will switch to AWD are when cornering, going uphill, starting off or accelerating, and when the road surface is slippery due to snow, rain, etc.

■ Dynamic Torque Vectoring AWD system (AWD models)

Automatically switches from front wheel drive to all-wheel drive (AWD) according to the driving conditions, helping to ensure reliable handling and stability. Examples of conditions where the system will switch to AWD are when cornering, going uphill, starting off or accelerating, and when the road surface is slippery due to snow, rain, etc.


Also, when the vehicle is cornering, the drive torque distribution between the front and rear wheels and between the rear left and right wheels is precisely controlled to improve drivability and stability.

Emergency brake signal (if equipped)

When the brakes are applied suddenly, the emergency flashers automatically flash to alert the vehicle behind.

■ When the TRC/VSC/Trailer Sway Control systems are operating


The slip indicator light will flash while the TRC/VSC/Trailer Sway Control systems are operating.



■ Disabling the TRC system

If the vehicle gets stuck in mud, dirt or snow, the TRC system may reduce power from the engine to the wheels.

To turn the TRC system off, quickly press and release $\frac{1}{OFF}$.



"Traction Control Turned OFF" will be shown on the multi-information display.

Press again to turn the system back

Turning off the TRC/VSC/Trailer Sway Control systems

To turn the TRC/VSC/Trailer Sway Control systems off, press and hold off for more than 3 seconds while the vehicle is stopped.

The VSC OFF indicator light will come on and the "Traction Control Turned OFF" will be shown on the multi-infor-

mation display.*

Press space again to turn the systems back on

- *: On vehicles with PCS (Pre-Collision System), PCS will also be disabled (only Pre-Collision warning is available). The PCS warning light will come on and a message will be displayed on the multi-information display. (→P.191)
- When the message is displayed on the multi-information display showing that TRC has been disabled even if has not been pressed

TRC is temporary deactivated. If the information continues to show, contact your Toyota dealer.

Operating conditions of hill-start

When the following four conditions are met, the hill-start assist control will operate:

- Vehicles with automatic transmission or CVT: The shift lever is in a position other than P or N (when starting off forward/backward on an upward incline).
- The vehicle is stopped.
- The accelerator pedal is not depressed.
- The parking brake is not engaged.
- Automatic system cancelation of hill-start assist control

The hill-start assist control will turn off in any of the following situations:

- Vehicles with automatic transmission or CVT: The shift lever is shifted to P or N.
- The accelerator pedal is depressed.
- The parking brake is engaged.
- No more than 2 seconds have elapsed after the brake pedal is released.

■ Sounds and vibrations caused by the ABS, brake assist, VSC, Trailer Sway Control, TRC and hill-start assist control systems

- A sound may be heard from the engine compartment when the brake pedal is depressed repeatedly, when the engine is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has occurred in any of these systems.
- Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.
- Vibrations may be felt through the vehicle body and steering.
- A motor sound may be heard also after the vehicle comes to a stop.
- The brake pedal may pulsate slightly after the ABS is activated.
- The brake pedal may move down slightly after the ABS is activated.

Automatic reactivation of TRC, Trailer Sway Control and VSC systems

After turning the TRC, Trailer Sway Control and VSC systems off, the systems will be automatically re-enabled in the following situations:

- When the engine switch is turned off.
- If only the TRC system is turned off, the TRC will turn on when vehicle speed increases.
 If both the TRC and VSC systems are

If both the TRC and VSC systems are turned off, automatic re-enabling will not occur when vehicle speed increases.

Active Cornering Assist operation sounds and vibrations

When Active Cornering Assist is operated, operation sounds and vibrations may be generated from the brake system, but this is not a malfunction.

AWD system operation sounds and vibrations when switching between AWD and front wheel drive

When the vehicle switches from AWD to front wheel drive and vice versa, opera-

tion sounds and vibrations may be generated, but this is not a malfunction.

■ EPS operation sound

When the steering wheel is operated, a motor sound (whirring sound) may be heard. This does not indicate a malfunction

Reduced effectiveness of the EPS system

The effectiveness of the EPS system is reduced to prevent the system from overheating when there is frequent steering input over an extended period of time. The steering wheel may feel heavy as a result. Should this occur, refrain from excessive steering input or stop the vehicle and turn the engine off. The EPS system should return to normal within 10 minutes.

Secondary Collision Brake operating conditions

The vehicle speed is approximately 10 km/h (6 mph) or more and the airbag sensor detects a collision. (The Secondary Collision Brake will not operate when the vehicle speed is below approximately 10 km/h [6 mph].)

Secondary Collision Brake automatic cancellation

The Secondary Collision Brake is automatically canceled in the following situations:

- The vehicle speed drops below approximately 10 km/h (6 mph)
- A certain amount of time elapses during operation
- The accelerator pedal is depressed a large amount

Operating conditions of Active Cornering Assist

The system operates in the following situations.

- TRC/VSC can operate
- The system determines that the vehicle is drifting to the outer side when attempting to accelerate during cornering

- The brake pedal is released
- Operating conditions of emergency brake signal

When the following conditions are met, the emergency brake signal will operate:

- The emergency flashers are off.
- Actual vehicle speed is over 55 km/h (35 mph).
- The system judges from the vehicle deceleration that it is a sudden brak-

ing operation.

■ Automatic system cancelation of emergency brake signal

The emergency brake signal will be canceled in any of the following situations:

- The emergency flashers are turned on.
- The system judges from the vehicle deceleration that is not a sudden braking operation.

If a message about AWD is shown on the multi-information display (AWD models)

Perform the following actions.

Message	Details/Actions
oodgo	
"AWD System Over- heated Switching to 2WD Mode"	 AWD system is overheating. → Perform the following actions. Reduce the vehicle speed until the message disappears. Stop the vehicle in a safe place and let the engine idle.* Once the display message on the multi-information display turns off, there is no problem continuing to drive. If the message does not disappear, have your vehicle checked by your Toyota dealer immediately.
"AWD System Over- heated 2WD Mode Engaged"	The vehicle switched from all-wheel drive (AWD) to front wheel drive due to overheating. → Perform the following actions. • Reduce the vehicle speed until the message disappears. • Stop the vehicle in a safe place and let the engine idle.* Once the display message on the multi-information display turns off, the AWD system returns to normal. If the message does not disappear, have your vehicle checked by your Toyota dealer immediately.
"AWD System Malfunction 2WD Mode Engaged Visit Your Dealer"	A malfunction occurred in the AWD system. → Have your vehicle checked by your Toyota dealer immediately.

^{*:} Dynamic Torque Control AWD vehicles only. After stopping the vehicle, do not stop

the engine until the display message has turned off.

A

WARNING

- The ABS does not operate effectively when
- The limits of tire gripping performance have been exceeded (such as excessively worn tires on a snow covered road).
- The vehicle hydroplanes while driving at high speed on wet or slick roads.
- Stopping distance when the ABS is operating may exceed that of normal conditions

The ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you, especially in the following situations:

- When driving on dirt, gravel or snow-covered roads
- When driving with tire chains
- When driving over bumps in the road
- When driving over roads with potholes or uneven surfaces
- TRC/VSC may not operate effectively when

Directional control and power may not be achievable while driving on slippery road surfaces, even if the TRC/VSC system is operating. Drive the vehicle carefully in conditions where stability and power may be lost.

- Active Cornering Assist does not operate effectively when
- Do not rely solely upon Active Cornering Assist. Active Cornering Assist may not operate effectively when accelerating down slopes or driving on slippery road surfaces.

- When Active Cornering Assist frequently operates, Active Cornering Assist may temporarily stop operating to ensure proper operation of the brakes, TRC, VSC.
- Hill-start assist control does not operate effectively when
- Do not overly rely on hill-start assist control. Hill-start assist control may not operate effectively on steep inclines and roads covered with ice.
- Unlike the parking brake, hill-start assist control is not intended to hold the vehicle stationary for an extended period of time. Do not attempt to use hill-start assist control to hold the vehicle on an incline, as doing so may lead to an accident.
- When the TRC/VSC/Trailer Sway Control is activated

The slip indicator light flashes. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator light flashes.

■ When the TRC/VSC/Trailer Sway Control systems are turned off

Be especially careful and drive at a speed appropriate to the road conditions. As these are the systems to help ensure vehicle stability and driving force, do not turn the TRC/VSC/Trailer Sway Control systems off unless necessary.

Trailer Sway Control is part of the VSC system and will not operate if VSC is turned off or experiences a malfunction.



WARNING

Secondary Collision Brake

Do not overly rely on the Secondary Collision Brake. This system is designed to help reduce the possibility of further damage due to a secondary collision, however, that effect changes according to various conditions. Overly relying on the system may result in death or serious injury.

Dynamic Torque Vectoring AWD system (AWD models)

The cornering performance of the newly developed AWD system has been improved. However, do not overly rely on the system and drive with caution.

Replacing tires

Make sure that all tires are of the specified size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the recommended tire inflation pressure level.

The ABS, TRC and VSC/Trailer Swav Control systems will not function correctly if different tires are installed on the vehicle.

Contact your Toyota dealer for further information when replacing tires or wheels.

Handling of tires and the suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause a system to malfunction.

Trailer Swav Control precaution

The Trailer Sway Control system is not able to reduce trailer sway in all situations. Depending on many factors such as the conditions of the vehicle, trailer, road surface and driving environment, the Trailer Sway Control system may not be effective. Refer to your trailer owner's manual. for information on how to tow your trailer properly.

If trailer sway occurs

Observe the following precautions. Failing to do so may cause death or serious injury.

- Firmly grip the steering wheel. Steer straight ahead. Do not try to control trailer swaving by turning the steering wheel.
- Begin releasing the accelerator pedal immediately but very gradually to reduce speed.

Do not increase speed. Do not apply vehicle brakes.

If you make no extreme correction with the steering or brakes, your vehicle and trailer should stabilize. (→P.141)

Winter driving tips

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

Pre-winter preparations

- Use fluids that are appropriate to the prevailing outside temperatures
- · Engine oil
- · Engine coolant
- Washer fluid
- Have a service technician inspect the condition of the battery.
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the front tires.*

Ensure that all tires are the same size and brand, and that chains match the size of the tires.

*: Tire chains cannot be mounted on vehicles with 235/55R19 101V tires.

A

WARNING

Driving with snow tires

Observe the following precautions to reduce the risk of accidents. Failure to do so may result in a loss of vehicle control and cause death or serious injury.

- Use tires of the specified size.
- Maintain the recommended level of air pressure.

- Do not drive at speeds in excess of the speed limit or the speed limit specified for the snow tires being used
- Use snow tires on all, not just some wheels.
- Driving with tire chains (except 235/55R19 101V tires)

Observe the following precautions to reduce the risk of accidents. Failure to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used, or 50 km/h (30 mph), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.
- Do not use LTA (Lane Tracing Assist) system (if equipped).
- Do not use LDA (Lane Departure Alert with steering control) system (if equipped).

Before driving the vehicle

Perform the following according to the driving conditions:

Do not try to forcibly open a window or move a wiper that is frozen. Pour warm water over the frozen area to melt the ice. Wipe away the water immediately to

prevent it from freezing.

- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Check for and remove any excess ice or snow that may have accumulated on the exterior lights, vehicle's roof, chassis, around the tires or on the brakes.
- Remove any snow or mud from the bottom of your shoes before getting in the vehicle.

When driving the vehicle

Accelerate the vehicle slowly, keep a safe distance between you and the vehicle ahead, and drive at a reduced speed suitable to road conditions.

When parking the vehicle

• Park the vehicle and move the shift lever to P (automatic transmission or CVT) or 1 or R (manual transmission) without setting the parking brake. The parking brake may freeze up, preventing it from being released. If the vehicle is parked without setting the parking brake, make sure to block the wheels.

Failure to do so may be dangerous because it may cause the vehicle to move unexpectedly, possibly leading to an accident. Vehicles with automatic transmission or CVT: When the parking brake is in automatic mode, release the parking brake after shifting the shift lever to P. $(\rightarrow P.164)$

Vehicles with manual transmission: Turn the automatic mode of the parking brake off before turning off the engine. (→P.164)

- If the vehicle is left parked with the brakes damp in cold temperatures, there is a possibility of the brakes freezing.
- Vehicles with automatic transmission or CVT: If the vehicle is parked without setting the parking brake, confirm that the shift lever cannot be moved out of P*.
- The shift lever will be locked if it is attempted to be shifted from P to any other position without depressing the brake pedal. If the shift lever can be shifted from P, there may be a problem with the shift lock system. Have the vehicle inspected by your Toyota dealer immediately.

A

WARNING


■When parking the vehicle

When parking the vehicle without applying the parking brake, make sure to chock the wheels. If you do not chock the wheels, the vehicle may move unexpectedly, possibly resulting in an accident.

Selecting tire chains

► Vehicles without 235/55R19 101V tires

Use the correct tire chain size when mounting the tire chains. Chain size is regulated for each tire size.



Side chain:

- A 3 mm (0.12 in.) in diameter
- B 10 mm (0.39 in.) in width
- C 30 mm (1.18 in.) in length
- D 4 mm (0.16 in.) in diameter
- E 14 mm (0.55 in.) in width
- F 25 mm (0.98 in.) in length
- ➤ Vehicles with 235/55R19 101V tires

Tire chains cannot be mounted.

Snow tires should be used instead.

Regulations on the use of tire chains (except 235/55R19 101V tires)

Regulations regarding the use of tire chains vary depending on location and type of road. Always check local regulations before installing chains

■ Tire chain installation

Observe the following precautions when installing and removing chains:

- Install and remove tire chains in a safe location
- Install tire chains on the front tires only. Do not install tire chains on the rear tires.
- Install tire chains on front tires as tightly as possible. Retighten chains after driving 0.5 - 1.0 km (1/4 - 1/2 mile).
- Install tire chains following the instructions provided with the tire chains.

Utility vehicle precautions

This vehicle belongs to the utility vehicle class, which has higher ground clearance and narrower tread in relation to the height of its center of gravity to make it capable of performing in a wide variety of offroad applications.

Utility vehicle feature

- Specific design characteristics give it a higher center of gravity than ordinary passenger cars.
 This vehicle design feature causes this type of vehicle to be more likely to rollover. And, utility vehicles have a significantly higher rollover rate than other types of vehicles.
- An advantage of the higher ground clearance is a better view of the road allowing you to anticipate problems.
- It is not designed for cornering at the same speeds as ordinary passenger cars any more than low-slung sports cars are designed to perform satisfactorily under off-road conditions. Therefore, sharp turns at excessive speeds may cause the vehicle to rollover.

MARNING

Utility vehicle precautions

Always observe the following precautions to minimize the risk of death, serious injury or damage to your vehicle:

- In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt.
 Therefore, the driver and all passengers should always fasten their seat belts.
- Avoid sharp turns or abrupt maneuvers, if at all possible.
 Failure to operate this vehicle correctly may result in loss of control or vehicle rollover causing death or serious injury.
- Loading cargo on the roof luggage carrier (if equipped) will make the center of the vehicle gravity higher. Avoid high speeds, sudden starts, sharp turns, sudden braking or abrupt maneuvers, otherwise it may result in loss of control or vehicle rollover due to failure to operate this vehicle correctly.
- Always slow down in gusty crosswinds. Because of its profile and higher center of gravity, your vehicle is more sensitive to side winds than an ordinary passenger car. Slowing down will allow you to have better control.
- Do not drive horizontally across steep slopes. Driving straight up or straight down is preferred. Your vehicle (or any similar off-road vehicle) can tip over sideways much more easily than forward or backward.

Off-road driving

When driving your vehicle off-road, please observe the following pre-

cautions to ensure your driving enjoyment and to help prevent the closure of areas to off-road vehicles:

- Drive your vehicle only in areas where off-road vehicles are permitted to travel
- Respect private property. Get owner's permission before entering private property.
- Do not enter areas that are closed. Honor gates, barriers and signs that restrict travel.
- Stay on established roads. When conditions are wet, driving techniques should be changed or travel delayed to prevent damage to roads.



WARNING

Off-road driving precautions

Always observe the following precautions to minimize the risk of death, serious injury or damage to your vehicle:

- Drive carefully when off the road.
 Do not take unnecessary risks by driving in dangerous places.
- Do not grip the steering wheel spokes when driving off-road. A bad bump could jerk the wheel and injure your hands. Keep both hands and especially your thumbs on the outside of the rim.
- Always check your brakes for effectiveness immediately after driving in sand, mud, water or snow.

- After driving through tall grass, mud, rock, sand, rivers, etc., check that there is no grass, bush, paper, rags, stone, sand, etc. adhering or trapped on the underbody. Clear off any such matter from the underbody. If the vehicle is used with these materials trapped or adhering to the underbody, a breakdown or fire could occur.
- When driving off-road or in rugged terrain, do not drive at excessive speeds, jump, make sharp turns, strike objects, etc. This may cause loss of control or vehicle rollover causing death or serious injury. You are also risking expensive damage to your vehicle's suspension and chassis.

A

NOTICE

To prevent the water damage

Take all necessary safety measures to ensure that water damage to the engine or other components does not occur.

- Water entering the engine air intake will cause severe engine damage.
- Water entering the automatic transmission will cause deterioration in shift quality, locking up of your transmission accompanied by vibration, and ultimately damage.
- Water can wash the grease from wheel bearings, causing rusting and premature failure, and may also enter the differentials, transmission and transfer case (AWD models), reducing the gear oil's lubricating qualities.

■When you drive through water


If driving through water, such as when crossing shallow streams, first check the depth of the water and the bottom of the riverbed for firmness. Drive slowly and avoid deep water.



NOTICE

■Inspection after off-road driving

- Sand and mud that has accumulated around brake discs may affect braking efficiency and may damage brake system components.
- Always perform a maintenance inspection after each day of off-road driving that has taken you through rough terrain, sand, mud, or water.




5-1.	Using the air conditioning system and defogger
	Manual air conditioning system280
	Automatic air conditioning system285
	Seat heaters/Seat ventilators
5-2.	Using the interior lights
	Interior lights list292
5-3 .	Using the storage features
	List of storage features294
	Luggage compartment features
_	298
5-4.	Using the other interior features
	Other interior features302

Manual air conditioning system

*: If equipped

Air conditioning controls



- A Temperature control switch
- B Fan speed control switch
- C On/off switch
- D Rear window defogger and outside rear view mirror defoggers switch
- E Windshield defogger switch
- F Airflow mode control switch
- G Outside/recirculated air mode switch
- H "A/C" switch

■ Adjusting the temperature setting

To adjust the temperature setting, turn the temperature control switch clockwise (warm) or counterclockwise (cool).

If "A/C" switch is not pressed, the system will blow ambient temperature air or heated air.

■ Fan speed setting

To adjust the fan speed, turn the fan speed control switch clockwise

(increase) or counterclockwise (decrease).


Pressing the on/off switch turns off the

When the fan is off, pressing the on/off switch or turning the fan speed control switch will turn on the fan.

■ Change the airflow mode

Press the airflow mode control switch.

The airflow mode changes as follows each time the switch is pressed.



- 1 Upper body
- 2 Upper body and feet
- 3 Feet
- 4 Feet and the windshield defogger operates

Switching between outside air and recirculated air modes

Press the outside/recirculated air mode switch.

The mode switches between outside air mode and recirculated air mode each time the switch is operated.

When recirculated air mode is selected, the indicator illuminates on the out-side/recirculated air mode switch.

Set cooling and dehumidification function

Press the "A/C" switch.

When the function is on, the indicator illuminates on the "A/C" switch.

■ Defogging the windshield

Defoggers are used to defog the windshield and front side windows.

Press the windshield defogger

switch

Set the outside/recirculated air mode switch to outside air mode if the recirculated air mode is used

To defog the windshield and the side windows quickly, turn the air flow and temperature up.

To return to the previous mode, press the windshield defogger switch again when the windshield is defogged.

When the windshield defogger switch is on, the indicator illuminates on the windshield defogger switch.

Defogging the rear window and outside rear view mirrors

Defoggers are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.

Press the rear window defogger and outside rear view mirror defoggers switch.

When the rear window defogger and outside rear view mirror defoggers switch is on, the indicator illuminates on the rear window defogger and outside rear view mirror defoggers switch.

The defoggers will automatically turn off after 15 minutes.

■ Operation of the air conditioning system in Eco drive mode

In Eco drive mode, the air conditioning system is controlled to prioritize fuel efficiency by regulating the engine speed and compressor operation to restrict the heating/cooling capacity.

To improve air conditioning performance, perform the following operations:

Adjust the fan speed

- Adjust the temperature setting
- Turn off Eco drive mode (→P.257)

■ Fogging up of the windows

- The windows will easily fog up when the humidity in the vehicle is high. Turning the "A/C" switch on will dehumidify the air from the outlets and defog the windshield effectively.
- If you turn the "A/C" switch off, the windows may fog up more easily.
- The windows may fog up if the recirculated air mode is used

Outside/recirculated air mode

When driving on dusty roads such as tunnels or in heavy traffic, set the outside/recirculated air mode switch to the recirculated air mode. This is effective in preventing outside air from entering the vehicle interior. During cooling operation, setting the recirculated air mode will also cool the vehicle interior effectively.

■ When the outside temperature falls to nearly 0°C (32°F)

The dehumidification function may not operate even when the "A/C" switch is pressed.

■ Ventilation and air conditioning odors

- To let fresh air in, set the air conditioning system to the outside air mode.
- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring:
 - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
- When parking, the system automatically switches to outside air mode to encourage better air circulation throughout the vehicle, helping to reduce odors that occur when starting the vehicle.

■ Air conditioning system operations when the engine is stopped due to the Stop & Start system (vehicles with Stop & Start system)

When the engine is stopped due to the Stop & Start system operations, the air conditioning cooling, heating and dehumidification functions turn off and only ambient temperature air is blown, and there is a possibility that the blowing of ambient temperature air will stop. To prevent the air conditioning system from turning off, press the Stop & Start cancel switch to deactivate the system.

■ When the windshield is fogged up and the engine is stopped due to the Stop & Start system (vehicles with Stop & Start system)

Press the windshield defogger switch to restart the engine and defog the windshield.

If the windshield continuously fogs up, press the Stop & Start cancel switch and refrain from using the Stop & Start system.

When an odor comes from the air conditioning system while the engine is stopped due to the Stop & Start system (vehicles with Stop & Start system)

Press the Stop & Start cancel switch to restart the engine.

■ Air conditioning filter

→P.335



WARNING

■ To prevent the windshield from fogging up

Do not use the windshield defogger switch during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.



WARNING

■ When the outside rear view mirror defoggers are operating

Do not touch the rear view mirror surfaces when the outside rear view mirror defoggers are on.



NOTICE


■To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.


Air outlet layout and operations

■ Location of air outlets


The air outlets and air volume change according to the selected airflow mode.



- Adjusting the air flow direction and opening/closing the air outlets
- ▶ Front



- Direct air flow to the left or right, up or down.
- 2 Open the vent
- 3 Close the vent
- Rear



- Direct air flow to the left or right, up or down
- 2 Open the vent
- 3 Close the vent



WARNING

■ To not interrupt the windshield defogger from operating

Do not place anything on the instrument panel which may cover the air outlets. Otherwise, air flow may be obstructed, preventing the windshield defoggers from defogging.




Automatic air conditioning system^{*}

*: If equipped

Air outlets and fan speed are automatically adjusted according to the temperature setting.

Air conditioning controls



- A "DUAL" switch
- B Left-hand side temperature control switch
- C Right-hand side temperature control switch
- D Automatic mode switch
- E "A/C" switch
- F S-FLOW mode switch
- G Outside/recirculated air mode switch
- H Airflow mode control switch
- I Fan speed decrease switch
- J Fan speed increase switch
- K Eco air conditioning mode switch
- L Windshield defogger switch
- M Rear window defogger and outside rear view mirror defoggers switch
- N "OFF" switch

Adjusting the temperature setting

Turn driver's side temperature control dial clockwise to increases the temperature and turn the dial counterclockwise to decreases the temperature.

The air conditioning system switches between individual and simultaneous modes each time the "DUAL" switch is pressed.

Simultaneous mode (the indicator on the "DUAL" switch is on):

The driver's side temperature control dial can be used to adjust the temperature for the driver's and passenger's side. At this time, operate the passenger's side temperature control dial to enter individual mode.

Individual mode (the indicator on the "DUAL" switch is off):

The temperature for the driver's and passenger's side can be adjusted separately.

■ Setting the fan speed


Press the fan speed increase switch to increase the fan speed and the fan speed decrease switch to decrease the fan speed.

Pressing the "OFF" switch to turns off the fan.

Change the airflow mode

Press the airflow mode control switch.

The airflow mode changes as follows each time the switch is pressed.



- Upper body
- 2 Upper body and feet
- 3 Feet
- 4 Feet and the windshield defogger operates

Switching between outside air and recirculated air modes

Press the outside/recirculated air mode switch.

The mode switches between outside air mode and recirculated air mode each time the switch is operated.

When recirculated air mode is selected, the indicator illuminates on the outside/recirculated air mode switch.

Set cooling and dehumidification function

Press the "A/C" switch.

When the function is on, the indicator illuminates on the "A/C" switch.

■ Defogging the windshield

Defoggers are used to defog the windshield and front side windows.

Press the windshield defogger

5

switch

Set the outside/recirculated air mode switch to outside air mode if the recirculated air mode is used. (It may switch automatically.)

To defog the windshield and the side windows quickly, turn the air flow and temperature up.

To return to the previous mode, press the windshield defogger switch again when the windshield is defogged.

When the windshield defogger switch is on, the indicator illuminates on the windshield defogger switch.

Defogging the rear window and outside rear view mirrors

Defoggers are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.

Press the rear window defogger and outside rear view mirror defoggers switch.

The defoggers will automatically turn off after 15 minutes.

When the rear window defogger and outside rear view mirror defoggers switch is on, the indicator illuminates on the rear window defogger and outside rear view mirror defoggers switch.

Eco air conditioning mode

The air conditioning is controlled with low fuel consumption prioritized such as reducing fan speed, etc.

Press the eco air conditioning mode switch.

When the eco air conditioning mode is

on, the indicator illuminates on the eco air conditioning mode switch.

■ S-FLOW mode

Priority for airflow is given to the front seats, and the airflow and air conditioning for the rear seats is effectively controlled.

Press the S-FLOW mode switch to turn the system on/off.

When the S-FLOW mode is on, the indicator illuminates on the S-FLOW mode switch.

■ Fogging up of the windows

- The windows will easily fog up when the humidity in the vehicle is high. Turning "A/C" on will dehumidify the air from the outlets and defog the windshield effectively.
- If you turn "A/C" off, the windows may fog up more easily.
- The windows may fog up if the recirculated air mode is used.

Outside/recirculated air mode

- When driving on dusty roads such as tunnels or in heavy traffic, set the outside/recirculated air mode switch to the recirculated air mode. This is effective in preventing outside air from entering the vehicle interior. During cooling operation, setting the recirculated air mode will also cool the vehicle interior effectively.
- Outside/recirculated air mode may automatically switch depending on the temperature setting or the inside temperature.

Operation of the air conditioning system in Eco drive mode

- In Eco drive mode, the air conditioning system is controlled as follows to prioritize fuel efficiency:
- Engine speed and compressor operation controlled to restrict heating/cool-

ing capacity

- Fan speed restricted when automatic mode is selected
- To improve air conditioning performance, perform the following operations:
- · Adjust the fan speed
- Turn off Eco drive mode (→P.257)
- Turn off Eco air conditioning mode
- When the driving mode is set to Eco driving mode, the fan speed setting mode will be changed to Eco air conditioning mode automatically. Even in this case, the fan speed control mode can be changed by pressing the Eco air conditioning switch.

■ When the outside temperature falls to nearly 0°C (32°F)

The dehumidification function may not operate even when "A/C" is pressed.

■ Ventilation and air conditioning odors

- To let fresh air in, set the air conditioning system to the outside air mode.
- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring:
- It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
- The start timing of the blower may be delayed for a short period of time immediately after the air conditioning system is started in automatic mode.
- When parking, the system automatically switches to outside air mode to encourage better air circulation throughout the vehicle, helping to reduce odors that occur when starting the vehicle.

Air conditioning system operations when the engine is stopped due to the Stop & Start system (vehicles with Stop & Start system)

When the engine is stopped due to Stop & Start system operations, the automatic air conditioning cooling, heating and dehumidification functions turn off and the fan speed is decreased according to the outside temperature etc. or air blowing stops. To stop the air conditioning system from turning off, press the Stop & Start cancel switch and refrain from using the Stop & Start system.

■ When the windshield is fogged up and the engine is stopped due to the Stop & Start system (vehicles with Stop & Start system)

Press the windshield defogger switch to restart the engine and defog the windshield.

If the windshield continuously fogs up, press the Stop & Start cancel switch and refrain from using the Stop & Start system.

When an odor comes from the air conditioning system while the engine is stopped due to the Stop & Start system (vehicles with Stop & Start system)

Press the Stop & Start cancel switch to restart the engine.

■ Air conditioning filter

→P.335

Customization

Settings (e.g. outside/recirculated air mode) can be changed. (Customizable features: →P.417)



WARNING

To prevent the windshield from fogging up

Do not use the windshield defogger switch during cool air operation in extremely humid weather.

The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up. blocking your vision.

When the outside rear view mirror defoggers are operating

Do not touch the rear view mirror surfaces when the outside rear view mirror defoggers are on.



NOTICE

To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.

Using automatic mode

Press the "AUTO" switch.

The dehumidification function begins to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting and humidity.

- 2 Adjust the temperature setting.
- 3 To stop the operation, press the "OFF" switch.

If the fan speed setting or air flow modes are operated, the automatic mode indicator goes off. However, automatic mode for functions other than that operated is maintained.

Using automatic mode


Fan speed is adjusted automatically according to the temperature setting and the ambient conditions

Therefore, the fan may stop for a while until warm or cool air is ready to flow immediately after the automatic mode switch is pressed.


Air outlet layout and operations

Location of air outlets

The air outlets and air volume change according to the selected air flow mode




- Adjusting the air flow direction and opening/closing the air outlets
- ▶ Front



- Direct air flow to the left or right, up or down
- Open the vent
- Close the vent

A If equipped

Rear



- Direct air flow to the left or right, up or down
- 2 Open the vent
- 3 Close the vent



WARNING

To not interrupt the windshield defogger from operating

Do not place anything on the instrument panel which may cover the air outlets. Otherwise, air flow may be obstructed, preventing the windshield defoggers from defogging.



Seat heaters*/Seat ventilators*

: If equipped

Seat heaters warm up the seat upholstery. Seat ventilators maintain good ventilation by pulling air through the seat upholstery



WARNING

■ To prevent minor burn injuries

Care should be taken if anyone in the following categories comes in contact with the steering wheel or seats when the heater is on:

- Babies, small children, the elderly, the sick and the physically challenged
- Persons with sensitive skin
- Persons who are fatiqued
- Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)



NOTICE

■ To prevent damage to the seat heaters and seat ventilators


Do not put heavy objects that have an uneven surface on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.

■To prevent battery discharge

Do not use the functions when the engine is not running.

5

Seat heaters



- High temperature
- 2 Low temperature

When the seat heater is on, the indicator illuminates on the seat heater switch.

When not in use, put the switch in the neutral position. The indicator will turn off.

■ Operation condition

The seat heaters can be used when the engine switch is in ON.



WARNING


To prevent causes of overheating and minor burn injuries

Observe the following precautions when using a seat heater:

- Do not cover the seat with a blanket or cushion when using the seat heater.
- Do not use seat heater more than necessary.

Seat heaters and ventilators

Each time the switch is pressed, the operation condition changes as follows. Hi (3 segments lit) \rightarrow Mid (2 segments lit) \rightarrow Lo (1 segment lit) \rightarrow Off



1 Turns the seat heater on

The level indicators (yellow) A light up during operation.

2 Turns the seat ventilator on

The level indicators (green) A light up during operation.

- Operation condition
- The engine switch is in ON.
- Air conditioning system-linked control mode

When a seat ventilator is set to Hi, the fan speed of the seat ventilator may increase according to the fan speed of the air conditioning system.



WARNING


■ To prevent causes of overheating and minor burn injuries

Observe the following precautions when using a seat heater:

- Do not cover the seat with a blanket or cushion when using the seat heater.
- Do not use seat heater more than necessary.

Interior lights list

Location of the interior lights



- A Open tray lights (if equipped)
- **B** Front interior lights/personal lights (→P.292, 293)
- C Rear interior light (→P.293)
- D Footwell lights (if equipped)*
- Front cup holder lights (if equipped)*
- *: These lights turn on when a door is unlocked.

 Vehicles with automatic transmission or CVT: When the shift lever is in a position other than P, the brightness of these lights will reduce intensity.

Vehicles with manual transmission: When the parking brake is released, the brightness of these lights will reduce intensity.



NOTICE


■To prevent battery discharge


Do not leave the lights on longer than necessary when the engine is not running.

Operating interior lights

■ Front interior lights

Turns the lights on/off






1 Turns the door position on

When a door is opened while the door position is on, the lights turn on.

- 2 Turns the lights off
- Rear interior light




- Turns the light off
- Turns the door position on

When a door is opened while the door position is on, the light turns on.

3 Turns the light on

Operating personal lights

Turns the lights on/off



■ Illuminated entry system

The lights automatically turn on/off according to the engine switch mode, the presence of the electronic key, whether the doors are locked/unlocked, and whether the doors are opened/closed.

To prevent the battery from being discharged

If the interior lights remain on when the engine switch is turned to OFF, the lights will go off automatically after 20 minutes.

■ If the SRS airbags deploy (inflate)

If any of the SRS airbags deploy (inflate) or in the event of a strong rear impact, the interior lights will turn on automatically.

The interior lights will turn off automatically after approximately 20 minutes.

The interior lights can be turned off manually. However, in order to help prevent further collisions, it is recommended that they be left on until safety can be ensured.


(The interior lights may not turn on automatically depending on the force of the impact and conditions of the collision.)

Customization

Some functions can be customized. $(\rightarrow P.421)$

List of storage features

Location of the storage features



- A Open tray (→P.297)
- B Auxiliary box (→P.296)
- C Card holder (→P.297)
- D Bottle holders (→P.296)
- E Console box (→P.295)
- F Cup holders (→P.295)
- G Glove box (→P.295)



WARNING


Items that should not be left in the vehicle

Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:

- Glasses may be deformed by heat or cracked if they come into contact with other stored items.
- Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.

Glove box

Pull up the lever to open the glove box.






WARNING

Caution while driving

Keep the glove box closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by the open glove box or the items stored inside.


Console box

Lift the lid while pushing the button to release the lock.



■ Console box tray (if equipped)

The tray can be removed and stored in the bottom of the console box.



A


WARNING

Caution while driving

Keep the console box closed. Injuries may result in the event of an accident or sudden braking.


Cup holders

Front



▶ Rear

Pull the armrest down



A

WARNING


Items unsuitable for the cup holders

Do not place anything other than cups or beverage cans in the cup holders. Inappropriate items must not be stored in the cup holders even if the lid is closed.


Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury. If possible, cover hot drinks to prevent burns

Bottle holders

▶ Front



Rear



■ Bottle holders

- When storing a bottle, close the cap.
- The bottle may not be stored depending on its size or shape.



WARNING

Items unsuitable for the bottle

Do not place anything other than a bottle in the bottle holders.

Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury.




NOTICE

Items that should be not stowed in the bottle holders

Do not place open bottles or glass and paper cups containing liquid in the bottle holders. The contents may spill and glasses may break.

Auxiliary box

Push the lid.



A

WARNING

■ Caution while driving

Do not leave the auxiliary box open while driving.


Injuries may result in the event of an accident or sudden braking.

■ Items unsuitable for storing

Do not store items heavier than 200 g (0.44 lb.).


Doing so may cause the auxiliary box to open and the items inside may fall out, resulting in an accident.

Card holder




Open tray


Driver's side



► Front passenger's side



▶ Front of console





WARNING

■ Items unsuitable for the open tray

Observe the following precautions when putting items in the open tray. Failure to do so may cause items to be thrown out of the tray in the event of sudden braking or steering. In these cases, the items may interfere with pedal operation or cause driver distraction, resulting in an accident.


- Do not store items in the tray that can easily shift or roll out.
- Do not stack items in the tray higher than the tray's edge.
- Do not put items in the tray that may protrude over the tray's edge.

Luggage compartment features

Cargo hooks

Raise the hook to use.

The cargo hooks are provided for securing loose items.





WARNING


When cargo hooks are not in use

To avoid injury, always return the hooks to their stowed positions when not in use.

Deck board


Setting the deck board underside (resin side) up (except for vehicles with full-size spare tire)

Deck board can be set underside (resin side) up depending on the situation.




- A Original position
- **B** Underside (resin side)
- Changing the deck board positions (except for vehicles with full-size spare tire)

Height of the deck floor can be changed by setting the deck board under the floor.




- A Upper
- **B** Lower


1 Pull up the tab to raise the deck board and move it toward you to remove



Place the deck board through the groove and move forward



 Setting the deck board upright (except for vehicles with fullsize spare tire)



- 1 Remove the deck board →P.299
- 2 Turn the deck board underside up and place the front edge into the hole.

3 Fold the deck board and place the rear edge into the holes.



WARNING

■When operating the deck board

Do not place anything on the deck board when operating the board. Otherwise, your fingers may be caught or an accident may result causing injuries.


Caution while driving

Keep the deck board closed.


In the event of sudden braking, an accident may occur due to an occupant being struck by the deck board or the items stored under the deck board.

Side auxiliary box

Type A



► Type B




■ Removing the partition plate




Disengage the claws

Luggage cover (if equipped)

- Installing the luggage cover
- Compress the both ends of the luggage cover and insert into the recess to install.




2 Pull out the luggage cover and hook it onto the anchors.




■ Removing the luggage cover


1 Release the cover from the left and right anchors and allow it to retract




2 Compress the end of the luggage cover and lift the luggage cover up.



- Stowing the luggage cover (except for vehicles with fullsize spare tire)
- Open the rear deck board and remove the side deck covers.



Place the both ends of the luggage cover into the holder.



Λ


WARNING

Luggage cover

- When installing/stowing the luggage cover, make sure that the luggage cover is securely installed/stowed. Failure to do so may result in serious injury in the event of sudden braking or a collision.
- Do not place anything on the luggage cover. In the event of sudden braking or turning, the item may go flying and strike an occupant. This could lead to an unexpected accident, resulting in death or serious injury.
- Do not allow children to climb on the luggage cover. Climbing on the luggage cover could result in damage to the luggage cover, possibly causing death or serious injury to the child.

Other interior features

Sun visors




- 1 To set the visor in the forward position, flip it down.
- 2 To set the visor in the side position, flip down, unhook, and swing it to the side.

Vanity mirrors

Slide the cover to open.

The light turns on when the cover is opened.



Automatic light off to prevent battery discharge

If the vanity lights remain on when the engine switch is turned to OFF, the lights will go off automatically after 20 minutes.




■To prevent battery discharge

Do not leave the vanity lights on for extended periods while the engine is off.

Portable ashtray (if equipped)

The ashtray can be installed in the cup holder.




Power outlet

Please use a power supply for electronic goods that use less than 12 VDC/10 A (power consumption of 120 W).

When using electronic goods, make sure that the power consumption of all the connected power outlets is less than 120 W.


■ Front

Open the lid.




■ Console box (if equipped)

Open the console box and open the lid




■ Rear (if equipped)

Open the lid.



Luggage compartment (if equipped)

Open the lid.



■ The power outlet can be used when The engine switch is in ACC or ON.

When turning the engine switch off

Disconnect electrical devices with charging functions, such as mobile battery packs.

If such devices are left connected, the engine switch may not be turned off normally.

NOTICE

When power outlet is not in use

To avoid damaging the power outlet, close the power outlet lid when the power outlet is not in use.

Foreign objects or liquids that enter the power outlet may cause a short circuit.

■To prevent blown fuse

Do not use an accessory that uses more than 12 V 10 A.

■To prevent battery discharge

Do not use the power outlet longer than necessary when the engine is off.

USB charging ports (if equipped)

The USB charging ports are used to supply 2.1 A of electricity at 5 V to external devices.

The USB charging ports are for


charging only. They are not designed for data transfer or other purposes.

Depending on the external device, it may not charge properly. Refer to the manual included with the device before using a USB charging port.

■ Using the USB charging ports


Console box

Open the console box and open the lid.



Rear

Open the lid.



The USB charging ports can be used when

The engine switch is in ACC or ON.

- Situations in which the USB charging ports may not operate correctly
- If a device which consumes more than 2.1 A at 5 V is connected

- If a device designed to communicate with a personal computer, such as a USB memory device, is connected
- If the connected external device is turned off (depending on device)
- If the temperature inside the vehicle is high, such as after the vehicle has been parked in the sun

About connected external devices

Depending on the connected external device, charging may occasionally be suspended and then start again. This is not a malfunction.



NOTICE

- To prevent damage to the USB charging ports
- Do not insert foreign objects into the ports.
- Do not spill water or other liquids into the ports.
- When the USB charging ports are not in use, close the lids. If a foreign object or liquid enters a port may cause a short circuit.
- Do not apply excessive force to or impact the USB charging ports.
- Do not disassemble or modify the USB charging ports.
- To prevent damage to external devices
- Do not leave external devices in the vehicle. The temperature inside the vehicle may become high, resulting in damage to an external device.
- Do not push down on or apply unnecessary force to an external device or the cable of an external device while it is connected.
- ■To prevent battery discharge

Do not use the USB charging ports for a long period of time with the engine is off.

Wireless charger (if equipped)

A portable device can be charged by just placing Qi standard wireless charge compatible portable devices according to the Wireless Power Consortium, such as smartphones and mobile batteries, etc., on the charge area.


This function cannot be used with portable devices that are larger than the charging area. Also, depending on the portable device, it may not operate as normal. Please read the operation manual for portable devices to be used.

■ The "Qi" symbol

The "Qi" symbol is a trademark of the Wireless Power Consortium.



Name for all parts



- A Power supply switch
- **B** Operation indicator light
- C Charge area


Using the wireless charger

Press the power supply switch of the wireless charger.

Switches on and off with each press of the power supply switch.

When turned on, the operation indicator light (green) comes on.

Even with the engine off, the on/off state of the power supply switch is memorized.




2 Place the charging side of the portable device down.

When charging, the operation indicator

light (orange) comes on.

If charging is not occurring, try placing the portable device as close to the center of the charging area as possible.

When charging is complete, the operation indicator light (green) comes on.



■ Recharging function

- When charging is complete and after a fixed time in the charge suspension state, charging restarts.
- When the portable device is moved, charging is stopped for a moment and then it restarts.
- Lighting conditions of operation indicator light

Operation indicator light	Conditions
Turning off	When the Wireless charger power supply is off
Green	On Standby (charging possible state)
(comes on)	When charging is complete*

Opera indica ligh	ator	Conditions
Orange (comes on)	When placing the portable device on the charging area (detecting the portable device)	
	Charging	

- *: Depending on the portable device, there are cases where the operation indicator light will continue being lit up orange even after the charging is complete.
- When the operation indicator light flashes

When an error occurs, the operation indicator light flashes an orange color.

Handle the error based on the following tables.

Flashing repeatedly once every second (Orange)

Suspected causes	Handling method
Vehicle to charger communication failure.	Contact your Toyota dealer.

Repeatedly flashes 3 times continuously (Orange)

Suspected causes	Handling method
A foreign substance is between the portable device and charge area.	Remove the for- eign substance from between por- table device and the charge area.
The portable device is out of sync due to the device being shifted from the center of the charge area.	Place the portable device near the center of the charge area.

Repeatedly flashes 4 times continuously (Orange)

Suspected causes	Handling method
Temperature rising within the wireless charger.	Stop charging at once and start charging again after for a while.

The wireless charger can be operated when

The engine switch is in ACC or ON.

Usable portable devices

Qi standard wireless charge standard can be used on compatible devices. However, not all Qi standard devices and compatibility are guaranteed.

Starting with mobile phones and smartphones, it is aimed for low power electrically supplied portable devices of no more than 5W.

■ When covers and accessories are attached to portable devices

Do not charge in situations where cover and accessories not able to handle Qi are attached to the portable device. Depending on the type of cover and accessory, it may not be possible to charge. When charging is not performed even with the portable device placed on the charge area, remove the cover and accessories

■ While charging, noise enters the AM radio

Turn off the wireless charger and confirm that the noise has decreased. If the noise decreases, continuously pushing the power supply switch of the wireless charger for 2 seconds, the frequency of the charger can be changed and the noise can be reduced. Also, on that occasion, the operation indicator light will flash orange 2 times.

Important points of the wireless charger

- If the electronic key cannot be detected within the vehicle interior, charging cannot be done. When the door is opened and closed, charging may be temporarily suspended.
- When charging, the wireless charging device and portable device will get warmer, however this is not a malfunction.

When a portable device gets warm while charging, charging may stop due to the protection function on the portable device side. In this case, when the temperature of the portable device drops significantly, charge again.

■ Operation sounds

When the power supply is turned on, while searching for the portable device a sound will be produced, however this is not a malfunction



WARNING

■ Caution while driving

When charging a portable device, for safety reasons, the driver should not operate the main part of the portable device while driving.

A

WARNING

■ Caution regarding interference with electronic devices

People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators, as well as any other electrical medical device, should consult their physician about the usage of the wireless charger. The operations of the wireless charger may have an affect on medical devices.

■To prevent damage or burns

Observe the following precautions.
Failure to do so may result in a possibility of equipment failure and damage, catch fire, burns due to overheat.

- Do not insert any metallic objects between the charging area and the portable device while charging
- Do not attach stickers, metallic objects, etc., to the charger area or portable device
- Do not cover with cloth, etc., and charge
- Do not charge portable devices other than designated
- Do not attempt to dismantle for disassembly or modifications
- Do not hit or apply a strong force



NOTICE

Conditions in which the function may not operate correctly

In the following conditions, it may not operate correctly

- The portable device is fully charged
- There is foreign matter between the charge area and portable device
- The temperature of the portable device gets higher from charging

- The charging surface of the portable device is facing up
- The placement of the portable device is out of alignment with the charge area
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When the electronic key is in contact with, or is covered by the following metallic objects
- Cards to which aluminum foil is attached
- Cigarette boxes that have aluminum foil inside
- · Metallic wallets or bags
- Coins
- Hand warmers made of metal.
- Media such as CDs and DVDs
- When other wireless keys (that emit radio waves) are being used nearby In addition, excluding the above-mentioned, when the charger does not perform normally or the operation display lamp is flashing continuously, it is considered that the wireless charger is malfunctioning. Contact authorized Toyota dealer.

■ To prevent failure or damage to data

Do not bring magnetic cards, such as credit cards, or magnetic recording media, etc., close to the charger while charging, otherwise, data may disappear under the influence of magnetism. Also, do not bring precision instruments such as wrist watches, etc., close to the charger, as such objects may break.



NOTICE

 Do not leave portable devices in the cabin. The temperature inside the cabin may become high, when under the sun, and cause damage to the device.

■ To prevent battery discharge

When the engine is stopped, do not use the wireless charger for a long time.

Armrest

Fold down the armrest for use.



Ţ


NOTICE

■ To prevent damage to the armrest

Do not apply too much load on the armrest.

Assist grips

An assist grip installed on the ceiling can be used to support your body while sitting on the seat.



A

WARNING

Assist grips

Do not use the assist grip when getting in or out of the vehicle or rising from your seat.




NOTICE

To prevent damage to the assist grip

Do not hang any heavy object or put a heavy load on the assist grip.

Coat hooks

The coat hooks are provided with the rear assist grips.





WARNING

■ Items that must not be hanged on the hook

Do not hang coat hangers or other hard or sharp objects on the hook. If the SRS curtain shield airbags deploy, these items may become projectiles, causing death or serious injury.

6-1.	Maintenance and care	
	Cleaning and protecting the vehicle exterior312	
	Cleaning and protecting the vehicle interior315	
6-2.	Maintenance	
	Maintenance requirements318	
6-3.	Do-it-yourself maintenance	
	Do-it-yourself service precautions320	
	Hood322	
	Positioning a floor jack323	
	Engine compartment325	
	Tires331	
	Tire inflation pressure333	
	Wheels334	
	Air conditioning filter335	
	Wiper insert replacement337	
	Wireless remote control/electronic key battery341	
	Checking and replacing fuses	
	Dalak bulba 240	

Maintenance and care

Cleaning and protecting the vehicle exterior

Perform the following to protect the vehicle and maintain it in prime condition:

Cleaning instructions

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.

If water does not bead on a clean surface, apply wax when the vehicle body is cool.

Automatic car washes

- Before washing the vehicle:
- Fold the mirrors
- Turn off the power back door (if equipped)

Start washing from the front of the vehicle. Make sure to extend the mirrors before driving.

- Brushes used in automatic car washes may scratch the vehicle surface and harm your vehicle's paint.
- Rear spoiler may not be washable in

some automatic car washes. There may also be an increased risk of damage to vehicle.

■ High pressure car washes

As water may enter the cabin, do not bring the nozzle tip near the gaps around the doors or perimeter of the windows, or spray these areas continuously.

Note for a smart entry & start system (if equipped)

If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In that case, follow the following correction procedures to wash the vehicle:

- Place the key in a position 2 m (6 ft.) or more separate from the vehicle while the vehicle is being washed. (Take care to ensure that the key is not stolen.)
- Set the electronic key to battery-saving mode to disable the smart entry & start system. (→P.105)

Aluminum wheels (if equipped)

- Remove any dirt immediately by using a neutral detergent.
- Wash detergent off with water immediately after use.
- To protect the paint from damage, make sure to observe the following precautions.
- Do not use acidic, alkaline or abrasive detergent.
- · Do not use hard brushes.
- Do not use detergent on the wheels when they are hot, such as after driving or parking in hot weather.
- For vehicles with 19-inch matte painted wheels: The wheels are not maintained in the same way as normal aluminum wheels. For details, contact your Toyota dealer.
- When washing the vehicle, use water to wash off dirt.

If the vehicle is particularly dirty, use a diluted neutral detergent and a sponge

or a soft cloth and wash off the dirt by hand.

Wash detergent off with water immediately after use.

After using detergent, wash the detergent off with water and wipe the vehicle dry with a soft cloth.

- For vehicles with 19-inch matte painted wheels: Make sure to observe the following precautions to prevent damage to the matte paint.
- Do not polish or scrub with dry cloths, brushes, etc.
- Do not use detergents containing coatings or abrasives.
- If using an automatic car wash, make sure it does not include dedicated wheel brushes.
- Do not use high-pressure spray guns or steam cleaners.
- Do not use detergent on the wheels when they are hot, such as after driving or parking in hot weather.

■ Bumpers

Do not scrub with abrasive cleaners.




WARNING

When washing the vehicle

Do not apply water to the inside of the engine compartment. Doing so may cause the electrical components, etc. to catch fire.

When cleaning the windshield

Set the wiper switch to off. If the wiper switch is in "AUTO", the wipers may operate unexpectedly in the following situations, and may result in hands being caught or other serious injuries and cause damage to the wiper blades.



- A Off
- B "AUTO"
- When the upper part of the windshield where the raindrop sensor is located is touched by hand
- When a wet rag or similar is held close to the raindrop sensor
- If something bumps against the windshield
- If you directly touch the raindrop sensor body or if something bumps into the raindrop sensor

■ Precautions regarding the exhaust pipes

Exhaust gasses cause the exhaust pipes to become quite hot.

When washing the vehicle, be careful not to touch the pipes until they have cooled sufficiently, as touching hot exhaust pipes can cause burns.

Precaution regarding the rear bumper with Blind Spot Monitor (if equipped)

If the paint of the rear bumper is chipped or scratched, the system may malfunction. If this occurs, consult your Toyota dealer.

Λ

NOTICE

- To prevent paint deterioration and corrosion on the body and components (aluminum wheels, etc.)
- Wash the vehicle immediately in the following cases:
- · After driving near the sea coast
- · After driving on salted roads
- If coal tar or tree sap is present on the paint surface
- If dead insects, insect droppings or bird droppings are present on the paint surface
- After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
- If the vehicle becomes heavily soiled with dust or mud
- If liquids such as benzene and gasoline are spilled on the paint surface
- If the paint is chipped or scratched, have it repaired immediately.
- To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing the wheels.

■ Cleaning the exterior lights

 Wash carefully. Do not use organic substances or scrub with a hard brush.

This may damage the surfaces of the lights.

Do not apply wax to the surfaces of the lights.

Wax may cause damage to the lenses.

When using an automatic car wash

Set the wiper switch to off position. If the wiper switch is in "AUTO", the wipers may operate and the wiper blades may be damaged.

When using a high pressure car wash

- When washing the vehicle, do not let water from the high-pressure washer directly hit the camera (if equipped) or the area around the camera. Due to the shock from the high pressure water, it is possible that the device may not operate normally.
- Do not bring the nozzle tip close to boots (rubber or resin manufactured cover), or connectors or the following parts.

The parts may be damaged if they come into contact with high-pressure water.

- Traction related parts
- Steering parts
- Suspension parts
- Brake parts
- Keep the cleaning nozzle at least 30 cm (11.9 in.) away from the vehicle body. Otherwise resin section, such as moldings and bumpers, may be deformed and damaged. Also, do not continuously hold the nozzle in the same place.
- Do not spray the lower part of the windshield continuously. If water enters the air conditioning system intake located near the lower part of the windshield, the air conditioning system may not operate correctly.

Cleaning and protecting the vehicle interior

Perform cleaning in a manner appropriate to each component and its material.

Protecting the vehicle interior

- Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.
- If dirt cannot be removed, wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.

Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

■ Shampooing the carpets

There are several commercial foamingtype cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not use water. Wipe dirty surfaces and let them dry. Excellent results are obtained by keeping the carpet as dry as possible.

Handling the seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.

A 1

WARNING

Water in the vehicle

- Do not splash or spill liquid in the vehicle.
 - Doing so may cause electrical components, etc., to malfunction or catch fire.
- Do not get any of the SRS components or wiring in the vehicle interior wet.

(→P.31)

An electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or serious injury.

■ Vehicles with wireless charger:

Do not let the wireless charger (\rightarrow P.305) get wet. Failure to do so may cause the charger to become hot and cause burns or could cause electric shock resulting in death or serious injury.

Cleaning the interior (especially instrument panel)

Do not use a polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.



NOTICE

■ Cleaning detergents

- Do not use the following types of detergent, as they may discolor the vehicle interior or cause streaks or damage to painted surfaces:
- Non-seat portions: Organic substances such as benzene or gasoline, alkaline or acidic solutions, dye, and bleach
- Seats: Alkaline or acidic solutions, such as thinner, benzene, and alcohol

A

NOTICE

 Do not use a polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.

■ Preventing damage to leather surfaces

Observe the following precautions to avoid damage to and deterioration of leather surfaces:

- Remove any dust or dirt from leather surfaces immediately.
- Do not expose the vehicle to direct sunlight for extended periods of time. Park the vehicle in the shade, especially during summer.
- Do not place items made of vinyl, plastic, or containing wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

■ Water on the floor

Do not wash the vehicle floor with water

Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components such as the audio system above or under the floor of the vehicle. Water may also cause the body to rust.

When cleaning the inside of the windshield (vehicles with Toyota Safety Sense)

Do not allow glass cleaner to contact the lens. Also, do not touch the lens. (→P.180)

Cleaning the inside of the rear window

- Do not use a glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires.
- Be careful not to scratch or damage the heater wires.

Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe off any excess dirt and dust with a soft cloth dampened with diluted detergent.

Use a diluted water solution of approximately 5% neutral wool detergent.

- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry, soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded and ventilated area

■ Caring for leather areas

Toyota recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

Cleaning the synthetic leather areas

 Remove dirt and dust using a vacuum cleaner.

- Wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.
- Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

Maintenance requirements

To ensure safe and economical driving, day-to-day care and regular maintenance are essential. Toyota recommends the following maintenance:



WARNING

If your vehicle is not properly maintained

Improper maintenance could result in serious damage to the vehicle and possible death or serious injury.

Handling of the battery

Battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. (→P.328)

Scheduled maintenance

Scheduled maintenance should be performed at specified intervals according to the maintenance schedule.

For full details of your maintenance schedule, refer to the "Warranty and Service Booklet".

Do-it-yourself maintenance

What about do-it-yourself maintenance?

Many of the maintenance items are easy to do yourself if you have a little mechanical ability and a few basic automotive tools.

Note, however, that some maintenance

tasks require special tools and skills. These are best performed by qualified technicians. Even if you are an experienced do-it-yourself mechanic, we recommend that repairs and maintenance be conducted by your Toyota dealer who will keep a record of maintenance on your vehicle. This record could be helpful should you ever require Warranty Service.

Where to go for the maintenance service?

It makes good sense to take your vehicle to your local Toyota dealer for the maintenance service as well as other inspections and repairs.

Toyota technicians are well-trained specialists receiving the latest service information through technical bulletins, service tips and in-dealership training programs. They learn to work on Toyota before they work on your vehicle, rather than while they are working on it. Doesn't that seem like the best way?

Your Toyota dealer has invested a lot of money in special Toyota tools and service equipment. It helps them to do the job better and at less cost.

Your Toyota dealer's service department will perform all of the scheduled maintenance on your vehicle reliably and economically.

■ Does your vehicle need repairs?

Be on the alert for changes in performance and sounds, and visual tip-offs that indicate service is needed. Some important clues are:

- Engine missing, stumbling or pinging
- Appreciable loss of power
- Strange engine noises
- A fluid leak under the vehicle (However, water dripping from the air conditioning system after use is normal.)
- Change in exhaust sound (This may indicate a dangerous carbon monox-

ide leak. Drive with the windows open and have the exhaust system checked immediately.)

- Flat-looking tires, excessive tire squeal when cornering, uneven tire wear
- Vehicle pulls to one side when driven straight on a level road
- Strange noises related to suspension movement
- Loss of brake effectiveness, spongy feeling brake pedal, pedal almost touches the floor, vehicle pulls to one side when braking
- Engine coolant temperature continually higher than normal (→P.63, 66)

If you notice any of these clues, take your vehicle to your Toyota dealer as soon as possible. Your vehicle may need adjustment or repair.

Do-it-yourself service precautions

If you perform maintenance by yourself, be sure to follow the correct procedure as given in these sections.

Maintenance

Items	Parts and tools
Battery condition (→P.328)	 Grease Conventional wrench (for terminal clamp bolts)
Engine cool- ant level (→P.327)	"Toyota Super Long Life Coolant" or a similar high quality ethylene glycolbased non-silicate, non-amine, non-nitrite and non-borate coolant with long-life hybrid organic acid technology "Toyota Super Long Life Coolant" is premixed with 50% coolant and 50% deionized water. Funnel (used only for adding coolant)
Engine oil level (→P.325)	 "Toyota Genuine Motor Oil" or equivalent Rag or paper towel Funnel (used only for adding engine oil)

Items	Parts and tools
Fuses (→P.343)	Fuse with same amperage rating as original
Light bulbs (→P.346)	 Bulb with same number and wattage rating as original Phillips-head screwdriver Flathead screwdriver Wrench
Radiator and condenser (→P.328)) –
Tire inflation pressure (→P.333)	Tire pressure gauge Compressed air source
Washer fluid (→P.330)	 Water or washer fluid containing anti- freeze (for winter use) Funnel (used only for adding water or washer fluid)

WARNING

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury, observe the following precautions.

When working on the engine compartment

Keep hands, clothing and tools away from the moving fan and engine drive belt.

WARNING

- Be careful not to touch the engine. radiator, exhaust manifold, etc... right after driving as they may be hot. Oil and other fluids may also be hot.
- Do not leave anything that may burn easily, such as paper and rags, in the engine compartment.
- Do not smoke, cause sparks or expose an open flame to fuel or the battery. Fuel and battery fumes are flammable
- Be extremely cautious when working on the battery. It contains poisonous and corrosive sulfuric acid.
- Take care because brake fluid can. harm your hands or eyes and damage painted surfaces. If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately. If you still experience discomfort, consult a doctor.
- When working near the electric cooling fan or radiator grille

Be sure the engine switch is off. With the engine switch in ON, the electric cooling fan may automatically start to run if the air conditioning is on and/or the coolant temperature is high. (→P.328)

Safety glasses

Wear safety glasses to prevent flying or falling material, fluid spray, etc., from getting in your eyes.



NOTICE

If you remove the air cleaner filter

Driving with the air cleaner filter removed may cause excessive engine wear due to dirt in the air.

If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear or when the fluid level in the accumulator is high.

If the reservoir needs frequent refilling, it may indicate a serious problem.




Hood

Release the lock from the inside of the vehicle to open the hood.


Opening the hood

1 Pull the hood lock release lever.


The hood will pop up slightly.



2 Push the auxiliary catch lever to the left and lift the hood.



3 Hold the hood open by inserting the supporting rod into the slot.



WARNING

Pre-driving check

Check that the hood is fully closed and locked.


If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.

After installing the support rod into the slot

Make sure the rod supports the hood securely from falling down on to your head or body.

■When closing the hood

When closing the hood, take extra care to prevent your fingers etc. from being caught.



6



NOTICE

When closing the hood

Be sure to return the support rod to its clip before closing the hood. Closing the hood without returning the support rod properly could cause the hood to bend.


Positioning a floor jack

When using a floor lack, follow the instructions in the manual provided with the jack and perform the operation safely. When raising your vehicle with a floor jack, position the jack correctly.


Improper placement may damage your vehicle or cause injury.

Location of the jack point

■ Front




■ Rear



Engine compartment

Components



- A Fuse box (if equipped) (→P.343)
- B Engine oil filler cap (→P.325)
- C Engine oil level dipstick (→P.325)
- D Battery (→P.328)
- E Radiator (→P.328)
- F Electric cooling fan
- G Condenser (→P.328)
- H Washer fluid tank (→P.330)
- Engine coolant reservoir (→P.327)


Checking and adding the engine oil

With the engine at operating temperature and turned off, check the oil level on the dipstick.


■ Checking the engine oil

 Park the vehicle on level ground. After warming up the engine and turning off the engine, wait more than 5 minutes for the oil to drain back into the bottom of the engine.

2 Holding a rag under the end, pull the dipstick out.



- 3 Wipe the dipstick clean.
- 4 Reinsert the dipstick fully.
- 5 Holding a rag under the end, pull the dipstick out and check the oil level



- A Low
- **B** Normal
- Excessive

The shape of the dipstick may differ depending on the type of vehicle or engine.

6 Wipe the dipstick and reinsert it fully.

■ Checking the oil type and preparing the items needed


Make sure to check the oil type and prepare the items needed before adding oil.

- Engine oil selection
- →P.402
- Oil quantity (Low → Full)
 1.5 L (1.6 qt., 1.3 lmp.qt.)
- Item

Clean funnel

Adding engine oil

If the oil level is below or near the low level mark, add engine oil of the same type as that already in the engine.



- 1 Remove the oil filler cap by turning it counterclockwise.
- 2 Add engine oil slowly, checking the dipstick.
- 3 Install the oil filler cap by turning it clockwise.

■ Engine oil consumption

A certain amount of engine oil will be consumed while driving. In the following situations, oil consumption may increase, and engine oil may need to be refilled in between oil maintenance inter-

6

vals

- When the engine is new, for example directly after purchasing the vehicle or after replacing the engine
- If low quality oil or oil of an inappropriate viscosity is used
- When driving at high engine speeds or with a heavy load, when towing, or when driving while accelerating or decelerating frequently
- When leaving the engine idling for a long time, or when driving frequently through heavy traffic

A

WARNING

Used engine oil

- Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation and skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.
- Dispose of used oil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the ground. Call your Toyota dealer, service station or auto parts store for information concerning recycling or disposal.
- Do not leave used engine oil within the reach of children.

NOTICE

To prevent serious engine damage

Check the oil level on a regular basis.


- When replacing the engine oil
- Be careful not to spill engine oil on the vehicle components.

- Avoid overfilling, or the engine could be damaged.
- Check the oil level on the dipstick every time you refill the vehicle.
- Be sure the engine oil filler cap is properly tightened.
- If oil is spilled on the engine cover (A25A-FKS engine)

To prevent the engine cover from being damaged, remove any engine oil from the engine cover as soon as possible using a neutral detergent. Do not use an organic solvent such as brake cleaner.

Checking the coolant

The coolant level is satisfactory if it is between the "FULL" and "LOW" lines on the reservoir when the engine is cold.



- A Reservoir cap
- B "FULL" line
- C "LOW" line

If the level is on or below the "LOW" line, add coolant up to the "FULL" line. (→P.395)

■ Coolant selection

Only use "Toyota Super Long Life Coolant" or a similar high quality ethylene

glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology. "Toyota Super Long Life Coolant" is a mixture of 50% coolant and 50% deionized water. (Minimum temperature: - 35°C [-31°F])

For more details about coolant, contact your Toyota dealer.

If the coolant level drops within a short time of replenishing

Visually check the radiators, hoses, engine/power control unit coolant reservoir caps, drain cock and water pump. If you cannot find a leak, have your Toyota dealer, test the cap and check for leaks in the cooling system.



WARNING

■When the engine is hot

Do not remove the engine coolant reservoir cap.

The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.



NOTICE

■When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

If you spill coolant

Be sure to wash it off with water to prevent it from damaging parts or paint.

Checking the radiator and condenser

Check the radiator and condenser, and clear away any foreign objects.

If either of the above parts is extremely dirty or you are not sure of their condition, have your vehicle inspected by your Toyota dealer.



WARNING

■When the engine is hot

Do not touch the radiator or condenser as they may be hot and cause serious injuries, such as burns.

When the electric cooling fan is operating

Do not touch the engine compartment.


With the engine switch in ON, the electric cooling fan may automatically start to run if the air conditioning is on and/or the coolant temperature is high. Be sure the engine switch is off when working near the electric cooling fan or radiator grille.

Checking the battery

Check the battery as follows.

Battery exterior

Make sure that the battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.



- **A** Terminals
- B Hold-down clamp

■ Before recharging

When recharging, the battery produces hydrogen gas which is flammable and explosive. Therefore, observe the following precautions before recharging:

- If recharging with the battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the battery.
- After recharging/reconnecting the battery (vehicles with smart entry & start system)

The engine may not start. Follow the procedure below to initialize the system.

- Shift the shift lever to P (automatic transmission or CVT) or depress the brake pedal with the shift lever in N (manual transmission).
- 2 Open and close any of the doors.
- 3 Restart the engine.
- Unlocking the doors using the smart entry & start system may not be possible immediately after reconnecting the battery. If this happens, use the wireless remote control or the mechanical key to lock/unlock the doors.
- Start the engine with the engine switch in ACC. The engine may not start with the engine switch turned off. However, the engine will operate normally from the second attempt.
- The engine switch mode is recorded by the vehicle. If the battery is disconnected and reconnected, the vehicle will return the engine switch mode to the status it was in before the battery was disconnected. Make sure to turn off the engine switch before disconnecting the battery. Take extra care when connecting the battery if the engine switch mode prior to the battery being disconnected is unknown.

If the engine will not start even after multiple attempts, contact your Toyota

dealer

A

WARNING

■ Chemicals in the battery

A battery contains poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near the battery:

- Do not cause sparks by touching the battery terminals with tools.
- Do not smoke or light a match near the battery.
- Avoid contact with eyes, skin and clothes.
- Never inhale or swallow electrolyte.
- Wear protective safety glasses when working near the battery.
- Keep children away from the battery.

Where to safely charge the battery

Always charge the battery in an open area. Do not charge the battery in a garage or closed room where there is not sufficient ventilation.

Emergency measures regarding electrolyte

- If electrolyte gets in your eyes Flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility.
- If electrolyte gets on your skin Wash the affected area thoroughly.
 If you feel pain or burning, get medical attention immediately.

A

WARNING

- If electrolyte gets on your clothes It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.
- If you accidentally swallow electrolyte
 Drink a large quantity of water or milk. Get emergency medical attention immediately.

When there is insufficient battery fluid

Do not use if there is insufficient fluid in the battery. There is a possible danger that the battery may explode.




NOTICE

■When recharging the battery

Never recharge the battery while the engine is running. Also, be sure all accessories are turned off.


Checking and adding the washer fluid

If the washer fluid level is at "LOW", add washer fluid.



■ Using the gauge

The washer fluid level can be checked by observing the position of the level on the liquid-covered holes in the gauge. If the level falls below the second hole from the bottom (the "LOW" position), refill the washer fluid.



A Current fluid level



WARNING

When adding washer fluid

Do not add washer fluid when the engine is not or running as washer fluid contains alcohol and may catch fire if spilled on the engine, etc.

NOTICE

Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid. Doing so may cause streaking on the vehicle's painted surfaces, as well as damaging the pump leading to problems of the washer fluid not spraying.

Diluting washer fluid

Dilute washer fluid with water as necessary.

Refer to the freezing temperatures listed on the label of the washer fluid bottle.

6


Tires

Replace or rotate tires in accordance with maintenance schedules and treadwear.

Checking tires

Check if the treadwear indicators are showing on the tires. Also check the tires for uneven wear, such as excessive wear on one side of the tread

Check the spare tire condition and pressure if not rotated.



- A New tread
- B Worn tread
- C Treadwear indicator

The location of treadwear indicators is shown by a "TWI" or " \wedge " mark, etc..

molded into the sidewall of each tire. Replace the tires if the treadwear indicators are showing on a tire.

■ When to replace your vehicle's tires

Tires should be replaced if:

- The treadwear indicators are showing on a tire.
- You have tire damage such as cuts, splits, cracks deep enough to expose the fabric, and bulges indicating internal damage.
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage.

If you are not sure, consult with your Toyota dealer.

■ Tire life

Any tire over 6 years old must be checked by a qualified technician even if it has seldom or never been used or damage is not obvious.

If the tread on snow tires wears down below 4 mm (0.16 in.)

The effectiveness of the tires as snow tires is lost.



WARNING

When inspecting or replacing tires

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to parts of the drive train as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- Do not mix tires of different makes, models or tread patterns.
 Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Toyota.



WARNING

- Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- Do not mix summer, all season and snow tires
- Do not use tires that have been used on another vehicle.
 Do not use tires if you do not know how they were used previously.
- Vehicles with compact spare tire:
 Do not tow if your vehicle has a compact spare tire installed.



NOTICE

Driving on rough roads

Take particular care when driving on roads with loose surfaces or potholes. These conditions may cause losses in tire inflation pressure, reducing the cushioning ability of the tires. In addition, driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.

■ If tire inflation pressure of each tire becomes low while driving

Do not continue driving, or your tires and/or wheels may be ruined.

Tire rotation

Rotate the tires in the order shown.


2WD models:

To equalize tire wear and help extend tire life, Toyota recommends that tire rotation is carried out approximately every 10000 km (6000 miles).


AWD models:

To equalize tire wear and help extend tire life, Toyota recommends that tire rotation is carried out approximately every 5000 km (3000 miles).

► Vehicles without full-size spare tire



- A Front
- ▶ Vehicles with full-size spare tire



A Front

Tire inflation pressure

Make sure to maintain the proper tire inflation pressure. Tire inflation pressure should be checked at least once per month. However, Toyota recommends that tire inflation pressure be checked once every two weeks. (→P.407)

■ Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel economy
- Reduced driving comfort and poor handling
- Reduced tire life due to wear
- Reduced safety
- Damage to the drive train

If a tire needs frequent inflating, have it checked by your Toyota dealer.

■ Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

- Check only when the tires are cold. If your vehicle has been parked for at least 3 hours or has not been driven for more than 1.5 km or 1 mile, you will get an accurate cold tire inflation pressure reading.
 - Always use a tire pressure gauge. It is difficult to judge if a tire is properly inflated based only on its appearance.
- It is normal for the tire inflation pressure to be higher after driving as heat is generated in the tire. Do not reduce tire inflation pressure after driving.
- Passengers and luggage weight should be placed so that the vehicle is balanced.

A

WARNING

■ Proper inflation is critical to save tire performance

Keep your tires properly inflated. If the tires are not properly inflated, the following conditions may occur which could lead to an accident resulting in death or serious injury:

- Excessive wear
- Uneven wear
- Poor handling
- Possibility of blowouts resulting from overheated tires
- Air leaking from between tire and wheel
- Wheel deformation and/or tire damage
- Greater possibility of tire damage while driving (due to road hazards, expansion joints, sharp edges in the road, etc.)



NOTICE

When inspecting and adjusting tire inflation pressure

Be sure to put the tire valve caps back on.

If a valve cap is not installed, dirt or moisture may get into the valve and cause an air leak, resulting in decreased tire inflation pressure.

Wheels

If a wheel is bent, cracked or heavily corroded, it should be replaced. Otherwise, the tire may separate from the wheel or cause a loss of handling control.

Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width and inset*

Replacement wheels are available at your Toyota dealer.

- *: Conventionally referred to as offset. Toyota does not recommend using the following:
- Wheels of different sizes or types
- Used wheels
- Bent wheels that have been straightened

A


WARNING

When replacing wheels

- Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in a loss of handling control.
- Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing death or serious injury.

■When installing the wheel nuts

Be sure to install the wheel nuts with the tapered ends facing inward. Installing the nuts with the tapered ends facing outward can cause the wheel to break and eventually cause the wheel to come off while driving, which could lead to an accident resulting in death or serious injury.



A Tapered portion

- Never use oil or grease on the wheel bolts or wheel nuts. Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing an accident and resulting in death or serious injury. Remove any oil or grease from the wheel bolts or wheel nuts.
- Use of defective wheels prohibited

Do not use cracked or deformed wheels

Doing so could cause the tire to leak air during driving, possibly causing an accident.

Aluminum wheel precautions

 Use only Toyota wheel nuts and wrenches designed for use with your aluminum wheels.


- When rotating, repairing or changing your tires, check that the wheel nuts are still tight after driving 1600 km (1000 miles).
- Be careful not to damage the aluminum wheels when using tire chains
- Use only Toyota genuine balance weights or equivalent and a plastic or rubber hammer when balancing your wheels.

Air conditioning filter


The air conditioning filter must be changed regularly to maintain air conditioning efficiency.

Removal method

- 1 Turn the engine switch off.
- 2 Open the glove box and slide off the damper.




Push in each side of the glove box to disconnect the claws, and then slowly and fully open the glove box while supporting it.




With the glove box fully open, slightly lift up the glove box and pull toward the seat to detach the bottom of the glove box.


Do not use excessive force if the glove box does not detach when lightly pulled. Instead, pull toward the seat while slightly adjusting the height of the glove box.



5 Unlock the filter cover (A), pull the filter cover out of the claws (B), and remove the filter cover.



6 Remove the air conditioning filter and replace it with a new one.



7 When installing, reverse the steps listed.

■ Checking interval

Inspect and replace the air conditioning filter according to the maintenance schedule. In dusty areas or areas with heavy traffic flow, early replacement may be required. (For scheduled maintenance information, please refer to the "Warranty and Service Booklet")

If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.



NOTICE

When using the air conditioning system

Make sure that a filter is always installed.

Using the air conditioning system without a filter may cause damage to the system.

■ When removing the glove box

Always follow the specified procedure to remove the glove box (→P.335). If the glove box is removed without following the specified procedure, the hinge of the glove box may become damaged.



NOTICE

■ To prevent damage to the filter cover

When moving the filter cover in the direction of arrow to release the fitting, pay attention not to apply excessive force to the claws. Otherwise, the claws may be damaged.



Wiper insert replacement


When replacing the wiper insert, perform the following procedure to operate each wiper.

Windshield wipers

- Windshield wiper blade removal and installation
- 1 While holding the hook portion

 A of the wiper arm, first lift up
 the driver side, and then lift up
 the passenger side.


When returning the wiper arms to their original positions, first lower the passenger side, and then lower the driver side.



2 Lift the stopper using a flat-head screwdriver as shown in the illustration.


To prevent damage to the wiper arm, protect the tip of the screwdriver with a

raa.



3 Slide the wiper blade to remove it from the wiper arm.


When installing, reverse the steps listed.



■ Wiper insert replacement


1 Pull the wiper insert to remove the claw of the wiper blade from

the stopper, and pull out the wiper insert.



- A Stopper
- **B** Claw
- 2 Remove the 2 metal plates from the wiper insert pulled out, and install the plates to a new wiper insert.

Make sure that the cutout location and warp direction of the metal blades are same as the original.




- 3 Install the wiper insert to the wiper blade from the side without the stopper.
- 4 Secure the stopper of the wiper insert with the claw of the wiper blade.

6


Rear window wiper

Move the wiper blade until a click sound can be heard and the claw detaches, and then remove the wiper blade from the wiper arm.




Pull the wiper insert out past the stopper on the wiper blade, and then continue to pull until it is completely removed.

Lightly grasp between the claws of the wiper blade to allow the wiper insert to lift up, making it easier to remove.




3 Remove the 2 metal plates from the old wiper insert and install

them to the replacement wiper insert



Insert the wiper insert starting from the claw at the center of the wiper blade. Pass the wiper insert through the 3 claws so that it sticks out from the stopper, and then pass the wiper insert through the final remaining claw.

Applying a small amount of washer fluid to the wiper insert can make it easier to insert the claws into the grooves.




5 Check that the wiper blade claws are fitted in the grooves of the wiper insert.

If the wiper blade claws are not fitted in the grooves of the wiper insert, grasp the wiper insert and slide it back and forth multiple times to insert the claws into the grooves.

Lightly lift up the center of the wiper insert to make the rubber easier to

slide.



6 When installing a wiper blade, reverse the procedure in step 1.

After installing the wiper blade, check that the connection is locked.

■ Wiper blade and wiper insert handling

Improper handling may result in damage to the wiper blades or wiper insert. If you have any concerns about replacing the wiper blades or wiper insert yourself, contact your Toyota dealer.



NOTICE

When lifting the windshield wipers

- When raising the wiper arms off the windshield, lift up the driver side first, and then lift up passenger side. When returning the wipers to their original position, return the passenger side first.
- Do not lift a windshield wiper by the wiper blade. Otherwise, the wiper blade may be deformed.
- Do not operate the wiper lever when the windshield wipers are lifted. Otherwise, the windshield wipers may contact the hood, possibly resulting in damage to the windshield wipers and/or hood.

To prevent damage

 Be careful not to damage the claws when replacing the wiper insert.

- After the wiper blade is removed from the wiper arm, place a cloth, etc., between the rear window and wiper arm to prevent damage to the rear window
- Be sure not to pull excessively on the wiper insert or deform its metal plates.

Wireless remote control/electronic key battery

Replace the battery with a new one if it is depleted.

■ If the key battery is depleted

The following symptoms may occur:

- The smart entry & start system (if equipped) and wireless remote control will not function properly.
- The operational range will be reduced.

Items to prepare

Prepare the following before replacing the battery:

- Flathead screwdriver
- Small flathead screwdriver
- Lithium battery CR2032

■ Use a CR2032 lithium battery

- Batteries can be purchased at your Toyota dealer, local electrical appliance shops or camera stores.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the local laws.


Replacing the battery

- Vehicles without smart entry & start system
- Remove the cover.

Use a screwdriver of an appropriate size. Forcedly prying may cause the cover damaged.


To prevent damage to the key, cover

the tip of the screwdriver with a rag.



2 Remove the battery cover


If the battery cover is difficult to remove, lift the edge to remove it.



3 Remove the depleted battery.

When removing the battery, use a screwdriver of an appropriate size.


Insert a new battery with the "+" terminal facing up.



4 Install the battery cover with the tab facing up.

Push the entire edge of the battery


cover into the key.




5 Install the key cover.

Align the key cover with the key and then press it straight into the key.

Make sure that the key cover is securely installed without any gaps between it and the key.



- Vehicles with smart entry & start system
- 1 Release the lock and remove the mechanical key.




2 Remove the key cover.

Use a screwdriver of an appropriate size. Forcedly prying may cause the

cover damaged.

To prevent damage to the key, cover the tip of the flathead screwdriver with a rag.




3 Remove the depleted battery using a small flathead screw-driver.

When removing the cover, the electronic key module may stick to the cover and the battery may not be visible. In this case, remove the electronic key module in order to remove the battery.

When removing the battery, use a screwdriver of an appropriate size.

Insert a new battery with the "+" terminal facing up.



4 When installing, reverse the steps listed.



WARNING

Removed battery and other parts

These parts are small and if swallowed by a child, they can cause choking. Keep away from children. Failure to do so could result in death or serious injury.



NOTICE

For normal operation after replacing the battery

Observe the following precautions to prevent accidents:

- Always work with dry hands.
 Moisture may cause the battery to rust.
- Do not touch or move any other component inside the remote control.
- Do not bend either of the battery terminals.


Checking and replacing fuses

If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.

Checking and replacing fuses


- 1 Turn the engine switch off.
- 2 Open the fuse box cover.
- Engine compartment: Type A fuse box (if equipped)

Push claw (A) and (B) to completely release the lock, and then lift up the cover.




► Engine compartment: Type B fuse box

Push claw (A) and (B) to completely release the lock, and then lift up the cover.



▶ Left side instrument panel


Push the tab in and remove the cover, and then remove the lid.



3 Remove the fuse.

Only type A fuse can be removed using


the pullout tool.




4 Check if the fuse is blown

Replace the blown fuse with a new fuse of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.

▶ Type A




- A Normal fuse
- B Blown fuse
- ▶ Type B



- A Normal fuse
- B Blown fuse

6

▶ Type C



- A Normal fuse
- B Blown fuse

■ After a fuse is replaced

- When installing the lid, make sure that the tab is installed securely.
- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement. (→P.346)
- If the replaced fuse blows again, have the vehicle inspected by your Toyota dealer.

If there is an overload in a circuit

The fuses are designed to blow, protecting the wiring harness from damage.



WARNING

■ To prevent system breakdowns and vehicle fire

Observe the following precautions. Failure to do so may cause damage to the vehicle, and possibly a fire or injury.

- Never use a fuse of a higher amperage rating than that indicated, or use any other object in place of a fuse.
- Always use a genuine Toyota fuse or equivalent.
 Never replace a fuse with a wire, even as a temporary fix.

 Do not modify the fuses or fuse boxes



NOTICE

■ Before replacing fuses

Have the cause of electrical overload determined and repaired by your Toyota dealer as soon as possible.

■ To prevent damage to the engine compartment fuse box cover

When opening the fuse box, completely release the claw locks before lifting up the cover. Otherwise, the claws may be damaged.

Light bulbs


You may replace the following bulbs by yourself. The difficulty level of replacement varies depending on the bulb. As there is a danger that components may be damaged, we recommend that replacement is carried out by your Toyota dealer.

Preparing for light bulb replacement

Check the wattage of the light bulb to be replaced. (→P.409)


Bulb location

► Front (type A)




- A Front turn signal lights
- B Fog lights
- C Outer foot lights (if equipped)

Front (type B)



- A Front turn signal lights
- **B** Fog lights
- C Outer foot lights (if equipped)
- Rear



- A Rear turn signal lights
- B Back-up lights
- Lights that need to be replaced by your Toyota dealer
- Headlights
- Daytime running lights
- Front position lights
- Side turn signal lights
- Tail lights
- Stop lights
- High mounted stoplight
- License plate lights

■LED lights

The lights other than the following lights each consist of a number of LEDs. If any of the LEDs burn out, take your vehicle to your Toyota dealer to have the light replaced.

- Front turn signal
- Fog lights
- Rear turn signal lights
- Back-up lights
- Outer foot lights (if equipped)

■ Condensation build-up on the inside of the lens


Temporary condensation build-up on the inside of the light lens does not indicate a malfunction. Contact your Toyota dealer for more information in the following situations:

- Large drops of water have built up on the inside of the lens.
- Water has built up inside the light.


Replacing light bulb

■ Front turn signal lights (front type A and B)


1 Turn the bulb base counterclockwise



2 Remove the light bulb.




Install a new light bulb then install the bulb base to the light unit by inserting it and turning the bulb base clockwise.




■ Fog lights

1 To allow enough working space, turn the steering wheel.




2 Remove the screws.




3 Remove the screws and clips, partly remove the fender liner.



4 Unplug the connector




5 Turn the bulb base counterclockwise




6 Set the new light bulb.

Align the 3 tabs on the light bulb with the mounting, and insert. Turn it clockwise to set.




7 Set the connector.


Shake the bulb base gently to check that it is not loose, turn the front fog lights on once and visually confirm that no light is leaking through the mounting.



8 Reinstall the fender liner.




9 Reinstall the screws.




■ Rear turn signal lights

1 Open the back door and remove the cover.




2 Remove the securing screws and remove the unit.


Remove the lamp assembly by pulling it directly backward from the rear of the vehicle.



3 Turn the bulb base counterclockwise.




4 Remove the light bulb.




Install a new light bulb then install the bulb base to the light

unit by inserting it and turning the bulb base clockwise




6 Align the grooves on the light unit with the claws, and insert the light unit straight so that the pin on the light unit fit into the hole.


Confirm that the light unit is completely secured.



7 Reinstall the screws.




8 Reinstall the cover.



Back-up lights

Open the back door and remove the cover.


To prevent damage to the cover, protect the tip of the screwdriver with a rag.




2 Turn the bulb base counterclockwise.

Remove the cord from the clip before


turning the bulb base.



3 Remove the light bulb.




4 Install a new light bulb.




Install the bulb base to the light unit by inserting it and turning the bulb base clockwise.

Secure the cord with the clip back again

after installing the bulb base.



6 Reinstall the cover.




■ Outer foot lights (if equipped)

Press the upper part of the outside rear view mirror to tilt the mirror face upward, and disconnect the four tabs behind the mirror.

Pry the mirror out toward you, and disconnect two tabs at a time.

Work carefully, ensuring that you do not


drop the mirror.




2 Disconnect the connectors behind the mirror, and remove the mirror.

Make sure to check the connectors, to avoid connecting upside down when reinstalling.


Work carefully, ensuring that you do not drop the mirror.



3 Disconnect the tabs behind the mirror cover, and remove the mirror cover.



4 Fold the mirror before removing the light unit.




5 Remove the light unit.

Remove the two screws, and disengage the two tabs with a flat-head screwdriver.

Work carefully, ensuring that you do not


6

damage the tabs.




6 Turn the bulb base counter-clockwise.

Remove the cord from the clip before turning the bulb base.




7 Remove the light bulb.



8 Install a new light bulb then install the bulb base to the light unit by inserting it and turning the bulb base clockwise.


Secure the cord with the clip back again after installing the bulb base.




9 Install the light unit.

Make sure that the two tabs of the light unit are engaged securely, and install


the two screws.




10 Extend the mirror.



11 Install the mirror cover.




12 Reconnect the connectors of the mirror



13 Align the tabs, and secure the mirror by pushing in each diagonally-opposite pair of tabs in order.

Make sure to insert the tabs in order as shown in the illustration, and push them in until a click is heard.

If you do not hear the click, do not force the tabs in. Instead, remove the mirror and check that the tabs are aligned.





WARNING


Replacing light bulb

- Turn off the light. Do not attempt to replace the bulb immediately after turning off the light. The bulb become very hot and may cause burns.
- Do not touch the glass portion of the light bulb with bare hands. When it is unavoidable to hold the glass portion, use and hold with a clean dry cloth to avoid getting moisture and oils on the bulb. Also, if the bulb is scratched or dropped, it may blow out or crack.
- Fully install light bulb and any parts used to secure it. Failure to do so may result in heat damage, fire, or water entering the light unit. This may damage the light or cause condensation to build up on the lens.
- Do not attempt to repair or disassemble light bulbs, connectors, electric circuits or component parts. Doing so may result in death or serious injury due to electric shock.

To prevent damage or fire

- Make sure bulb is fully seated and locked.
- Check the wattage of the bulb before installing to prevent heat damage.





7-1.	Essential information
	Emergency flashers358
	If your vehicle has to be
	stopped in an emergency358
	If the vehicle is trapped in rising water360
7-2.	Steps to take in an emergency
	If your vehicle needs to be towed361
	If you think something is wrong366
	Fuel pump shut off system367
	If a warning light turns on or a warning buzzer sounds368
	If a warning message is displayed5
	If you have a flat tire378
	If the engine will not start .386
	If you lose your keys388
	If the electronic key does not operate properly (vehicles
	with smart entry & start system)388
	If the vehicle battery is discharged391
7	If your vehicle overheats395
	If the vehicle becomes stuck

When trouble arises



Emergency flashers


The emergency flashers are used to warn other drivers when the vehicle has to be stopped in the road due to a breakdown, etc.

Operating instructions

Press the switch

All the turn signal lights will flash.

To turn them off, press the switch once again.



■ Emergency flashers

- If the emergency flashers are used for a long time while the engine is not operating, the battery may discharge.
- If any of the SRS airbags deploy (inflate) or in the event of a strong rear impact, the emergency flashers will turn on automatically.

The emergency flashers will turn off automatically after operating for approximately 20 minutes. To manually turn the emergency flashers off, press the switch twice. (The emergency flashers may not turn on automatically depending on the force of the impact and conditions of the collision.)

If your vehicle has to be stopped in an emergency

Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

Stopping the vehicle


 Steadily step on the brake pedal with both feet and firmly depress it.

Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.

- Shift the shift lever to N.
- If the shift lever is shifted to N
- After slowing down, stop the vehicle in a safe place by the road.
- 4 Stop the engine.
- If the shift lever cannot be shifted to N
- 3 Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.
- **4** Perform the following procedure to stop the engine:


Vehicles without smart entry & start system

Turn the engine switch to ACC.



▶ Vehicles with smart entry & start system

Press and hold the engine switch for 2 consecutive seconds or more, or press it briefly 3 times or more in succession.




5 Stop the vehicle in a safe place by the road.



WARNING

- If the engine has to be turned off while driving
- Power assist for the brakes and steering wheel will be lost, making the brake pedal harder to depress and the steering wheel heavier to turn. Decelerate as much as possible before turning off the engine.

Vehicles without smart entry & start system: Never attempt to remove the key, as doing so will lock the steering wheel.



If the vehicle is trapped in rising water

In the event the vehicle is submerged in water, remain calm and perform the following.

- Remove the seat belt first.
- If the door can be opened, open the door and exit the vehicle.
- If the door can not be opened, open the window using the power window switch and exit the vehicle through the window.
- If the window can not be opened using the power window switch, remain calm, wait until the water level inside the vehicle rises to the point that the water pressure inside of the vehicle equals the water pressure outside of the vehicle, and then open the door and exit the vehicle.

A

WARNING

■ Using an emergency hammer * for emergency escape

The front side windows and rear side windows, as well as the rear window can be shattered with an emergency hammer used for emergency escape. However, an emergency hammer can not shatter the windshield as it is laminated glass.

Contact your Toyota dealer or any reliable repairer, or aftermarket accessory manufacturer for further information about an emergency hammer.

Escaping the vehicle from the window

There are cases where escaping the vehicle from the window is not possible due to seating position, passenger body type, etc.

When using an emergency hammer, consider your seat location and the size of the window opening to ensure that the opening is accessible and large enough to escape.

If your vehicle needs to be towed

If towing is necessary, we recommend having your vehicle towed by your Toyota dealer or commercial towing service, using a wheel-lift type truck or flathed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws.

2WD models: If towing your vehicle with a wheel-lift type truck from the front, the vehicle's rear wheels and axles must be in good conditions. (→P.363)

If they are damaged, use a towing dolly or flatbed truck.

AWD models: If towing your vehicle with a wheel-lift type truck, use a towing dolly. (→P.363)



WARNING


Observe the following precautions.

Failure to do so may result in death or serious injury.

When towing the vehicle


▶ 2WD models

Be sure to transport the vehicle with the front wheels raised or with all four wheels raised off the ground. If the vehicle is towed with the front wheels contacting the ground, the drivetrain and related parts may be damaged.



► AWD models

Be sure to transport the vehicle with all four wheels raised off the ground. If the vehicle is towed with the tires contacting the ground, the drivetrain or related parts may be damaged, the vehicle may fly off the truck.





WARNING

While towing

- When towing using cables or chains, avoid sudden starts, etc. which place excessive stress on the towing eyelets, cables or chains. The towing eyelets, cables or chains may become damaged, broken debris may hit people, and cause serious damage.
- Do not turn the engine switch to OFF.
 There is a possibility that the steering wheel is locked and cannot be operated.

Installing towing eyelet to the vehicle

Make sure that towing eyelet is installed securely.

If not securely installed, towing eyelet may come loose during towing.



NOTICE

- To prevent damage to the vehicle when towing using a wheel-lift type truck
- Do not tow the vehicle from the rear when the engine switch is in OFF or the key is removed (vehicles without smart entry & start system). The steering lock mechanism is not strong enough to hold the front wheels straight.
- When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.
- To prevent damage to the vehicle when towing with a sling-type truck

Do not tow with a sling-type truck, either from the front or rear.

■ To prevent damage to the vehicle during emergency towing

Do not secure cables or chains to the suspension components.

■ When towing the vehicle (vehicles with Stop & Start system)

When it is necessary to tow the vehicle with all four wheels contacting the ground, perform the following procedure before towing the vehicle to protect the system.

Turn the engine switch to OFF once, and then start the engine. If the engine does not start, turn the engine switch to ON.


Situations when it is necessary to contact dealers before towing

The following may indicate a problem with your transmission. Contact your Toyota dealer or commercial towing service before towing.

- The engine is running but the vehicle does not move.
- The vehicle makes an abnormal sound.


Towing with a sling-type truck

Do not tow with a sling-type truck to prevent body damage.




Towing with a wheel-lift type truck

► From the front (2WD models) Release the parking brake.



➤ From the front (AWD models)
Use a towing dolly under the rear wheels.




From the rear

Use a towing dolly under the front wheels.




Using a flatbed truck

If your vehicle is transported by a flatbed truck, it should be tied down at the locations shown in the illustration.



If you use chains or cables to tie down your vehicle, the angles shaded in black must be 45°.

Do not overly tighten the tie downs or the vehicle may be damaged.



Emergency towing

If a tow truck is not available in an emergency, your vehicle may be temporarily towed using cables or chains secured to the emergency towing eyelets. This should only be attempted on hard surfaced roads for at most 80 km (50 miles) at under 30 km/h (18 mph).

A driver must be in the vehicle to steer and operate the brakes. The vehicle's wheels, drive train, axles, steering and brakes must be in good condition.

For vehicles with automatic transmission or CVT, only the front towing evelet may be used.


Emergency towing procedure

To have your vehicle towed by another vehicle, the towing eyelet must be installed to your vehicle. Install the towing eyelet by following the specified procedure.


- Take out the towing eyelet.
 (→P.379)
- 2 Using a flathead screwdriver, remove eyelet cover (A), and then remove eyelet cover (B).

To protect the bodywork, place a rag between the screwdriver and the vehicle body as shown in the illustration.


▶ Type A




▶ Type B



- Insert the towing eyelet into the hole and tighten partially by hand.
- ▶ Type A




▶ Type B




Tighten down the towing eyelet securely using a wheel nut wrench or hard metal bar.

Type A



▶ Type B



Securely attach cables or chains to the towing eyelet.

Take care not to damage the vehicle body.

6 Enter the vehicle being towed and start the engine.

If the engine does not start, turn the engine switch to ON.

Vehicles with Stop & Start system: Before towing the vehicle, turn the engine switch to OFF once, and then start the engine.

7 Shift the shift lever to N and release the parking brake.

When the shift lever cannot be shifted: →P.155, 158

■ While towing

If the engine is not running, the power assist for the brakes and steering will not function, making steering and braking more difficult.

■ Wheel nut wrench

Wheel nut wrench is installed in the tool bag. $(\rightarrow P.379)$

If you think something is wrong

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact your Toyota dealer as soon as possible.

Visible symptoms

- Fluid leaks under the vehicle (Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear
- Engine coolant temperature gauge needle continually points higher than normal.

Audible symptoms

- Changes in exhaust sound
- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Pinging or other noises related to the engine

Operational symptoms

- Engine missing, stumbling or running roughly
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking

- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

Fuel pump shut off system

To minimize the risk of fuel leakage when the engine stalls or when an airbag inflates upon collision, the fuel pump shut off system stops the supply of fuel to the engine.

Restarting the engine

Follow the procedure below to restart the engine after the system is activated

- Turn the engine switch to ACC or off.
- 2 Restart the engine.



NOTICE

■ Before starting the engine

Inspect the ground under the vehicle. If you find that fuel has leaked onto the ground, the fuel system has been damaged and is in need of repair. Do not restart the engine.

If a warning light turns on or a warning buzzer sounds

Calmly perform the following actions if any of the warning lights comes on or flashes. If a light comes on or flashes, but then goes off, this does not necessarily indicate a malfunction in the system. However, if this continues to occur, have the vehicle inspected by your Toyota dealer.

Actions to the warning lights or warning buzzers

■ Brake system warning light (warning buzzer)

Warning light	Details/Actions
(Red)	Indicates that: ■ The brake fluid level is low; or ■ The brake system is malfunctioning → Immediately stop the vehicle in a safe place and contact your Toyota dealer. Continuing to drive the vehicle may be dangerous.

■ Brake system warning light

Warning light	Details/Actions
(Yellow)	Indicates a malfunction in the parking brake system → Have the vehicle inspected by your Toyota dealer immediately.

■ Charging system warning light

Warning light	Details/Actions
	Indicates a malfunction in the vehicle's charging system → Immediately stop the vehicle in a safe place and contact your Toyota dealer.

High coolant temperature warning light* (warning buzzer)

Warning light	Details/Actions
₽	Indicates that the engine is overheating → Immediately stop the vehicle in a safe place. Handling method (→P.395)

*: This light illuminates on the multi-information display with a message.

■ Low engine oil pressure warning light* (warning buzzer)

Warning light	Details/Actions
وسيح.	Indicates that the engine oil pressure is too low → Immediately stop the vehicle in a safe place and contact your Toyota dealer.

^{*:} This light illuminates on the multi-information display with a message.

■ Malfunction indicator lamp

Warning light	Details/Actions
y ~~	Indicates a malfunction in: ■ The electronic engine control system; ■ The electronic throttle control system; ■ The emission control system (if equipped); or ■ The electronic CVT control system → Have the vehicle inspected by your Toyota dealer immediately.

■ SRS warning light

Warning light	Details/Actions
×	Indicates a malfunction in: ■ The SRS airbag system; or ■ The seat belt pretensioner system → Have the vehicle inspected by your Toyota dealer immediately.

■ ABS warning light

Warning light	Details/Actions
(ABS)	Indicates a malfunction in: ■ The ABS; or ■ The brake assist system → Have the vehicle inspected by your Toyota dealer immediately.

■ Electric power steering system warning light (warning buzzer)

Warning light	Details/Actions
(Red/yellow)	Indicates a malfunction in the EPS (Electric Power Steering) system → Have the vehicle inspected by your Toyota dealer immediately.

■ iMT indicator

Warning light	Details/Actions
(Yellow) (If equipped)	Indicates a malfunction in the iMT → Have the vehicle inspected by your Toyota dealer immediately.

■ PCS warning light (warning buzzer)

Warning light	Details/Actions
	When a buzzer sounds simultaneously: Indicates a malfunction has occurred in the PCS (Pre-Collision System). → Have the vehicle inspected by your Toyota dealer immediately.
(Flashes or illuminates)	When a buzzer does not sound: The PCS (Pre-Collision System) has become temporarily unavailable, corrective action may be necessary. → Follow the instructions displayed on the multi-
	information display (→P.182, 376)
O	If the PCS (Pre-Collision System) or VSC (Vehicle Stability Control) system is disabled, the PCS warning light will illuminate. → P.191

■ LTA indicator/LDA indicator (warning buzzer)

Warning light	Details/Actions
(Orange) (If equipped)	Indicates a malfunction in the LTA (Lane Tracing Assist) or LDA (Lane Departure Alert with steering control) → Follow the instructions displayed on the multi-information display. (→P.201, 208)

■ Stop & Start cancel indicator

Warning light	Details/Actions
(Flashes) (If equipped)	Indicates a malfunction in the Stop & Start system → Have the vehicle inspected by your Toyota dealer immediately.

■ Toyota parking assist-sensor OFF indicator (warning buzzer)

Warning light	Details/Actions
P₩≜ OFF (Flashes) (If equipped)	When a buzzer sounds: Indicates a malfunction in the Toyota parking assistsensor function → Have the vehicle inspected by your Toyota dealer immediately. When a buzzer does not sound: Indicates that the system is temporarily unavailable, possibly due to a sensor being dirty or covered with ice, etc. → Follow the instructions displayed on the multi-information display. (→P.246, 375)

■ RCTA OFF indicator (warning buzzer)

Warning light	Details/Actions
	When a buzzer sounds:
60,	Indicates a malfunction in the RCTA (Rear Cross Traffic Alert) function
RCTA	→ Have the vehicle inspected by your Toyota dealer immediately.
(Flashes) (If equipped)	When a buzzer does not sound: Indicates that the rear bumper around the radar sensor is covered with dirt, etc. (→P.237)
	\rightarrow Follow the instructions displayed on the multi-information display. (\rightarrow P.237, 375)

■ Slip indicator light

Warning light	Details/Actions
	Indicates a malfunction in: ■ The VSC/Trailer Sway Control system; ■ The TRC system; ■ The hill-start assist control system; or ■ The downhill assist control system (if equipped) → Have the vehicle inspected by your Toyota dealer immediately.

■ Brake Override System/Drive-Start Control (if equipped) warning light^{*} (warning buzzer)

Warning light	Details/Actions
	Brake Override System
	Indicates that the accelerator and brake pedals are being depressed simultaneously, and the Brake Override System is operating.
	→ Release the accelerator pedal and depress the brake pedal.
	Indicates a malfunction in the Brake Override System (with warning buzzer)
o To	→ Have the vehicle inspected by your Toyota dealer immediately.
- U	Drive-Start Control
60,	Indicates that the shift position was changed and Drive-Start Control was operated while depressing the accelerator pedal. (with warning buzzer)
X Y	ightarrow Momentarily release the accelerator pedal.
	Indicates a malfunction in the Drive-Start Control (with warning buzzer)
	→ Have the vehicle inspected by your Toyota dealer immediately.

^{*:} This light illuminates on the multi-information display with a message.

■ Brake hold operated indicator (warning buzzer)

Warning light	Details/Actions
HOLD	Indicates a malfunction in the brake hold system → Have the vehicle inspected by your Toyota dealer immediately.

■ Parking brake indicator

Warning light	Details/Actions
	It is possible that the parking brake is not fully engaged or released → Operate the parking brake switch once again.
(Flasiles)	This light comes on when the parking brake is not released. If the light turns off after the parking brake is fully released, the system is operating normally.

■ Low fuel level warning light

Warning light	Details/Actions
	Indicates that remaining fuel is approximately 8.3 L (2.2 gal., 1.8 lmp. gal.) or less → Refuel the vehicle.

■ Driver's and front passenger's seat belt reminder light (warning buzzer)*

Warning light	Details/Actions
80.	Warns the driver and/or front passenger to fasten their seat belts
	→ Fasten the seat belt. If the front passenger's seat is occupied, the front passenger's seat belt also needs to be fastened to make the warning light (warning buzzer) turn off.

Driver's and front passenger's seat belt warning buzzer:

The driver's and front passenger's seat belt warning buzzer sounds to alert the driver and front passenger that his or her seat belt is not fastened. The buzzer sounds for 30 seconds after the vehicle reaches a speed of 20 km/h (12 mph). Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 90 more seconds.

■ Rear passengers' seat belt reminder light (warning buzzer)*

Warning light	Details/Actions
	Warns the rear passengers to fasten their seat belts \rightarrow Fasten the seat belt.

*: Rear passengers' seat belt warning buzzer:

The rear passengers' seat belt warning buzzer sounds to alert the rear passenger that his or her seat belt is not fastened. The buzzer sounds once if the vehicle reaches a speed of 20 km/h (12 mph). If the seat belt is still unfastened, the buzzer will sound intermittently for 6 seconds. Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 60 more seconds.

■ Warning buzzer

In some cases, the buzzer may not be heard because of noisy place or an audio sound.

■ Front passenger detection sensor, seat belt reminder and warning

- If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash and the warning buzzer to sound even if a passenger is not sitting in the seat.
- If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.

If the malfunction indicator lamp comes on while driving

The malfunction indicator lamp will come on if the fuel tank becomes completely empty. If the fuel tank is empty, refuel the vehicle immediately. The malfunction indicator lamp will go off after several trips.

In the malfunction indicator lamp does not go off, contact your Toyota dealer as soon as possible.

■ Electric power steering system warning light (warning buzzer)

When the battery charge becomes insufficient or the voltage temporarily drops, the electric power steering sys-

tem warning light may come on and the warning buzzer may sound.

∧ v

WARNING

If a warning light comes on or a warning buzzer sounds when a warning message is shown on the multi-information display*

Check and follow the message shown on the multi-information display.

Failure to do so may result in death or serious injury.


- *: Warning lights illuminate in red or yellow and the warning buzzer beeps once or sounds continuously.
- When the electric power steering system warning light comes on

When the light comes on yellow, the assist to the power steering is restricted. When the light comes on red, the assist to the power steering is lost and handling operations of the steering wheel become extremely heavy.

If the steering wheel becomes heavier than usual when operating, hold firmly and operate using more force than usual.

If a warning message is displayed

The multi-information display shows warnings of system malfunctions, incorrectly performed operations, and messages that indicate a need for maintenance. When a message is shown, perform the correction procedure appropriate to the message.



If a warning message is displayed again after the appropriate actions have been performed, contact your Toyota dealer.

■ Warning messages

The warning messages explained below may differ from the actual messages according to operation conditions and vehicle specifications.

If a message about an operation is shown

If a message about an operation of the accelerator pedal or brake pedal is shown

A warning message about an operation of the brake pedal may be shown while the driving assist systems such as PCS (Pre-Collision system) (if equipped) or the dynamic radar cruise control with

full-speed range (if equipped) is operating. If a warning message is shown, be sure to decelerate the vehicle or follow an instruction shown on the multi-information display.

A warning message is shown when Brake Override System or Drive-Start Control (if equipped) (→P.133). Follow the instructions on the multi-information display operates.

 If a message about an operation of the engine switch is shown

An instruction for operation of the engine switch is shown when the incorrect procedure for starting the engine is performed or the engine switch is operated incorrectly. Follow the instructions shown on the multi-information display to operate the engine switch again.

If a message about a shift lever operation is shown

To prevent the shift lever from being operated incorrectly or the vehicle from moving unexpectedly, a message that requires shifting the shift lever may be shown on the multi-information display. In that case, follow the instruction of the message and shift the shift lever.

 If a message or image about an open/close state of a part or replenishment of a consumable is shown
 Confirm the part indicated by the multi-

Confirm the part indicated by the multiinformation display or a warning light, and then perform the coping method such as closing the open door or replenishing a consumable.

If a message that indicates the need for visiting your Toyota dealer is displayed

The system or part shown on the multiinformation display is malfunctioning. Have the vehicle inspected by your Toyota dealer immediately.

If a message that indicates the need for referring to Owner's Manual is displayed

- If "Engine Coolant Temp High" is shown, follow the instructions (→P.395)
- If the following messages are shown, there may be a malfunction. Immediately stop the vehicle in a safe place and contact your Toyota dealer. Continuing to drive the vehicle may be dangerous.
- "Charging System Malfunction"
- "High Transmission Fluid Temp" (vehicles with automatic transmission)
- "Transmission Oil Temp. High" (vehicles with CVT)
- "Smart Entry & Start System Malfunction"
- If the following messages are shown, there may be a malfunction.
 Immediately have the vehicle inspected by your Toyota dealer.
- "Oil Pressure Low"
- "Braking Power Low"

■If "Shift to P when Parked" is shown

Message is displayed when the driver's door is opened without turning the engine switch to OFF with the shift lever in any position other than P.

Shift the shift lever to P.

■ If "Auto Power OFF to Conserve Battery" is shown

Power was turned off due to the automatic power off function.

Next time when starting the engine, increase the engine speed slightly and maintain that level for approximately 5 minutes to recharge the battery.

If "Engine Oil Level Low Add or Replace" is displayed

The engine oil level may be low. Check the level of the engine oil, and add engine oil if necessary. This message may be displayed if the vehicle is stopped on a slope. Move the vehicle to a level surface and check if the message disappears.

■If "Front Camera Unavailable" or "Front Camera Unavailable See Owner's Manual" is displayed

The following systems may be suspended until the problem shown in the message is resolved. (→P.182, 368)

- PCS (Pre-Collision System)
- LTA (Lane Tracing Assist)
- LDA (Lane Departure Alert with steering control)
- Automatic High Beam
- RSA (Road Sign Assist)
- Dynamic radar cruise control with fullspeed range
- Dvnamic radar cruise control

If "Radar Cruise Control Unavailable See Owner's Manual" is shown

The dynamic radar cruise control with full-speed range (if equipped) or dynamic radar cruise control (if equipped) system is suspended temporarily or until the problem shown in the message is resolved. (causes and coping methods: →P.182)

■If "Radar Cruise Control Unavailable" is shown

The dynamic radar cruise control with full-speed range (if equipped) or dynamic radar cruise control (if equipped) system cannot be used temporarily. Use the system when it becomes available again.

■ Warning buzzer

→P.374



WARNING

If a warning light comes on or a warning buzzer sounds when a warning message is shown on the multi-information display

→P.374



NOTICE

"High Power Consumption Partial Limit On AC/Heater Operation" is frequently shown

There is a possible malfunction relating to the charging system or the battery may be deteriorating. Have the vehicle inspected by your Toyota dealer.

If you have a flat tire

Your vehicle is equipped with a spare tire. The flat tire can be replaced with the spare tire.

For details about tires: →P.331



WARNING

■ If you have a flat tire


Do not continue driving with a flat tire.

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair, which could result in an accident.

Before jacking up the vehicle

- Stop the vehicle in a safe place on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to P (vehicles with automatic transmission or CVT) or R (vehicles with manual transmission).
- Stop the engine.
- Turn on the emergency flashers. (→P.358)
- For vehicles with power back door; Turn off the power back door system.
 (→P.102)

Location of the spare tire, jack and tools



- A Jack
- **B** Tool bag
- C Jack handle
- D Wheel nut wrench
- E Towing eyelet
- F Spare tire



WARNING

■ Using the tire jack

Observe the following precautions. Improper use of the tire jack may cause the vehicle to suddenly fall off the jack, leading to death or serious injury.


 Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains. Only use the tire jack that comes with this vehicle for replacing a flat tire.

Do not use it on other vehicles, and do not use other tire jacks for replacing tires on this vehicle.

A

WARNING

Put the jack properly in its jack point.




- Do not put any part of your body under the vehicle while it is supported by the jack.
- Do not start the engine or drive the vehicle while the vehicle is supported by the jack.
- Do not raise the vehicle while someone is inside
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.
- Stop the vehicle on firm, flat and level ground, firmly set the parking brake and shift the shift lever to P (automatic transmission or CVT) or R (manual transmission). Block the wheel diagonally opposite to the one being changed if necessary.
- When lowering the vehicle, make sure that there is no-one near the vehicle. If there are people nearby, warn them vocally before lowering.

Taking out the jack

 Vehicles without full-size spare tire: Open the deck board (→P.298). Vehicles with full-size spare tire: Take out the deck board.


2 Take out the jack.

Do not touch the threaded portion of the jack as it is greased.




Taking out the tool bag

Take out the tool bag.




Taking out the spare tire

1 Take out the jack holder.



Loosen the center fastener that

secures the spare tire.




WARNING

■When storing the spare tire

Be careful not to catch fingers or other body parts between the spare tire and the body of the vehicle.

Replacing a flat tire


Chock the tires.




	Flat tire	Wheel chock positions
•	Front left- hand side	Behind the rear right- hand side tire
	Front right- hand side	Behind the rear left-hand side tire
	Rear left- hand side	In front of the front right- hand side tire
	Rear right- hand side	In front of the front left- hand side tire

2 Remove the wheel ornament using the wrench.

Vehicles with full wheel ornament: To protect the wheel ornament, place a rag between the wrench and the wheel ornament




Slightly loosen the wheel nuts (one turn).




4 Turn the tire jack portion A by hand until the notch of the jack is in contact with the jack point.

After removing the jack from the jack holder, turn part A of the jack in the opposite direction to lower the jack, and then adjust the jack set position.


The jack point guides are located under the rocker panel. They indicate the jack point positions.



5 Assemble the jack handle and the wheel nut wrench as shown in the illustration




6 Raise the vehicle until the tire is slightly raised off the ground.



Remove all the wheel nuts and the tire.

When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel

surface



Λ

WARNING

Replacing a flat tire

 Do not touch the disc wheels or the area around the brakes immediately after the vehicle has been driven.

After the vehicle has been driven the disc wheels and the area around the brakes will be extremely hot. Touching these areas with hands, feet or other body parts while changing a tire, etc. may result in burns.

- Failure to follow these precautions could cause the wheel nuts to loosen and the tire to fall off, resulting in death or serious injury.
- Have the wheel nuts tightened with a torque wrench to 103 N•m (10.5 kgf•m, 76 ft•lbf) as soon as possible after changing wheels.
- Do not attach a heavily damaged wheel ornament, as it may fly off the wheel while the vehicle is moving.
- When installing a tire, only use wheel nuts that have been specifically designed for that wheel.
- If there are any cracks or deformations in the bolt screws, nut threads or bolt holes of the wheel, have the vehicle inspected by your Toyota dealer.
- When installing the wheel nuts, be sure to install them with the tapered ends facing inward. (→P.334)




WARNING

For vehicles with power back door: In cases such as when replacing tires, make sure to turn off the power back door system (→P.102). Failure to do so may cause the back door to operate unintentionally if the power back door switch is accidentally touched, resulting in hands and fingers being caught and iniured.

Installing the spare tire


1 Remove any dirt or foreign matter from the wheel contact surface

If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, causing the tire to come off




2 Install the spare tire and loosely tighten each wheel nut by hand by approximately the same amount.


When replacing a steel wheel with a steel wheel, tighten the nuts until the tapered portion A comes into loose contact with the disc wheel seat B




When replacing an aluminum wheel with a steel wheel, tighten the wheel nuts until the tapered portion A comes into loose contact with the disc wheel seat B



When replacing an aluminum wheel with an aluminum wheel, turn the wheel nuts until the washers A come into contact with the disc wheel B.




Lower the vehicle.




4 Firmly tighten each wheel nut two or three times in the order shown in the illustration.

Tightening torque: 103 N•m (10.5 kgf•m, 76 ft•lbf)



5 Reinstall the wheel ornament*.

Align the cutout of the wheel ornament with the valve stem as shown.



- The wheel ornament cannot be installed on the compact spare tire.
- 6 Stow the flat tire, tire jack and all tools.

■ The compact spare tire (if equipped)

 The compact spare tire is identified by the label "TEMPORARY USE ONLY" on the tire sidewall.

Use the compact spare tire temporarily, and only in an emergency.

- Make sure to check the tire inflation pressure of the compact spare tire.
 (→P.407)
- When the compact spare tire (if equipped) is equipped

The vehicle height may becomes lower when driving with the compact spare tire compared to when driving with standard tires.


If you have a flat front tire on a road covered with snow or ice (vehicles with compact spare tire)

Install the compact spare tire on one of the rear wheels of the vehicle. Perform the following steps and fit tire chains to the front tires:

- Replace a rear tire with the compact spare tire.
- 2 Replace the flat front tire with the tire removed from the rear of the vehicle
- 3 Fit tire chains to the front tires.

■ When stowing the jack

Before storing the jack, adjust the height of the jack to match the shape of the jack holder.



WARNING

- When using the compact spare tire (if equipped)
- Remember that the compact spare tire provided is specifically designed for use with your vehicle. Do not use your compact spare tire on another vehicle.
- Do not use more than one compact spare tire simultaneously.
- Replace the compact spare tire with a standard tire as soon as possible.
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.
- When the compact spare tire (if equipped) is attached

The vehicle speed may not be correctly detected, and the following systems may not operate correctly:

- ABS & Brake assist
- VSC/Trailer Sway Control (if equipped)
- TRC
- Cruise control (if equipped)
- Dvnamic radar cruise control with full-speed range (if equipped)
- · Dynamic radar cruise control (if equipped)
- PCS (Pre-Collision System) (if equipped)
- FPS
- LDA (Lane Departure Alert with steering control) (if equipped)
- · LTA (Lane Tracing Assist) (if equipped)
- · Tire pressure warning system (if equipped)

- Automatic High Beam (if equipped)
- · BSM (Blind Spot Monitor) (if equipped)
- · Downhill assist control system (if equipped)
- · Rear view monitor system (if equipped)
- · Panoramic view monitor (if equipped)
- Tovota parking assist monitor (i equipped)
- Tovota parking assist-sensor (if equipped)
- Navigation system (if equipped)

Also, not only can the following systems not be utilized fully, but they may actually negatively affect the drivetrain components:

- Dynamic Torque Control AWD svstem (if equipped)
- Dynamic Torque Vectoring AWD system (if equipped)
- Speed limit when using the compact spare tire (if equipped)

Do not drive at speeds in excess of 80 km/h (50 mph) when a compact spare tire is installed on the vehicle.

The compact spare tire is not designed for driving at high speeds. Failure to observe this precaution may lead to an accident causing death or serious injury.

After using the tools and jack

Before driving, make sure all the tools and jack are securely in place in their storage location to reduce the possibility of personal injury during a collision or sudden braking.



NOTICE

Be careful when driving over bumps with the compact spare tire installed on the vehicle (if equipped)

The vehicle height may becomes lower when driving with the compact spare tire compared to when driving with standard tires. Be careful when driving over uneven road surfaces.

- Driving with tire chains and the compact spare tire (if equipped)
- Vehicles with T165/80D17 104M tire: Compact spare tires fitted to this vehicle must have a maximum load rating of not less than 900 kg or a load index of 104 and a speed category symbol of not less than M (130 km/h).
 - Vehicles with T165/90D18 107M tire: Compact spare tires fitted to this vehicle must have a maximum load rating of not less than 975 kg or a load index of 107 and a speed category symbol of not less than M (130 km/h).
- Do not fit tire chains to the compact spare tire. Tire chains may damage the vehicle body and adversely affect driving performance.

If the engine will not start

If the engine will not start even though correct starting procedures are being followed (→P.148, 149), consider each of the following points:

The engine will not start even though the starter motor operates normally

One of the following may be the cause of the problem:

- There may not be sufficient fuel in the vehicle's tank.
 Refuel the vehicle.
- The engine may be flooded.
 Try to restart the engine again following correct starting procedures. (→P.148, 149)
- There may be a malfunction in the engine immobilizer system.
 (→P.54)

The starter motor turns over slowly, the interior lights and headlights are dim, or the horn does not sound or sounds at a low volume

One of the following may be the cause of the problem:

- The battery may be discharged.
 (→P.391)
- The battery terminal connec-

tions may be loose or corroded.

The starter motor does not turn over (vehicles with smart entry & start system)

The engine starting system may be malfunctioning due to an electrical problem such as electronic key battery depletion or a blown fuse. However, an interim measure is available to start the engine. (→P.387)

The starter motor does not turn over, the interior lights and headlights do not turn on, or the horn does not sound

One of the following may be the cause of the problem:

- The battery may be discharged. (→P.391)
- One or both of the battery terminals may be disconnected.
- There may be a malfunction in the (vehicles with smart entry & start system).

Contact your Toyota dealer if the problem cannot be repaired, or if repair procedures are unknown.

Emergency start function (vehicles with smart entry & start system except manual transmission)

When the engine does not start, the following steps can be used as an interim measure to start the engine if the engine switch is functioning normally:

Pull the parking brake switch to check that the parking brake is set. (→P.164)

Parking brake indicator will come on.

- 2 Shift the shift lever to P.
- 3 Turn the engine switch to ACC.
- 4 Press and hold the engine switch for about 15 seconds while depressing the brake pedal firmly.

Even if the engine can be started using the above steps, the system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

If you lose your keys

New genuine keys can be made by your Toyota dealer using the other key and the key number stamped on your key number plate. Keep the plate in a safe place such as your wallet, not in the vehicle.



NOTICE

When an electronic key is lost (if equipped)

If the electronic key remains lost, the risk of vehicle theft increases significantly. Visit your Toyota dealer immediately with all remaining electronic keys that were provided with your vehicle

If the electronic key does not operate properly (vehicles with smart entry & start system)

If communication between the electronic key and vehicle is interrupted (→P.105) or the electronic key cannot be used because the battery is depleted, the smart entry & start system and wireless remote control cannot be used. In such cases, the doors can be opened and the engine can be started by following the procedure below.

- When the electronic key does not work properly
- Make sure that the smart entry & start system has not been deactivated in the customization setting. If it is off, turn the function on.

 (Customizable features →P.414)
- Check if battery-saving mode is set. If it is set, cancel the function. (→P.105)



NOTICE


In case of a smart entry & start system malfunction, or other key related problems

Take your vehicle with all the electronic keys provided with your vehicle to your Toyota dealer.

Locking and unlocking the doors


Use the mechanical key (\rightarrow P.87) in order to perform the following oper-

ations



- Locks all the doors
- 2 Unlocks all the door

■ Key linked functions



- 1 Closes the windows and the moon roof*1 or panoramic moon roof*1 (turn and hold)*2
- 2 Opens the windows and the moon roof^{*1} or panoramic moon roof^{*1} (turn and hold)^{*2}
- *1: If equipped
- *2: These settings must be customized at your Toyota dealer.

⚠ WARNING

When using the mechanical key and operating the power windows or the moon roof (if equipped) or panoramic moon roof (if equipped)


Operate the power window or the moon roof or panoramic moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window or the moon roof or panoramic moon roof. Also, do not allow children to operate the mechanical key. It is possible for children and other passengers to get caught in the power window or the moon roof or panoramic moon roof.

Starting the engine

- Automatic transmission or CVT
 - Ensure that the shift lever is in P and depress the brake pedal.
- Touch the Toyota emblem side of the electronic key to the engine switch.

When the electronic key is detected, a buzzer sounds and the engine switch will turn to ON.

When the smart entry & start system is deactivated in customization setting, the engine switch will turn to ACC.



- 3 Firmly depress the brake pedal and check that is displayed on the multi-information display.
- **4** Press the engine switch shortly and firmly.

In the event that the engine still cannot be started, contact your Toyota dealer.

- ▶ Manual transmission
- 1 Ensure that the shift lever is in N and depress the clutch pedal.
- 2 Touch the Toyota emblem side of the electronic key to the engine switch.

When the electronic key is detected, a buzzer sounds and the engine switch will turn to ON.

When the smart entry & start system is deactivated in customization setting, the engine switch will turn to ACC.



- 3 Firmly depress the clutch pedal
 - and check that is shown on the multi-information display.
- 4 Press the engine switch.

In the event that the engine still cannot be started, contact your Toyota dealer.

■ Stopping the engine

- ▶ Automatic transmission or CVT Shift the shift lever to P and press the engine switch as you normally do when stopping the engine.
- ► Manual transmission

 Shift the shift lever to N and press the engine switch as you normally do when stopping the engine.

■ Replacing the key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery is depleted. (\$\infty\$P.341)

■ Changing engine switch modes

▶ Automatic transmission or CVT Release the brake pedal and press the engine switch in step 3 above.

The engine does not start and modes will be changed each time the switch is pressed. (→P.151)

Manual transmission

Release the clutch pedal and press the engine switch in step 3 above.

The engine does not start and modes will be changed each time the switch is pressed. (→P.151)

If the vehicle battery is discharged


The following procedures may be used to start the engine if the vehicle's battery is discharged.

You can also call your Toyota dealer or a qualified repair shop.

Restarting the engine

If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your vehicle by following the steps below.


- **1** Open the hood. $(\rightarrow P.322)$
- 2 Connect a positive jumper cable clamp to A on your vehicle and connect the clamp on the other end of the positive cable to B on the second vehicle. Then, connect a negative cable clamp to C on the second vehicle and connect the clamp at the other end of the negative cable to D.
- ▶ M20A-FKS engine



- A Positive (+) battery terminal (your vehicle)
- B Positive (+) battery terminal (second vehicle)
- C Negative (-) battery terminal (second vehicle)
- D Solid, stationary, unpainted metallic point away from the battery and any

moving parts as shown in the illustration

▶ A25A-FKS engine



- A Positive (+) battery terminal (your vehicle)
- B Positive (+) battery terminal (second vehicle)
- C Negative (-) battery terminal (second vehicle)
- D Solid, stationary, unpainted metallic point away from the battery and any moving parts as shown in the illustration
- 3 Start the engine of the second vehicle. Increase the engine speed slightly and maintain at that level for approximately 5 minutes to recharge the battery of your vehicle.
- Vehicles with smart entry & start system only: Open and close any of the doors of your vehicle with the engine switch OFF.
- Vehicles without smart entry & start system: Maintain the engine speed of the second vehicle and start the engine of your vehicle.

Vehicles with smart entry & start

- system: Maintain the engine speed of the second vehicle and start the engine of your vehicle by turning the engine switch to ON.
- 6 Once the vehicle's engine has started, remove the jumper cables in the exact reverse order from which they were connected.

Once the engine starts, have the vehicle inspected at your Toyota dealer as soon as possible.

■ Starting the engine when the battery is discharged

The engine cannot be started by push-

starting.

■ To prevent battery discharge

- Turn off the headlights and the audio system while the engine is stopped. (Vehicles with Stop & Start system: Except when the engine is stopped due to the Stop & Start system)
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic.

■ When the battery is removed or discharged

- Information stored in the ECU is cleared. When the battery is depleted, have the vehicle inspected at your Toyota dealer.
- Some systems may require initialization. (→P.423)

■ When removing the battery terminals

When the battery terminals are removed, the information stored in the ECU is cleared. Before removing the battery terminals, contact your Toyota dealer.

■ Charging the battery

The electricity stored in the battery will discharge gradually even when the vehicle is not in use, due to natural discharge and the draining effects of certain electrical appliances. If the vehicle is left for a long time, the battery may discharge, and the engine may be unable to start. (The battery recharges automatically during driving.)

When recharging or replacing the battery (vehicles with smart entry & start system)

- In some cases, it may not be possible to unlock the doors using the smart entry & start system when the battery is discharged. Use the wireless remote control or the mechanical key to lock or unlock the doors.
- The engine may not start on the first attempt after the battery has

recharged but will start normally after the second attempt. This is not a malfunction

The engine switch mode is memorized by the vehicle. When the battery is reconnected, the system will return to the mode it was in before the battery was discharged. Before disconnecting the battery, turn the engine switch off.

If you are unsure what mode the engine switch was in before the battery discharged, be especially careful when reconnecting the battery.

■ When the battery is removed or discharged (vehicles with Stop & Start system)

After the battery terminals have been disconnected and reconnected or the battery has been replaced, the Stop & Start system may not automatically stop the engine for approximately 5 to 60 minutes.

When replacing the battery

- Vehicles with Stop & Start system:
 Use a genuine battery specifically
 designed for use with the Stop & Start
 system or a battery with equivalent
 specifications to a genuine battery. If an
 unsupported battery is used, Stop &
 Start system functions may be restricted
 to protect the battery. Also, battery performance may decrease and the engine
 may not be able to restart. Contact your
 Toyota dealer for details.
- Use a battery that conforms to European regulations.
- Type A:

Use a battery that the case size is same as the previous one (LN3), 20 hours rate capacity (20HR) is equivalent (65Ah) or greater, and performance rating (CCA) is equivalent (603A) or greater.

Type B:

Use a battery that the case size is same

as the previous one (LN2), 20 hours rate capacity (20HR) is equivalent (60Ah) or greater, and performance rating (CCA) is equivalent (560A) or greater.

Type C:

Use a battery that the case size is same as the previous one (LN2), 20 hours rate capacity (20HR) is equivalent (60Ah) or greater, and performance rating (CCA) is equivalent (360A) or greater.

- If the sizes differ, the battery cannot be properly secured.
- If the 20 hour rate capacity is low, even if the time period where the vehicle is not used is a short time, the battery may discharge and engine may not be able to start.

A

WARNING

When removing the battery terminals

Always remove the negative (-) terminal first. If the positive (+) terminal contacts any metal in the surrounding area when the positive (+) terminal is removed, a spark may occur, leading to a fire in addition to electrical shocks and death or serious injury.

Avoiding battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the battery.

- Make sure each jumper cable is connected to the correct terminal and that it is not unintentionally in contact with any other than the intended terminal.
- Do not allow the other end of the jumper cable connected to the "+" terminal to come into contact with any other parts or metal surfaces in the area, such as brackets or unpainted metal.

- Do not allow the + and clamps of the jumper cables to come into contact with each other.
- Do not smoke, use matches, cigarette lighters or allow open flame near the battery.

Battery precautions

The battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the battery:

- When working with the battery, always wear safety glasses and take care not to allow any battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- Do not lean over the battery.
- In the event that battery fluid comes into contact with the skin or eyes, immediately wash the affected area with water and seek medical attention.

Place a wet sponge or cloth over the affected area until medical attention can be received.

- Always wash your hands after handling the battery support, terminals, and other battery-related parts.
- Do not allow children near the battery.

■ When replacing the battery

For information regarding battery replacement, contact your Toyota dealer.

To prevent damage to the vehicle (vehicles with manual transmission)

Do not pull- or push-start the vehicle as the three-way catalytic converter may overheat and become a fire hazard.



NOTICE

When handling jumper cables

When connecting the jumper cables, ensure that they do not become entangled in the cooling fans or engine drive belt.

If your vehicle overheats

The following may indicate that your vehicle is overheating.


- The needle of the engine coolant temperature gauge
 (→P.63, 66) enters the red
 zone or a loss of engine power
 is experienced. (For example,
 the vehicle speed does not
 increase.)
- "Engine Coolant Temp High Stop in a Safe Place See Owner's Manual" is shown on the multi-information display.
- Steam comes out from under the hood.

Correction procedures


- Stop the vehicle in a safe place and turn off the air conditioning system, and then stop the engine.
- 2 If you see steam: Carefully lift the hood after the steam subsides. If you do not see steam: Carefully lift the hood.

3 After the engine has cooled down sufficiently, inspect the hoses and radiator core (radiator) for any leaks.

If a large amount of coolant leaks, immediately contact your Toyota dealer.




- A Radiator
- **B** Cooling fan
- The coolant level is satisfactory if it is between the "FULL" and "LOW" lines on the reservoir.



- A Reservoir
- B "FULL" line
- "LOW" line
- **5** Add coolant if necessary. Water can be used in an emergency if

coolant is unavailable.



6 Start the engine and turn the air conditioning system on to check that the radiator cooling fan operate and to check for coolant leaks from the radiator or hoses.

The fan operate when the air conditioning system is turned on immediately after a cold start. Confirm that the fan is operating by checking the fan sound and air flow. If it is difficult to check these, turn the air conditioning system on and off repeatedly. (The fan may not operate in freezing temperatures.)

- If the fan is not operating:
 Stop the engine immediately
 and contact your Toyota dealer.
 If the fan is operating:
 Have the vehicle inspected at
 the nearest Toyota dealer.
- 8 Check if "Engine Coolant Temp High Stop in a Safe Place See Owner's Manual" is shown on the multi-information display. If the message does not disappear:

Stop the engine and contact your Toyota dealer.

If the message is not displayed: Have the vehicle inspected at the nearest Toyota dealer.



WARNING

When inspecting under the hood of vour vehicle

Observe the following precautions. Failure to do so may result in serious iniury such as burns.

- If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot
- Keep hands and clothing (especially a tie, a scarf or a muffler) away from the fan and belts. Failure to do so may cause the hands or clothing to be caught, resulting in serious injury.
- Do not loosen the coolant reservoir. cap while the engine and radiator are hot. High temperature steam or coolant could spray out.



NOTICE

When adding engine coolant

Add coolant slowly after the engine has cooled down sufficiently. Adding cool coolant to a hot engine too quickly can cause damage to the enaine.

To prevent damage to the cooling system

Observe the following precautions:

- Avoid contaminating the coolant with foreign matter (such as sand or dust etc.).
- Do not use any coolant additive.

If the vehicle becomes stuck


Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud. dirt or snow:

Recovering procedure

- Stop the engine. Set the parking brake and shift the shift lever to P (vehicles with automatic transmission or CVT) or N (vehicles with manual transmission).
- 2 Remove the mud, snow or sand from around the stuck tire.
- Place wood, stones or some other material to help provide traction under the tires.
- 4 Restart the engine.
- 5 Shift the shift lever to D or R (vehicles with automatic transmission or CVT) or 1 or R (vehicles with manual transmission) and release the parking brake. Then, while exercising caution, depress the accelerator pedal.

■ When it is difficult to free the vehicle

Press ₹ to turn off TRC. (→P.267)



A

WARNING

When attempting to free a stuck vehicle

If you choose to push the vehicle back and forth to free it, make sure the surrounding area is clear to avoid striking other vehicles, objects or people. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

When shifting the shift lever (vehicles with automatic transmission or CVT)

Be careful not to shift the shift lever with the accelerator pedal depressed.

This may lead to unexpected rapid acceleration of the vehicle that may cause an accident resulting in death or serious injury.



NOTICE

- To avoid damaging the transmission and other components
- Avoid spinning the wheels and depressing the accelerator pedal more than necessary.
- If the vehicle remains stuck even after these procedures are performed, the vehicle may require towing to be freed.

8-1.	Specifications
	Maintenance data (fuel, oil level, etc.)400
	Fuel information410
8-2.	Customization
	Customizable features411
8-3.	Initialization
	Items to initialize423

Maintenance data (fuel, oil level, etc.)

Dimensions

Overall length*1		4600 mm (181.1 in.)*2
		4610 mm (181.5 in.)*3
Overall width*1		1855 mm (73.0 in.)*2
Overall width		1865 mm (73.4 in.)*3
Q #4 * 1.*1		1685 mm (66.3 in.)*4
Overall height*1		1690 mm (66.5 in.)*5
Wheelbase*1		2690 mm (105.9 in.)
	Front	1605 mm (63.2 in.)*4
Tread ^{*1}		1595 mm (62.8 in.)*5
IIeau	Rear	1625 mm (64.0 in.)*4
		1615 mm (63.6 in.)*5


^{*1:} Unladen vehicle

Vehicle identification

■ Vehicle identification number

The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Toyota. It is used in registering the ownership of your vehicle.

This number is also on the manufacturer's label.



^{*2:} Except for AXAA54R-ANZVBQ model*6


^{*3:} For AXAA54R-ANZVBQ model*6

^{*4:} Vehicles without 235/55R19 tires

^{*5:} Vehicles with 235/55R19 tires

 $^{^{*6}}$: The model code is indicated on the manufacturer's label. (→P.400)


This number is also stamped under the right-hand front seat.



■ Engine number

The engine number is stamped on the engine block as shown.

▶ M20A-FKS engine



► A25A-FKS engine



Engine

▶ M20A-FKS

Model	M20A-FKS	
Туре	4-cylinder in line, 4-cycle, gasoline	
Bore and stroke	80.5 × 97.6 mm (3.17 × 3.84 in.)	
Displacement	1987 cm ³ (121.3 cu.in.)	
Valve clearance	Automatic adjustment	
Drive belt tension	Automatic adjustment	

A25A-FKS

Model	A25A-FKS
Туре	4-cylinder in line, 4-cycle, gasoline
Bore and stroke	87.5 × 103.4 mm (3.44 × 4.07 in.)
Displacement	2487 cm ³ (151.8 cu.in.)

Valve clearance	Automatic adjustment
Drive belt tension	Automatic adjustment

Fuel

Fuel type	Unleaded gasoline only	
Research Octane Number	91 or higher	
Fuel tank capacity (Reference)	55 L (14.5 gal., 12.1 lmp.gal.)	

Lubrication system

■ Oil capacity (Drain and refill — reference*)

	M20A-FKS engine	A25A-FKS engine
With filter	4.3 L (4.5 qt., 3.8 lmp. qt.)	4.5 L (4.8 qt., 4.0 lmp. qt.)
Without filter	3.9 L (4.1 qt., 3.4 lmp. qt.)	4.2 L (4.4 qt., 3.7 lmp. qt.)

^{*:} The engine oil capacity is a reference quantity to be used when changing the engine oil. Warm up and turn off the engine, wait more than 5 minutes, and check the oil level on the dipstick.

■ Engine oil selection

"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Use Toyota approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade:


0W-16:

API grade SN "Resource-Conserving" multigrade engine oil 0W-20, 5W-20, 5W-30 and 10W-30:

API grade SL "Energy-Conserving", SM "Energy-Conserving" or SN "Resource-Conserving"; or ILSAC multigrade engine oil 15W-40: API grade SL, SM or SN multigrade engine oil

Recommended viscosity (SAE):

If you use SAE 10W-30 or a higher viscosity engine oil in extremely low temperatures, the engine may become difficult to start, so SAE 0W-16, 0W-20, 5W-20 or 5W-30 engine oil is recommended.




A Temperature range anticipated before next oil change

Oil viscosity (0W-16 is explained here as an example):

- The 0W in 0W-16 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 16 in 0W-16 indicates the viscosity characteristic of the oil when the oil is at high temperature. An oil with a higher viscosity (one with a higher value) may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

How to read oil container labels:

Either or both API registered marks are added to some oil containers to help you select the oil you should use.



A API Service Symbol

Top portion: "API SERVICE SN" means the oil quality designation by American Petroleum Institute (API).

Center portion: "SAE 0W-16" means the SAE viscosity grade.

Lower portion: "Resource-Conserving" means that the oil has fuel-saving and environmental protection capabilities.

B ILSAC Certification Mark

The International Lubricant Specification Advisory Committee (ILSAC) Certification Mark is displayed on the front of the container.

Cooling system

	With automatic transmission	7.0 L (7.4 qt., 6.2 lmp.qt.)	
Capacity*	With CVT	6.9 L (7.3 qt., 6.1 Imp.qt.)	
	With manual trans- mission	6.4 L (6.8 qt., 5.6 Imp.qt.)	
		Use either of the following: "Toyota Super Long Life Coolant" Similar high-quality ethylene glycolbased non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology Do not use plain water alone.	

^{*:} The coolant capacity is the quantity of reference.

If replacement is necessary, contact your Toyota dealer.

Ignition system (spark plug)

Make	M20A-FKS engine	DENSO FC20HR-Q8
	A25A-FKS engine	DENSO FC16HR-Q8
Gap		0.8 mm (0.031 in.)



NOTICE

■ Iridium-tipped spark plugs

Use only iridium-tipped spark plugs. Do not adjust the spark plug gap.

Electrical system (battery)

Specific voltage reading at 20°C (68°F):		12.3 V or higher (Turn the engine switch to OFF and turn on the high beam headlights for 30 seconds.) If the voltage is lower than the standard value, charge the battery.
Charging	Quick charge	15 A max.
rates	Slow charge	5 A max.

Automatic transmission

Fluid capacity*	7.4 L (7.8 qt., 6.5 lmp.qt.)
Fluid type	Toyota Genuine ATF WS

*: The fluid capacity is the quantity of reference.

If replacement is necessary, contact your Toyota dealer.



NOTICE

■ Transmission fluid type

Using transmission fluid other than "Toyota Genuine ATF WS" may ultimately damage the transmission of your vehicle.

CVT (Continuously Variable Transaxle)

Elvidonocity*	Without Stop & Start system	8.6 L (9.1 qt., 7.6 Imp.qt.)
Fluid capacity	With Stop & Start system	8.3 L (8.8 qt., 7.3 Imp.qt.)
Fluid type		Toyota Genuine CVT Fluid FE

^{*:} The fluid capacity is the quantity of reference.

If replacement is necessary, contact your Toyota dealer.



NOTICE

■ CVT (Continuously Variable Transaxle) fluid type

Using CVT (Continuously Variable Transaxle) fluid other than "Toyota Genuine CVT Fluid FE" may cause deterioration in shift quality, locking up of your transmission accompanied by vibration, and ultimately damage the transmission of your vehicle.

Manual transmission

Gear oil capacity	1.5 L (1.6 qt., 1.3 lmp.qt.)
litiear oil type	"TOYOTA Genuine Manual Transmission Gear Oil LV GL-4 75W" or equivalent



NOTICE

Manual transmission gear oil

- Please be aware that depending on the particular characteristics of the gear oil used or the operating conditions, idle sound, shift feeling and/or fuel efficiency may be different or affected and, in the worst case, damage to the vehicle's transmission. Toyota recommends to use "TOYOTA Genuine Manual Transmission Gear Oil LV GL-4 75W" to achieve optimal performance.
- Your Toyota vehicle is filled with "TOYOTA Genuine Manual Transmission Gear Oil LV GL-4 75W" at the factory. Use Toyota approved "TOYOTA Genuine Manual Transmission Gear Oil LV GL-4 75W" or an equivalent oil of matching quality that satisfies the above specifications. Please contact your Toyota dealer for further details.

Clutch

Clutch pedal free play	5 — 15 mm (0.2 — 0.6 in.)
Fluid type	SAE J1703 or FMVSS No.116 DOT 3
	SAE J1704 or FMVSS No.116 DOT 4

Transfer (AWD models)

Oil capacity	Dynamic Torque Control AWD vehicle	0.45 L (0.48 qt., 0.40 lmp.qt.)
, ,	Dynamic Torque Vectoring AWD vehicle	0.405 L (0.428 qt., 0.356 Imp.qt.)
Oil type and	viscosity	Toyota Genuine Differential gear oil LX 75W-85 GL-5 or equivalent

Your Toyota vehicle is filled with "Toyota Genuine Differential Gear Oil" at the factory.

Use Toyota approved "Toyota Genuine Differential Gear Oil" or an equivalent of matching quality to satisfy the above specification. Please contact your Toyota dealer for further details.

Rear differential (AWD models)

Oil capacity	Dynamic Torque Control AWD vehicle	0.5 L (0.5 qt., 0.4 Imp.qt.)
On capacity	Dynamic Torque Vectoring AWD vehicle	0.525 L (0.554 qt., 0.462 Imp.qt.)
Oil type and viscosity		Toyota Genuine Differential gear oil LX 75W-85 GL-5 or equivalent

Your Toyota vehicle is filled with "Toyota Genuine Differential Gear Oil" at the factory.

Use Toyota approved "Toyota Genuine Differential Gear Oil" or an equivalent of matching quality to satisfy the above specification. Please contact your Toyota dealer for further details.

Brakes

Pedal clearance*	142 mm (5.6 in.)
Pedal free play	1.0 — 6.0 mm (0.04 — 0.24 in.)
Fluid type	SAE J1703 or FMVSS No. 116 DOT 3 SAE J1704 or FMVSS No. 116 DOT 4

^{*:} Minimum pedal clearance when depressed with a force of 300 N (30.5 kgf, 67.4 lbf) while the engine is running.

Steering

· ·	
Free play	Less than 30 mm (1.2 in.)

Tires and wheels

Full-size tire

Type A

Tire size		225/65R17 102H
Tire inflation pressure (Recommended cold	Front	230 kPa (2.3 kgf/cm ² or bar, 33 psi)
tire inflation pressure)	Rear	230 kPa (2.3 kgf/cm ² or bar, 33 psi)

408

8-1. Specifications

Wheel size	17 × 7J
Wheel nut torque	103 N•m (10.5 kgf•m, 76 ft•lbf)

▶ Type B

Tire size		225/60R18 100H
Tire inflation pressure (Recommended cold	Front	230 kPa (2.3 kgf/cm ² or bar, 33 psi)
tire inflation pressure)	Rear	230 kPa (2.3 kgf/cm ² or bar, 33 psi)
Wheel size		18 × 7J
Wheel nut torque		103 N•m (10.5 kgf•m, 76 ft•lbf)

▶ Type C

Tire size		235/55R19 101V
Tire inflation pressure (Recommended cold	Front	230 kPa (2.3 kgf/cm ² or bar, 33 psi)
tire inflation pressure)	Rear	230 kPa (2.3 kgf/cm ² or bar, 33 psi)
Wheel size		19 × 7 1/2J
Wheel nut torque		103 N•m (10.5 kgf•m, 76 ft•lbf)

■ Compact spare tire (if equipped)

▶ Type A

Tire size	T165/80D17 104M
Tire inflation pressure (Recommended cold tire inflation pressure)	420 kPa (4.2 kgf/cm ² or bar, 60 psi)
Wheel size	17 × 4T
Wheel nut torque	103 N•m (10.5 kgf•m, 76 ft•lbf)

Type B

Tire size	T165/90D18 107M
Tire inflation pressure (Recommended cold tire inflation pressure)	420 kPa (4.2 kgf/cm ² or bar, 60 psi)
Wheel size	18 × 4T
Wheel nut torque	103 N•m (10.5 kgf•m, 76 ft•lbf)

Light bulbs

	Light bulbs	W	Туре
Fog lights		19	Α
	Front turn signal lights	21	В
Exterior	Rear turn signal lights	21	В
	Back-up lights	16	С
	Outer foot lights*	5	С
	Vanity lights	8	С
Interior	Front interior lights/personal lights	5	С
IIILETIOI	Rear interior light	8	D
	Luggage compartment light	5	С

A: H16 halogen bulbs

B: Wedge base bulbs (amber)

C: Wedge base bulbs (clear)

D: Double end bulbs (clear)

*: If equipped

Fuel information

You must only use unleaded gasoline in your vehicle.

For optimum engine performance, select unleaded gasoline with a Research Octane Number of 91 or higher.

■ Use of ethanol blended gasoline in a gasoline engine

Toyota allows the use of ethanol blended gasoline where the ethanol content is up to 10%. Make sure that the ethanol blended gasoline to be used has a Research Octane Number that follows the above

■ If your engine knocks

- Consult your Toyota dealer.
- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.



NOTICE

■ Notice on fuel quality

- Do not use improper fuels. If improper fuels are used, the engine will be damaged.
- Do not use gasoline with metallic additives, for example manganese, iron or lead, otherwise it may cause damage on your engine or emission control system.
- Do not add aftermarket fuel additives which contain metallic additives.
- Do not use the methanol blended gasoline such as M15, M85, M100.
 The use of gasoline containing methanol may cause engine damage or failure.

Customizable features

Your vehicle includes a variety of electronic features that can be personalized to suit your preferences. The settings of these features can be changed using the multi-information display, navigation/multimedia system, or at your Toyota dealer.

Some function settings are changed simultaneously with other functions being customized. Contact your Toyota dealer for further details

Customizing vehicle features

- Changing using the navigation/multimedia system
- 1 Press the "MENU" button.
- 2 Select "Setup" on the menu screen and select "Vehicle".
- 3 Select "Vehicle Customization".

Various setting can be changed. Refer to the list of settings that can be changed for details.

- Changing using the multiinformation display
- 1 Press or of the meter control switches and select .
- 2 Press or of the meter control switches, select the item.

- 3 To switch the function on and off, press os to switch to the desired setting.
- 4 To perform detailed setting of functions that support detailed settings, press and hold and display the setting screen.

The method of performing detailed setting differs for each screen. Please refer to the advice sentence displayed on the screen.

To go back to the previous screen or exit the customize mode, press \bigcirc .

■ When customizing using the navigation/multimedia system or multiinformation display

Stop the vehicle in a safe place, apply the parking brake, and shift the shift lever to P^{*1} or N^{*2}. Also, to prevent battery discharge, leave the engine running while customizing the features.

- Vehicles with automatic transmission or CVT
- *2: Vehicles with manual transmission



■ During customization

As the engine needs to be operating during customization, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.



NOTICE

During customization

To prevent battery discharge, ensure that the engine is running while customizing features.

Customizable Features

Some function settings are changed simultaneously with other functions being customized. Contact your Toyota dealer for further details.

- A Vehicles with navigation system or multimedia system: Settings that can be changed using the navigation system or multimedia system
- B Settings that can be changed using the multi-information display
- © Settings that can be changed by your Toyota dealer

Definition of symbols: O = Available, - = Not available

■ Gauges, meters and multi-information display (→P.63, 66, 70)

Function*1	Default setting	Customized set- ting	Α	В	С
Language	English	French	_	0	ı
Units	L/100 km	km/L	_	0	-
Speedometer display*2	Analog	Digital	_	0	-
Eco Driving Indicator Light*3	On	Off	_	0	-
"Fuel Economy"	"Total Average" –	"Trip Average"	_	С	
		"Tank Average"			
Audio system linked display	On	Off	-	0	-
AWD system display*4	On	Off	_	0	ı
Drive information type	Trip	Total	_	0	1
Drive information items (first	Distance	Average Speed		С	
item)	Distance	Total Time		0	
Drive information items (second	Total Time	Average Speed		С	_
item)	Total Time	Distance			
Pop-up display	On	Off	_	0	_

Function*1	Default setting	Customized set- ting	Α	В	С
Multi-Information display off	Off	On	ı	0	_
Suggestion function	On	On (when the vehicle is stopped)	0	_	0

^{*1:} For details about each function: →P.75

■ Door lock (→P.88, 388)

Function	Default setting	Customized set- ting	Α	В	С
Unlocking using a key	All doors unlocked in first step	Driver's door unlocked in first step, all doors unlocked in sec- ond step	_	_	0
Speed linked door locking function	On	Off	0	_	0
Shift position linked door locking function	Off	On	0	_	0
Shift position linked door unlocking function	Off	On	0	_	0
Driver's door linked door unlocking function	On	Off	0	_	0

Smart entry & start system^{*} and wireless remote control (→P.86, 104)

Function	Default setting	Customized set- ting	Α	В	С
Operation signal (emergency flashers)	On	Off	0	-	0
Operation buzzer volume	5	Off 1 to 7	0	1	0

^{*2:} Vehicles with 7-inch display only

^{*3:} If equipped

^{*4:} AWD models

414

Function	Default setting	Customized set- ting	Α	В	С
Time elapsed before the auto-		60 seconds			
matic door lock function is acti- vated if a door is not opened after being unlocked	30 seconds	120 seconds	0	_	0
Open door reminder buzzer (When locking the vehicle)	On	Off	ı	-	0

^{*:} If equipped

■ Smart entry & start system*1 (→P.104)

Function	Default setting	Customized set- ting	A	В	С
Smart entry & start system	On	Off	_	1	0
Smart door unlocking	All the doors	Driver's door	0	-	0
Number of consecutive door lock operations	2 times ^{*2}	As many as desired*2			0
	As many as desired*3	2 times ^{*3}			
Time elapsed before unlocking	0	1.5 seconds			
all the door when gripping and holding the driver's door han-	Off	2 seconds	_	_	0
dle ^{*4}		2.5 seconds			

^{*1:} If equipped

^{*2:} For vehicles without double locking system

^{*3:} For vehicles with double locking system

^{*4:} This setting can be changed when the smart door unlocking setting is set to "Driver's door".

■ Wireless remote control (→P.86)

Function	Default setting	Customized set- ting	Α	В	С
Wireless remote control	On	Off	_	_	0
Unlocking operation	All doors unlocked in first step	Driver's door unlocked in first step, all doors unlocked in sec- ond step	0	-	0
The function that activates the	Off	On (Unlocking all the door) On (Unlocking back door only)	Ī	_	0

^{*:} If equipped

■ Power back door*1 (→P.97)

Function	Default setting	Customized set- ting	Α	В	С
Power back door operations	On	Off	-	0	-
Back door opener switch operations	Press and hold	One short press	-	-	0
)	One short press			
switch of the wireless	Press and hold	Push twice	_	_	0
remote control operation		Off			
Operation buzzer volume	3	1		0	_
operation buzzer volume	3	2)	
Operation buzzer while the back	Off	On	ı	ı	0
door is operating*2	0::	OII)
Opening angle	5	1 to 4		0	
Opening angle	ა	User setting*3	_	U	_

Function	Default setting	Customized set- ting	Α	В	С
Power back door open operation when the opener switch is pressed with the back door fully closed	On	Off	ı	ı	0

^{*1:} If equipped

■ Driving position memory* (→P.111)

Function	Default setting	Customized set- ting	A	В	С
Selection the door linking driving position memory with door unlock operation	Driver's door	All doors	_	_	0
Function to prevent contact between the head restraint and ceiling (while moving to memory location)	On	Off	_	_	0

^{*:} If equipped

■ Power windows, and moon roof* or panoramic moon roof* (→P.120, 123, 125)

Function	Default setting	Customized set- ting	Α	В	С
Key linked operation (open)	Off	On	1	1	0
Key linked operation (close)	Off	On	ı	ı	0
Wireless remote control linked operation (open)	Off	On	-	-	0
Wireless remote control linked operation (close)	Off	On	ı	ı	0
Wireless remote control linked operation signal (buzzer)	On	Off	ı	ı	0

^{*2:} The operation buzzer that sounds when the back door begins to operate cannot be turned off.

^{*3:} The open position is set by the power back door switch. (→P.103)

Function	Default setting	Customized set- ting	Α	В	С
Side windows open warning function	On	Off	ı	_	0
Sliding roof open warning function	On	Off	-	_	0

^{*:} If equipped

■ Turn signal lever (→P.163)

Function	Default setting	Customized set- ting	A	В	С
The number of times the turn signal lights flash automatically when the turn signal lever is moved to the first position during a lane change	3	4 5 6 7 Off	-	_	0

■ Lights (→P.169)

Function	Default setting	Customized set- ting	Α	В	С
Light reminder buzzer	On	Off	ı	-	0

■ Automatic light control system (→P.169)

Function	Default setting	Customized set- ting	Α	В	С
Light sensor sensitivity	Standard	-2 to 2	0	_	0
Time elapsed before headlights		Off			
automatically turn off after doors	30 seconds	60 seconds	0	_	0
are closed		90 seconds			
Time elapsed before headlights automatically turn on	Standard	Long	-	_	0

■ Rear window wiper (→P.176)

Function	Default setting	Customized set- ting	Α	В	С
Back door opening linked rear window wiper stop function	Off	On	_	_	0
Washer linked rear window wiper operation	On	Off	_	_	0
Shift position linked rear win-	Only once	Off			0
dow wiper operation [*] (→P.177)	Offiny Office	Continuous			

^{*:} If equipped

■ PCS (Pre-Collision System)* (→P.184)

Function	Default setting	Customized set- ting	Α	В	С
PCS (Pre-Collision System)	On	Off	-	0	ı
Adjust alert timing	Middle	Far		0	-
rajuot aiort airmig	Wildelie	Near			

^{*:} If equipped

■ LTA (Lane Tracing Assist)* (→P.192)

Function	Default setting	Customized set- ting	Α	В	С
Lane centering function	Off	On	-	0	-
Steering assist function	On	Off	-	0	-
Alert sensitivity	Standard	High	-	0	ı
Vehicle sway warning function	On	Off	-	0	-
Vehicle sway warning sensitivity	Standard	Low		0	_
verticie sway warriing serisitivity	Standard	High)	

^{*}If equipped

■ LDA (Lane Departure Alert with steering control)* (→P.201)

Function	Default setting	Customized set- ting	Α	В	С
Steering assist function	On	Off	_	0	-
Alert sensitivity	Standard	High	_	0	-
Vehicle sway warning function	On	Off	_	0	7
Vehicle sway warning sensitivity	Standard	Low		6	
verifice sway warriing sensitivity	Standard	High			

^{*:} If equipped

■ RSA (Road Sign Assist)* (→P.209)

Function	Default setting	Customized set- ting	Α	В	С
RSA (Road Sign Assist)	On	Off	1	0	ı
Excess speed notification method		No notification			
	Display only	Display and buzzer	-	0	-
No-overtaking notification method		No notification			
	Display only	Display and buzzer	-	0	-
Other notifications method (No-		No notification			
Other notifications method (No- entry notification)	Display only	Display and buzzer	_	0	_
Excess speed notification level	2 km/h (1 mph)	5 km/h (3 mph)		0	
Excess speed nothication level	Z KIII/II (T IIII/II)	10 km/h (5 mph)			

[:] If equipped

■ Dynamic radar cruise control with full-speed range* (→P.211)

Function	Default setting	Customized set- ting	Α	В	С
Dynamic Radar Cruise Control with Road Sign Assist*	On	Off	-	0	-

^{*:} If equipped

■ BSM (Blind Spot Monitor)* (→P.235)

Function	Default setting	Customized set- ting	Α	В	С
BSM (Blind Spot Monitor)	On	Off	_	0	-
Outside rear view mirror indicator brightness	Bright	Dim	_	0	_
		Early			
Alert timing for presence of		Late	•		
approaching vehicle (sensitivity)	Intermediate	Only when vehi- cle detected in blind spot		O	_

^{*:} If equipped

■ RCTA (Rear cross traffic alert) function*1 (→P.235)

Function	Default setting	Customized set- ting	Α	В	С
RCTA (Rear cross traffic alert) function	On	Off	-	0	_
Buzzer volume ^{*2}	Level 2	Level 1		0	
Duzzei voluitie	LGVEI Z	Level 3	_		_

^{*1:} If equipped

■ Toyota parking assist-sensor*1 (→P.243)

Function	Default setting	Customized set- ting	Α	В	С	
Display setting (When Toyota parking assist-sensor is operating)	On	Off	_	0	0	
Buzzer volume ^{*2}	2	3	-	0	0	

^{*1:} If equipped

^{*2:} This setting is linked with the buzzer volume of the Toyota parking assist-sensor.

^{*2:} This setting is linked with the buzzer volume of the RCTA (Rear cross traffic alert) function.

■ Stop & Start system* (→P.250)

Function	Default setting	Customized set- ting	Α	В	С
Change the Stop & Start system duration when the A/C is on	Standard	Extended	-	0	ı

^{*:} If equipped

■ Automatic air conditioning system^{*} (→P.285)

Function	Default setting	Customized set- ting	A	В	С
Switching between outside air and recirculated air mode linked to "AUTO" switch operation	On	Off	0	_	0
A/C Auto switch operation	On	Off	0	_	0
Switching to the outside air mode when the vehicle is parked	On	Off	_	_	0

^{*:} If equipped

■ Illumination (→P.292)

Function	Default setting	Customized set- ting	Α	В	С
		Off			
Time elapsed before the interior lights turn off	15 seconds	7.5 seconds	0	-	0
X		30 seconds			
Operation after the engine switch is turned off	On	Off	_	ı	0
Operation when the doors are unlocked	On	Off	_	1	0
Operation when you approach the vehicle with the electronic key on your person*1	On	Off	_	-	0
Footwell lighting*2	On	Off	-	-	0

^{*1:} Vehicles with smart entry & start system only

^{*2:} If equipped

■ Vehicle customization

- When the speed linked door locking function and shift position linked door locking function are both on, the door lock operates as follows.
- If the vehicle is started with all the doors locked, the speed linked door locking function would not operate.
- If the vehicle is started with any door unlocked, the speed linked door locking function will operate.
- When shifting the shift lever to any position other than P, all the doors will be locked
- When the smart entry & start system is off, the selecting door to unlock cannot be customized
- When the doors remain closed after unlocking the doors and the automatic door lock function is activated, the signals will be generated in accordance with the Operation signal (buzzer) and the Operation signal (emergency flashers) settings.


Items to initialize

The following items must be initialized for normal system operation after such cases as the battery being reconnected, or maintenance being performed on the vehicle:

List of the items to initialize

Item	When to initialize Referen	
Power back door*	\$	P.100
Power windows	 After reconnecting or changing the battery 	P.120
Moon roof*	After changing a fuse	P.123
Panoramic moon roof*		P.127
Toyota parking assist monitor*		Refer to
	40	"Navigation and Multime-
	After reconnecting or changing	dia System
Panoramic view monitor*	the batteryAfter changing a fuse	Owner's Manual" or "Multimedia
		Owner's
		Manual"

^{*:} If equipped



Index

What to do if... (Troubleshooting)426
Alphabetical Index429

What to do if... (Troubleshooting)

If you have a problem, check the following before contacting your Toyota dealer.

The doors cannot be locked, unlocked, opened or closed



You lose your keys

- If you lose your keys or mechanical keys, new genuine keys or mechanical keys can be made by your Toyota dealer. (→P.388)
- Vehicles with smart entry & start system:

If you lose your electronic keys, the risk of vehicle theft increases significantly. Contact your Toyota dealer immediately. (→P.388)



The doors cannot be locked or unlocked

- Is the key battery weak or depleted? (→P.341)
- Vehicles with smart entry & start system:

Is the engine switch in ON? When locking the doors, turn the engine switch off. (→P.151)

Vehicles with smart entry & start system:

Is the electronic key left inside the vehicle?

When locking the doors, make

- sure that you have the electronic key on your person.
- The function may not operate properly due to the condition of the radio wave. (→P.86, 105)



The rear door cannot be opened

• Is the child-protector lock set? The rear door cannot be opened from inside the vehicle when the lock is set. Open the rear door from outside and then unlock the child-protector lock. (→P.92)

If you think something is wrong



The engine does not start (vehicles without smart entry & start system)

- Vehicles with automatic transmission or CVT:
 Is the shift lever in P? (→P.148)
- Vehicles with manual transmission:
 Do you turn the key with the clutch pedal depressed firmly?
 - clutch pedal depressed firmly? (→P.148)
- Is the battery discharged? (→P.391)



The engine does not start (vehicles with smart entry & start system)


Did you press the engine switch

while firmly depressing the brake pedal (vehicles with automatic transmission or CVT) or the clutch pedal (vehicles with manual transmission)? (→P.149)

- Vehicles with automatic transmission or CVT:
 Is the shift lever in P? (→P.149)
- Is the electronic key anywhere detectable inside the vehicle? (→P.104)
- Is the steering wheel unlocked? (→P.150)
- Is the electronic key battery weak or depleted?
 In this case, the engine can be started in a temporary way.
 (→P.389)
- Is the battery discharged? (→P.391)

The shift lever cannot be shifted from P even if you depress the brake pedal (vehicles with automatic transmission or CVT)

Is the engine switch in ON?
 If you cannot release the shift
 lever by depressing the brake
 pedal with the engine switch in
 ON (→P.155, 158)



Vehicles without smart entry & start system:

It is locked to prevent theft of the vehicle if the key is removed from the engine switch. (→P.148)

 Vehicles with smart entry & start system:
 It is locked automatically to prevent theft of the vehicle. (→150)



The windows do not open or close by operating the power window switches

 Is the window lock switch pressed?
 The power window except for the one at the driver's seat cannot be operated if the window lock switch is pressed. (→P.122)



The engine switch is turned off automatically (vehicles with smart entry & start system)

 The auto power off function will be operated if the vehicle is left in ACC or ON (the engine is not running) for a period of time. (→P.152)



A warning buzzer sounds during driving

 The seat belt reminder light is flashing

Are the driver and the passengers wearing the seat belts? $(\rightarrow P.373)$

 The parking brake indicator is on Is the parking brake released? (→P.164)

Depending on the situation, other

types of warning buzzer may also sound. (→P.368, 375)



A warning buzzer sounds when leaving the vehicle (vehicles with smart entry & start system)

 Is the message displayed on the multi-information display?
 Check the message on the multiinformation display. (→P.375)



A warning light turns on or a warning message is displayed

 When a warning light turns on or a warning message is displayed, refer to P.368, 375.

When a problem has occurred



If you have a flat tire

 Stop the vehicle in a safe place and replace the flat tire with the spare tire. (→P.378)



The vehicle becomes stuck

Try the procedure for when the vehicle becomes stuck in mud, dirt, or snow. (→P.397)

Alphabetical Index

A
A/C280, 285
Air conditioning filter335
Automatic air conditioning system
285
Eco air conditioning mode287
Manual air conditioning system 280
S-FLOW mode287
ABS (Anti-lock Brake System) 265
Function265
Warning light369
ACA (Active Cornering Assist)266
Active Cornering Assist (ACA)266
Airbags30
Airbag operating conditions32
Airbag precautions for your child .34
Airbag warning light
Curtain shield airbag operating con-
ditions32
Curtain shield airbag precautions 34
General airbag precautions34
Locations of airbags30
Modification and disposal of airbags
37
Side airbag operating conditions32
Side airbag precautions34
Side and curtain shield airbags oper-
ating conditions32
Side and curtain shield airbags pre-
cautions34
SRS airbags30
SRS warning light
Air conditioning filter335
Air conditioning system280, 285
Air conditioning filter
Automatic air conditioning system
285 Eco air conditioning mode287
Manual air conditioning system 280
manda an conditioning system. 200

S-FLOW mode28	7
Alarm	
Warning buzzer36	8
Anchor fittings5	1
Antenna (Smart entry & start system	n)
10	-
Anti-lock brake system (ABS)26	
Function26	
Warning light36	
Approach warning218, 22	
Armrest30	ia
Ashtray30	
Assist grips30	
	9
Automatic air conditioning system	_
28	
Air conditioning filter33	
Eco air conditioning mode28	
S-FLOW mode28	
Automatic headlight leveling system	
17	
Automatic High Beam17	
Automatic light control system16	
Automatic transmission15	3
S mode15	5
Auxiliary box29	6
Average fuel consumption7	9
Average fuel economy7	
Average vehicle speed74, 7	
	•
В	
	_
Back door9	
Power back door9	
Wireless remote control9	7
Back-up lights	
Replacing light bulbs34	6
Wattage40	9
Battery	
Checking32	8
If the vehicle battery is discharged	
39	11
Preparing and checking before win	_

ter272	Child restraint system40
Replacing393	How your child should wear the seat
Warning light368	belt28
Blind Spot Monitor (BSM)235	Moon roof precautions124
Blind Spot Monitor function 238	Panoramic moon roof precautions
Rear Cross Traffic Alert function 240	127
Bottle holders296	Power window lock switch122
Brake	Power window precautions 121
Brake Hold167	Rear door child-protectors92
Parking brake164	Removed key battery precautions
Warning light368	343
Brake assist265	Seat belt precautions27
Brake Hold167	Seat heater precautions290
Break-in tips134	Cleaning312, 315
BSM (Blind Spot Monitor)235	Aluminum wheels312
Blind Spot Monitor function 238	Exterior312
Rear Cross Traffic Alert function 240	Interior315
	Radar sensor181
C	Seat belts315
	Clock65, 69
Card holder297	Coat hooks309
Care	Condenser328
Aluminum wheels312	Console box295
Exterior312	Consumption screen79
Interior315	Continuously Variable Transaxle
Seat belts315	(CVT)157
Cargo hooks298	Coolant
Chains274	Checking327
Child-protectors92	Preparing and checking before win-
Child restraint system40	ter272
Fixed with a seat belt48	Warning light368
Fixed with an ISOFIX rigid anchor50	Cooling system327
Points to remember40	Engine overheating395
Riding with children39	Cruise control
Types of child restraint system instal-	Cruise control232
lation method47	Dynamic radar cruise control with
Using a child restraint anchor fitting	full-speed range211
51	Dynamic radar cruise control222
Child safety39	Cup holders295
Airbag precautions34	Current fuel consumption79
Back door precautions93	Current fuel economy79
Battery precautions329, 394	Our ent luci economy12

Curtain shield airbags30	Door lock88
Customizable features 411	Open door warning buzzer92
CVT (Continuously Variable Tran-	Outside rear view mirrors118
saxle)157	Rear door child-protectors92
•	Side doors88
D	Double locking system55
Parties and in the section 400	Downhill assist control system263
Daytime running light system 169	Drive information74
Replacing light bulbs346	Driver's seat belt reminder light373
Deck board298	Driver's seat position memory 111
Defogger	Driving position memory 111
Outside rear view mirrors281, 287	Memory recall function112
Rear window	Drive-start control134
Windshield281, 286	Driving
Differential407	Break-in tips134
Dimensions400	Correct posture25
Display	Driving mode select switch257
BSM (Blind Spot Monitor)236	Procedures132
Cruise control232	Winter drive tips272
Drive information74	Driving information display72
Dynamic radar cruise control with	Driving mode select switch257
full-speed range211	Driving position memory111
Dynamic radar cruise control 222	Memory recall function 112
Fuel consumption information79	Driving support system information
LDA (Lane Departure Alert with	display74
steering control)206	Dynamic radar cruise control
LTA (Lane-Tracing Assist) 197	Function222
Multi-information display70	Warning message375
RCTA236	Dynamic radar cruise control with
Toyota parking assist-sensor 243	full-speed range
Warning messages	Function211
Do-it-yourself maintenance320	Warning message375
Door lock	Dynamic Torque Control AWD sys-
Back door93	tem266
Side doors88	Dynamic Torque Vectoring AWD sys-
Smart entry & start system104	tem266
Wireless remote control86	
Doors	E
Automatic door locking and unlock-	Fac drive made
ing system92	Eco drive mode257
Back door93	Eco Driving Indicator73
Door glasses120	Eco Driving Indicator Light73

EDR (Event data recorder)7	How to start the engine148, 149
Elapsed time74	Identification number401
Electric Power Steering (EPS)	If the engine will not start386
Function266	If your vehicle has to be stopped in
Warning light370	an emergency358
Electronic key	Ignition switch (Engine switch).148,
Battery-saving function105	149
If the electronic key does not operate	Overheating395
properly388	Tachometer63, 66
Replacing the battery341	Engine coolant
Electronic sunshade	Capacity404
Jam protection function126	Checking327
Operation125	Preparing and checking before win-
Emergency, in case of	ter272
If a warning buzzer sounds368	Warning light368
If a warning light turns on368	Engine coolant temperature gauge
If a warning message is displayed	63, 66
375	Engine immobilizer system54
If the electronic key does not operate	Engine oil
properly388	Capacity402
If the engine will not start 386	Checking325
If the vehicle battery is discharged	Preparing and checking before win-
391	ter272
If the vehicle is trapped in rising	Warning light369
water360	Engine switch148, 149
If you have a flat tire378	Auto power off function152
If you lose your keys388	Changing the engine switch modes
If you think something is wrong 366	151
If your vehicle becomes stuck397	Changing the engine switch posi-
If your vehicle has to be stopped in	tions148
an emergency358	If your vehicle has to be stopped in
If your vehicle needs to be towed	an emergency358
361	Starting the engine148, 149
If your vehicle overheats395	EPS (Electronic Power Steering)
Emergency brake signal266	Function266
Emergency flashers358	Warning light370
Engine	Event data recorder (EDR)7
ACC148, 151	
Compartment	F
Engine switch148, 149	Flat tire378
Hood322	Floor mats24

Fluid	Current fuel consumption79
Automatic transmission405	Fuel filler door179
Brake407	Refueling178
Clutch406	Fuel gauge63, 66
Continuously Variable Transaxle 405	Fuel pump shut off system367
Washer330	Fuses343
Fog lights	
Replacing light bulbs346	G
Switch174	Con station information 444
Wattage409	Gas station information444 Gauges63, 66
Footwell lights292	Glove box295
Front passenger's seat belt reminder	Glove box295
light373	Н
Front position lights	
Light switch169	Headlights169
Replacing light bulbs346	Automatic headlight leveling170
Front seats108	Automatic High Beam system171
Adjustment108	Light switch169
Cleaning315	Replacing light bulbs346
Correct driving posture25	Head restraints114
Driving position memory 111	Heaters
Head restraints114	Automatic air conditioning system
Memory recall function112	285
Seat heaters290	Manual air conditioning system280
Seat position memory 111	Outside rear view mirrors281, 287
Seat ventilators290	Seat heaters291
Front turn signal lights	High mounted stoplight
Replacing light bulbs346	Replacing light bulbs346
Turn signal lever163	Hill-start assist control266
Wattage409	Hood322
Fuel	Hooks
Capacity402	Cargo hooks298
Fuel gauge63, 66	Coat hooks309
Fuel pump shut off system367	Retaining hooks (floor mat)24
Gas station information	Horn116
Information410	
Refueling178	
Type402	Identification
Warning light	Engine401
Fuel consumption information79	Vehicle400
Average fuel consumption79	V 3711010

Ignition switch (Engine switch).148,	K
Auto power off function	Keyless entry Smart entry & start system 104 Wireless remote control 86 Keys 84 Battery-saving function 105 Electronic key 84 Engine switch 148, 149 If the electronic key does not operate properly 388 If you lose your keys 388 Key number plate 84 Keyless entry 86, 104 Mechanical key 87 Replacing the battery 341 Warning buzzer 104 Wireless remote control key 86 Knee airbags 30
Power windows	
Installing a child restraint system to	
a front passenger seat41	Lane Departure Alert with steering
Interior lights292 Switch292	control (LDA) 201 Operation 201 Warning messages 208
Wattage409	Lane Tracing Assist (LTA)192Operation192Warning messages201
Jack Positioning a floor jack	Language (multi-information dis- play)77, 412 LDA (Lane Departure Alert with
Vehicle-equipped jack379	steering control)201
Jack handle379	Operation201
Jam protection function126Electronic sunshade	Warning messages
	License plate lights

Light switch169	Meters63, 66
Replacing light bulbs346	Multi-information display70
Light bulbs	Settings75, 411
Replacing346	Units77, 412
Wattage409	Warning lights368
Lights	Warning messages375
Automatic High Beam system171	Meter control switches71
Fog light switch174	Mirrors
Front interior lights292	Inside rear view mirror117
Headlight switch169	Outside rear view mirror defoggers
Illuminated entry system293	281, 287
Interior light list292	Outside rear view mirrors118
Interior lights292	Vanity mirrors302
Personal lights293	Moon roof
Rear interior light293	Door lock linked moon roof operation
Replacing light bulbs346	123
Turn signal lever163	Jam protection function123
Vanity lights302	Operation123
Wattage409	Warning message124
Lock steering column150	Mud & Sand mode259
LTA (Lane Tracing Assist)192	Multi-information display
Operation192	Audio system-linked display74
Warning messages201	Changing the display71
Luggage compartment light 96, 98	Cruise control232
Wattage409	Display contents70
Luggage cover300	Driving information display72
	Driving support system information
M	display74
Maintaga	Dynamic radar cruise control with
Maintenance	full-speed range211
Do-it-yourself maintenance320	Dynamic radar cruise control222
Maintenance data	Eco Driving Indicator73
Maintenance requirements 318	Language77, 412
Malfunction indicator lamp369	LDA (Lane Departure Alert with
Manual air conditioning system 280	steering control)206
Air conditioning filter335 Manual transmission160	LTA (Lane-Tracing Assist)197
Menu icons71	Menu icons71
Meter	Meter control switches71
Clock65, 69	Navigation system-linked display .74
Indicators58	PCS (Pre-Collision System) 184
Meter control switches 71	Pop-up display77

O-Hinara 75 444	
Settings	Р
Suggestion function	Panoramic moon roof
Toyota parking assist-sensor 243	Jam protection function126
Units77, 412	Operation125
Vehicle information display74	Warning message127
Warning message display78	Parking assist sensors (Toyota park-
Warning messages375	ing assist-sensor)243
Multi-terrain Select259	Parking brake
	Operation164
N	Parking brake engaged warning
Navigation system-linked display.74	buzzer166
Normal mode257, 259	Warning light373
, , , , ,	Warning message165
0	PCS (Pre-Collision System)
	Enabling/disabling the pre-collision
Odometer63, 66	system186
Odometer and trip meter display	Function184
"ODO TRIP" switch65, 69	Warning light370
"ODO TRIP"switch65, 69	Warning message182, 376
Oil	Personal lights293
Engine oil402	Switch
Manual transaxle oil405	Wattage
Rear differential oil407	Power back door opener switch98
Transfer oil406	Power outlet302
Opener	Power steering (Electric Power
Back door96, 98	Steering system)266
Fuel filler door179	Warning light370
Hood322	Power windows
Outer foot lights	Door lock linked window operation
Replacing light bulbs346	121
Wattage409	Jam protection function120
Outside rear view mirrors118	Operation120
Adjusting and folding 119	Window lock switch122
BSM (Blind Spot Monitor) 235	Pre-Collision System (PCS)
Outside rear view mirror defoggers	Enabling/disabling the pre-collision
281, 287	system186
Outside temperature display 63, 66	Function184
Overheating395	Warning light370
	Warning message182, 376
	waiting illessage 102, 370

R	
Radar cruise control	Seat belt re
Dynamic radar cruise control with	Seat belts
full-speed range211	Adjusting
Dynamic radar cruise control 222	anchor h
Radiator328	Child rest
RCTA (Rear Cross Traffic Alert)	Cleaning
RCTA Function235, 240	belt
Warning message237	Emergend
Rear Cross Traffic Alert (RCTA) 235	How to we
Rear passengers' seat belt reminder	How your
light374	belt
Rear seat109	Pregnant
Folding down the rear seatbacks110	use
Head restraints114	Reminder
Rear turn signal lights	Seat belt
Replacing light bulbs346	SRS warr
Turn signal lever163	Seat heaters
Wattage409	Seat position
Rear view mirror	Seats
Inside rear view mirror	Adjustme
Outside rear view mirrors 118	Adjustme
Rear window defogger281, 287	Child rest
Rear window wiper176	Cleaning.
Refueling178	Driving po
Capacity402	Folding do
Fuel types402	Head rest
Opening the fuel tank cap178	Properly s
Replacing	Seat heat
Electronic key battery341	Seat posi
Fuses343	Seat vent
Light bulbs346	Seat ventila
Tires378	Secondary
Wiper insert337	Sensor
Wireless remote control battery . 341	Automatio
Road Sign Assist209	Automatio
Rock & Dirt mode259	BSM (Blin
RSA (Road Sign Assist)209	Inside rea

S

Seat belt reminder light373, 374
Seat belts27
Adjusting the seat belt shoulder
anchor height29
Child restraint system installation.48
Cleaning and maintaining the seat
belt315
Emergency Locking Retractor29
How to wear your seat belt28
How your child should wear the seat
belt28
Pregnant women, proper seat belt
use27
Reminder light and buzzer .373, 374
Seat belt pretensioners29
SRS warning light369
Seat heaters290
Seat position memory111
Seats
Adjustment precautions108, 109
Adjustment108, 109
Child restraint system installation.40
Cleaning315
Driving position memory111
Folding down the rear seatbacks110
Head restraint114
Properly sitting in the seat25
Seat heaters290
Seat position memory 111
Seat ventilators290
Seat ventilators290
Secondary Collision Brake266
Sensor
Automatic headlight system 169
Automatic High Beam system171
BSM (Blind Spot Monitor)237
Inside rear view mirror118
LDA (Lane Departure Alert with
steering control) 201

LTA (Lane Tracing Assist)192	Column lock release148, 150
Rain-sensing windshield wipers.175	Steering lock system warning mes-
RCTA237	sage150
Toyota parking assist-sensor 243	Steering wheel
Toyota Safety Sense180	Adjustment 116
Service reminder indicators58	Meter control switches71
S-FLOW mode287	Stop lights
Shift lever153, 157, 160	Replacing light bulbs346
Automatic transmission153	Storage feature294
CVT (Continuously Variable Tran-	Storage precautions295
saxle)157	Stuck
If the shift lever cannot be shifted	If the vehicle becomes stuck397
from P155, 158	Suggestion function78
Manual transmission160	Sunglass holder296
Shift lock system155, 158	Sunshade123, 125
Side airbags30	Sun visors302
Side auxiliary box300	Switches
Side doors88	"ODO TRIP"switch65, 69
Side mirrors118	Automatic High Beam switch171
Adjustment119	Brake hold switch167
BSM (Blind Spot Monitor) 235	BSM (Blind Spot Monitor)236
Folding 119	Cruise control switch 211, 222, 232
Heaters281, 287	Door lock switch91
Side turn signal lights	Driving mode select switch257
Replacing light bulbs346	Driving position memory switches
Turn signal lever163	111
Side windows120	Dynamic radar cruise control with
Smart entry & start system104	full-speed range212
Antenna location104	Dynamic radar cruise control223
Entry functions88, 95	Electronic sunshade switch125
Starting the engine148, 149	Emergency flashers switch358
Warning message375	Engine switch148, 149
Snow mode switch262	Fog light switch174
Snow tires272	Ignition switch (Engine switch).148,
Spare tire	149
Storage location379	LDA switch205
Spark plug404	Light switch169
Specifications400	LTA switch197
Speedometer63, 66	Meter control switches71
Sport mode257	Moon roof switches123
Steering lock	Outside rear view mirror switches

119	Spare tire
Panoramic moon roof switches125	Tools
Parking brake switch164	Towing
PCS (Pre-Collision System) 186	Emergency towing
Power back door opener switch 98	Towing eyelet
Power door lock switch91	Trailer sway control.
Power window switch120	Trailer towing
RCTA236	Toyota parking assist-
Rear window and outside rear view	Function
mirror defoggers switch 281, 287	Warning message
Rear window wiper and washer	Toyota Safety Sense
switch176	Automatic High Bear
Seat heater switches291	Dynamic radar cruise
Seat ventilator switches291	full-speed range
Snow mode switch262	Dynamic radar cruise
Toyota parking assist-sensor 244	LDA (Lane Departure
Vehicle-to-vehicle distance switch	steering control)
211, 222	LTA (Lane Tracing As
VSC OFF switch267	PCS (Pre-Collision S
Window lock switch122	RSA (Road Sign Ass
Windshield defogger switch281, 286	Traction Control (TRC
Windshield wipers and washer	Trailer sway control
switch174	Trailer towing
	Transmission
Т	Automatic transmissi
Tachometer63, 66	CVT (Continuously V
Tail lights	saxle)
Light switch169	Manual transmission
Replacing light bulbs346	S mode
Theft deterrent system	TRC (Traction Control
Double locking system55	Trip meters
Engine immobilizer system54	Turn signal lights
Tire inflation pressure407	Replacing light bulbs
Tires331	Turn signal lever
Chains274	Wattage
Checking331	
If you have a flat tire378	U
Inflation pressure333	USB charging ports
Replacing378	Utility vehicle precaut
Rotating tires332	
Snow tires 272	

USB charging ports Utility vehicle precautions	
U	
•	
Wattage	
Turn signal lever	
Replacing light bulbs	346
Turn signal lights	-,
Trip meters6	
TRC (Traction Control)	
S mode	
Manual transmission	
saxle)	
CVT (Continuously Variable Tra	
Automatic transmission	150
Transmission	141
Trailer sway control	
RSA (Road Sign Assist) Traction Control (TRC)	
PCS (Pre-Collision System)	
LTA (Lane Tracing Assist)	
steering control)	
LDA (Lane Departure Alert with	204
Dynamic radar cruise control	222
full-speed range	
Dynamic radar cruise control wi	
Automatic High Beam	
Toyota Safety Sense	
Warning message	
Function	
Toyota parking assist-sensor	
Trailer towing	
Trailer sway control	_
Towing eyelet364	
Emergency towing	
Towing	
Tools	379
Spare tire	378


V	Brake hold operated indicator 373
Jamita Bakta	Brake Override System372
Vanity lights	Brake system368
Vanity lights302	Charging system368
Wattage	Drive-Start Control372
Vanity mirrors302	Electric power steering370
Vehicle data recordings7	Engine369
Vehicle identification number400	High coolant temperature368
Vehicle Stability Control (VSC) 265	iMT indicator370
Ventilators (seat ventilators) 290	LDA indicator370
VSC (Vehicle Stability Control)265	Low engine oil pressure369
147	Low fuel level373
W	LTA indicator370
Warning buzzers	Malfunction indicator lamp369
Approach warning218, 228	Parking brake indicator373
Brake hold373	PCS warning light370
Brake Override System372	RCTA OFF indicator371
Brake system368	Seat belt reminder light373
Downshifting 156, 159	Slip indicator372
Drive-Start Control372	SRS369
Electric power steering370	Stop & Start cancel indicator371
High coolant temperature368	Toyota parking assist-sensor OFF
LDA (Lane Departure Alert with	indicator371
steering control)201	Warning messages375
LDA indicator370	Washer
Low engine oil pressure369	Checking330
LTA (Lane Tracing Assist)192	Low washer fluid warning message
LTA indicator370	330, 375
Open door92	Preparing and checking before win-
Open hood92	ter272
Open window121	Switch174, 176
Pre-collision warning185	Washing and waxing312
RCTA (Rear Cross Traffic Alert) . 236	Wheels334
RCTA OFF indicator371	Replacing wheels334
Seat belt reminder373	Window glasses
Toyota parking assist-sensor OFF	Power windows120
indicator371	Window lock switch122
Toyota parking assist-sensor 249	Windows
Vehicle sway warning196, 205	Power windows120
Warning lights	Rear window defogger281, 287
ABS 369	Washer174, 176

Windshield defogger281,	286
Windshield wipers	
Intermittent windshield wipers	.174
Position	. 174
Rain-sensing windshield wipers	. 174
Replacing the wiper insert	.337
Winter driving tips	. 272
Wiper insert	.337
Wireless charger	. 305
Wireless remote control	86
Battery-saving function	. 105
Locking/Unlocking	86
Replacing the hattery	3/11


For vehicles with navigation system, refer to "Navigation and Multimedia System Owner's Manual" or "Multimedia Owner's Manual" for information regarding the equipment listed below.

- · Navigation system
- · Audio system
- · Rear view monitor system
- · Toyota parking assist monitor
- · Panoramic view monitor





GAS STATION INFORMATION



- A Auxiliary catch lever (→P.322)
- \blacksquare Back door opener switch $(\rightarrow P.97)$
- C Fuel filler door (→P.179)
- D Hood lock release lever (→P.322)
- E Tire inflation pressure (→P.407)
- *: Vehicles with power back door

Fuel tank capacity (Reference)	55 L (14.5 gal., 12.1 lmp.gal.)	
Fuel type	Unleaded gasoline only	P.402
Cold tire inflation pressure		P.407
Engine oil capacity (Drain and refill — reference)		P.402
Engine oil type		P.402

